

## INT 16H: Keyboard Services

This is the application-level interface to the keyboard. Keystrokes are processed asynchronously (in the background). As each keystroke is received from the keyboard, it is processed by <a href="INT 09H">INT 09H</a> and placed into a circular queue at 40:001e in the <a href="BIOS Data Area">BIOS Data Area</a>.

AH BIOS Service	Supported by		
	00000		
<u>OOH</u> read keyboard input	[PC]	[XT]	[AT]
<u>O1H</u> query keyboard status/preview key	[PC]	[XT]	[AT]
<u>O2H</u> query keyboard shift flags	[PC]	[XT]	[AT]
O3H set typeamatic rate and delay	[PC]	[XT]	[AT]
04H (reserved)			
<u>O5H</u> store key data			[AT]
10H read extended keyboard input			[AT]
11H query extended keyboard status			[AT]
12H query extended keyboard shift fla	gs		[AT]

See Also: ROM-BIOS Functions

Character I/O Functions (DOS fns)

BIOS Data Area

<u>Cables and Pin Outs</u>

-\*-