

*SET THE CORRESPONDING FIRE PROTECTION ON THE LIFE SAFETY – WALL RATING LEGEND PARAMETER TO AUTOMATICALY FILL THE PARAMETERS AND TABLES THAT REPRESENT THE CORRECT PROTECTION TYPE.

WALL CODES

1 HOUR PARTITIONS

UNIT 1-HR FIRE PARTITION - CORRIDOR WALL PER IBC 708



- Select a wall that contains "Corridor" in its name.
- o In the interior links fill set the Type Code parameter to "FP "
- Color Magenta





- Select a wall that contains "Unit Separation" in its name.
- In the interior links set the parameter Type Code to "FP"
- o Color RGB 255-128-064

• UNIT 1-HR FIRE PARTITION - INTERIOR BEARING WALL PER IBC 601



- o Select the IW 03 1 wall type.
- Set the Type Code parameter to "FP"
- Set the Comments parameter to "BEARING"
- o Color RGB 106-109-234
- For walls that are bearing on 3rd floor also
- o Mark 3RD

SET OUT CONSTRUCTION

SET OUT CONSTRUCTION



- Use an Interior Metal wall (Prefixed as IM-)
- Set the instance parameter Comments to "Set Out"
- Wall rating is 0 // Non-Rated wall
- Color Green



*SET THE CORRESPONDING FIRE PROTECTION ON THE *LIFE SAFETY – WALL RATING LEGEND PARAMETER* TO AUTOMATICALY FILL THE PARAMETERS AND TABLES THAT REPRESENT THE CORRECT PROTECTION TYPE.


FIRE PARTITIONS

- COMMONS FIRE PARTITION 1-HR PER IBC 420.2 / 708
 - For the commons walls around storage or similar that need to be rated partitions make walls 1-HR.
 - Set the Comments parameter to "Commons FP"
 - Color Yellow
 - o For the garage walls in TH units choose a 1-HR wall.
 - Set the *Comments* parameter to "Garage FP"
 - Change filter in the template to read "Garage FP"
 - Set the Type Code parameter to "FP"

FIRE BARRIERS

- COMMONS FIRE BARRIER 1-HR PER IBC 707
 - Use a proper Revit wall for the location it's being used.
 - 1-HR Rated wall
 - Set the instance parameter Type Code to "FB"
 - o Color RGB 255-128-192
- COMMONS FIRE BARRIER 1-HR PER IBC 707

TRASH ROOM, OCCUPANCY SEPARATION



- Set the Comments parameter to "Commons FB"
- Set the Type Code parameter to "FB"
- o Color RGB 0-128-0



*SET THE CORRESPONDING FIRE PROTECTION ON THE *LIFE SAFETY – WALL RATING LEGEND PARAMETER* TO AUTOMATICALY FILL THE PARAMETERS AND TABLES THAT REPRESENT THE CORRECT PROTECTION TYPE.

• COMMONS FIRE BARRIER - 2-HR PER IBC 707 (STAIRS, ELEVATORS, SHAFTS, TRASH TERMINATION)



- Set the Type Code instance parameter to "FB"
- o CMU or Concrete Walls to be 2-HR rating
- o For **Stud walls** holding shaft set the *Comments parameter* "Shaft"
- Color Red
- COMMONS FIRE BARRIER 3-HR PER IBC 707 (VERTICAL PODIUM STEP)



- Select a 3-HR rated wall type.
- Set the Type Code parameter to "FB"
- o Color RGB 160-119-63
- COMMONS SMOKE BARRIER 1-HR PER IBC 709



- Use a proper Revit wall for the location it's being used.
- o 1-HR Rated wall
- Set the instance parameter Type Code to "SB"
- o Color RGB 241-183-046

FIRE WALLS

COMMONS FIRE WALL - 2-HR PER 706 (FOR SHAFT WALLS)



- o Do a Fill Region called "2-HR Fire Wall"
- o Solid Fill
- Color light grey RGB 150-150-150
- COMMONS FIRE WALL 2-HR PER 706
 - Select a 2-HR rated wall type.
 - Set the Type Code parameter to "FW"
 - o Color light grey RGB 150-150-150



*SET THE CORRESPONDING FIRE PROTECTION ON THE *LIFE SAFETY – WALL RATING LEGEND PARAMETER* TO AUTOMATICALY FILL THE PARAMETERS AND TABLES THAT REPRESENT THE CORRECT PROTECTION TYPE.

COMMONS FIRE WALL - 3-HR PER 706



- Do a Fill Region called "3-HR Fire Wall"
- o Solid Fill
- Color Black

EXTERIOR WALLS

• EXTERIOR WALL - 1-HR PER IBC 601



- Set the Type Code parameter to "EX"
- o Color RGB 022-220-231

• EXTERIOR WALL - 2-HR PER IBC 601



- Set the Type Code parameter to "EX"
- o Color RGB 154-048-099

GARAGE WRAP PROJECT EXTERIOR WALL - 1-HR AND 2-HR PER 601 & 705.3

- Select a 2-HR rated wall type for the garage side.
 - Set the Type Code Parameter to "EX"
 - Set the Comments Parameter to "Wrap Project"
- Select a 1-HR rated wall type for the Main Building side.
 - Set the Type Code Parameter to "EX"
 - Set the Comments Parameter to "Wrap Project"