Connect to USB-C:

Pin 1 (GND): A1 or A12 or B1 or B12

Pin 2 (CC2): B5 Pin 3 (CC1): A5 Pin 4 (5 V): A4 or A9 or or B4 or B9









