



公告

## 优秀不够,你是否无可替代

#### 



昵称: 杨奉武 园龄: 5年9个月 粉丝: 629 关注: 1 搜索

找找看 谷歌搜索

#### 我的标签

8266(88) MQTT(50) GPRS(33) SDK(29) Air202(28) 云服务器(21) ESP8266(21) Lua(18) 小程序(17) STM32(16) 更多

#### 随笔分类

备份(22)

Android(22)
Android 开发(8)
C# 开发(4)
CH395Q学习开发(17)
CH579M学习开发(7)
ESP32学习开发(10)
ESP8266 AT指令开发(基于STC89C52单片机)(3)
ESP8266 AT指令开发(基于STM32)(1)
ESP8266 AT指令开发基础入门篇备份(12)
ESP8266 LUA脚本语言开发(13)
ESP8266 LUA开发基础入门篇

#### 102-ESP32学习开发(SDK)-GPIO

<iframe name="ifd" src="https://mnifdv.cn/resource/cnblogs/LearnESP32" frameborder="0" scrolling="auto" width="100%" height="1500"></iframe>

#### 开源ESP32开发(源码见资料源码)

测试板链接:ESP32测试板链接

资料源码:https://github.com/yangfengwu45/learn-esp32.git

【点击加入乐鑫WiFi模组开发交流群】(群号 822685419)<u>https://jq.qq.com/?wv=1027&k=fXgd3UOo</u>

python虚拟机: python-3.8.4-amd64.exe

ESP-IDF工具安装器: esp-idf-tools-setup-2.3.exe

- 基础开源教程:ESP32开发(arduino)
- <u>基础开源教程:ESP8266:LUA脚本开发</u>
- 基础开源教程:ESP8266 AT指令开发(基于51单片机)
- 基础开源教程:Android学习开发
- 基础开源教程:C#学习开发
- 基础开源教程:微信小程序开发入门篇 需要搭配的Android, C#等基础教程如上,各个教程正在整理。
- 000-ESP32开发板使用说明
- ESP32 SDK开发
- 001-开发环境搭建(Windows+VSCode)
- <u>002-测试网络摄像头(OV2640),实现远程视频监控(花生壳http映射)</u>
- 003-学习ESP32资料说明
- 004-新建工程模板和创建新的文件
- 005-ESP32学习开发(SDK)-新建工程补充-通过官方示例创建工程
- <u>101-ESP32学习开发(SDK)-ESP32管脚说明</u>
- •
- .

- .

ESP8266 SDK开发(32) ESP8266 SDK开发基础入门篇 备份(30) GPRS Air202 LUA开发(11) HC32F460(华大) + BC260Y(NB-IOT) 物联网开发 NB-IOT Air302 AT指令和LUA 脚本语言开发(25) PLC(三菱PLC)基础入门篇(2) STM32+Air724UG(4G模组) 物联网开发(43) STM32+BC26/260Y物联网开 发(37) STM32+CH395Q(以太网)物 联网开发(21) STM32+ESP8266(ZLESP8266/ 物联网开发(1) STM32+ESP8266+AIR202/302 远程升级方案(16) STM32+ESP8266+AIR202/302 终端管理方案(6) STM32+ESP8266+Air302物 联网开发(64) STM32+W5500+AIR202/302 基本控制方案(25) STM32+W5500+AIR202/302

远程升级方案(6) UCOSii操作系统(1)

门篇(6)

篇(4)

(16)

W5500 学习开发(8) 编程语言C#(11)

编程语言Python(1)

板学习入门篇(3)

编程语言Lua脚本语言基础入

单片机(LPC1778)LPC1778(2)

单片机(MSP430)开发基础入门

单片机(STC89C51)单片机开发

单片机(STM32)基础入门篇(3)


单片机(STM32)综合应用系列

电路模块使用说明(11)

软件安装使用: MQTT(8) 软件安装使用: OpenResty(6)

# 控制GPIO25输出高低电平

#### 1.原理图



左方引脚

GND 3V3 EN GPIO36/SENSOR\_V GPIO39/SENSOR\_V GPIO34/ADC1\_CH6. GPIO35/ADC1\_CH7.

GPIO35/ADC1 CH7, GPIO32/XTAL 32K GPIO33/XTAL 32K GPIO25/DAC 1/ADG GPIO26/DAC 2/ADG GPIO27/ADC2 CH7,

GPIO14/ADC2\_CH6 GPIO12/ADC2\_CH5

#### 更多 **最新评论**

感想(6)

- 1. Re:单片机模块化程序: 看 看是不是你想要的按键处理 视频不见了
- --伊森亨特 2. Re:C#开发: 通信篇-TCP客 户端


感谢分享,直接就用上了 --7fe

--Zfen

#### 阅读排行榜

- 1. ESP8266使用详解(AT,LUA, SDK)(172693)
- 2. 1-安装MQTT服务器(Windo ws),并连接测试(98591)
- 3. ESP8266刷AT固件与node mcu固件(64580)
- 4. 用ESP8266+android,制作 自己的WIFI小车(ESP8266篇) (64060)
- 5. 有人WIFI模块使用详解(384 74)

#### 2.参考官方例程



- 6. (一)基于阿里云的MQTT远程控制(Android 连接MQTT服务器,ESP8266连接MQTT服务器实现远程通信控制----简单的连接通信)(35888)
- 7. 关于TCP和MQTT之间的转 换(33124)
- 8. C#中public与private与stat ic(32280)
- 9. android 之TCP客户端编程 (31854)
- 10. android客服端+eps8266 +单片机+路由器之远程控制系 统(31298)

#### 推荐排行榜

- 1. C#委托+回调详解(9)
- 2. 用ESP8266+android,制作 自己的WIFI小车(ESP8266篇) (8)
- 3. 用ESP8266+android,制作自己的WIFI小车(Android 软件)(6)
- 4. ESP8266使用详解(AT,LUA, SDK)(6)
- 5. 关于TCP和MQTT之间的转 换(5)

#### 3.程序


```
main > C qpio_example_main.c > ...
      #include <string.h>
      #include "freertos/FreeRTOS.h"
#include "freertos/task.h"
      #include "freertos/queue.h"
      #include "driver/gpio.h"
      #define gpio_pin 25
      void app_main(void)
          gpio_config_t io_conf;
           //禁止中間
          io_conf.intr_type = GPIO_PIN_INTR_DISABLE;
          //输出模式
          io_conf.mode = GPIO_MODE_OUTPUT;
          //配置要设置的引脚
          io_conf.pin_bit_mask = (unsigned long long)1<<gpio_pin;</pre>
          io_conf.pull_down_en = 0;
          io_conf.pull_up_en = 0;
          //配置gpio(不设置上下拉默认输出低电平)
          gpio_config(&io_conf);
          while(1) {
              gpio_set_level(gpio_pin, θ);//设置引脚输出低电平
              vTaskDelay(3000 / portTICK_RATE_MS);//延时约3S
              gpio_set_level(gpio_pin, 1);//设置引脚输出高电平
              vTaskDelay(3000 / portTICK_RATE_MS);//延时约3S
```

```
#include <stdio.h>
  #include <string.h>
  #include <stdlib.h>
  #include "freertos/FreeRTOS.h"
  #include "freertos/task.h"
  #include "freertos/queue.h"
  #include "driver/gpio.h"
  #define gpio pin 25
  void app_main(void)
      //gpio配置结构体
      gpio config t io conf;
      //禁止中断
      io_conf.intr_type = GPIO_PIN_INTR_DISABLE;
      //输出模式
      io_conf.mode = GPIO_MODE_OUTPUT;
      //配置要设置的引脚
      io_conf.pin_bit_mask = (unsigned long long)1<<gpio_pin;</pre>
      //禁止下拉
      io_conf.pull_down_en = 0;
      //禁止上拉
      io conf.pull up en = 0;
```

```
//配置gpio(不设置上下拉默认输出低电平)
gpio_config(&io_conf);

while(1) {
    gpio_set_level(gpio_pin, 0);//设置引脚输出低电平
    vTaskDelay(3000 / portTICK_RATE_MS);//延时约3S
    gpio_set_level(gpio_pin, 1);//设置引脚输出高电平
    vTaskDelay(3000 / portTICK_RATE_MS);//延时约3S
}

}
```



## 控制GPIO25 和 GPIO26 输出高低电平

```
C gpio_example_main.c U x C sidxconfigh U C gpio_typesh

main > C gpio_example_main.c > ...

#include "recertos/task.h"

#include "frecertos/queue.h"

#include "driver/gpio.h"

#define gpio_pin 25

#define gpio_pin 26

//gpio_confige_t io_conf;

//ki_them

io_conf.intr_type = GPIO_PIN_INTR_DISABLE;

//ki_them

io_conf.intr_dype = GPIO_MODE_OUTPUT;

//ki_them

io_conf.jnb_bit_mask = (((unsigned long long)1<<gpio_pin) | ((unsigned long long)1<<gp>io_conf.pull_down_en = 0;

//ki_them

io_conf.pull_down_en = 0;

//ki_them

io_conf.pull_up_en = 0;

//ki_thed

io_conf.
```

```
#include <stdio.h>
  #include <string.h>
  #include <stdlib.h>
  #include "freertos/FreeRTOS.h"
  #include "freertos/task.h"
  #include "freertos/queue.h"
  #include "driver/gpio.h"
  #define gpio_pin 25
  #define gpio_pin1 26
  void app_main(void)
      //gpio配置结构体
      gpio_config_t io_conf;
      //禁止中断
      io_conf.intr_type = GPIO_PIN_INTR_DISABLE;
      //输出模式
     io conf.mode = GPIO MODE OUTPUT;
      //配置要设置的引脚
      io_conf.pin_bit_mask = (((unsigned long long)1<<gpio_pin) | ((unsigned lo</pre>
      //禁止下拉
     io_conf.pull_down_en = 0;
      //禁止上拉
      io_conf.pull_up_en = 0;
      //配置gpio(不设置上下拉默认输出低电平)
      gpio config(&io conf);
      while(1) {
         gpio set level(gpio pin, 0);//设置引脚输出低电平
          gpio_set_level(gpio_pin1, 0);//设置引脚输出低电平
```

```
vTaskDelay(3000 / portTICK_RATE_MS);//延时约3S

gpio_set_level(gpio_pin, 1);//设置引脚输出高电平
gpio_set_level(gpio_pin1, 1);//设置引脚输出高电平

vTaskDelay(3000 / portTICK_RATE_MS);//延时约3S

}

}
```



#### 补充:

#### 配置gpio还有一个参数 driver

GPIO\_DRIVE\_CAP\_0 弱 weak
GPIO\_DRIVE\_CAP\_1 强
GPIO\_DRIVE\_CAP\_2 默认值
GPIO\_DRIVE\_CAP\_DEFAULT 默认值
GPIO\_DRIVE\_CAP\_3 最强

io\_conf.driver = GPIO\_DRIVE\_CAP\_3;

## 提示

#### GPIO的模式

GPIO\_MODE\_INPUT 输入
GPIO\_MODE\_OUTPUT 输出
GPIO\_MODE\_OUTPUT\_OD 开漏输出

# GPIO\_MODE\_INPUT\_OUTPUT\_OD 开漏输入输出 GPIO\_MODE\_INPUT\_OUTPUT 输入输出(如果想让模块即做输入检测又做输出控制,需要设置这个模式)

```
GPIO_INTR_MAX,

} gpio_int_type_t;

typedef enum {

GPIO_MODE_DISABLE = GPIO_MODE_DEF_DISABLE,

GPIO_MODE_INPUT = GPIO_MODE_DEF_INPUT,

GPIO_MODE_OUTPUT = GPIO_MODE_DEF_OUTPUT,

GPIO_MODE_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OUTPUT_OU
```

# 配置GPIO0作为输入输出模式,检测引脚输出状态

```
C gpio_example_main.c U X C gpio.c
                                        C gpio_types.h
main > C gpio_example_main.c > 🗘 app_main(void)
      #include <stdio.h>
      #include <string.h>
     #include "freertos/FreeRTOS.h"
     #include "freertos/task.h'
     #include "freertos/queue.h"
#include "driver/gpio.h"
     #define gpio pin 0
      void app_main(void)
          gpio_config_t io_conf;
          //禁止中断
          io_conf.intr_type = GPIO_PIN_INTR_DISABLE;
          io_conf.mode = GPIO_MODE_INPUT_OUTPUT;
          io_conf.pin_bit_mask = (unsigned long long)1<<gpio_pin;</pre>
          io_conf.pull_down_en = 0;
          //禁止上拉
          io_conf.pull_up_en = 0;
          //配置gpio(不设置上下拉默认输出低电平)
          gpio_config(&io_conf);
          while(1) {
              gpio_set_level(gpio_pin, 0);//设置引脚输出低电平
              printf("获取引脚状态=%d\r\n",gpio_get_level(gpio_pin));
              vTaskDelay(3000 / portTICK_RATE_MS);//延时约3S
              gpio_set_level(gpio_pin, 1);//设置引脚输出高电平
              printf("获取引脚状态=%d\r\n",gpio_get_level(gpio_pin));
              vTaskDelay(3000 / portTICK_RATE_MS);//延时约3S
```

```
#include <stdio.h>
  #include <string.h>
  #include <stdlib.h>
  #include "freertos/FreeRTOS.h"
  #include "freertos/task.h"
  #include "freertos/queue.h"
  #include "driver/gpio.h"
  #define gpio_pin 0
  void app_main(void)
     //gpio配置结构体
     gpio_config_t io_conf;
     //禁止中断
     io_conf.intr_type = GPIO_PIN_INTR_DISABLE;
      //输入输出模式
     io_conf.mode = GPIO_MODE_INPUT_OUTPUT;
     //配置要设置的引脚
     io_conf.pin_bit_mask = (unsigned long long)1<<gpio_pin;</pre>
     //禁止下拉
     io_conf.pull_down_en = 0;
     //禁止上拉
     io_conf.pull_up_en = 0;
     //配置gpio(不设置上下拉默认输出低电平)
      gpio_config(&io_conf);
      while(1) {
         gpio_set_level(gpio_pin, 0);//设置引脚输出低电平
         printf("获取引脚状态=%d\r\n",gpio_get_level(gpio_pin));
         vTaskDelay(3000 / portTICK_RATE_MS);//延討约3S
         gpio_set_level(gpio_pin, 1);//设置引脚输出高电平
         printf("获取引脚状态=%d\r\n",gpio_get_level(gpio_pin));
         vTaskDelay(3000 / portTICK_RATE_MS);//延时约3S
      }
```

## 配置GPIO0下降沿中断

## 1,中断类型

GPIO\_INTR\_DISABLE 禁用GPIO中断
GPIO\_INTR\_POSEDGE GPIO中断类型:上升沿
GPIO\_INTR\_NEGEDGE 下降沿
GPIO\_INTR\_ANYEDGE 上升沿和下降沿
GPIO\_INTR\_LOW\_LEVEL 输入低电平触发
GPIO\_INTR\_HIGH LEVEL 输入高电平触发

#### 2,程序

```
gpio_example_main.c U X C esp_intr_alloc.h H:\...\esp32\include
                                                            C intr_alloc.c
main > C gpio_example_main.c > 😚 app_main(void)
     #include <string.h>
     #include "freertos/task.h"
#include "freertos/queue.h"
#include "driver/gpio.h"
     #define gpio_pin 0
     static xQueueHandle gpio_evt_queue = NULL;
     static void IRAM_ATTR gpio_isr_handler(void* arg)
         uint32_t gpio_num = (uint32_t) arg;
         xQueueSendFromISR(gpio_evt_queue, &gpio_num, NULL);
     static void gpio_task_example(void* arg)
         uint32_t io_num;
          if(xQueueReceive(gpio_evt_queue, &io_num, portMAX_DELAY)) {
                  printf("GPIO[%d] intr, val: %d\n", io_num, gpio_get_level(io_num));
     void app_main(void)
          gpio_config_t io_conf;
          io_conf.intr_type = GPIO_INTR_NEGEDGE;
          io_conf.mode = GPIO_MODE_INPUT;
```

```
#include <stdio.h>
  #include <string.h>
  #include <stdlib.h>
  #include "freertos/FreeRTOS.h"
  #include "freertos/queue.h"
  #include "driver/gpio.h"
  #define gpio_pin 0
  static xQueueHandle gpio_evt_queue = NULL;
  /*gpio中断回调函数*/
  static void IRAM_ATTR gpio_isr_handler(void* arg)
      uint32_t gpio_num = (uint32_t) arg;
      //把消息存储到消息队列
      xQueueSendFromISR(gpio_evt_queue, &gpio_num, NULL);
  }
  /*任务函数*/
  static void gpio_task_example(void* arg)
      uint32_t io_num;
      for(;;) {
          /*消息队列里面有消息*/
```

```
if(xQueueReceive(gpio_evt_queue, &io_num, portMAX_DELAY)) {
            printf("GPIO[%d] intr, val: %d\n", io_num, gpio_get_level(io_num)
  }
  void app_main(void)
     //gpio配置结构体
     gpio_config_t io_conf;
     //下降沿中断
     io_conf.intr_type = GPIO_INTR_NEGEDGE;
     //输入模式
     io_conf.mode = GPIO_MODE_INPUT;
     //配置要设置的引脚
     io_conf.pin_bit_mask = (unsigned long long) 1 << gpio_pin;</pre>
     //禁止下拉
     io_conf.pull_down_en = 0;
     //上拉
     io_conf.pull_up_en = 1;
     //配置gpio
     gpio_config(&io_conf);
     /*中断里面不能写printf,写了会死机; 所以就用任务+消息队列打印*/
     //创建消息队列
     gpio_evt_queue = xQueueCreate(10, sizeof(uint32_t));
     //创建任务
     xTaskCreate(gpio_task_example, "gpio_task_example", 2048, NULL, 10, NULL)
     //设置中断优先级(1-8级),如果参数写0,则内部自动从1-3级中分配一个优先级; 7级优先级为最高
     //如果设置为8,则此中断是共享中断,即多个外设都可触发这个中断(处理起来应该会很麻烦,到时候
     gpio_install_isr_service(ESP_INTR_FLAG_LEVEL1);
     //移除中断
     gpio_isr_handler_remove(gpio_pin);
     gpio_isr_handler_add(gpio_pin, gpio_isr_handler, (void*) gpio_pin);
     while(1) {
         //必须加延时,任务不能没有延时,否则导致任务无法切换.
         vTaskDelay(1000 / portTICK_RATE_MS);
     }
  4
```

### 3,其实主要的就几句话

```
void app_main(void)
39
40
           io_conf.intr_type = GPIO_INTR_NEGEDGE;
42
43
44
45
46
47
48
49
50
51
           io_conf.mode = GPIO_MODE_INPUT;
           io_conf.pin_bit_mask = (unsigned long long)1<<gpio_pin;</pre>
           io_conf.pull_down_en = 0;
           io_conf.pull_up_en = 1;
           gpio_config(&io_conf);
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
           gpio_evt_queue = xQueueCreate(10, sizeof(uint32_t));
           xTaskCreate(gpio_task_example, "gpio_task_example", 2048, NULL, 10, NULL);
           //设置中断优先级(1-8级),如果参数写e,则内部自动从1-3级中分配一个优先级;7级优先级为最高;
//如果设置为8,则此中断是共享中断,即多个外设都可触发这个中断(处理起来应该会很麻烦,到时候真的使用到再说)
           gpio_install_isr_service(ESP_INTR_FLAG_LEVEL1);
           gpio_isr_handler_remove(gpio_pin);
           gpio_isr_handler_add(gpio_pin, gpio_isr_handler, (void*) gpio_pin);
```

#### 4,动作 按键 (GPIO0)



```
I (307) gpio: GPIO[0]| InputEn: 1| OutputEn: 0|
GPIO[0] intr, val: 0
GPIO[0] intr, val: 1
GPIO[0] intr, val: 0
GPIO[0] intr, val: 1
GPIO[0] intr, val: 1
GPIO[0] intr, val: 0
```

#### 5,提示

按理说下降沿中断,读取到的引脚电平只有0才对,但是呢之所有1,是因为



提交评论 退出

[Ctrl+Enter快捷键提交]

【推荐】大型组态、工控、仿真、CAD\GIS 50万行VC++源码免费下载!

#### 编辑推荐:

- ·聊聊【向上管理】中的"尺度"
- · 一个故事看懂进程间通信技术
- ·记一次 .NET 某云采购平台API 挂死分析
- ·利用 PGO 提升 .NET 程序性能
- · 我给鸿星尔克写了一个720°看鞋展厅

#### 最新新闻:

- ·特斯拉前CTO另立门户:搞旧电池回收,获7亿美元融资
- ·新能源车和燃油车相争, 4S店却先倒下了?
- ·比微信支付宝更安全!今日起 北京地铁可用数字人民币买票充值
- ·去年夏天,英特尔为何"崩盘"了,5年后能反超吗
- ·天体物理学家在追寻 "层次分明"的黑洞
- » 更多新闻...

## Powered by:

博客园

Copyright © 2021 杨奉武 Powered by .NET 5.0 on Kubernetes







单片机,物联网,上位机,… 扫一扫二维码,加入群聊。