

Nios II Processor Reference Handbook



101 Innovation Drive San Jose, CA 95134 (408) 544-7000 http://www.altera.com

Copyright © 2003 Altera Corporation. All rights reserved. Altera, The Programmable Solutions Company, the stylized Altera logo, specific device designations, and all other words and logos that are identified as trademarks and/or service marks are, unless noted otherwise, the trademarks and service marks of Altera Corporation in the U.S. and other countries. All other product or service names are the property of their respective holders. Altera products are protected under numerous U.S. and foreign patents and pending applications, maskwork rights, and copyrights. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera Corporation. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.



ii

Altera Corporation

I.S. EN ISO 9001

Contents



Chapter Revision Dates	vi i
About This Handhask	i.
About This Handbook	
Introduction	
Assumptions about the Reader	
How to Contact Altera	
Typographical Conventions	
Section I. Nios II Processor	Ι. 1
Revision History	I–1
Chapter 1. Introduction	
Introduction	1–1
Nios II Processor System Basics	1–1
Getting Started with the Nios II Processor	
Customizing Nios II Processor Designs	
Configurable Soft-Core Processor Concepts	1–3
Configurable Soft-Core Processor	
Flexible Peripheral Set & Address Map	
Custom Instructions	
Automated System Generation	1–5
Chapter 2. Processor Architecture	
Introduction	2–1
Processor Implementation	
Register File 1	
Arithmetic Logic Unit	
Unimplemented Instructions	
Custom Instructions	
Floating Point Instructions	
Reset Signals	
Exception & Interrupt Controller	
Exception Controller	
Integral Interrupt Controller	
ning-m merrip. Comment	
Memory & I/O Organization	
Instruction & Data Buses	2_8

Cache Memory	2–10
Tightly Coupled Memory	
Address Map	
JTAG Debug Module	
JTAG Target Connection	
Download & Execute Software	
Software Breakpoints	
Hardware Breakpoints	
Hardware Triggers	
Trace Capture	
Chapter 3. Programming Model	
Introduction	3–1
General-Purpose Registers	
Control Registers	
Operating Modes	
Supervisor Mode	
User Mode	
Debug Mode	
Changing Modes	
Exception Processing	
Exception Types	
Determining the Cause of Exceptions	
Nested Exceptions	
Returning from an Exception	3–13
Break Processing	3–14
Processing a Break	
Returning from a Break	
Register Usage	
Memory & Peripheral Access	
Addressing Modes	
Cache Memory	
Processor Reset State	
Instruction Set Categories	
Data Transfer Instructions	
Arithmetic & Logical Instructions	
Move Instructions	3–20
Comparison Instructions	
Shift & Rotate Instructions	
Program Control Instructions	
Other Control Instructions	3–23
Custom Instructions	3–23
No-Operation Instruction	
Potential Unimplemented Instructions	3–24
Chapter 4. Implementing the Nios II Processor in SOPC Buil	lder
Introduction	

Nios II Core Tab	4–2
Core Setting	
Multiply & Divide Settings	4–3
Caches & Tightly Coupled Memories Tab	
Instruction Settings	
Data Settings	4–5
Advanced Features Tab	
JTAG Debug Module Tab	4–6
Debug Level Settings	
On-Chip Trace Buffer Settings	4–9
Custom Instructions Tab	
Floating-Point Custom Instructions	4–10
Section II. Appendixes	
Revision History	Section II-1
Chapter 5. Nios II Core Implementation Details	
Introduction	
Device Support	
Nios II/f Core	5–3
Overview	
Register File	5–3
Arithmetic Logic Unit	5–3
Memory Access	
Tightly Coupled Memory	5–7
Execution Pipeline	
Instruction Performance	
Exception Handling	
JTAG Debug Module	
Unsupported Features	5–11
Nios II/s Core	
Overview	
Register File	
Arithmetic Logic Unit	
Memory Access	
Tightly Coupled Memory	
Execution Pipeline	
Instruction Performance	
Exception Handling	
JTAG Debug Module	
Unsupported Features	
Nios II/e Core	
Overview	
Register File	5–18
Arithmetic Logic Unit	5_18

Memory Access	5–19
Instruction Execution Stages	5–19
Instruction Performance	
Exception Handling	5–20
JTAG Debug Module	
Unsupported Features	
O O.N. II.D	
Chapter 6. Nios II Processor Revision History	
Introduction	
Nios II Versions	
Architecture Revisions	
Core Revisions	
Nios II/f Core	
Nios II/s Core	
Nios II/e Core	
JTAG Debug Module Revisions	6–6
Chanter 7 Application Pinary Interface	
Chapter 7. Application Binary Interface	= 4
Data Types	
Memory Alignment	
Register Usage	
Endianess of Data	
Stacks	
Frame Pointer Elimination	
Call Saved Registers	
Further Examples of Stacks	
Function Prologs	
Arguments & Return Values	
Arguments	
Return Values	
Chapter 8. Instruction Set Reference	
Introduction	0 1
Word Formats	
I-Type	
R-Type	
J-Type	
Instruction Opcodes	
Assembler Pseudo-instructions	
Assembler Macros	
Instruction Set Reference	8–8



Chapter Revision Dates

The chapters in this book, *Nios II Processor Reference Handbook*, were revised on the following dates. Where chapters or groups of chapters are available separately, part numbers are listed.

Chapter 1. Introduction

Revised: May 2006 Part number: NII51001-6.0.0

Chapter 2. Processor Architecture

Revised: May 2006 Part number: NII51002-6.0.0

Chapter 3. Programming Model

Revised: May 2006 Part number: NII51003-6.0.0

Chapter 4. Implementing the Nios II Processor in SOPC Builder

Revised: May 2006 Part number: NII51004-6.0.0

Chapter 5. Nios II Core Implementation Details

Revised: May 2006 Part number: NII51015-6.0.0

Chapter 6. Nios II Processor Revision History

Revised: May 2006 Part number: NII51018-6.0.0

Chapter 7. Application Binary Interface

Revised: May 2006 Part number: NII51016-6.0.0

Chapter 8. Instruction Set Reference

Revised: May 2006 Part number: NII51017-6.0.0

Altera Corporation vii

viii Altera Corporation



About This Handbook

Introduction

The handbook you are holding (the *Nios II Processor Reference Handbook*) is the primary reference for the Nios[®] II family of embedded processors. This handbook answers the question "What is the Nios II processor?" from a high-level conceptual description to the low-level details of implementation. The chapters in this handbook define the Nios II processor architecture, the programming model, the instruction set, information about peripherals, and more.

This handbook is part of a larger collection of documents covering the Nios II processor and its usage. See "How to Find Further Information".

Assumptions about the Reader

This handbook assumes you have a basic familiarity with embedded processor concepts. You do not need to be familiar with any specific Altera® technology or with Altera development tools. This handbook was written intentionally to minimize discussion of hardware implementation details of the processor system. That said, the Nios II processor was designed for Altera field programmable gate array (FPGA) devices, and FPGA implementation concepts will inevitably arise from time to time. While familiarity with FPGA technology is not required, it may give you a deeper understanding of the engineering tradeoffs that went into the design and implementation of the Nios II processor.

Altera Corporation ix

How to Find Further Information

This handbook is one part of the complete Nios II processor documentation. The following references are also available.

- The *Nios II Processor Reference Handbook* (this handbook) defines the basic processor architecture and features.
- The *Nios II Software Developer's Handbook* describes the software development environment, and discusses application programming for the Nios II processor.
- The *Quartus II Handbook, Volume 5: Embedded Peripherals* discusses Altera-provided peripherals and Nios II drivers which are included with the Quartus[®] II software.
- The Nios II integrated development environment (IDE) provides tutorials and complete reference for using the features of the graphical user interface. The help system is available after launching the Nios II IDE.
- Altera's on-line solutions database is an internet resource that offers solutions to frequently asked questions via an easy-to-use search engine. Go to the support center on www.altera.com and click on the Find Answers link.
- Altera application notes and tutorials offer step-by-step instructions on using the Nios II processor for a specific application or purpose. These documents are often installed with Altera development kits, or can be obtained online from www.altera.com.

How to Contact Altera

For the most up-to-date information about Altera products, go to the Altera world-wide web site at www.altera.com. For technical support on this product, go to www.altera.com/mysupport. For additional information about Altera products, consult the sources shown below.

Information Type	USA & Canada	All Other Locations
Technical support www.altera.com/mysupport/		www.altera.com/mysupport/
	(800) 800-EPLD (3753) (7:00 a.m. to 5:00 p.m. Pacific Time)	+1 408-544-8767 7:00 a.m. to 5:00 p.m. (GMT -8:00) Pacific Time
Product literature	www.altera.com	www.altera.com
Altera literature services	literature@altera.com	literature@altera.com
Non-technical customer service	(800) 767-3753	+ 1 408-544-7000 7:00 a.m. to 5:00 p.m. (GMT -8:00) Pacific Time
FTP site	ftp.altera.com	ftp.altera.com

Typographical **Conventions**

This document uses the typographic conventions shown below.

Visual Cue	Meaning	
Bold Type with Initial Capital Letters	Command names, dialog box titles, checkbox options, and dialog box options are shown in bold, initial capital letters. Example: Save As dialog box.	
Bold type	External timing parameters, directory names, project names, disk drive names, filenames, filename extensions, and software utility names are shown in bold type. Examples: f _{MAX} , \qdesigns directory, d: drive, chiptrip.gdf file.	
Italic Type with Initial Capital Letters	Document titles are shown in italic type with initial capital letters. Example: AN 75: High-Speed Board Design.	
Italic type	Internal timing parameters and variables are shown in italic type. Examples: $t_{P A}$, $n+1$.	
	Variable names are enclosed in angle brackets (< >) and shown in italic type. Example: <file name="">, <pre><pre></pre></pre><pre><pre>Example: <file name="">, <pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre></file></pre></pre></file>	
Initial Capital Letters	Keyboard keys and menu names are shown with initial capital letters. Examples: Delete key, the Options menu.	
"Subheading Title"	References to sections within a document and titles of on-line help topics are shown in quotation marks. Example: "Typographic Conventions."	
Courier type	Signal and port names are shown in lowercase Courier type. Examples: data1, tdi, input. Active-low signals are denoted by suffix n, e.g., resetn.	
	Anything that must be typed exactly as it appears is shown in Courier type. For example: c:\qdesigns\tutorial\chiptrip.gdf. Also, sections of an actual file, such as a Report File, references to parts of files (e.g., the AHDL keyword SUBDESIGN), as well as logic function names (e.g., TRI) are shown in Courier.	
1., 2., 3., and a., b., c., etc.	Numbered steps are used in a list of items when the sequence of the items is important, such as the steps listed in a procedure.	
•••	Bullets are used in a list of items when the sequence of the items is not important.	
✓	The checkmark indicates a procedure that consists of one step only.	
	The hand points to information that requires special attention.	
CAUTION	The caution indicates required information that needs special consideration and understanding and should be read prior to starting or continuing with the procedure or process.	
A	The warning indicates information that should be read prior to starting or continuing the procedure or processes	
4	The angled arrow indicates you should press the Enter key.	
•••	The feet direct you to more information on a particular topic.	

Altera Corporation



Section I. Nios II Processor

This section provides information about the Nios® II processor.

This section includes the following chapters:

- Chapter 1, Introduction
- Chapter 2, Processor Architecture
- Chapter 3, Programming Model
- Chapter 4, Implementing the Nios II Processor in SOPC Builder

Revision History

The following table shows the revision history for Chapters 1–4.

Chapter(s)	Date / Version	Changes Made
1	May 2006, v6.0.0	 Added single precision floating point and integration with SignalTap®II logic analyzer to features list. Updated performance to 250 DMIPS.
	October 2005, v5.1.0	No change from previous release.
	May 2005, v5.0.0	No change from previous release.
	September 2004, v1.1	Updates for Nios II 1.01 release.
	May 2004, v1.0	First publication.

Altera Corporation Section I-1

Chapter(s)	Date / Version	Changes Made
2	May 2006, v6.0.0	 Added description of optional cpu_resetrequest and cpu_resettaken. Added section on single precision floating point.
	October 2005, v5.1.0	No change from previous release.
	May 2005, v5.0.0	Added tightly coupled memory.
	December 2004, v1.2	Added new control register ct15.
	September 2004, v1.1	Updates for Nios II 1.01 release.
	May 2004, v1.0	First publication.
3	May 2006, v6.0.0	No change from previous release.
	October 2005, v5.1.0	No change from previous release.
	May 2005, v5.0.0	No change from previous release.
	September 2004, v1.1	 Added details for new control register ctl5. Updated details of debug mode and break processing to reflect new behavior of the break instruction.
	May 2004, v1.0	First publication.
4	May 2006, v6.0.0	 Added details on floating point custom instructions. Added section on Advanced Features tab.
	October 2005, v5.1.0	No change from previous release.
	May 2005, v5.0.0	 Updates to reflect new GUI options in Nios II processor version 5.0. New details in "Caches and Tightly Coupled Memory" section.
	September 2004, v1.1	 Updates to reflect new GUI options in Nios II processor version 1.1. New details in section "Multiply and Divide Settings."
	May 2004, v1.0	First publication.

Section I–2 Altera Corporation

1. Introduction



NII51001-6.0.0

Introduction

This chapter is an introduction to the Nios® II embedded processor family. This chapter will help both hardware and software engineers understand the similarities and differences between the Nios II processor and traditional embedded processors.

Nios II Processor System Basics

The Nios II processor is a general-purpose RISC processor core, providing:

- Full 32-bit instruction set, data path, and address space
- 32 general-purpose registers
- 32 external interrupt sources
- Single-instruction 32 × 32 multiply and divide producing a 32-bit result
- Dedicated instructions for computing 64-bit and 128-bit products of multiplication
- Floating-point instructions for single-precision floating-point operations
- Single-instruction barrel shifter
- Access to a variety of on-chip peripherals, and interfaces to off-chip memories and peripherals
- Hardware-assisted debug module enabling processor start, stop, step and trace under integrated development environment (IDE) control
- Software development environment based on the GNU C/C++ tool chain and Eclipse IDE
- Integration with Altera's SignalTap(r) II logic analyzer, enabling realtime analysis of instructions and data along with other signals in the FPGA design
- Instruction set architecture (ISA) compatible across all Nios II processor systems
- Performance up to 250 DMIPS

A Nios II processor system is equivalent to a microcontroller or "computer on a chip" that includes a CPU and a combination of peripherals and memory on a single chip. The term "Nios II processor system" refers to a Nios II processor core, a set of on-chip peripherals, on-chip memory, and interfaces to off-chip memory, all implemented on a single Altera® chip. Like a microcontroller family, all Nios II processor systems use a consistent instruction set and programming model.

Getting Started with the Nios II Processor

Getting started with the Nios II processor is similar to any other microcontroller family. The easiest way to start designing effectively is to purchase a development kit from Altera that includes a ready-made evaluation board and all the software development tools necessary to write Nios II software.

The Nios II software development environment is called The Nios II integrated development environment (IDE). The Nios II IDE is based on the GNU C/C++ compiler and the Eclipse IDE, and provides a familiar and established environment for software development. Using the Nios II IDE, designers can immediately begin developing and simulating Nios II software applications. Using the Nios II hardware reference designs included in an Altera development kit, designers can prototype their application running on a board before building a custom hardware platform. Figure 1–1 shows an example of a Nios II processor reference design available in an Altera Nios II development kit.




Figure 1–1. Example of a Nios II Processor System

If the prototype system adequately meets design requirements using an Altera-provided reference design, the reference design can be copied and used as-is in the final hardware platform. Otherwise, the designer can customize the Nios II processor system until it meets cost or performance requirements.

Customizing Nios II Processor Designs

Altera FPGAs provide flexibility to add features and enhance performance of the processor system. Conversely, unnecessary processor features and peripherals can be eliminated to fit the design in a smaller, lower-cost device.

Because the pins and logic resources in Altera devices are programmable, many customizations are possible:

- The pins on the chip can be rearranged to make board design easier. For example, address and data pins for external SDRAM memory can be moved to any side of the chip to shorten board traces.
- Extra pins and logic resources on the chip can be used for functions unrelated to the processor. Extra resources can provide a few extra gates and registers as "glue logic" for the board design; or extra resources can implement entire systems. For example, a Nios II processor system consumes only 5% of a large Altera FPGA, leaving the rest of the chip's resources available to implement other functions.
- Extra pins and logic on the chip can be used to implement additional peripherals for the Nios II processor system. Altera offers a growing library of peripherals that can be easily connected to Nios II processor systems.

In practice, most FPGA designs do implement some extra logic in addition to the Nios II processor system. Additional logic has no affect on the programmer's view of the Nios II processor.

Configurable Soft-Core Processor Concepts

This section introduces Nios II concepts that are unique or different from discrete microcontrollers. The concepts described below are mentioned here because they provide the background upon which other features are documented.

For the most part, these concepts relate to the flexibility for hardware designers to fine-tune system implementation. Software programmers generally are not affected by the hardware implementation details, and can write programs without awareness of the configurable nature of the Nios II processor core.

Configurable Soft-Core Processor

The Nios II processor is a configurable soft-core processor, as opposed to a fixed, off-the-shelf microcontroller. In this context, "configurable" means that features can be added or removed on a system-by-system basis to meet performance or price goals. "Soft-core" means the CPU core is offered in "soft" design form (i.e., not fixed in silicon), and can be targeted to any Altera FPGA family. In other words, Altera does not sell "Nios II chips"; Altera sells blank FPGAs. It is the users that configure the Nios II processor and peripherals to meet their specifications, and then program the system into an Altera FPGA.

Configurability does not mean that designers must create a new Nios II processor configuration for every new design. Altera provides readymade Nios II system designs that system designers can use as-is. If these designs meet the system requirements, there is no need to configure the design further. In addition, software designers can use the Nios II instruction set simulator to begin writing and debugging Nios II applications before the final hardware configuration is determined.

Flexible Peripheral Set & Address Map

A flexible peripheral set is one of the most notable differences between Nios II processor systems and fixed microcontrollers. Because of the softcore nature of the Nios II processor, designers can easily build made-to-order Nios II processor systems with the exact peripheral set required for the target applications.

A corollary of flexible peripherals is a flexible address map. Software constructs are provided to access memory and peripherals generically, independently of address location. Therefore, the flexible peripheral set and address map does not affect application developers.

Peripherals can be categorized into two broad classes: Standard peripherals and custom peripherals.

Standard Peripherals

Altera provides a set of peripherals commonly used in microcontrollers, such as timers, serial communication interfaces, general-purpose I/O, SDRAM controllers, and other memory interfaces. The list of available peripherals continues to grow as Altera and third-party vendors release new soft peripheral cores.

Custom Peripherals

Designers can also create their own custom peripherals and integrate them into Nios II processor systems. For performance-critical systems that spend most CPU cycles executing a specific section of code, it is a common technique to create a custom peripheral that implements the same function in hardware. This approach offers a double performance benefit: the hardware implementation is faster than software; and the processor is free to perform other functions in parallel while the custom peripheral operates on data.

Custom Instructions

Like custom peripherals, custom instructions are a method to increase system performance by augmenting the processor with custom hardware. The soft-core nature of the Nios II processor enables designers to integrate custom logic into the arithmetic logic unit (ALU). Similar to native Nios II instructions, custom instruction logic can take values from up to two source registers and optionally write back a result to a destination register.

By using custom instructions, designers can fine tune the system hardware to meet performance goals. Because the processor is implemented on reprogrammable Altera FPGAs, software and hardware engineers can work together to iteratively optimize the hardware and test the results of software executing on real hardware.

From the software perspective, custom instructions appear as machinegenerated assembly macros or C functions, so programmers do not need to know assembly in order to use custom instructions.

Automated System Generation

Altera's SOPC Builder design tool fully automates the process of configuring processor features and generating a hardware design that can be programmed into an FPGA. The SOPC Builder graphical user interface (GUI) enables hardware designers to configure Nios II processor systems with any number of peripherals and memory interfaces. Entire processor systems can be created without requiring the designer to perform any

schematic or hardware description-language (HDL) design entry. SOPC Builder can also import a designer's HDL design files, providing an easy mechanism to integrate custom logic into a Nios II processor system.

After system generation, the design can be programmed into a board, and software can be debugged executing on the board. Once the design is programmed into a board, the processor architecture is fixed. Software development proceeds in the same manner as for traditional, nonconfigurable processors.

2. Processor Architecture

NII51002-6.0.0

Introduction

This chapter describes the hardware structure of the Nios[®] II processor, including a discussion of all the functional units of the Nios II architecture and the fundamentals of the Nios II processor hardware implementation.

The *Nios II architecture* describes an instruction set architecture (ISA). The ISA in turn necessitates a set of functional units that implement the instructions. A *Nios II processor core* is a hardware design that implements the Nios II instruction set and supports the functional units described in this document. The processor core does not include peripherals or the connection logic to the outside world. It includes only the circuits required to implement the Nios II architecture.

Figure 2–1 shows a block diagram of the Nios II processor core.

Nios II Processor Core reset **Tightly Coupled** Program Instruction Memory clock Controller cpu_resetrequest General cpu_resettaken Purpose Address Registers JTAG Generation r0 to r31 Instruction Tightly Coupled **JTAG** interface Cache Instruction Memory Debug Module to software debugger Exception Controller Control irq[31..0] Registers Instruction Bus Interrupt ctl0 to ctl5 Controller Data Bus Custom Arithmetic Custom Tightly Coupled Logic Unit Cache Instruction Data Memory Signals Logic

Figure 2-1. Nios II Processor Core Block Diagram

Tightly Coupled Data Memory The Nios II architecture defines the following user-visible functional units:

- Register file
- Arithmetic logic unit
- Interface to custom instruction logic
- Exception controller
- Interrupt controller
- Instruction bus
- Data bus
- Instruction and data cache memories
- Tightly coupled memory interfaces for instructions and data
- JTAG debug module

The following sections discuss hardware implementation details related to each functional unit.

Processor Implementation

The functional units of the Nios II architecture form the foundation for the Nios II instruction set. However, this does not indicate that any unit is implemented in hardware. The Nios II architecture describes an instruction set, not a particular hardware implementation. A functional unit can be implemented in hardware, emulated in software, or omitted entirely.

A Nios II implementation is a set of design choices embodied by a particular Nios II processor core. All implementations support the instruction set defined in the *Nios II Processor Reference Handbook*. Each implementation achieves specific objectives, such as smaller core size or higher performance. This allows the Nios II architecture to adapt to the needs of different target applications.

Implementation variables generally fit one of three trade-off patterns: more-or-less of a feature; inclusion-or-exclusion of a feature; hardware implementation or software emulation of a feature. An example of each trade-off follows:

- More or less of a feature—For example, to fine-tune performance, designers can increase or decrease the amount of instruction cache memory. A larger cache increases execution speed of large programs, while a smaller cache conserves on-chip memory resources.
- Inclusion or exclusion of a feature—For example, to reduce cost, designers can choose to omit the JTAG debug module. This decision conserves on-chip logic and memory resources, but it eliminates the ability to use a software debugger to debug applications.

■ Hardware implementation or software emulation—For example, in control applications that rarely perform complex arithmetic, designers can choose for the division instruction to be emulated in software. Removing the divide hardware conserves on-chip resources but increases the execution time of division operations.



For details of which Nios II cores supports what features, refer to the Nios II Core Implementation Details chapter of the Nios II Processor Reference Handbook. For complete details of user-selectable parameters for the Nios II processor, refer to the Implementing the Nios II Processor in SOPC Builder chapter of the Nios II Processor Reference Handbook.

Register File

The Nios II architecture supports a flat register file, consisting of thirty two 32-bit general-purpose integer registers, and six 32-bit control registers. The architecture supports supervisor and user modes that allow system code to protect the control registers from errant applications.

The Nios II architecture allows for the future addition of floating point registers.

Arithmetic Logic Unit

The Nios II arithmetic logic unit (ALU) operates on data stored in general-purpose registers. ALU operations take one or two inputs from registers, and store a result back in a register. The ALU supports the data operations shown in Table 2–1:

Table 2–1. Operations Supported by the Nios II ALU			
Category	Details		
Arithmetic	The ALU supports addition, subtraction, multiplication, and division on signed and unsigned operands.		
Relational	The ALU supports the equal, not-equal, greater-than-or-equal, and less-than relational operations (==, != >=, <) on signed and unsigned operands.		
Logical	The ALU supports AND, OR, NOR, and XOR logical operations.		
Shift and Rotate	The ALU supports shift and rotate operations, and can shift/rotate data by 0 to 31 bit-positions per instruction. The ALU supports arithmetic shift right and logical shift right/left. The ALU supports rotate left/right.		

To implement any other operation, software computes the result by performing a combination of the fundamental operations in Table 2–1.

Unimplemented Instructions

Some Nios II processor cores do not provide hardware to perform multiplication or division operations. The following instructions are the only operations that the processor core may emulate in software: mul, muli, muliss, mulisu, muliu, div, divu. In such a core, these are known as unimplemented instructions. All other instructions are implemented in hardware.

The processor generates an exception whenever it issues an unimplemented instruction, and the exception handler calls a routine that emulates the operation in software. Therefore, unimplemented instructions do not affect the programmer's view of the processor.

Custom Instructions

The Nios II architecture supports user-defined custom instructions. The Nios II ALU connects directly to custom instruction logic, enabling designers to implement in hardware operations that are accessed and used exactly like native instructions. For further information see the *Nios II Custom Instruction User Guide*.

Floating Point Instructions

The Nios II architecture supports single precision floating point instructions as specified by the IEEE Std 754-1985. These floating point instructions are implemented as custom instructions. Table 2–2 provides a detailed description of the conformance to IEEE 754-1985.

Table 2–2. Hardware Conformance with IEEE 754-1985 Floating Point		
Feature Implementation		Implementation
Operations ⁽¹⁾	Addition	Implemented
	Subtraction	Implemented
	Multiplication	Implemented
	Division	Optional
Precision	Single	Implemented
	Double	Not implemented. Double precision operations are implemented in software.

Table 2–2. Hardware Conformance with IEEE 754-1985 Floating Point			
Feature		Implementation	
Exception conditions	Invalid operation	Result is Not a Number (NaN)	
	Division by zero	Result is ±infinity	
	Overflow	Result is ±infinity	
	Inexact	Result is a normal number	
	Underflow	Result is ±0 ⁽²⁾	
Rounding Modes	Round to nearest	Implemented	
	Round toward zero	Not implemented	
	Round toward +infinity	Not implemented	
	Round toward -infinity	Not implemented	
NaN	Quiet	Implemented	
	Signaling	Not implemented	
Subnormal (denormalized) numbers		Subnormal operands are treated as zero. The floating point custom instructions do not generate subnormal numbers. (2)	
Software exceptions		Not implemented. IEEE 754-1985 exception conditions are detected and handled as shown elsewhere in this table.	
Status flags		Not implemented. IEEE 754-1985 exception conditions are detected and handled as shown elsewhere in this table.	

Notes to: Table 2-2

- (1) The Nios II IDE generates a software implementation of primitive floating point operations other than addition, subtraction, multiplication, and division. This includes operations such as floating point conversions and comparisons. The software implementations of these primitives are 100% compliant with IEEE 754-1985.
- (2) Some implementations of the floating point custom instructions might generate subnormals in the underflow condition.



The floating point custom instructions can be added to any Nios II processor core. The Nios II software development tools recognize C code that can take advantage of the floating point instructions when they are present in the processor core.

Reset Signals

The Nios II CPU core supports two reset signals.

- reset This a global hardware reset signal that forces the processor core to reset immediately.
- cpu_resetrequest This is an local reset signal that causes the CPU to reset without affecting other components in the Nios II system. The processor finishes executing any instructions in the pipeline, and then enters the reset state. This process can take several clock cycles. The processor core asserts the cpu_resettaken signal

for 1 cycle when the reset is complete and then periodically if cpu_resetrequest remains asserted. The CPU remains in reset for as long as cpu_resetrequest is asserted.

The CPU does not respond to <code>cpu_resetrequest</code> when the processor is under the control of the JTAG debug module. The processor responds to the <code>cpu_resetrequest</code> signal only if it is still asserted after the JTAG Debug Module relinquishes control.

Exception & Interrupt Controller

Exception Controller

The Nios II architecture provides a simple, non-vectored exception controller to handle all exception types. All exceptions, including hardware interrupts, cause the processor to transfer execution to a single *exception address*. The exception handler at this address determines the cause of the exception and dispatches an appropriate exception routine.

The exception address is specified at system generation time.

Integral Interrupt Controller

The Nios II architecture supports thirty two external hardware interrupts. The processor core has 32 level-sensitive interrupt request (IRQ) inputs, irq0 through irq31, providing a unique input for each interrupt source. IRQ priority is determined by software. The architecture supports nested interrupts.

The software can enable and disable any interrupt source individually through the <code>ienable</code> control register, which contains an interrupt-enable bit for each of the IRQ inputs. Software can enable and disable interrupts globally using the PIE it of the <code>status</code> control register. A hardware interrupt is generated if and only if all three of these conditions are true:

- The PIE bit of the status register is 1
- An interrupt-request input, irqn, is asserted
- The corresponding bit *n* of the ienable register is 1

Memory & I/O Organization

This section explains hardware implementation details of the Nios II memory and I/O organization. The discussion covers both general concepts true of all Nios II processor systems, as well as features that may change from system to system.

The flexible nature of the Nios II memory and I/O organization may be the most notable difference between Nios II processor systems and traditional microcontrollers. Because Nios II processor systems are

configurable, the memories and peripherals vary from system to system. As a result, the memory and I/O organization varies from system to system.

A Nios II core uses one or more of the following to provide memory and I/O access:

- Instruction master port An Avalon master port that connects to instruction memory via Avalon switch fabric
- Instruction cache Fast cache memory internal to the Nios II core
- Data master port An Avalon master port that connects to data memory and peripherals via Avalon switch fabric
- Data cache Fast cache memory internal to the Nios II core
- Tightly coupled instruction or data memory port Interface to fast memory outside the Nios II core

The Nios II architecture hides the hardware details from the programmer, so programmers can develop Nios II applications without awareness of the hardware implementation.



For details that affect programming issues, see the *Programming Model* chapter of the *Nios II Processor Reference Handbook*.

Figure 2–2 shows a diagram of the memory and I/O organization for a Nios II processor core.




Figure 2-2. Nios II Memory & I/O Organization

Instruction & Data Buses

The Nios II architecture supports separate instruction and data buses, classifying it as a Harvard architecture. Both the instruction and data buses are implemented as Avalon master ports that adhere to the AvalonTM interface specification. The data master port connects to both memory and peripheral components, while the instruction master port connects only to memory components.



Refer to the Avalon Interface Specification for details of the Avalon interface.

Memory & Peripheral Access

The Nios II architecture provides memory-mapped I/O access. Both data memory and peripherals are mapped into the address space of the data master port. The Nios II architecture is little endian. Words and halfwords are stored in memory with the more-significant bytes at higher addresses.

The Nios II architecture does not specify anything about the existence of memory and peripherals; the quantity, type, and connection of memory and peripherals are system-dependent. Typically, Nios II processor systems contain a mix of fast on-chip memory and slower off-chip memory. Peripherals typically reside on-chip, although interfaces to off-chip peripherals also exist.

Instruction Master Port

The Nios II instruction bus is implemented as a 32-bit Avalon master port. The instruction master port performs a single function: Fetch instructions that will be executed by the processor. The instruction master port does not perform any write operations.

The instruction master port is a pipelined Avalon master port. Support for pipelined Avalon transfers minimizes the impact of synchronous memory with pipeline latency and increases the overall f_{MAX} of the system. The instruction master port can issue successive read requests before data has returned from prior requests. The Nios II processor can prefetch sequential instructions and perform branch prediction to keep the instruction pipe as active as possible.

The instruction master port always retrieves 32 bits of data. The instruction master port relies on dynamic bus-sizing logic contained in the Avalon switch fabric. By virtue of dynamic bus sizing, every instruction fetch returns a full instruction word, regardless of the width of the target memory. Consequently, programs do not need to be aware of the widths of memory in the Nios II processor system.

The Nios II architecture supports on-chip cache memory for improving average instruction fetch performance when accessing slower memory. See "Cache Memory" on page 2–10 for details. The Nios II architecture supports tightly coupled memory, which provides guaranteed low-latency access to on-chip memory. See "Tightly Coupled Memory" on page 2–12 for details.

Data Master Port

The Nios II data bus is implemented as a 32-bit Avalon master port. The data master port performs two functions:

- Read data from memory or a peripheral when the processor executes a load instruction
- Write data to memory or a peripheral when the processor executes a store instruction

Byte-enable signals on the master port specify which of the four byte-lane(s) to write during store operations. The data master port does not support pipelined Avalon transfers, because it is not meaningful to predict data addresses or to continue execution before data is retrieved. Consequently, any memory pipeline latency is perceived by the data master port as wait states. Load and store operations can complete in a single clock-cycle when the data master port is connected to zero-wait-state memory.

The Nios II architecture supports on-chip cache memory for improving average data transfer performance when accessing slower memory. See "Cache Memory" for details. The Nios II architecture supports tightly coupled memory, which provides guaranteed low-latency access to on-chip memory. Refer to "Tightly Coupled Memory" on page 2–12 for details.

Shared Memory for Instructions & Data

Usually the instruction and data master ports share a single memory that contains both instructions and data. While the processor core has separate instruction and data buses, the overall Nios II processor system may present a single, shared instruction/data bus to the outside world. The outside view of the Nios II processor system depends on the memory and peripherals in the system and the structure of the Avalon switch fabric.

The data and instruction master ports never cause a gridlock condition in which one port starves the other. For highest performance, the data master port should be assigned higher arbitration priority on any memory that is shared by both instruction and data master ports.

Cache Memory

The Nios II architecture supports cache memories on both the instruction master port (instruction cache) and the data master port (data cache). Cache memory resides on-chip as an integral part of the Nios II processor core. The cache memories can improve the average memory access time for Nios II processor systems that use slow off-chip memory such as SDRAM for program and data storage.

The instruction and data caches are enabled perpetually at run-time, but methods are provided for software to bypass the data cache so that peripheral accesses do not return cached data. Cache management and cache coherency are handled by software. The Nios II instruction set provides instructions for cache management.

Configurable Cache Memory Options

The cache memories are optional. The need for higher memory performance (and by association, the need for cache memory) is application dependent. Many applications require the smallest possible processor core, and can trade-off performance for size.

A Nios II processor core may include one, both, or neither of the cache memories. Furthermore, for cores that provide data and/or instruction cache, the sizes of the cache memories are user-configurable. The inclusion of cache memory does not affect the functionality of programs, but it does affect the speed at which the processor fetches instructions and reads/writes data.

Effective Use of Cache Memory

The effectiveness of cache memory to improve performance is based on the following premises:

- Regular memory is located off-chip, and access time is long compared to on-chip memory
- The largest, performance-critical instruction loop is smaller than the instruction cache
- The largest block of performance-critical data is smaller than the data cache

Optimal cache configuration is application specific, although designers can make decisions that are effective across a range of applications. For example, if a Nios II processor system includes only fast, on-chip memory (i.e., it never accesses slow, off-chip memory), it is unlikely that instruction or data caches will offer any performance gain. As another example, if the critical loop of a program is 2 Kbytes, but the size of the instruction cache is 1 Kbyte, the instruction cache will not improve execution speed. In fact, performance will probably decrease.

If an application always requires certain data or sections of code to be located in cache memory for performance reasons, the tightly coupled memory feature might provide a more appropriate solution. Refer to "Tightly Coupled Memory" on page 2–12 for details.

Cache Bypass Method

The Nios II architecture provides load and store I/O instructions such as ldio and stio that bypass the data cache and force an Avalon data transfer to a specified address. Additional cache bypass methods may be provided, depending on the processor core implementation.

Some Nios II processor cores support a mechanism called *bit-31 cache bypass* to bypass the cache depending on the value of the most-significant bit of the address.



Refer to the *Implementing the Nios II Core Implementation Details* chapter of the *Nios II Processor Reference Handbook* for details.

Tightly Coupled Memory

Tightly coupled memory provides guaranteed low-latency memory access for performance-critical applications. Compared to cache memory, tightly coupled memory provides the following benefits:

- Performance similar to cache memory
- Software can guarantee that performance-critical code or data is located in tightly coupled memory
- No real-time caching overhead, such as loading, invalidating, or flushing memory

Physically, a tightly coupled memory port is a separate master port on the Nios II processor core, similar to the instruction or data master port. A Nios II core can have zero, one, or multiple tightly coupled memories. The Nios II architecture supports tightly coupled memories for both instruction and data access. Each tightly coupled memory port connects directly to exactly one memory with guaranteed low, fixed latency. The memory is external to the Nios II core and is usually located on chip.

Accessing Tightly Coupled Memory

Tightly coupled memories occupy normal address space, the same as other memory devices connected via Avalon switch fabric. The address ranges for tightly coupled memories (if any) are determined at system generation time.

Software accesses tightly coupled memory using regular load and store instructions. From the software's perspective, there is no difference accessing tightly coupled memory compared to other memory.

Effective Use of Tightly Coupled Memory

A system can use tightly coupled memory to achieve maximum performance for accessing a specific section of code or data. For example, interrupt-intensive applications can partition exception handler code into a tightly coupled memory to minimize interrupt latency. Similarly, compute-intensive digital signal processing (DSP) applications can partition data buffers into tightly coupled memory for the fastest possible data access.

If the application's memory requirements are small enough to fit entirely on chip, it is possible to use tightly coupled memory exclusively for code and data. Larger applications must selectively choose what to include in tightly coupled memory to maximize the cost-performance trade-off.

Address Map

The address map for memories and peripherals in a Nios II processor system is design dependent. The designer specifies the address map at system generation time.

There are three addresses that are part of the CPU and deserve special mention:

- reset address
- exception address
- break handler address

Programmers access memories and peripherals by using macros and drivers. Therefore, the flexible address map does not affect application developers.

JTAG Debug Module

The Nios II architecture supports a JTAG debug module that provides onchip emulation features to control the processor remotely from a host PC. PC-based software debugging tools communicate with the JTAG debug module and provide facilities, such as:

- Downloading programs to memory
- Starting and stopping execution
- Setting breakpoints and watchpoints
- Analyzing registers and memory
- Collecting real-time execution trace data

The debug module connects to the JTAG circuitry in an Altera® FPGA. External debugging probes can then access the processor via the standard JTAG interface on the FPGA. On the processor side, the debug module connects to signals inside the processor core. The debug module has non-maskable control over the processor, and does not require a software stub linked into the application under test. All system resources visible to the processor in supervisor mode are available to the debug module. For trace data collection, the debug module stores trace data in memory either on-chip or in the debug probe.

The debug module gains control of the processor either by asserting a hardware break signal, or by writing a break instruction into program memory to be executed. In both cases, the processor transfers control to a routine located at the break address. The *break address* is specified at system generation time.

Soft-core processors such as the Nios II processor offer unique debug capabilities beyond the features of traditional, fixed processors. The soft-core nature of the Nios II processor allows designers to debug a system in development using a full-featured debug core, and later remove the debug features to conserve logic resources. For the release version of a product, the JTAG debug module functionality can be reduced, or removed altogether.

The sections below describe the capabilities of the Nios II JTAG debug module hardware. The usage of all hardware features is dependent on host software, such as the Nios II IDE, which manages the connection to the target processor and controls the debug process.

JTAG Target Connection

The JTAG target connection refers to the ability to connect to the CPU through the standard JTAG pins on the Altera FPGA. This provides the basic capabilities to start and stop the processor, and examine/edit registers and memory. The JTAG target connection is also the minimum requirement for the Nios II IDE flash programmer.

Download & Execute Software

Downloading software refers to the ability to download executable code and data to the processor's memory via the JTAG connection. After downloading software to memory, the JTAG debug module can then exit debug mode and transfer execution to the start of executable code.

Software Breakpoints

Software breakpoints provide the ability to set a breakpoint on instructions residing in RAM. The software breakpoint mechanism writes a break instruction into executable code stored in RAM. When the processor executes the break instruction, control is transferred to the JTAG debug module.

Hardware Breakpoints

Hardware breakpoints provide the ability to set a breakpoint on instructions residing in nonvolatile memory, such as flash memory. The hardware breakpoint mechanism continuously monitors the processor's

current instruction address. If the instruction address matches the hardware breakpoint address, the JTAG debug module takes control of the processor.

Hardware breakpoints are implemented using the JTAG debug module's hardware trigger feature.

Hardware Triggers

Hardware triggers activate a debug action based on conditions on the instruction or data bus during real-time program execution. Triggers can do more than halt processor execution. For example, a trigger can be used to enable trace data collection during real-time processor execution.

Table 2–3 lists all the conditions that can cause a trigger. Hardware trigger conditions are based on either the instruction or data bus. Trigger conditions on the same bus can be logically ANDed, enabling the JTAG debug module to trigger, for example, only on write cycles to a specific address.

Table 2–3. Trigger Conditions		
Condition	Bus (1)	Description
Specific address	D, I	Trigger when the bus accesses a specific address.
Specific data value	D	Trigger when a specific data value appears on the bus.
Read cycle	D	Trigger on a read bus cycle.
Write cycle	D	Trigger on a write bus cycle.
Armed	D, I	Trigger only after an armed trigger event. See "Armed Triggers" on page 2–15.
Range D Trigger on a range of address values, data values, or both. See "Triggering of Ranges of Values" on page 2–16.		
Notes: (1) "I" indicates instruction bus, "D" indicates data bus.		

When a trigger condition occurs during processor execution, the JTAG debug module triggers an action, such as halting execution, or starting trace capture. Table 2–4 lists the trigger actions supported by the Nios II JTAG debug module.

Armed Triggers

The JTAG debug module provides a two-level trigger capability, called armed triggers. Armed triggers enable the JTAG debug module to trigger on event B, only after event A. In this example, event A causes a trigger action that enables the trigger for event B.

Action	Description
Break	Halt execution and transfer control to the JTAG debug module.
External trigger	Assert a trigger signal output. This trigger output can be used, for example, to trigger an external logic analyzer.
Trace on	Turn on trace collection.
Trace off	Turn off trace collection.
Trace sample (1)	Store one sample of the bus to trace buffer.
Arm	Enable an armed trigger.

Triggering on Ranges of Values

The JTAG debug module can trigger on ranges of data or address values on the data bus. This mechanism uses two hardware triggers together to create a trigger condition that activates on a range of values within a specified range.

Trace Capture

Trace capture refers to ability to record the instruction-by-instruction execution of the processor as it executes code in real-time. The JTAG debug module offers the following trace features:

- Capture execution trace (instruction bus cycles).
- Capture data trace (data bus cycles).
- For each data bus cycle, capture address, data, or both.
- Start and stop capturing trace in real time, based on triggers.
- Manually start and stop trace under host control.
- Optionally stop capturing trace when trace buffer is full, leaving the processor executing.
- Store trace data in on-chip memory buffer in the JTAG debug module. (This memory is accessible only through the JTAG connection.)
- Store trace data to larger buffers in an off-chip debug probe.

Certain trace features require additional licensing or debug tools from third-party debug providers. For example, an on-chip trace buffer is a standard feature of the Nios II processor, but using an off-chip trace buffer requires additional debug software and hardware provided by First Silicon Solutions (FS2). For details, see www.fs2.com.

Execution vs. Data Trace

The JTAG debug module supports tracing the instruction bus (execution trace), the data bus (data trace), or both simultaneously. Execution trace records only the addresses of the instructions executed, enabling designers to analyze where in memory (i.e., in which functions) code executed. Data trace records the data associated with each load and store operation on the data bus.

The JTAG debug module can filter the data bus trace in real time to capture the following:

- Load addresses only
- Store addresses only
- Both load and store addresses
- Load data only
- Load address and data
- Store address and data
- Address and data for both loads and stores
- Single sample of the data bus upon trigger event

Trace Frames

A "frame" is a unit of memory allocated for collecting trace data. However, a frame is not an absolute measure of the trace depth.

To keep pace with the processor executing in real time, execution trace is optimized to store only selected addresses, such as branches, calls, traps, and interrupts. From these addresses, host-side debug software can later reconstruct an exact instruction-by-instruction execution trace. Furthermore, execution trace data is stored in a compressed format, such that one frame represents more than one instruction. As a result of these optimizations, the actual start and stop points for trace collection during execution may vary slightly from the user-specified start and stop points.

Data trace stores 100% of requested loads and stores to the trace buffer in real time. When storing to the trace buffer, data trace frames have lower priority than execution trace frames. Therefore, while data frames are always stored in chronological order, execution and data trace are not guaranteed to be exactly synchronized with each other.



3. Programming Model

NII51003-6.0.0

Introduction

This chapter describes the Nios[®] II programming model, covering processor features at the assembly language level. The programmer's view of the following features are discussed in detail:

- General-purpose registers, page 3–1
- Control registers, page 3–2
- Supervisor mode vs. user mode privileges, page 3–4
- Hardware-assisted debug processing, page 3–14
- Exception processing, page 3–8
- Hardware interrupts, page 3–9
- Unimplemented instructions, page 3–11
- Memory and peripheral organization, page 3–15
- Cache memory, page 3–16
- Processor reset state, page 3–16
- Instruction set categories, page 3–17
- Custom instructions, page 3–23

High-level software development tools are not discussed here. See the *Nios II Software Developer's Handbook* for information about developing software.

General-Purpose Registers

The Nios II architecture provides thirty-two 32-bit general-purpose registers, r0 through r31. See Table 3–1 on page 2. Some registers have names recognized by the assembler. The zero register (r0) always returns the value 0, and writing to zero has no effect. The ra register (r31) holds the return address used by procedure calls and is implicitly accessed by call and ret instructions. C and C++ compilers use a common procedure-call convention, assigning specific meaning to registers r1 through r23 and r26 through r28.



For more information, refer to the *Application Binary Interface* chapter of the *Nios II Processor Reference Handbook*.

Access to certain registers, such as et (r24), bt (r25), ea (r29), and ba (r30) is limited to certain execution modes. For further information, see "Operating Modes" on page 3–4.

Table 3–1. The Nios II Register File					
	General Purpose Registers				
Register	Name	Function	Register	Name	Function
r0	zero	0x00000000	r16		
r1	at	Assembler Temporary	r17		
r2		Return Value	r18		
r3		Return Value	r19		
r4		Register Arguments	r20		
r5		Register Arguments	r21		
r6		Register Arguments	r22		
r7		Register Arguments	r23		
r8		Caller-Saved Register	r24	et	Exception Temporary (1)
r9		Caller-Saved Register	r25	bt	Breakpoint Temporary (2)
r10		Caller-Saved Register	r26	gp	Global Pointer
r11		Caller-Saved Register	r27	sp	Stack Pointer
r12		Caller-Saved Register	r28	fp	Frame Pointer
r13		Caller-Saved Register	r29	ea	Exception Return Address (1)
r14		Caller-Saved Register	r30	ba	Breakpoint Return Address (2)
r15		Caller-Saved Register	r31	ra	Return Address

Notes to Table 3-1:

- (1) This register is not available in user mode.
- (2) This register is not available in user mode or supervisor mode. It is used exclusively by the JTAG debug module.

Control Registers

There are six 32-bit control registers, ctl0 through ctl5. All control registers have names recognized by the assembler.

Control registers are accessed differently than the general-purpose registers. The special instructions rdctl and wrctl provide the only means to read and write to the control registers. Control registers can be accessed only in supervisor mode; they are not accessible in user mode. See "Operating Modes" on page 3–4 for further details.

Details of the control registers are shown in Table 3–2. For details on the relationship between the control registers and exception processing, see Figure 3–2 on page 3–10.

Table 3–2. Control Register & Bits				
Register	Name	312	1	0
ct10	status	Reserved	U	PIE
ctl1	estatus	Reserved	EU	EPIE
ct12	bstatus	Reserved	BU	BPIE
ct13	ienable	Interrupt-enable bits		
ctl4	ipending	Pending-interrupt bits		
ct15	cpuid	Unique processor identifier		

status (ctl0)

The value in the status register controls the state of the Nios II processor. All status bits are cleared after processor reset. See "Processor Reset State" on page 3–16. Two bits are defined: PIE and U, as shown in Table 3–3.

Table 3–3. status Register Bits		
Bit	Description	
PIE bit	PIE is the processor interrupt-enable bit. When PIE is 0, external interrupts are ignored. When PIE is 1, external interrupts can be taken, depending on the value of the <code>ienable</code> register.	
U bit	U is the user-mode bit. 1 indicates user mode; 0 indicates supervisor mode.	

estatus (ctl1)

The estatus register holds a saved copy of the status register during exception processing. Two bits are defined: EPIE and EU. These are the saved values of PIE and U, as defined in Table 3–3.

The exception handler can examine estatus to determine the preexception status of the processor. When returning from an interrupt, the eret instruction causes the processor to copy estatus back to status, restoring the pre-exception value of status.



See "Exception Processing" on page 3–8 for more information.

bstatus (ctl2)

The bstatus register holds a saved copy of the status register during debug break processing. Two bits are defined: BPIE and BU. These are the saved values of PIE and U, as defined in Table 3–3 on page 3–3.

When a break occurs, the value of the status register is copied into bstatus. Using bstatus, the status register can be restored to the value it had prior to the break.



See "Debug Mode" on page 3-6 for more information.

ienable (ctl3)

The ienable register controls the handling of external hardware interrupts. Each bit of the ienable register corresponds to one of the interrupt inputs, irq0 through irq31. A bit value of 1 means that the corresponding interrupt is enabled; a bit value of 0 means that the corresponding interrupt is disabled.



See "Exception Processing" on page 3–8 for more information.

ipending (ctl4)

The value of the ipending register indicates which interrupts are pending. A value of 1 in bit n means that the corresponding irqn input is asserted, and that the corresponding interrupt is enabled in the ienable register. The effect of writing a value to the ipending register is undefined.

cpuid (ctl5)

The cpuid register holds a static value that uniquely identifies the processor in a multi-processor system. The cpuid value is determined at system generation time. Writing to the cpuid register has no effect.



See "Exception Processing" on page 3–8 for more information.

Operating Modes

The Nios II processor has three operating modes:

- Supervisor mode
- User mode
- Debug mode

The following sections define the modes and the transitions between modes. This discussion makes a distinction between system code and application code:

- System code consists of routines that perform system-level functions, such as an operating system (OS) or low-level hardware driver.System code is generally provided as part of a run-time library or OS kernel. System code typically executes in supervisor mode.
- Application code consists of routines that run on top of the services provided by system code. Application code is generally written by programmers writing target applications.

Supervisor Mode

In supervisor mode all defined processor functions are available and unrestricted. In general, system code executes in supervisor mode. However, simple programs that do not use an operating system may remain in supervisor mode indefinitely, and application code can run normally under supervisor mode.

General-purpose registers bt (r25) and ba (r30) are not available in supervisor mode. Programs are not prevented from storing values in these registers, but if they do, the values could be changed by the debug mode. The bstatus register (ct12) is also unavailable in supervisor mode.

When the processor is in supervisor mode, the U bit is 0. The processor is in supervisor mode immediately after processor reset.

User Mode

User mode provides a restricted subset of supervisor-mode functionality. User mode provides enhanced reliability for operating systems supervising multiple tasks. System code may choose to switch to user mode before passing control to application code.

In user mode, some processor features are not accessible, and attempting to access them will generate an exception. The control registers are not available in user mode. In addition, general-purpose registers et (r24), bt (r25), ea (r29), and ba (r30) are not available. Programs executing in user mode are not prevented from storing values in these registers, but if they do, the values may be changed by exception routines in supervisor mode or by the debug mode.

When the processor is in user mode, issuing any of the following instructions will cause an exception:

- rdctl
- wrctl
- bret
- eret
- initd
- initi

When the processor is in user mode, the U bit is 1.

Processor Implementation & User Mode Support

Some Nios II processor implementations do not support user mode. On these cores, all code executes in supervisor mode, and the U bit is always 0. Therefore, application code should never be written such that it depends on a particular value of the U bit in order to execute correctly.

Application code executes normally in both user mode or supervisor mode. On Nios II processor cores that do not support user mode, system code cannot rely on user mode or access violation exceptions for protection of restricted resources.



Refer to the *Nios II Core Implementation Details* chapter of the *Nios II Processor Reference Handbook* for complete details of which processor cores support user mode.

Debug Mode

Debug mode is used by software debugging tools to implement features such as breakpoints and watch-points. System code and application code never execute in debug mode. The processor enters debug mode only after the break instruction or after the JTAG debug module forces a break via hardware.

In debug mode all processor functions are available and unrestricted to the software debugging tool. In debug mode, the U bit is 0. Refer to "Break Processing" on page 3–14 for further information.

Changing Modes

Figure 3–1 diagrams the transitions between user, supervisor and debug modes.




Figure 3-1. Transitions Between Operating Modes

The processor starts in supervisor mode after reset.

A program may switch from supervisor mode into user mode using an eret (exception return) instruction. eret copies the value of the estatus register (ctll) to the status register (ctll), and then transfers control to the address in the ea register (r29). To enter user mode for the first time after processor reset, system code must set up the estatus and ea registers appropriately and then execute an eret instruction.

The processor remains in user mode until an exception occurs, at which point the processor reenters supervisor mode. All exceptions clear the U bit to 0 and save the contents of status to estatus. Assuming the exception routines do not modify the estatus register, using eret to return from the exception will restore the pre-exception mode.

The processor enters debug mode only as directed by software debugging tools. System code and application code have no control over when the processor enters debug mode. The processor always returns to its prior state when exiting from debug mode.



For further details, refer to "Exception Processing" on page 3–8 and "Break Processing" on page 3–14.

Exception Processing

An exception is a transfer of control away from a program's normal flow of execution, caused by an event, either internal or external to the processor, which requires immediate attention. Exception processing is the act of responding to an exception, and then returning to the preexception execution state.

An exception causes the processor to take the following steps automatically. The processor:

- 1. Copies the contents of the status register (ctl0) to estatus (ctl1) saving the processor's pre-exception status
- 2. Clears the U bit of the status register, forcing the processor into supervisor mode
- Clears the PIE bit of the status register, disabling external processor interrupts
- Writes the address of the instruction after the exception to the ea register (r29)
- 5. Transfers execution to the address of the *exception handler* that determines the cause of the interrupt

The address of the exception handler is specified at system generation time. At run-time this address is fixed, and it cannot be changed by software. Programmers do not directly access the exception handler address, and can write programs without awareness of the address.

The exception handler is a routine that determines the cause of each exception, and then dispatches an appropriate *exception routine* to respond to the interrupt.



For a detailed discussion of writing programs to take advantage of exception and interrupt handling, see the *Exception Handling* chapter in the *Nios II Software Developer's Handbook*.

Exception Types

Nios II exceptions fall into the following categories:

- Hardware interrupt
- Software trap
- Unimplemented instruction
- Other

Each exception type is described in detail in the following sections.

Hardware Interrupt

An external source such as a peripheral device can request a hardware interrupt by asserting one of the processor's 32 interrupt-request inputs, <code>irq0</code> through <code>irq31</code>. A hardware interrupt is generated if and only if all three of these conditions are true:

- The PIE bit of the status register (ctl0) is 1
- An interrupt-request input, irqn, is asserted
- The corresponding bit n of the ienable register (ctl3) is 1.

Upon hardware interrupt the PIE bit is set to 0, disabling further interrupts. The value of the ipending register (ctl4) shows which interrupt requests (IRQ) are pending. By peripheral design, an IRQ bit is guaranteed to remain asserted until the processor explicitly responds to the peripheral. Figure 3–2 shows the relationship between ipending, ienable, PIE, and the generation of an interrupt.




Figure 3–2. Relationship Between ienable, ipending, PIE & Hardware Interrupts

A software exception routine determines which of the pending interrupts has the highest priority, and then transfers control to the appropriate *interrupt service routine (ISR)*. The ISR must stop the interrupt from being visible (either by clearing it at the source or masking it using ienable) before returning and/or before re-enabling PIE. The ISR must also save estatus (ctll) and ea (r29) before re-enabling PIE.

Interrupts can be re-enabled by writing 1 to the PIE bit, thereby allowing the current ISR to be interrupted. Typically, the exception routine adjusts <code>ienable</code> so that IRQs of equal or lower priority are disabled before re-enabling interrupts.



See "Nested Exceptions" on page 3-13.

Software Trap

When a program issues the trap instruction, it generates a software trap exception. A program typically issues a software trap when the program requires servicing by the operating system. The exception handler for the operating system determines the reason for the trap and responds appropriately.

Unimplemented Instruction

When the processor issues a valid instruction that is not implemented in hardware, an unimplemented instruction exception is generated. The exception handler determines which instruction generated the exception. If the instruction is not implemented in hardware, control is passed to an exception routine that emulates the operation in software.



See "Potential Unimplemented Instructions" on page 3–24 for further details.



Note that "unimplemented instruction" does not mean "invalid instruction." Processor behavior for undefined, i.e., invalid, instruction words is dependent on the Nios II core. For most Nios II core implementations, executing an invalid instruction produces an undefined result. See the *Nios II Core Implementation Details* chapter of the *Nios II Processor Reference Handbook* for details.

Other Exceptions

The previous sections describe all of the exception types defined by the Nios II architecture at the time of publishing. However, some processor implementations may generate exceptions that do not fall into the above categories. For example, a future implementation may provide a memory management unit (MMU) that generates access violation exceptions. Therefore, a robust exception handler should provide a safe response (such as issuing a warning) in the event that it cannot exactly identify the cause of an exception.

Determining the Cause of Exceptions

The exception handler must determine the cause of each exception and then transfer control to an appropriate exception routine. Figure 3–3 shows an example of the process used to determine the exception source.




Figure 3-3. Process to Determine the Cause of an Exception

If the EPIE bit of the <code>estatus</code> register (ctll) is 1 and the value of the <code>ipending</code> register (ctll) is non-zero, the exception was caused by an external hardware interrupt. Otherwise, the exception may be caused by a software trap or an unimplemented instruction. To distinguish between software traps and unimplemented instructions, read the instruction at address <code>ea-4</code> (the Nios II data master must have access to the code memory to read this address). If the instruction is <code>trap</code>, the exception is a software trap. If the instruction at address <code>ea-4</code> is one of the instructions that may be implemented in software, the exception was caused by an unimplemented instruction. See "Potential Unimplemented Instructions" on page 3–24 for details. If none of the above conditions apply, the exception type is unrecognized, and the exception handler should report the condition.

Nested Exceptions

Exception routines must take special precautions before:

- Issuing a trap instruction
- Issuing an unimplemented instruction
- Re-enabling hardware interrupts

Before allowing any of these actions, the exception routine must save estatus (ctll) and ea (r29), so that they can be restored properly before returning.

Returning from an Exception

The eret instruction is used to resume execution from the pre-exception address. Except for the et register (r24), any registers modified during exception processing must be restored by the exception routine before returning from exception processing.

When executing the eret instruction, the processor:

- 1. Copies the contents of estatus (ctl1) to status (ctl0)
- 2. Transfers program execution to the address in the ea register (r29)

Return Address

The return address requires some consideration when returning from exception processing routines. After an exception occurs, ea contains the address of the instruction *after* the point where the exception was generated.

When returning from software trap and unimplemented instruction exceptions, execution must resume from the instruction following the software trap or unimplemented instruction. Therefore, ea contains the correct return address.

On the other hand, hardware interrupt exceptions must resume execution from the interrupted instruction itself. In this case, the exception handler must subtract 4 from ea to point to the interrupted instruction.

Break Processing

A break is a transfer of control away from a program's normal flow of execution caused by a break instruction or the JTAG debug module. Software debugging tools can take control of the Nios II processor via the JTAG debug module. Only debugging tools control the processor when executing in debug mode; application and system code never execute in this mode.

Break processing is the means by which software debugging tools implement debug and diagnostic features, such as breakpoints and watchpoints. Break processing is similar to exception processing, but the break mechanism is independent from exception processing. A break can occur during exception processing, enabling debug tools to debug exception handlers.

Processing a Break

The processor enters the break processing state under the following conditions:

- The processor issues the break instruction
- The JTAG debug module asserts a hardware break

A break causes the processor to take the following steps automatically. The processor:

- Stores the contents of the status register (ctl0) to bstatus (ctl2)
- Clears the U bit of the status register, forcing the processor into supervisor mode
- 3. Clears the PIE bit of the status register, disabling external processor interrupts
- 4. Writes the address of the instruction following the break to the ba register (r30).
- 5. Transfers execution to the address of the *break handler*. The address of the break handler is specified at system generation time.

Returning from a Break

After performing break processing, the debugging tool releases control of the processor by executing a bret instruction. The bret instruction restores status and returns program execution to the address in ba.

Register Usage

The break handler may use bt (r25) to help save additional registers. Aside from bt, all other registers are guaranteed to be returned to their pre-break state after returning from the break-processing routine.

Memory & Peripheral Access

Nios II addresses are 32 bits, allowing access up to a 4 gigabyte address space. However, many Nios II core implementations restrict addresses to 31 bits or fewer.



For details, refer to the *Nios II Core Implementation Details* chapter of the *Nios II Processor Reference Handbook*.

Peripherals, data memory, and program memory are mapped into the same address space. The locations of memory and peripherals within the address space are determined at system generation time. Reading or writing to an address that does not map to a memory or peripheral produces an undefined result.

The processor's data bus is 32-bits wide. Instructions are available to read and write byte, half-word (16-bit), or word (32-bit) data.

The Nios II architecture is little endian. For data wider than 8-bits stored in memory, the more-significant bits are located in higher addresses.

Addressing Modes

The Nios II architecture supports the following addressing modes:

- Register addressing
- Displacement addressing
- Immediate addressing
- Register indirect addressing
- Absolute addressing

In register addressing, all operands are registers, and results are stored back to a register. In displacement addressing, the address is calculated as the sum of a register and a signed, 16-bit immediate value. In immediate addressing, the operand is a constant within the instruction itself. Register indirect addressing uses displacement addressing, but the displacement is the constant 0. Limited-range absolute addressing is achieved by using displacement addressing with register r0, whose value is always 0x00.

Cache Memory

The Nios II architecture and instruction set accommodate the presence of data cache and instruction cache memories. Cache management is implemented in software by using cache management instructions. Instructions are provided to initialize the cache, flush the caches whenever necessary, and to bypass the data cache to properly access memory-mapped peripherals.

Some Nios II processor cores support a mechanism called bit-31 cache bypass to bypass the cache depending on the value of the most-significant bit of the address. The address space of these processor implementations is 2 GBytes, and the high bit of the address controls the caching of data memory accesses.



Refer to the *Nios II Core Implementation Details* chapter of the *Nios II Processor Reference Handbook* for complete details of which processor cores support bit-31 cache bypass.

Code written for a processor core with cache memory will behave correctly on a processor core without cache memory. The reverse is not true. Therefore, for a program to work properly on all Nios II processor core implementations, the program must behave as if the instruction and data caches exist. In systems without cache memory, the cache management instructions perform no operation, and their effects are benign. For a complete discussion of cache management, see the *Nios II Software Developer's Handbook*.

Some consideration is necessary to ensure cache coherency after processor reset. See "Processor Reset State" on page 3–16 for details.



For details on the cache architecture and the memory hierarchy see the *Processor Architecture* chapter of the *Nios II Processor Reference Handbook*.

Processor Reset State

After reset, the Nios II processor:

- 1. Clears the status register to 0x0.
- 2. Invalidates the instruction-cache line associated with the *reset address*, the address of the reset routine.
- 3. Begins executing from the reset address.

Clearing status (ct10) has the effect of putting the processor in supervisor mode and disabling hardware interrupts. Invalidating the reset cache line guarantees that instruction fetches for reset code will come from uncached memory. The reset address is specified at system generation time.

Aside from the instruction-cache line associated with the reset address, the contents of the cache memories are indeterminate after reset. To ensure cache coherency after reset, the reset routine must immediately initialize the instruction cache. Next, either the reset routine or a subsequent routine should proceed to initialize the data cache.

The reset state is undefined for all other system components, including but not limited to:

- General-purpose registers, except for zero (r0) which is permanently zero.
- Control registers, except for status (ctl0) which is reset to 0x0.
- Instruction and data memory.
- Cache memory, except for the instruction-cache line associated with the reset address.
- Peripherals. Refer to the appropriate peripheral data sheet or specification for reset conditions.
- Custom instruction logic. Refer to the custom instruction specification for reset conditions.

Instruction Set Categories

This section introduces the Nios II instructions categorized by type of operation performed.

Data Transfer Instructions

The Nios II architecture is a load-store architecture. Load and store instructions handle all data movement between registers, memory, and peripherals. Memories and peripherals share a common address space. Some Nios II processor cores use memory caching and/or write buffering to improve memory bandwidth. The architecture provides instructions for both cached and uncached accesses.

Table 3–4 describes the ldw, stw, ldwio, and stwio instructions.

Table 3–4. Data Transfer Instructions (Idw, stw, Idwio & stwio)		
Instruction	Description	
ldw	The ldw and stw instructions load and store 32-bit data words from/to memory. The effective	
stw	address is the sum of a register's contents and a signed immediate value contained in the instruction. Memory transfers may be cached or buffered to improve program performance. This caching and buffering may cause memory cycles to occur out of order, and caching may suppress some cycles entirely.	
	Data transfers for I/O peripherals should use ldwio and stwio.	
ldwio	ldwio and stwio instructions load and store 32-bit data words from/to peripherals without	
stwio	caching and buffering. Access cycles for $ldwio$ and $stwio$ instructions are guaranteed to occur in instruction order and never will be suppressed.	

The data-transfer instructions in Table 3–5 support byte and half-word transfers.

Table 3–5. Data Transfer Instructions		
Instruction	Description	
ldb	ldb, ldbu, ldh and ldhu load a byte or half-word from memory to a register. ldb and ldh	
ldbu	sign-extend the value to 32 bits, and ldbu and ldhu zero-extend the value to 32 bits.	
stb	stb and sth store byte and half-word values, respectively.	
ldh	Memory accesses may be cached or buffered to improve performance. To transfer data to I/O	
ldhu	peripherals, use the "io" versions of the instructions, described below.	
sth		
ldbio	These operations load/store byte and half-word data from/to peripherals without caching or	
ldbuio	buffering.	
stbio		
ldhio		
ldhuio		
sthio		

Arithmetic & Logical Instructions

Logical instructions support and, or, xor, and nor operations. Arithmetic instructions support addition, subtraction, multiplication, and division operations. See Table 3-6.

Table 3–6. Arithmetic & Logical Instructions		
Instruction	Description	
and or xor nor	These are the standard 32-bit logical operations. These operations take two register values and combine them bit-wise to form a result for a third register.	
andi ori xori	These operations are immediate versions of the and, or, and xor instructions. The 16-bit immediate value is zero-extended to 32 bits, and then combined with a register value to form the result.	
andhi orhi xorhi	In these versions of and, or, and xor, the 16-bit immediate value is shifted logically left by 16 bits to form a 32-bit operand. Zeroes are shifted in from the right.	
add sub mul div divu	These are the standard 32-bit arithmetic operations. These operations take two registers as input and store the result in a third register.	
addi subi muli	These instructions are immediate versions of the add, sub, and mul instructions. The instruction word includes a 16-bit signed value.	
mulxss mulxuu	These instructions provide access to the upper 32 bits of a 32x32 multiplication operation. Choose the appropriate instruction depending on whether the operands should be treated as signed or unsigned values. It is not necessary to precede these instructions with a mul.	
mulxsu	This instruction is used in computing a 128-bit result of a 64x64 signed multiplication.	

Move Instructions

These instructions provide move operations to copy the value of a register or an immediate value to another register. See Table 3–7.

Table 3–7. Move Instructions		
Instruction	Description	
mov movhi movi movui movia	mov copies the value of one register to another register. movi moves a 16-bit signed immediate value to a register, and sign-extends the value to 32 bits. movui and movhi move an immediate 16-bit value into the lower or upper 16-bits of a register, inserting zeros in the remaining bit positions. Use movia to load a register with an address.	

Comparison Instructions

The Nios II architecture supports a number of comparison instructions. All of these compare two registers or a register and an immediate value, and write either 1 (if true) or 0 to the result register. These instructions perform all the equality and relational operators of the C programming language. See Table 3–8.

Table 3–8. Comparison Instructions (Part 1 of 2)		
Instruction	Description	
cmpeq	==	
cmpne	!=	
cmpge	signed >=	
cmpgeu	unsigned >=	
cmpgt	signed >	
cmpgtu	unsigned >	
cmple	unsigned <=	
cmpleu	unsigned <=	
cmplt	signed <	

Table 3–8. Comparison Instructions (Part 2 of 2)		
Instruction	Description	
cmpltu	unsigned <	
cmpeqi cmpnei cmpgei cmpgeui cmpgtui cmpgtui cmplei cmpleui	These instructions are immediate versions of the comparison operations. They compare the value of a register and a 16-bit immediate value. Signed operations sign-extend the immediate value to 32-bits. Unsigned operations fill the upper bits with zero.	
cmplti cmpltui		

Shift & Rotate Instructions

Shift and rotate operations are provided by the following instructions. The number of bits to rotate or shift can be specified in a register or an immediate value. See Table 3–9.

Table 3–9. Shift & Rotate Instructions		
Instruction	Description	
rol ror roli	The rol and roli instructions provide left bit-rotation. roli uses an immediate value to specify the number of bits to rotate. The ror instructions provides right bit-rotation. There is no immediate version of ror, because roli can be used to implement the equivalent operation.	
sll slli sra srl srai srli	These shift instructions implement the $<<$ and $>>$ operators of the C programming language. The $\verb sl _1, \verb sll _1, \verb srl _1$ instructions provide left and right logical bit-shifting operations, inserting zeros. The $\verb sra $ and $\verb sra $ instructions provide arithmetic right bit-shifting, duplicating the sign bit in the most significant bit. $\verb sll $ in $\verb sra $ and $\verb sra $ use an immediate value to specify the number of bits to shift.	

Program Control Instructions

The Nios II architecture supports the unconditional jump and call instructions listed in Table 3–10. These instructions do not have delay slots.

Table 3-10	Table 3–10. Unconditional Jump & Call Instructions		
Instruction	Description		
call	This instruction calls a subroutine using an immediate value as the subroutine's absolute address, and stores the return address in register ${\tt ra}$.		
callr	This instruction calls a subroutine at the absolute address contained in a register, and stores the return address in register \mathtt{ra} . This instruction serves the roll of dereferencing a C function pointer.		
ret	The ret instruction is used to return from subroutines called by call or callr. ret loads and executes the instruction specified by the address in register ra.		
jmp	The jmp instruction jumps to an absolute address contained in a register. jmp is used to implement switch statements of the C programming language.		
br	Branch relative to the current instruction. A signed immediate value gives the offset of the next instruction to execute.		

The conditional-branch instructions compare register values directly, and branch if the expression is true. See Table 3–11. The conditional branches support the equality and relational comparisons of the C programming language:

- == and !=
- < and <= (signed and unsigned)</p>
- > and >= (signed and unsigned)

The conditional-branch instructions do not have delay slots.

Table 3–11. Conditional-Branch Instructions		
Instruction	Description	
bge	These instructions provide relative branches that compare	
bgeu	two register values and branch if the expression is true.	
bgt	See "Comparison Instructions" on page 3-20 for a	
bgtu	description of the relational operations implemented.	
ble		
bleu		
blt		
bltu		
beq		
bne		

Other Control Instructions

Table 3–12 shows other control instructions.

Table 3–12. Other Control Instructions						
Instruction	Description					
trap eret	The trap and eret instructions generate and return from exceptions. These instructions are similar to the $\mathtt{call/ret}$ pair, but are used for exceptions. trap saves the status register in the $\mathtt{estatus}$ register, saves the return address in the \mathtt{ea} register, and then transfers execution to the exception handler. \mathtt{eret} returns from exception processing by restoring status from $\mathtt{estatus}$, and executing the instruction specified by the address in \mathtt{ea} .					
break bret	The break and bret instructions generate and return from breaks. break and bret are used exclusively by software debugging tools. Programmers never use these instructions in application code.					
rdctl wrctl	These instructions read and write control registers, such as the status register. The value is read from or stored to a general-purpose register.					
flushd flushi initd initi	These instructions are used to manage the data and instruction cache memories.					
flushp	This instruction flushes all pre-fetched instructions from the pipeline. This is necessary before jumping to recently-modified instruction memory.					
sync	This instruction ensures that all previously-issued operations have completed before allowing execution of subsequent load and store operations.					

Custom Instructions

The custom instruction provides low-level access to custom instruction logic. The inclusion of custom instructions is specified at system generation time, and the function implemented by custom instruction logic is design dependent.



For further details, see the "Custom Instructions" section of the *Processor Architecture* chapter of the *Nios II Processor Reference Handbook* and the *Nios II Custom Instruction User Guide*.

Machine-generated C functions and assembly macros provide access to custom instructions, and hide implementation details from the user. Therefore, most software developers never use the custom assembly instruction directly.

No-Operation Instruction

The Nios II assembler provides a no-operation instruction, nop.

Potential Unimplemented Instructions

Some Nios II processor cores do not support all instructions in hardware. In this case, the processor generates an exception after issuing an unimplemented instruction. Only the following instructions may generate an unimplemented-instruction exception:

- mul
- muli
- mulxss
- mulxsu
- mulxuu
- div
- divu

All other instructions are guaranteed not to generate an unimplemented-instruction exception.

An exception routine must exercise caution if it uses these instructions, because they could generate another exception before the previous exception was properly handled. See "Unimplemented Instruction" on page 3–11 for details regarding unimplemented instruction processing.



4. Implementing the Nios II Processor in SOPC Builder

NII51004-6.0.0

Introduction

This chapter describes the Nios® II configuration wizard in SOPC Builder. The Nios II configuration wizard allows you to specify the processor features for a particular Nios II hardware system. This chapter covers only the features of the Nios II processor that can be configured via the Nios II configuration wizard. It is not a user guide for creating complete Nios II processor systems.



To get started using SOPC Builder to design custom Nios II systems, refer to the *Nios II Hardware Development Tutorial*. Nios II development kits also provide a number of ready-made example hardware designs that demonstrate several different configurations of the Nios II processor.

The Nios II processor configuration wizard has several tabs. The following sections describe the settings available on each tab.




Due to evolution and improvement of the Nios II configuration wizard, the figures in this chapter might not match the exact screens that appear in SOPC Builder.

Nios II Core Tab

The **Nios II Core** tab presents the main settings for configuring the Nios II processor core. An example of the **Nios II Core** tab is shown in Figure 4–1.

Figure 4–1. Nios II Core Tab in the Nios II Configuration Wizard



Core Setting

The main purpose of the **Nios II Core** tab is to select the processor core. The core you select on this tab affects other options available on this and other tabs.

Currently, Altera® offers three Nios II cores:

- Nios II/f—The Nios II/f "fast" core is designed for fast performance. As a result, this core presents the most configuration options allowing you to fine-tune the processor for performance.
- Nios II/s—The Nios II/s "standard" core is designed for small size while maintaining performance.
- Nios II/e—The Nios II/e "economy" core is designed to achieve the smallest possible core size. As a result, this core has a limited feature set, and many settings are not available when the Nios II/e core is selected.

As shown in Figure 4–1, the **Nios II Core** tab displays a "selector guide" table that lists the basic properties of each core.



For complete details of each core, see the *Nios II Core Implementation Details* chapter of the *Nios II Processor Reference Handbook*.

Multiply & Divide Settings

The Nios II/s and Nios II/f cores offer different hardware multiply and divide options. You can choose the best option to balance embedded multiplier usage, logic element (LE) usage, and performance.

The **Hardware Multiply** setting provides the following options:

- Include embedded multipliers (e.g., the DSP blocks in Stratix[®] devices) in the arithmetic logic unit (ALU). This is the default when targeting devices that have embedded multipliers.
- Include LE-based multipliers in the ALU. This option achieves high multiply performance without consuming embedded multiplier resources.
- Omit hardware multiply. This option conserves logic resources by eliminating multiply hardware. Multiply operations are implemented in software.

Turning on the **Hardware Divide** setting includes LE-based divide hardware in the ALU. The **Hardware Divide** option achieves much greater performance than software emulation of divide operations.




For details on the effects of the **Hardware Multiply** and **Hardware Divide** options on performance, see the *Nios II Core Implementation Details* chapter of the *Nios II Processor Reference Handbook*.

Caches & Tightly Coupled Memories Tab

The Caches & Tightly Coupled Memories tab allows you to configure the cache and tightly coupled memory usage for the instruction and data buses. An example of the Caches & Tightly Coupled Memories tab is shown in Figure 4–2.

Figure 4–2. Caches & Tightly Coupled Memories Tab in the Nios II Configuration Wizard



Instruction Settings

The **Instruction** settings provide the following options for the Nios II/f and Nios II/s cores:

- Instruction Cache Specifies the size of the instruction cache. Valid sizes are from 512 bytes to 64 Kbytes, or None.
 - Choosing **None** disables the instruction cache, which also removes the Avalon instruction master port from the Nios II core. In this case, you must include a tightly coupled instruction memory.
- Include tightly coupled instruction master port(s) When turned on, the Nios II core includes tightly coupled memory ports. You can specify one to four ports with the Number of ports setting. Tightly coupled memory ports appear on the connection panel of the Nios II core in the SOPC Builder System Contents tab. You must connect each port to exactly one memory component in the system.

Data Settings

The **Data** settings provide the following options for the Nios II/f core:


- Data Cache Specifies the size of the data cache. Valid sizes are from 512 bytes to 64 Kbytes, or None. Depending on the value specified for Data Cache, the following options are available:
 - Data Cache Line Size Valid sizes are 4, 16, or 32 bytes.
 - Omit data master port If you set Data Cache to None, you can
 optionally turn on Omit data master port to remove the Avalon
 data master port from the Nios II core. In this case, you must
 include a tightly coupled data memory.
- Include tightly coupled data master port(s) When turned on, the Nios II core includes tightly coupled memory ports. You can specify one to four ports with the Number of ports setting. Tightly coupled memory ports appear on the connection panel of the Nios II core in the SOPC Builder System Contents tab. You must connect each port to exactly one memory component in the system.

Advanced Features Tab

The **Advanced Features** tab allows you to enable specialized features of the Nios II processor. It contains one option: **Include cpu_resetrequest and cpu_resettaken signals**. This option adds CPU-only reset request signals to the Nios II processor. These signals let another device individually reset the Nios II processor without resetting the entire SOPC Builder system. The signals are exported to the top level of your SOPC Builder system.

Figure 4–3 on page 4–6 shows the **Advanced Features** tab.

Figure 4-3. Advanced Features Tab in the Nios II Configuration Wizard





For further details on the CPU-only reset request signals, refer to the *Processor Architecture* chapter in the *Nios II Processor Reference Handbook*.

JTAG Debug Module Tab

The **JTAG Debug Module** tab presents settings for configuring the JTAG debug module on the Nios II core. You can select the debug features appropriate for your target application.

Soft-core processors such as the Nios II processor offer unique debug capabilities beyond the features of traditional-fixed processors. The soft-core nature of the Nios II processor allows you to debug a system in development using a full-featured debug core, and later remove the debug features to conserve logic resources. For the release version of a product, you might choose to reduce the JTAG debug module functionality, or remove it altogether.

Table 4--1 describes the debug features available to you for debugging your system.

Table 4–1. Debug Configuration Features							
Feature	Description						
JTAG Target Connection	The ability to connect to the CPU through the standard JTAG pins on the Altera FPGA. This provides the basic capabilities to start and stop the processor, and examine/edit registers and memory.						
Download Software	The ability to download executable code to the processor's memory via the JTAG connection.						
Software Breakpoints	The ability to set a breakpoint on instructions residing in RAM						
Hardware Breakpoints	The ability to set a breakpoint on instructions residing in nonvolatile memory, such as flash memory.						
Data Triggers	The ability to trigger based on address value, data value, or read or write cycle. You can use a trigger to halt the processor on specific events or conditions, or to activate other events, such as starting execution trace, or sending a trigger signal to an external logic analyzer. Two data triggers can be combined to form a trigger that activates on a range of data or addresses.						
Instruction Trace	The ability to capture the sequence of instructions executing on the processor in real time.						
Data Trace	The ability to capture the addresses and data associated with read and write operations executed by the processor in real time.						
On-Chip Trace	The ability to store trace data in on-chip memory.						
Off-Chip Trace	The ability to store trace data in an external debug probe. Off-chip trace requires a debug probe from First Silicon Solutions (FS2).						

Debug Level Settings

There are five debug levels in the **JTAG Debug Module** tab as shown in Figure 4–4.

Figure 4–4. JTAG Debug Module Tab in the Nios II Configuration Wizard




Table 4–2 on page 4–9 is a detailed list of the characteristics of each debug level. Different levels consume different amounts of on-chip resources. Certain Nios II cores have restricted debug options, and certain options require debug tools provided by First Silicon Solutions (FS2).



For details on the Nios II debug features available from FS2, visit www.fs2.com.

Table 4–2. JTAG Debug Module Levels								
Debug Feature	No Debug	Level 1	Level 2	Level 3	Level 4 (1)			
Logic Usage	0	300 - 400 LEs	800 - 900 LEs	2,400 - 2,700 LEs	3,100 - 3,700 LEs			
On-Chip Memory Usage	0	Two M4Ks	Two M4Ks	Four M4Ks	Four M4Ks			
External I/O Pins Required (2)	0	0	0	0	20			
JTAG Target Connection	No	Yes	Yes	Yes	Yes			
Download Software	No	Yes	Yes	Yes	Yes			
Software Breakpoints	None	Unlimited	Unlimited	Unlimited	Unlimited			
Hardware Execution Breakpoints	0	None	2	2	4			
Data Triggers	0	None	2	2	4			
On-Chip Trace	0	None	None	Up to 64K Frames	Up to 64K Frames			
Off-Chip Trace (4)	0	None	None	None	128K Frames			

Notes to Table 4–2:

- (1) Level 4 requires the purchase of a software upgrade from FS2.
- (2) Not including the dedicated JTAG pins on the Altera FPGA.
- (3) An additional license from FS2 is required to use more than 16 frames.
- (4) Off-chip trace requires the purchase of additional hardware from FS2.

On-Chip Trace Buffer Settings


Debug levels 3 and 4 support trace data collection into an on-chip memory buffer. The on-chip trace buffer size can be set to sizes from 128 to 64K trace frames.

Larger buffer sizes consume more on-chip M4K RAM blocks. Every M4K RAM block can store up to 128 trace frames.

Custom Instructions Tab

The **Custom Instructions** tab allows you to connect custom instruction logic to the Nios II arithmetic logic unit (ALU). You can achieve significant performance improvements—often on the order of 10x to 100x—by implementing performance-critical operations in hardware using custom-instruction logic. Figure 4–5 shows an example of the **Custom Instructions** tab.

Figure 4–5. Custom Instructions Tab in the Nios II Configuration Wizard



To add a custom instruction to the Nios II processor, select the custom instruction from the **Library** list at the left side of the dialog box, and click **Add**.



A complete discussion of the hardware and software design process for custom instructions is beyond the scope of this chapter. For full details on the topic of custom instructions, including working example designs, see the *Nios II Custom Instruction User Guide*.


Floating-Point Custom Instructions

The Nios II core offers a set of optional predefined custom instructions that implement floating-point arithmetic operations. You can choose to include these custom instructions to support computation-intensive floating-point applications.

The basic set of floating-point custom instructions includes single precision (32-bit) floating-point addition, subtraction, and multiplication. Floating-point division is available as an extension to the basic instruction set. The best choice for your hardware design depends on a balance among floating-point usage, hardware resource usage, and performance.

To add the floating-point custom instructions to the Nios II processor, select **Floating Point Hardware** from the **Library** list, and click **Add**.





The Nios II Floating Point Hardware dialog box, shown in Figure 4–6, provides one option: Use floating point division hardware. If you leave this check box off, SOPC Builder omits floating-point division from the Nios II processor, while including addition, subtraction, and multiplication. The floating-point division hardware requires more resources than the other instructions, so you might wish to omit it if your application does not make heavy use of floating-point division.

Click **Finish** to add the floating point custom instructions to the Nios II processor.

If the target device includes on-chip multiplier blocks, the floating-point custom instructions incorporates them as needed. If there are no on-chip multiplier blocks, the floating-point custom instructions are entirely based on general-purpose logic elements.



The opcode extensions for the floating-point custom instructions are 252 through 255 (0xFC through 0xFF). These opcode extensions cannot be modified.



For details on floating-point instruction usage in the Nios II Embedded Design Suite (EDS), see the tutorial *Using Nios II Floating-Point Custom Instructions*.



Section II. Appendixes

This section provides additional information about the Nios® II processor.

This section includes the following chapters:

- Chapter 5, Nios II Core Implementation Details
- Chapter 6, Nios II Processor Revision History
- Chapter 7, Application Binary Interface
- Chapter 8, Instruction Set Reference

Revision History

The table below shows the revision history for Chapters 17 - 20.

Chapter(s)	Date / Version	Changes Made
5	May 2006, v6.0.0	Performance for flushi and initi instructions changes from 1 to 4 cycles for Nios II/s and Nios II/f cores.
	October 2005, v5.1.0	No change from previous release.
	May 2005, v5.0.0	Updates to Nios II/f and Nios II/s cores. Added tightly coupled memory and new data cache options. Corrected cycle counts for shift/rotate operations.
	December 2004, v1.2	Updates to Multiple & Divide Performance section for Nios II/f & Nios II/s cores.
	September 2004, v1.1	Updates for Nios II 1.01 release.
	May 2004, v1.0	First publication.
6	May 2006, v6.0.0	Updates for Nios II cores version 6.0.
	October 2005, v5.1.0	Updates for Nios II cores version 5.1.
	May 2005, v5.0.0	Updates for Nios II cores version 5.0.
	December 2004, v1.1	Updates for Nios II cores version 1.1.
	September 2004 ,v1.0	First publication.

Altera Corporation Section II–1

Chapter(s)	Date / Version	Changes Made
7	May 2006, v6.0.0	No change from previous release.
	October 2005, v5.1.0	No change from previous release.
	May 2005, v5.0.0	No change from previous release.
	May 2004, v1.0	First publication.
8	May 2006, v6.0.0	No change from previous release.
	October 2005, v5.1.0	Correction to the blt instruction. Added U bit operation for break and trap instructions.
	July 2005, v5.0.1	 new flushda instruction. flushd instruction updated. Instruction Opcode table updated with flushda instruction.
	May 2005, v5.0.0	No change from previous release.
	December 2004, v1.2	break instruction update.srli instruction correction.
	September 2004, v1.1	Updates for Nios II 1.01 release.
	May 2004, v1.0	First publication.

Section II–2 Altera Corporation



5. Nios II Core Implementation Details

NII51015-6.0.0

Introduction

This document describes all of the Nios[®] II processor core implementations available at the time of publishing. This document describes only implementation-specific features of each processor core. All cores support the Nios II instruction set architecture.



For more information regarding the Nios II instruction set architecture, refer to the *Instruction Set Reference* chapter of the *Nios II Processor Reference Handbook*.

For details on a specific core, see the appropriate section for that core:

- "Nios II/f Core" on page 5–3
- "Nios II/s Core" on page 5–11
- "Nios II/e Core" on page 5–18

Table 5–1 compares the objectives and features of each Nios II processor core. The table is designed to help system designers choose the core that best suits their target application.

Table 5–1. N	Table 5–1. Nios II Processor Cores (Part 1 of 2)							
	Feature	Core						
		Nios II/e	Nios II/s	Nios II/f				
Objective		Minimal core size	Small core size	Fast execution speed				
Performance	DMIPS/MHz (1)	0.15	0.74	1.16				
	Max. DMIPS (2)	31	127	218				
	Max. f _{MAX} (2)	200 MHz	165 MHz	185 MHz				
Area		< 700 LEs; < 350 ALMs	< 1400 LEs; < 700 ALMs	< 1800 LEs; < 900 ALMs				
Pipeline		1 Stage	5 Stages	6 Stages				
External Addr	ess Space	2 Gbytes	2 GBytes	2 GBytes				
Instruction Bus	Cache	-	512 bytes to 64 kbytes	512 bytes to 64 kbytes				
	Pipelined Memory Access	-	Yes	Yes				
	Branch Prediction	_	Static	Dynamic				
	Tightly Coupled Memory	_	Optional	Optional				

Feature Core					
	reature		Core		
	Nios II/e Nios II/s		Nios II/s	Nios II/f	
Data Bus	Cache	-	-	512 bytes to 64 Kbytes	
	Pipelined Memory Access	_	-	_	
	Cache Bypass Methods	-	-	I/O instructions; bit-31 cache bypass	
	Tightly Coupled Memory	-	-	Optional	
Arithmetic	Hardware Multiply	-	3-Cycle (3)	1-Cycle (3)	
Logic Unit	Hardware Divide	_	Optional	Optional	
	Shifter	1 Cycle-per-bit 3-Cycle Shift (3)		1-Cycle Barrel Shifter (3)	
JTAG Debug Module	JTAG interface, run control, software breakpoints	Optional	Optional	Optional	
	Hardware Breakpoints	_	Optional	Optional	
	Off-Chip Trace Buffer	-	Optional	Optional	
Exception Types Handling		Software trap, unimplemented instruction, hardware interrupt	Software trap, unimplemented instruction, hardware interrupt	Software trap, unimplemented instruction, hardware interrupt	
	Integrated Interrupt Controller	Yes	Yes	Yes	
User Mode S	upport	No; Permanently in supervisor mode	No; Permanently in supervisor mode	No; Permanently in supervisor mode	
Custom Instruction Support		Yes	Yes	Yes	

Notes to Table 5-1:

- (1) DMIPS performance for the Nios II/s and Nios II/f cores depends on the hardware multiply option.
- (2) Using the fastest hardware multiply option, and targeting a Stratix II FPGA in the fastest speed grade.
- (3) Multiply and shift performance depends on which hardware multiply option is used. If no hardware multiply option is used, multiply operations are emulated in software, and shift operations require one cycle per bit. For details, see the arithmetic logic unit description for each core.

Device Support

All Nios II cores support the following Altera FPGA families:

- Stratix[®]
- Stratix II
- Cyclone[™]
- Cyclone II

Nios II/f Core

The Nios II/f "fast" core is designed for high execution performance. Performance is gained at the expense of core size, making the Nios II/f core approximately 25% larger than the Nios II/s core. Altera designed the Nios II/f core with the following design goals in mind:

- Maximize the instructions-per-cycle execution efficiency
- Maximize f_{MAX} performance of the processor core

The resulting core is optimal for performance-critical applications, as well as for applications with large amounts of code and/or data, such as systems running a full-featured operating system.

Overview

The Nios II/f core:

- Has separate instruction and data caches
- Can access up to 2 GBytes of external address space
- Supports optional tightly coupled memory for instructions and data
- Employs a 6-stage pipeline to achieve maximum DMIPS/MHz
- Performs dynamic branch prediction
- Provides hardware multiply, divide, and shift options to improve arithmetic performance
- Supports the addition of custom instructions
- Supports the JTAG debug module
- Supports optional JTAG debug module enhancements, including hardware breakpoints and real-time trace

The following sections discuss the noteworthy details of the Nios II/f core implementation. This document does not discuss low-level design issues or implementation details that do not affect Nios II hardware or software designers.

Register File

At system generation time, the cpuid control register (clt5) is assigned a value that is guaranteed to be unique for each processor in the system.

Arithmetic Logic Unit

The Nios II/f core provides several arithmetic logic unit (ALU) options to improve the performance of multiply, divide, and shift operations.

Multiply & Divide Performance

The Nios II/f core provides the following hardware multiplier options:

- No hardware multiply Does not include multiply hardware. In this case, multiply operations are emulated in software.
- Use embedded multipliers Includes dedicated embedded multipliers available on the target device. This option is available only on Altera FPGAs that have embedded multipliers, such as the DSP blocks in Stratix II FPGAs.
- Use LE-based multipliers Includes hardware multipliers built from logic element (LE) resources.

The Nios II/f core also provides a hardware divide option that includes LE-based divide circuitry in the ALU.

Including an ALU option improves the performance of one or more arithmetic instructions. Note that the performance of the embedded multipliers differ, depending on the target FPGA family.

Table 5–2 lists the details of the hardware multiply and divide options.

Table 5–2. Hardware Multiply & Divide Details for the Nios II/f Core								
ALU Option	Hardware Details	Cycles per Instruction	Result Latency Cycles	Supported Instructions				
No hardware multiply or divide	Multiply & divide instructions generate an exception	-	-	None				
LE-based multiplier	ALU includes 32 x 4-bit multiplier	11	+2	mul, muli				
Embedded multiplier on Stratix and Stratix II families	ALU includes 32 x 32-bit multiplier	1	+2	mul, muli, mulxss, mulxsu, mulxuu				
Embedded multiplier on Cyclone II family	ALU includes 32 x 16-bit multiplier	5	+2	mul, muli				
Hardware divide	ALU includes multicycle divide circuit	4 – 66	+2	div, divu				

The cycles per instruction value determines the maximum rate at which the ALU can dispatch instructions and produce each result. The latency value determines when the result becomes available. If there is no data dependency between the results and operands for back-to-back instructions, then the latency does not affect throughput. However, if an instruction depends on the result of an earlier instruction, then the processor stalls through any result latency cycles until the result is ready.

In the code example below, a multiply operation (with 1 instruction cycle and 2 result latency cycles) is followed immediately by an add operation that uses the result of the multiply. On the Nios II/f core, the addiinstruction, like most ALU instructions, executes in a single cycle. However, in this code example, execution of the addi instruction is delayed by two additional cycles until the multiply operation completes.

In contrast, the code below does not stall the processor.

```
mul r1, r2, r3 ; r1 = r2 * r3 or r5, r5, r6 ; No dependency on previous results or r7, r7, r8 ; No dependency on previous results addi r1, r1, 100 ; r1 = r1 + 100 (Depends on result of mul)
```

Shift & Rotate Performance

The performance of shift operations depends on the hardware multiply option. When a hardware multiplier is present, the ALU achieves shift and rotate operations in one or two clock cycles. Otherwise, the ALU includes dedicated shift circuitry that achieves one-bit-per-cycle shift and rotate performance. Refer to Table 5–4 on page 5–10 for details.

Memory Access

The Nios II/f core provides both instruction and data caches. The cache size for each is user-definable, between 512 bytes and 64 Kbytes. The Nios II/f core supports the bit-31 cache bypass method for accessing I/O on the data master port. Addresses are 31 bits wide to accommodate the bit-31 cache bypass method.

Instruction and Data Master Ports

The instruction and data master ports on the Nios II/f core are optional. A master port can be excluded, as long as the core includes at least one tightly coupled memory to take the place of the missing master port.

The instruction master port is a pipelined Avalon master port. If the core includes data cache with a line size greater than four bytes, then the data master port is a pipelined Avalon master port. Otherwise, the data master port is not pipelined.


Support for pipelined Avalon transfers minimizes the impact of synchronous memory with pipeline latency. The pipelined instruction and data master ports can issue successive read requests before prior requests complete.

Instruction Cache

The instruction cache memory has the following characteristics:

- Direct-mapped cache implementation
- 32 bytes (8 words) per cache line
- The instruction master port reads an entire cache line at a time from memory, and issues one read per clock cycle.
- Critical word first

The instruction byte address is divided into the following fields:



The sizes of the line and tag fields depend on the size of the cache memory, but the offset field is always three bits (i.e., an 8-word line). The maximum instruction byte address size is 31 bits.


The instruction cache is optional. However, excluding instruction cache from the Nios II/f core requires that the core include at least one tightly coupled instruction memory.

Data Cache

The data cache memory has the following characteristics:

- Direct-mapped cache implementation
- Configurable line size of 4, 16, or 32 bytes
- The data master port reads an entire cache line at a time from memory, and issues one read per clock cycle.
- Write-back
- Write-allocate (i.e., store instructions that miss allocate the line for that address)

The data byte address is divided into the following fields:



The size of the line and tag fields depend on the size of the cache memory, The size of the offset field depends on the line size. The maximum data byte address size is 31 bits.

The data cache is optional. If the data cache is excluded from the core, the data master port can also be excluded.

Cache Bypass

The normal method for bypassing the data cache is to use I/O load and store instructions that bypass the cache. In addition, the Nios II/f core also implements the bit-31 cache bypass method on the data master port. This method uses bit 31 of the address as a tag that indicates whether the processor should transfer data to/from cache, or bypass it. This is a convenience for software, which may wish to cache certain addresses and bypass others. Software can pass addresses as parameters between functions, without having to specify any further information about whether the addressed data is cached or not.

Mixing Cached and Noncached Accesses

Mixing cached and noncached accesses to the same cache line can result in invalid data reads. For example, the following sequence of events causes cache incoherency.

- 1. The Nios II core writes data to cache, creating a dirty data cache line.
- The Nios II core reads data from the same address, but bypasses the cache.

Software should not mix both cached and uncached accesses to the same cache line. If it is necessary to mix cached and uncached data accesses, flush the corresponding line of the data cache after completing the cached accesses and before performing the uncached accesses.

Tightly Coupled Memory

The Nios II/f core provides optional tightly-coupled memory interfaces for both instructions and data. A Nios II/f core can use up to four each of instruction and data tightly coupled memories. When a tightly-coupled memory interface is enabled, the Nios II core includes an additional memory interface master. Each tightly-coupled memory interface must connect directly to exactly one memory slave.

When tightly coupled memory is present, the Nios II core decodes addresses internally to determine if requested instructions or data reside in tightly coupled memory. If the address resides in tightly coupled memory, the Nios II core fetches the instruction or data through the tightly-coupled memory interface. Software accesses tightly coupled memory with the usual load and store instructions, such as ldw or ldwio.

Accessing tightly coupled memory bypasses cache memory. The processor core functions as if cache were not present for the address span of the tightly coupled memory. Instructions for managing cache, such as initd and flushd, do not affect the tightly coupled memory, even if the instruction specifies an address in tightly coupled memory.

Execution Pipeline

This section provides an overview of the pipeline behavior for the benefit of performance-critical applications. Designers can use this information to minimize unnecessary processor stalling. Most application programmers never need to analyze the performance of individual instructions, and live happy lives without ever studying the tables below.

The Nios II/f core employs a 6-stage pipeline. The pipeline stages are listed in Table 5–3.

Table 5–3. Implementation Pipeline Stages for Nios II/f Core				
Stage Letter Stage Name				
F	Fetch			
D	Decode			
E	Execute			
М	Memory			
Α	Align			
W	Writeback			

Up to one instruction is dispatched and/or retired per cycle. Instructions are dispatched and retired in-order. Dynamic branch prediction is implemented using a 2-bit branch history table. The pipeline stalls for the following conditions:

- Multi-cycle instructions
- Avalon[™] instruction master-port read accesses
- Avalon data master-port read/write accesses
- Data dependencies on long latency instructions (e.g., load, multiply, shift).

Pipeline Stalls

The pipeline is set up so that if a stage stalls, no new values enter that stage or any earlier stages. No "catching up" of pipeline stages is allowed, even if a pipeline stage is empty.

Only the A-stage and D-stage are allowed to create stalls.

The A-stage stall occurs if any of the following conditions occurs:

- An A-stage memory instruction is waiting for Avalon data master requests to complete. Typically this happens when a load or store misses in the data cache, or a flushd instruction needs to write back a dirty line.
- An A-stage shift/rotate instruction is still performing its operation. This only occurs with the multi-cycle shift circuitry (i.e., when the hardware multiplier is not available).
- An A-stage divide instruction is still performing its operation. This
 only occurs when the optional divide circuitry is available.
- An A-stage multi-cycle custom instruction is asserting its stall signal.
 This only occurs if the design includes multi-cycle custom instructions.

The D-stage stall occurs if the following condition occurs and no M-stage pipeline flush is active:

An instruction is trying to use the result of a late result instruction too early. The late result instructions are loads, shifts, rotates, rdctl, multiplies (if hardware multiply is supported), divides (if hardware divide is supported), and multi-cycle custom instructions (if present).

Branch Prediction

The Nios II/f core performs dynamic branch prediction to minimize the cycle penalty associated with taken branches.

Instruction Performance

All instructions take one or more cycles to execute. Some instructions have other penalties associated with their execution. Late result instructions have a two cycle bubble placed between them and an instruction that uses their result. Instructions that flush the pipeline cause up to three instructions after them to be cancelled. This creates a three-cycle penalty and an execution time of four cycles. Instructions that require Avalon transfers are stalled until any required Avalon transfers (up to one write and one read) are completed.

Execution performance for all instructions is shown in Table 5–4.

Table 5–4. Instruction Execution Performance for Nios II/f Core					
Instruction	Cycles	Penalties			
Normal ALU instructions (e.g., add, cmplt)	1				
Combinatorial custom instructions	1				
Multi-cycle custom instructions	1	Late result			
Branch (correctly predicted, taken)	2				
Branch (correctly predicted, not taken)	1				
Branch (mis-predicted)	4	Pipeline flush			
trap, break, eret, bret, flushp, wrctl, and unimplemented instructions	4	Pipeline flush			
call	2				
jmp, ret, callr	3				
rdctl	1	Late result			
load (without Avalon transfer)	1	Late result			
load (with Avalon transfer)	> 1	Late result			
store, flushd (without Avalon transfer)	1				
store, flushd (with Avalon transfer)	> 1				
initd	1				
flushi, initi	4				
Multiply	(1)	Late result			
Divide	(1)	Late result			
Shift/rotate (with hardware multiply using embedded multipliers)	1	Late result			
Shift/rotate (with hardware multiply using LE-based multipliers)	2	Late result			
Shift/rotate (without hardware multiply present)	1 - 32	Late result			
All other instructions	1				

Note to Table 5-4:

(1) Depends on the hardware multiply or divide option. See Table 5–2 on page 4 for details.

Exception Handling

The Nios II/f core supports the following exception types:

- Hardware interrupt
- Software trap
- Unimplemented instruction

JTAG Debug Module

The Nios II/f core supports the JTAG debug module to provide a JTAG interface to software debugging tools. The Nios II/f core supports an optional enhanced interface that allows real-time trace data to be routed out of the processor and stored in an external debug probe.

Unsupported Features

The Nios II/f core does not support user mode, as defined in the *Programming Model* chapter of the *Nios II Processor Reference Handbook*. This does not affect application code. However, it may affect system code that relies on user mode to protect restricted resources.

The Nios II/f core does not handle the execution of instructions with undefined opcodes. If the processor issues an instruction word with an undefined opcode, the resulting behavior is undefined.

Nios II/s Core

The Nios II/s "standard" core is designed for small core size. On-chip logic and memory resources are conserved at the expense of execution performance. The Nios II/s core uses approximately 20% less logic than the Nios II/f core, but execution performance also drops by roughly 40%. Altera designed the Nios II/s core with the following design goals in mind:

- Do not cripple performance for the sake of size.
- Remove hardware features that have the highest ratio of resource usage to performance impact.

The resulting core is optimal for cost-sensitive, medium-performance applications. This includes applications with large amounts of code and/or data, such as systems running an operating system where performance is not the highest priority.

Overview

The Nios II/s core:

- Has instruction cache, but no data cache
- Can access up to 2 Gbytes of external address space
- Supports optional tightly coupled memory for instructions
- Employs a 5-stage pipeline
- Performs static branch prediction
- Provides hardware multiply, divide, and shift options to improve arithmetic performance
- Supports the addition of custom instructions

- Supports the JTAG debug module
- Supports optional JTAG debug module enhancements, including hardware breakpoints and real-time trace

The following sections discuss the noteworthy details of the Nios II/s core implementation. This document does not discuss low-level design issues, or implementation details that do not affect Nios II hardware or software designers.

Register File

At system generation time, the cpuid control register (clt5) is assigned a value that is guaranteed to be unique for each processor in the system.

Arithmetic Logic Unit

The Nios II/s core provides several ALU options to improve the performance of multiply, divide, and shift operations.

Multiply & Divide Performance

The Nios II/s core provides the following hardware multiplier options:

- No hardware multiply Does not include multiply hardware. In this case, multiply operations are emulated in software.
- Use embedded multipliers Includes dedicated embedded multipliers available on the target device. This option is available only on Altera FPGAs that have embedded multipliers, such as the DSP blocks in Stratix II FPGAs.
- Use LE-based multipliers Includes hardware multipliers built from logic element (LE) resources.

The Nios II/s core also provides a hardware divide option that includes LE-based divide circuitry in the ALU.

Including an ALU option improves the performance of one or more arithmetic instructions. Note that the performance of the embedded multipliers differ, depending on the target FPGA family.

Table 5–5 lists the details of the hardware multiply and divide options.

Table 5–5. Hardware Multiply & Divide Details for the Nios II/s Core						
ALU Option	Hardware Details	Cycles per instruction	Supported Instructions			
No hardware multiply or divide	Multiply & divide instructions generate an exception	-	None			
LE-based multiplier	ALU includes 32 x 4-bit multiplier	11	mul, muli			
Embedded multiplier on Stratix and Stratix II families	ALU includes 32 x 32-bit multiplier	3	mul, muli, mulxss, mulxsu, mulxuu			
Embedded multiplier on Cyclone II family	ALU includes 32 x 16-bit multiplier	5	mul, muli			
Hardware divide	ALU includes multicycle divide circuit	4 – 66	div, divu			

Shift & Rotate Performance

The performance of shift operations depends on the hardware multiply option. When a hardware multiplier is present, the ALU achieves shift and rotate operations in three or four clock cycles. Otherwise, the ALU includes dedicated shift circuitry that achieves one-bit-per-cycle shift and rotate performance. Refer to Table 5–7 on page 5–16 for details.

Memory Access

The Nios II/s core provides instruction cache, but no data cache. The instruction cache size is user-definable, between 512 bytes and 64 Kbytes. The Nios II/s core can address up to 2 Gbyte of external memory. The Nios II/s core does not support bit-31 data cache bypass. The most-significant bit of addresses is ignored.

Instruction and Data Master Ports

The instruction port on the Nios II/s core is optional. The instruction master port can be excluded, as long as the core includes at least one tightly-coupled instruction memory. The instruction master port is a pipelined Avalon master port.

Support for pipelined Avalon transfers minimizes the impact of synchronous memory with pipeline latency. The pipelined instruction master port can issue successive read requests before prior requests complete.

The data master port on the Nios II/s core is always present.

Instruction Cache

The instruction cache for the Nios II/s core is nearly identical to the instruction cache in the Nios II/f core. The instruction cache memory has the following characteristics:

- Direct-mapped cache implementation
- The instruction master port reads an entire cache line at a time from memory, and issues one read per clock cycle.
- Critical word first

The instruction byte address is divided into the following fields:

	•		5	4	3	2	1	0
tag	line				offse	t	0	0

The size of the line and tag fields depend on the size of the cache memory, but the offset field is always three bits (i.e., an 8-word line). The maximum instruction byte address size is 31 bits.

The instruction cache is optional. However, excluding instruction cache from the Nios II/s core requires that the core include at least one tightly coupled instruction memory.

Tightly Coupled Memory

The Nios II/s core provides optional tightly-coupled memory interfaces for instructions. A Nios II/s core can use up to four tightly coupled instruction memories. When a tightly-coupled memory interface is enabled, the Nios II core includes an additional memory interface master. Each tightly-coupled memory interface must connect directly to exactly one memory slave.

When tightly coupled memory is present, the Nios II core decodes addresses internally to determine if requested instructions reside in tightly coupled memory. If the address resides in tightly coupled memory, the Nios II core fetches the instruction through the tightly-coupled memory interface. Software does not require awareness of whether code resides in tightly coupled memory or not.

Accessing tightly coupled memory bypasses cache memory. The processor core functions as if cache were not present for the address span of the tightly coupled memory. Instructions for managing cache, such as initi and flushi, do not affect the tightly coupled memory, even if the instruction specifies an address in tightly coupled memory.

Execution Pipeline

This section provides an overview of the pipeline behavior for the benefit of performance-critical applications. Designers can use this information to minimize unnecessary processor stalling. Most application programmers never need to analyze the performance of individual instructions, and live happy lives without ever studying Table 5–6.

The Nios II/s core employs a 5-stage pipeline. The pipeline stages are listed in Table 5–6.

Table 5–6. Implementation Pipeline Stages for Nios II/s Core					
Stage Letter	Stage Name				
F	Fetch				
D	Decode				
E	Execute				
М	Memory				
W	Writeback				

Up to one instruction is dispatched and/or retired per cycle. Instructions are dispatched and retired in-order. Static branch prediction is implemented using the branch offset direction; a negative offset is predicted as taken, and a positive offset is predicted as not-taken. The pipeline stalls for the following conditions:

- Multi-cycle instructions (e.g., shift/rotate without hardware multiply)
- Avalon instruction master-port read accesses
- Avalon data master-port read/write accesses
- Data dependencies on long latency instructions (e.g., load, multiply, shift operations)

Pipeline Stalls

The pipeline is set up so that if a stage stalls, no new values enter that stage or any earlier stages. No "catching up" of pipeline stages is allowed, even if a pipeline stage is empty.

Only the M-stage is allowed to create stalls.

The M-stage stall occurs if any of the following conditions occurs:

- An M-stage load/store instruction is waiting for Avalon data master transfer to complete.
- An M-stage shift/rotate instruction is still performing its operation when using the multi-cycle shift circuitry (i.e., when the hardware multiplier is not available).
- An M-stage shift/rotate/multiply instruction is still performing its operation when using the hardware multiplier (which takes three cycles).
- An M-stage multi-cycle custom instruction is asserting its stall signal.
 This only occurs if the design includes multi-cycle custom instructions.

Branch Prediction

The Nios II/s core performs static branch prediction to minimize the cycle penalty associated with taken branches.

Instruction Performance

All instructions take one or more cycles to execute. Some instructions have other penalties associated with their execution. Instructions that flush the pipeline cause up to three instructions after them to be cancelled. This creates a three-cycle penalty and an execution time of four cycles. Instructions that require an Avalon transfer are stalled until the transfer completes.

Execution performance for all instructions is shown in Table 5–7.

Table 5–7. Instruction Execution Performance for Nios II/s Core (Part 1 of 2)					
Instruction	Cycles	Penalties			
Normal ALU instructions (e.g., add, cmplt)	1				
Combinatorial custom instructions	1				
Multi-cycle custom instructions	1				
Branch (correctly predicted taken)	2				
Branch (correctly predicted not taken)	1				
Branch (mispredicted)	4	Pipeline flush			
trap, break, eret, bret, flushp, wrctl, unimplemented	4	Pipeline flush			
jmp, ret, call, callr	4	Pipeline flush			

Table 5–7. Instruction Execution Performance for Nios II/s Core (Part 2 of 2)					
Instruction	Cycles	Penalties			
rdctl	1				
load, store	> 1				
flushi, initi	4				
Multiply	(1)				
Divide	(1)				
Shift/rotate (with hardware multiply using embedded multipliers)	3				
Shift/rotate (with hardware multiply using LE-based multipliers)	4				
Shift/rotate (without hardware multiply present)	1 to 32				
All other instructions	1				

Note to Table 5-7:

Exception Handling

The Nios II/s core supports the following exception types:

- Hardware interrupt
- Software trap
- Unimplemented instruction

JTAG Debug Module

The Nios II/s core supports the JTAG debug module to provide a JTAG interface to software debugging tools. The Nios II/s core supports an optional enhanced interface that allows real-time trace data to be routed out of the processor and stored in an external debug probe.

Unsupported Features

The Nios II/s core does not support user mode, as defined in the *Programming Model* chapter of the *Nios II Processor Reference Handbook*. This does not affect application code. However, it may affect system code that relies on user mode to protect restricted resources.

The Nios II/s core does not handle the execution of instructions with undefined opcodes. If the processor issues an instruction word with an undefined opcode, the resulting behavior is undefined.

⁽¹⁾ Depends on the hardware multiply or divide option. See Table 5–5 on page 13 for details.

Nios II/e Core

The Nios II/e "economy" core is designed to achieve the smallest possible core size. Altera designed the Nios II/e core with a singular design goal: Reduce resource utilization any way possible, while still maintaining compatibility with the Nios II instruction set architecture. Hardware resources are conserved at the expense of execution performance. The Nios II/e core is roughly half the size of the Nios II/s core, but the execution performance is substantially lower.

The resulting core is optimal for cost-sensitive applications, as well as applications that require simple control logic.

Overview

The Nios II/e core:

- Executes at most one instruction per six clock cycles
- Can access up to 2 Gbytes of external address space
- Supports the addition of custom instructions
- Supports the JTAG debug module
- Does not provide hardware support for potential unimplemented instructions
- Has no instruction cache or data cache
- Does not perform branch prediction

The following sections discuss the noteworthy details of the Nios II/e core implementation. This document does not discuss low-level design issues, or implementation details that do not affect Nios II hardware or software designers.

Register File

At system generation time, the cpuid control register (clt5) is assigned a value that is guaranteed to be unique for each processor in the system.

Arithmetic Logic Unit

The Nios II/e core does not provide hardware support for any of the potential unimplemented instructions. All unimplemented instructions are emulated in software.

The Nios II/e core employs dedicated shift circuitry to perform shift and rotate operations. The dedicated shift circuitry achieves one-bit-per-cycle shift and rotate operations.

Memory Access

The Nios II/e core does not provide instruction cache or data cache. All memory and peripheral accesses generate an Avalon transfer. The Nios II/e core can address up to 2 Gbytes of external memory. The core does not support bit-31 data cache bypass. However, the most-significant bit of addresses is ignored to maintain consistency with Nios II core implementations that do support bit-31 cache bypass method.

Instruction Execution Stages

This section provides an overview of the pipeline behavior as a means of estimating assembly execution time. Most application programmers never need to analyze the performance of individual instructions, and live happy lives without ever studying the tables below.

Instruction Performance

The Nios II/e core dispatches a single instruction at a time, and the processor waits for an instruction to complete before fetching and dispatching the next instruction. Because each instruction completes before the next instruction is dispatched, branch prediction is not necessary. This greatly simplifies the consideration of processor stalls. Maximum performance is one instruction per six clock cycles. To achieve six cycles, the Avalon instruction master-port must fetch an instruction in one clock cycle. A stall on the Avalon instruction master-port directly extends the execution time of the instruction.

Execution performance for all instructions is shown in Table 5–8.

Table 5–8. Instruction Execution Performance for Nios II/e Core			
Instruction	Cycles		
Normal ALU instructions (e.g., add, cmplt)	6		
branch, jmp, ret, call, callr	6		
<pre>trap, break, eret, bret, flushp, wrctl, rdctl, unimplemented</pre>	6		
load word	6 + Duration of Avalon read transfer		
load halfword	9 + Duration of Avalon read transfer		
load byte	10 + Duration of Avalon read transfer		
store	6 + Duration of Avalon write transfer		
Shift, rotate	7 to 38		
All other instructions	6		
Combinatorial custom instructions	6		
Multi-cycle custom instructions	≥6		

Exception Handling

The Nios II/e core supports the following exception types:

- Hardware interrupt
- Software traps
- Unimplemented instruction

JTAG Debug Module

The Nios II/e core supports the JTAG debug module to provide a JTAG interface to software debugging tools. The JTAG debug module on the Nios II/e core does not support hardware breakpoints or trace.

Unsupported Features

The Nios II/e core does not support user mode, as defined in the *Programming Model* chapter of the *Nios II Processor Reference Handbook*. This does not affect application code. However, it may affect system code that relies on user mode to protect restricted resources.

The Nios II/e core does not handle the execution of instructions with undefined opcodes. If the processor issues an instruction word with an undefined opcode, the resulting behavior is undefined.



6. Nios II Processor Revision History

NII51018-6.0.0

Introduction

Each release of the Nios® II Embedded Design Suite (EDS) introduces improvements to the Nios II processor, the software development tools, or both. This document catalogs the history of revisions to the Nios II processor; it does not track revisions to development tools, such as the Nios II IDE.

Improvements to the Nios II processor may affect:

- Features of the Nios II architecture An example of an architecture revision is adding instructions to support floating-point arithmetic.
- Implementation of a specific Nios II core An example of a core revision is increasing the maximum possible size of the data cache memory for the Nios II/f core.
- Features of the JTAG debug module An example of a JTAG debug module revision is adding an additional trigger input to the JTAG debug module, allowing it to halt processor execution on a new type of trigger event.

Altera implements Nios II revisions such that code written for an existing Nios II core also works on future revisions of the same core.

Nios II Versions

The number for any version of the Nios II processor is determined by the version of the Nios II EDS. For example, in the Nios II EDS version 6.0, all Nios II cores are also version 6.0.

Table 6–1 lists the version numbers of all releases of the Nios II EDS.

Table 6–1. Nios II EDS Revision History			
Version	Release Date	Notes	
6.0	May 2006	The name Nios II Development Kit describing the software development tools changed to Nios II Embedded Design Suite.	
5.1 SP1	January 2006	Bug fix for Nios II/f core.	
5.1	October 2005	No changes.	
5.0	May 2005	 Changed version nomenclature. Altera® now aligns the Nios II processor version with Altera's Quartus II® software version. Memory structure enhancements: (1) Added tightly coupled memory. (2) Made data cache line size configurable. (3) Made cache optional in Nios II/f and Nios II/s cores. Verified Cyclone™ II device support in hardware. Support for HardCopy® devices. 	
1.1	December 2004	 Minor enhancements to the architecture: Added cpuid control register, and updated the break instruction. Increased user control of multiply and shift hardware in the arithmetic logic unit (ALU) for Nios II/s & Nios II/f cores. Minor bug fixes. 	
1.01	September 2004	 Verified Stratix™ II device support in hardware. Minor bug fixes. 	
1.0	May2004	Initial release of the Nios processor.	

Architecture Revisions

Architecture revisions augment the fundamental capabilities of the Nios II architecture, and affect all Nios II cores. A change in the architecture mandates a revision to all Nios II cores to accommodate the new architectural enhancement. For example, when Altera adds a new instruction to the instruction set, Altera consequently must update all Nios II cores to recognize the new instruction. Table 6–2 lists revisions to the Nios II architecture.

Table 6–2. Nios II Architecture Revisions (Part 1 of 2)				
Version	on Release Date Notes			
6.0	May 2006	Added optional cpu_resetrequest and cpu_resettaken signals to all processor cores.		
5.1	October 2005	No changes.		
5.0	May 2005	Added the flushda instruction.		

Version	Notes		
1.1	December 2004	 Added cpuid control register. Updated break instruction specification to accept an immediate argument for use by debugging tools. 	
1.01	September 2004	No changes.	
1.0	May 2004	Initial release of the Nios II processor architecture.	

Core Revisions

Core revisions introduce changes to an existing Nios II core. Core revisions most commonly fix identified bugs, or add support for an architecture revision. Not every Nios II core is revised with every release of the Nios II EDS.

Nios II/f Core

Table 6–3 lists revisions to the Nios II/f core.

Table 6–3. Ni	Table 6–3. Nios II/f Core Revisions			
Version	Release Date	Notes		
6.0	May 2006	Cycle count for flushi and initi instructions changes from 1 to 4 cycles. (SPR 201456)		
5.1 SP1	January 2006	Bug Fix: Back-to-back store instructions can cause memory corruption to the stored data. If the first store is not to the last word of a cache line and the second store is to the last word of the line, memory corruption occurs. (SPR 201895)		
5.1	October 2005	No changes.		
5.0	May 2005			

Table 6–3. N	Table 6–3. Nios II/f Core Revisions			
Version	Release Date	Notes		
1.1	December 2004	 Added user-configurable options affecting multiply and shift operations. Now designers can choose one of three options: (1) Use embedded multiplier resources available in the target device family (previously available). (2) Use logic elements to implement multiply and shift hardware (new option). (3) Omit multiply hardware. Shift operations take one cycle per bit shifted; multiply operations are emulated in software (new option). Added cpuid control register. Bug Fix: Interrupts that were disabled by wrctlienable remained enabled for one clock cycle following the wrctlinstruction. Now the instruction following such a wrctl cannot be interrupted. (SPR 164828) 		
1.01	September 2004	Verified Stratix II device support in hardware. Bug Fixes: (1) When a store to memory is followed immediately in the pipeline by a load from the same memory location, and the memory location is held in d-cache, the load may return invalid data. This situation can occur in C code compiled with optimization off (-O0). (SPR 158904) (2) The SOPC Builder top-level system module included an extra, unnecessary output port for systems with very small address spaces. (SPR 155871)		
1.0	May 2004	Initial release of the Nios II/f core.		

Nios II/s Core

Table 6–4 lists revisions to the Nios II/s core.

Table 6–4. N	Table 6–4. Nios II/s Core Revisions			
Version	Release Date	Notes		
6.0	May 2006	 Cycle count for flushi and initi instructions changes from 1 to 4 cycles. (SPR 201456) 		
5.1	October 2005	No changes.		
5.0	May 2005	 Added optional tightly coupled memory ports. Designers can add zero to four tightly coupled instruction master ports. Made instruction cache optional (previously instruction cache was always present). If the instruction cache is not present, the Nios II core does not have an instruction master port, and must use a tightly coupled instruction memory. Verified Cyclone II device support in hardware. Full support for HardCopy devices (previous versions required a work around to support HardCopy devices). 		

Table 6–4. I	Table 6–4. Nios II/s Core Revisions			
Version	Release Date	Notes		
1.1	December 2004	 Added user-configurable options affecting multiply and shift operations. Now designers can choose one of three options: (1) Use embedded multiplier resources available in the target device family (previously available). (2) Use logic elements to implement multiply and shift hardware (new option). (3) Omit multiply hardware. Shift operations take one cycle per bit shifted; multiply operations are emulated in software (new option). Added user-configurable option to include divide hardware in the ALU. Previously this option was available for only the Nios II/f core. Added cpuid control register. 		
1.01	September 2004	 Verified Stratix II device support in hardware. Bug Fix: The SOPC Builder top-level system module included an extra, unnecessary output port for systems with very small address spaces. (SPR 155871) 		
1.0	May 2004	Initial release of the Nios II/s core.		

Nios II/e Core

Table 6–5 lists revisions to the Nios II/e core.

Table 6-5.	Table 6–5. Nios II/e Core Revisions		
Version	Release Date	Notes	
6.0	May 2006	No changes.	
5.1	October 2005	No changes.	
5.0	May 2005	 Verified Cyclone II device support in hardware. Full support for HardCopy devices (previous versions required a work around to support HardCopy devices). 	
1.1	December 2004	Added cpuid control register.	
1.01	September 2004	 Verified Stratix II device support in hardware. Bug Fix: The SOPC Builder top-level system module included an extra, unnecessary output port for systems with very small address spaces. (SPR 155871) 	
1.0	May 2004	Initial release of the Nios II/e core.	

JTAG Debug Module Revisions

JTAG debug module revisions augment the debug capabilities of the Nios II processor, or fix bugs isolated within the JTAG debug module logic.

Table 6-6 lists revisions to the JTAG debug module.

Version	JTAG Debug Module Release Date	Notes	
version	Release Date	Nutes	
6.0	May 2006	No changes.	
5.1	October 2005	No changes.	
5.0	May 2005	Full support for HardCopy devices (previous versions of the JTAG debug module did not support HardCopy devices).	
1.1	December 2004	Bug fix: When using the Nios II/s and Nios II/f cores, hardware breakpoints may have falsely triggered when placed on the instruction sequentially following a jmp, trap, or any branch instruction. (SPR 158805)	
1.01	September 2004	 Feature enhancements: Added the ability to trigger based on the instruction address. Uses include triggering trace control (trace on/off), sequential triggers (see below), and trigger in/out signal generation. Enhanced trace collection such that collection can be stopped when the trace buffer is full without halting the Nios II processor. Armed triggers – Enhanced trigger logic to support two levels of triggers, or "armed triggers"; enabling the use of "Event A then event B" trigger definitions. Bug fixes: On the Nios II/s core, trace data sometimes recorded incorrect addresses during interrupt processing. (SPR 158033) Under certain circumstances, captured trace data appeared to start earlier or later than the desired trigger location. (SPR 154467) During debug, the processor would hang if a hardware breakpoint and an interrupt occurred simultaneously. (SPR 154097) 	
1.0	May 2004	Initial release of the JTAG debug module.	



7. Application Binary Interface

NII51016-6.0.0

This section describes the Application Binary Interface (ABI) for the Nios® II processor. The ABI describes:

- How data is arranged in memory
- Behavior and structure of the stack
- Function calling conventions

Data Types

Table 7–1 shows the size and representation of the C/C++ data types for the Nios II processor.

Table 7–1. Representation of Data Types			
Туре	Size (Bytes)	Representation	
char, signed char	1	2s complement (ASCII)	
unsigned char	1	binary (ASCII)	
short, signed short	2	2s complement	
unsigned short	2	binary	
int, signed int	4	2s complement	
unsigned int	4	binary	
long, signed long	4	2s complement	
unsigned long	4	binary	
float	4	IEEE	
double	8	IEEE	
pointer	4	binary	
long long	8	2s complement	
unsigned long long	8	binary	

Memory Alignment

Contents in memory are aligned as follows:

- A function must be aligned to a minimum of 32-bit boundary.
- The minimum alignment of a data element is its natural size. A data element larger than 32-bits need only be aligned to a 32-bit boundary.

- Structures, unions, and strings must be aligned to a minimum of 32 bits.
- Bit-fields inside structures are always 32-bit aligned.

Register Usage

The ABI adds additional usage conventions to the Nios II register file defined in the *Programming Model* chapter of the *Nios II Processor Reference Handbook*. The ABI uses the registers as shown in Table 7–2.

Register	Name	Used by Compiler	Callee Saved	Normal Usage
r0	zero	✓		0x00000000
r1	at			Assembler Temporary
r2		✓		Return Value (Least-significant 32 bits)
r3		✓		Return Value (Most-significant 32 bits)
r4		✓		Register Arguments (First 32 bits)
r5		✓		Register Arguments (Second 32 bits)
r6		✓		Register Arguments (Third 32 bits)
r7		✓		Register Arguments (Fourth 32 bits)
r8		✓		Caller-Saved General-Purpose Registers
r9		✓		
r10		✓		
r11		✓		
r12		✓		
r13		✓		
r14		✓		
r15		✓		
r16		✓	✓	Callee-Saved General-Purpose Registers
r17		✓	✓	
r18		✓	✓	
r19		✓	✓	
r20		✓	✓	
r21		✓	✓	
r22		✓	✓	
r23		✓	✓	
r24	et			Exception Temporary

Table 7-	2. Nios II AE	31 Register Us	age (Part 2 of	2)
Register	Name	Used by Compiler	Callee Saved	Normal Usage
r25	bt			Break Temporary
r26	gp	✓		Global Pointer
r27	sp	✓		Stack Pointer
r28	fp	✓		Frame Pointer (2)
r29	ea			Exception Return Address
r30	ba			Break Return Address
r31	ra	✓		Return Address

Notes to Table 7-2:

- (1) A function may use one of these registers if it saves it first. The function must restore the register's original value before exiting.
- (2) If the frame pointer is not used, the register is available as a temporary. See "Frame Pointer Elimination" on page 7–4.

Endianess of Data

The endianess of values greater than 8-bits is little endian. The upper 8 bits of a value are stored at the higher byte address.

Stacks

The stack grows downward (i.e. towards lower addresses). The Stack Pointer points to the last used slot. The frame grows upwards, which means that the Frame Pointer points to the bottom of the frame.

Figure 7–1 shows an example of the structure of a current frame. In this case, function a() calls function b(), and the stack is shown before the call and after the prolog in the called function has completed.




Figure 7–1. Stack Pointer, Frame Pointer & the Current Frame

Each section of the current frame is aligned to a 32-bit boundary. The ABI requires the stack pointer be 32-bit aligned at all times.

Frame Pointer Elimination

Because, in the normal case, the frame pointer is the same as the stack pointer, the information in the frame pointer is redundant. Therefore, to achieve most optimal code, eliminating the frame pointer is desirable. However, when the frame pointer is eliminated, because GDB has issues locating the stack properly, debugging without a frame pointer is difficult to do. When the frame pointer is eliminated, register fp becomes available as a temporary.

Call Saved Registers

Implementation note: the compiler is responsible for saving registers that need to be saved in a function. If there are any such registers, they are saved on the stack in this order from high addresses: ra, fp, r2, r3, r4, r5, r6, r7, r8, r9, r10, r11, r12, r13, r14, r15, r16, r17, r18, r19, r20, r21, r22, r23, r24, r25, gp, and sp. Stack space is not allocated for registers that are not saved.

Further Examples of Stacks

There are a number of special cases for stack layout, which are described in this section.

Stack Frame for a Function With alloca()

Figure 7–2 depicts what the frame looks like after alloca() is called. The space allocated by alloca() replaces the outgoing arguments and the outgoing arguments get new space allocated at the bottom of the frame.

Implementation note: the Nios II C/C++ compiler maintains a frame pointer for any function that calls alloca(), even if -fomit-frame-pointer is specifed.




Figure 7–2. Stack Frame after Calling alloca()

Stack Frame for a Function with Variable Arguments

Functions that take variable arguments still have their first 16-bytes of arguments arriving in registers r4 through r7, just like other functions.

Implementation note: In order for varargs to work, functions that take variable arguments will allocate 16 extra bytes of storage on the stack. They will copy to the stack the first 16-bytes of their arguments from registers r4 through r7 as shown in Figure 7–3.




Figure 7–3. Stack Frame Using Variable Arguments

Stack Frame for a Function with Structures Passed By Value

Functions that take struct value arguments still have their first 16-bytes of arguments arriving in registers r4 through r7, just like other functions.

Implementation note: if part of a structure is passed via registers, the function may need to copy the register contents back to the stack. This is similar to the variable arguments case as shown in Figure 7–3.

Function Prologs

The Nios II C/C++ compiler generates function prologs that allocate the stack frame of a function for storage of stack temporaries and outgoing arguments. In addition, each prolog is responsible for saving any state of its calling function for variables marked callee-saved by the ABI. The callee-saved register are listed in Table 7–2 on page 7–2. A function prolog is required to save a callee saved register only if the function will be using the register.

Debuggers can use the knowledge of how the function prologs work to disassemble the instructions to reconstruct state when doing a back trace. Preferably, debuggers can use information stored in the DWARF2 debugging information to find out what a prolog has done.

The instructions found in a Nios II function prolog perform the following tasks:

- Adjust the SP (to allocate the frame)
- Store registers to the frame.
- Assign the SP to the FP

Figure 7–4 shows an example of a function prolog.

Figure 7-4. A function prolog

```
/* Adjust the stack pointer */
addisp, sp, -120/* make a 120 byte frame */
/* Store registers to the frame */
stw ra, 116(sp)/* store the return address */
stw fp, 112(sp)/* store the frame pointer*/
stw r16, 108(sp)/* store callee-saved register */
stw r17, 104(sp) /* store callee-saved register */
/* Set the new frame pointer */
mov fp, sp
```

Prolog Variations

The following variations can occur in a prolog:

- If the function's frame size is greater than 32,767 bytes, extra temporary registers will be used in the calculation of the new SP as well as for the offsets of where to store callee-saved registers. This is due to the maximum size of immediate values allowed by the Nios II processor.
- If the frame pointer is not in use, the move of the SP to FP will not happen.
- If variable arguments are used, there will be extra instructions to store the argument registers to the stack.
- If the function is a leaf function, the return address will not be saved.
- If optimizations are on, especially instruction scheduling, the order of the instructions may change and may become interlaced with instructions located after the prolog.

Arguments & Return Values

This section discusses the details of passing arguments to functions and returning values from functions.

Arguments

The first 16-bytes to a function are passed in registers r4 through r7. The arguments are passed as if a structure containing the types of the arguments was constructed, and the first 16-bytes of the structure are located in r4 through r7.

A simple example:

```
int function (int a, int b);
```

The equivalent structure representing the arguments is:

```
struct { int a; int b; };
```

The first 16-bytes of the struct are assigned to r4 through r7. Therefore r4 is assigned the value of a and r5 the value of b.

Variable Arguments

The first 16-bytes to a function taking variable arguments are passed the same way as a function not taking variable arguments. It is the called function's responsibility to clean-up the stack as necessary to support the variable arguments. See "Stack Frame for a Function with Variable Arguments" on page 7–5.

Return Values

Return values of types up to 8-bytes are returned in r2 and r3. For return values greater than 8-bytes, the caller must allocate memory for the result and must pass the address of the result memory as a hidden zero argument.

The hidden zero argument is best explained through an example.

Example: function a () calls function b (), which returns a struct.

```
/* b() computes a structure-type result and returns it */
STRUCT b(int i, int j)
{
          ...
          return result;
}
void a(...)
{
```

```
value = b(i, j);
}
```

In this example, as long as the result type is no larger than 8 bytes, b() will return its result in r2 and r3.

If the return type is larger than 8 bytes, the Nios II C/C++ compiler treats this program as if a () had passed a pointer to b (). The example below shows how the Nios II C/C++ compiler sees the code above.

```
void b(STRUCT *p_result, int i, int j)
{
    ...
    *p_result = result;
}

void a(...)
{
    STRUCT value;
    ...
    b(*value, i, j);
}
```



8. Instruction Set Reference

NII51017-6.0.0

Introduction

This section introduces the Nios® II instruction-word format and provides a detailed reference of the Nios II instruction set.

Word Formats

There are three types of Nios II instruction word format: I-type, R-type, and J-type.

I-Type

The defining characteristic of the I-type instruction-word format is that it contains an immediate value embedded within the instruction word. I-type instructions words contain:

- A 6-bit opcode field OP
- Two 5-bit register fields A and B
- A 16 bit immediate data field IMM16

In most cases, fields A and IMM16 specify the source operands, and field B specifies the destination register. IMM16 is considered signed except for logical operations and unsigned comparisons.

I-type instructions include arithmetic and logical operations such as addi and andi; branch operations; load and store operations; and cachemanagement operations.

The I-type instruction format is:

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5 4	3 2	1 0
		Α					В									IIV	1M1	6									OP	

R-Type

The defining characteristic of the R-type instruction-word format is that all arguments and results are specified as registers. R-type instructions contain:

- A 6-bit opcode field OP
- Three 5-bit register fields A, B, and C
- An 11-bit opcode-extension field OPX

In most cases, fields A and B specify the source operands, and field C specifies the destination register. Some R-Type instructions embed a small immediate value in the low-order bits of OPX.

R-type instructions include arithmetic and logical operations such as add and nor; comparison operations such as cmpeq and cmplt; the custom instruction; and other operations that need only register operands.

The R-type instruction format is:

31 30 2	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
A	١				В					С							0	PX								0	Р		

J-Type

J-type instructions contain:

- A 6-bit opcode field
- A 26-bit immediate data field

The only J-type instruction is call.

The J-type instruction format is:

3	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
											IMI	ME	D26															0	Р		

Instruction Opcodes

The OP field in the Nios II instruction word specifies the major class of an opcode as shown in Table 8–1 and Table 8–2. Most values of OP are encodings for I-type instructions. One encoding, OP = 0x00, is the J-type instruction call. Another encoding, OP = 0x3a, is used for all R-type instructions, in which case, the OPX field differentiates the instructions. All unused encodings of OP and OPX are reserved.

Table	8–1. OP Encodin	gs						
0P	Instruction	0P	Instruction	OP	Instruction	C	P	Instruction
0x00	call	0x10	cmplti	0x20	cmpeqi	0x3	30	cmpltui
0x01		0x11		0x21		0x3	31	
0x02		0x12		0x22		0x3	32	custom
0x03	ldbu	0x13		0x23	ldbuio	0x3	33	initd
0x04	addi	0x14	ori	0x24	muli	0x3	34	orhi
0x05	stb	0x15	stw	0x25	stbio	0x3	35	stwio
0x06	br	0x16	blt	0x26	beq	0x3	36	bltu
0x07	ldb	0x17	ldw	0x27	ldbio	0x3	37	ldwio
0x08	cmpgei	0x18	cmpnei	0x28	cmpgeui	0x3	38	
0x09		0x19		0x29		0x3	39	
0x0A		0×1A		0x2A		0x3	ЗА	R-Type
0x0B	ldhu	0x1B	flushda	0x2B	ldhuio	0x3	ЗВ	flushd
0x0C	andi	0x1C	xori	0x2C	andhi	0x3	3C	xorhi
0x0D	sth	0x1D		0x2D	sthio	0x3	3 D	
0x0E	bge	0x1E	bne	0x2E	bgeu	0x3	3E	
0x0F	ldh	0×1F		0x2F	ldhio	0x3	3F	

Table 8	-2. OPX Encodi	ngs for R-Ty	pe Instructions				
ОРХ	Instruction	ОРХ	Instruction	ОРХ	Instruction	0PX	Instruction
0x00		0x10	cmplt	0x20	cmpeq	0x30	cmpltu
0x01	eret	0x11		0x21		0x31	add
0x02	roli	0x12	slli	0x22		0x32	
0x03	rol	0x13	sll	0x23		0x33	
0x04	flushp	0×14		0x24	divu	0x34	break
0x05	ret	0x15		0x25	div	0x35	
0x06	nor	0x16	or	0x26	rdctl	0x36	sync
0x07	mulxuu	0x17	mulxsu	0x27	mul	0x37	
0x08	cmpge	0x18	cmpne	0x28	cmpgeu	0x38	
0x09	bret	0x19		0x29	initi	0x39	sub
0x0A		0x1A	srli	0x2A		0x3A	srai
0x0B	ror	0x1B	srl	0x2B		0x3B	sra
0x0C	flushi	0×1C	nextpc	0x2C		0x3C	
0x0D	jmp	0x1D	callr	0x2D	trap	0x3D	
0x0E	and	0x1E	xor	0x2E	wrctl	0x3E	
0x0F		0x1F	mulxss	0x2F		0x3F	

Assembler Pseudo-instructions

Table 8–3 lists pseudoinstructions available in Nios II assembly language. Pseudoinstructions are used in assembly source code like regular assembly instructions. Each pseudoinstruction is implemented at the machine level using an equivalent instruction. The movia pseudoinstruction is the only exception, being implemented with two instructions. Most pseudoinstructions do not appear in disassembly views of machine code.

Table 8–3. Assembler Pseudoinstr	uctions
Pseudoinstruction	Equivalent Instruction
bgt rA, rB, label	blt rB, rA, label
bgtu rA, rB, label	bltu rB, rA, label
ble rA, rB, label	bge rB, rA, label
bleu rA, rB, label	bgeu rB, rA, label
cmpgt rC, rA, rB	cmplt rC, rB, rA
cmpgti rB, rA, IMMED	cmpgei rB, rA, (IMMED+1)
cmpgtu rC, rA, rB	cmpltu rC, rB, rA
cmpgtui rB, rA, IMMED	cmpgeui rB, rA, (IMMED+1)
cmple rC, rA, rB	cmpge rC, rB, rA
cmplei rB, rA, IMMED	cmplti rB, rA, (IMMED+1)
cmpleu rC, rA, rB	cmpgeu rC, rB, rA
cmpleui rB, rA, IMMED	cmpltui rB, rA, (IMMED+1)
mov rC, rA	add rC, rA, rO
movhi rB, IMMED	orhi rB, r0, IMMED
movi rB, IMMED	addi, rB, rO, IMMED
movia rB, label	orhi rB, r0, %hiadj(label) addi, rB, r0, %lo(label)
movui rB, IMMED	ori rB, r0, IMMED
nop	add r0, r0, r0
subi, rB, rA, IMMED	addi rB, rA, IMMED

Assembler Macros

The Nios II assembler provides macros to extract halfwords from labels and from 32-bit immediate values. Table 8–4 lists the available macros. These macros return 16-bit signed values or 16-bit unsigned values depending on where they are used. When used with an instruction that requires a 16-bit signed immediate value, these macros return a value ranging from –32768 to 32767. When used with an instruction that requires a 16-bit unsigned immediate value, these macros return a value ranging from 0 to 65535.

Table 8–4. Assembler Macros													
Macro Description Operation													
%lo(immed32)	Extract bits [150] of immed32	immed32 & 0xffff											
%hi(immed32)	Extract bits [3116] of immed32	(immed32 >> 16) & 0xffff											
%hiadj(immed32)	Extract bits [3116] and adds bit 15 of immed32	(immed32 >> 16) + 0xffff + ((immed32 >> 15) & 0x1)											
%gprel(immed32)	Replace the immed32 address with an offset from the global pointer ⁽¹⁾	immed32 –_gp											

Note to Table 8-4:

(1) See the Application Binary Interface chapter of the Nios II Processor Reference Handbook for more information about global pointers.

Instruction Set Reference

The following pages list all Nios II instruction mnemonics in alphabetical order. Table $8\!-\!5$ shows the notation conventions used to describe instruction operation.

Table 8–5. Nota	ation Conventions
Notation	Meaning
$X \leftarrow Y$	X is written with Y
PC ← X	The program counter (PC) is written with address X; the instruction at X will be the next instruction to execute
PC	The address of the assembly instruction in question
rA, rB, rC	One of the 32-bit general-purpose registers
IMM <i>n</i>	An <i>n</i> -bit immediate value, embedded in the instruction word
IMMED	An immediate value
X _n	The n^{th} bit of X, where $n = 0$ is the LSB
X _{nm}	Consecutive bits n through m of X
0xNNMM	Hexadecimal notation
X : Y	Bitwise concatenation For example, (0x12 : 0x34) = 0x1234
σ(X)	The value of X after being sign-extended into a full register-sized signed integer
X >> n	The value X after being right-shifted n bit positions
X << n	The value X after being left-shifted n bit positions
X & Y	Bitwise logical AND
X Y	Bitwise logical OR
X ^ Y	Bitwise logical XOR
~X	Bitwise logical NOT (one's complement)
Mem8[X]	The byte located in data memory at byte-address X
Mem16[X]	The halfword located in data memory at byte-address X
Mem32[X]	The word located in data memory at byte-address X
label	An address label specified in the assembly file
(signed) rX	The value of rX treated as a signed number
(unsigned) rX	The value of rX, treated as an unsigned number

add

Operation: $rC \leftarrow rA + rB$

Assembler Syntax: add rC, rA, rB

Example: add r6, r7, r8

Description: Calculates the sum of rA and rB. Stores the result in rC. Used for both signed and

unsigned addition.

Usage: Carry Detection (unsigned operands):

Following an add operation, a carry out of the MSB can be detected by checking whether the unsigned sum is less than one of the unsigned operands. The carry bit can be written to a register, or a conditional branch can be taken based on the carry condition. Both cases are shown below.

Overflow Detection (signed operands):

An overflow is detected when two positives are added and the sum is negative, or when two negatives are added and the sum is positive. The overflow condition can control a conditional branch, as shown below.

```
add rC, rA, rB; The original add operation xor rD, rC, rA; Compare signs of sum and rA xor rE, rC, rB; Compare signs of sum and rB and rD, rD, rE; Combine comparisons blt rD, rO, label; Branch if overflow occurred
```

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

C = Register index of operand rC

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В					С					0x	31					0					0>	За		

ibbs

add immediate

Operation: $rB \leftarrow rA + \sigma (IMM16)$ Assembler Syntax: addi rB, rA, IMM16 Example: addi r6, r7, -100

Description: Sign-extends the 16-bit immediate value and adds it to the value of rA. Stores the sum

in rB.

Usage: Carry Detection (unsigned operands):

Following an addi operation, a carry out of the MSB can be detected by checking whether the unsigned sum is less than one of the unsigned operands. The carry bit can be written to a register, or a conditional branch can be taken based on the carry condition. Both cases are shown below.

```
addi rB, rA, IMM16
                      ; The original add operation
cmpltu rD, rB, rA
                      ; rD is written with the carry bit
addi rB, rA, IMM16
                      ; The original add operation
bltu rB, rA, label
                      ; Branch if carry was generated
```

Overflow Detection (signed operands):

An overflow is detected when two positives are added and the sum is negative, or when two negatives are added and the sum is positive. The overflow condition can control a conditional branch, as shown below.

```
addi rB, rA, IMM16
                     ; The original add operation
xor rC, rB, rA
                     ; Compare signs of sum and rA
xorhi rD, rB, IMM16 ; Compare signs of sum and IMM16
and rC, rC, rD
                    ; Combine comparisons
blt rC, r0, label
                    ; Branch if overflow occurred
```

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
																										T					

Α	В	IMM16	0x04

and

bitwise logical and

Operation: $rC \leftarrow rA \& rB$

Assembler Syntax: and rC, rA, rB Example: and r6, r7, r8

Description: Calculates the bitwise logical AND of rA and rB and stores the result in rC.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B C 0x0e 0 0x3a

andhi

bitwise logical and immediate into high halfword

Operation: $rB \leftarrow rA \& (IMM16: 0x0000)$ Assembler Syntax: andhi rB, rA, IMM16
Example: andhi r6, r7, 100

Description: Calculates the bitwise logical AND of rA and (IMM16 : 0x0000) and stores the result in

rB.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit unsigned immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B IMM16 Ox2c

andi

bitwise logical and immediate

Operation: $rB \leftarrow rA \& (0x0000 : IMM16)$ Assembler Syntax: and irB, rA, IMM16
Example: and r6, r7, 100

Description: Calculates the bitwise logical AND of rA and (0x0000 : IMM16) and stores the result in

rB.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit unsigned immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	/116										0>	ОС		

beq

branch if equal

Operation: if (rA == rB)

then PC \leftarrow PC + 4 + σ (IMM16)

else PC \leftarrow PC + 4

Assembler Syntax: beq rA, rB, label Example: beq r6, r7, label

Description: If rA == rB, then beg transfers program control to the instruction at label. In the

instruction encoding, the offset given by IMM16 is treated as a signed number of bytes relative to the instruction immediately following \mathtt{beq} . The two least-significant bits of IMM16 are always zero, because instruction addresses must be word-aligned.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	/116										0х	26		

bge

branch if greater than or equal signed

Operation: if ((signed) rA >= (signed) rB)

then PC \leftarrow PC + 4 + σ (IMM16)

else PC \leftarrow PC + 4

Assembler Syntax: bge rA, rB, label

Example: bge r6, r7, top of loop

Description: If (signed) rA >= (signed) rB, then bge transfers program control to the instruction at

label. In the instruction encoding, the offset given by IMM16 is treated as a signed number of bytes relative to the instruction immediately following bge. The two least-significant bits of IMM16 are always zero, because instruction addresses must be

word-aligned.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	/116										0>	оe		

bgeu

branch if greater than or equal unsigned

Operation: if ((unsigned) rA >= (unsigned) rB)

then PC \leftarrow PC + 4 + σ (IMM16)

else PC ← PC + 4

Assembler Syntax: bgeu rA, rB, label

Example: bgeu r6, r7, top of loop

Description: If (unsigned) rA >= (unsigned) rB, then bgeu transfers program control to the

instruction at label. In the instruction encoding, the offset given by IMM16 is treated as a signed number of bytes relative to the instruction immediately following bgeu. The two least-significant bits of IMM16 are always zero, because instruction addresses

must be word-aligned.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

 $31 \quad 30 \quad 29 \quad 28 \quad 27 \quad 26 \quad 25 \quad 24 \quad 23 \quad 22 \quad 21 \quad 20 \quad 19 \quad 18 \quad 17 \quad 16 \quad 15 \quad 14 \quad 13 \quad 12 \quad 11 \quad 10 \quad 9 \quad 8 \quad 7 \quad 6 \quad 5 \quad 4 \quad 3 \quad 2 \quad 1 \quad 0$

Α	В	IMM16	0x2e
---	---	-------	------

bgt

branch if greater than signed

Operation: if ((signed) rA > (signed) rB)

then PC \leftarrow label else PC \leftarrow PC + 4

Assembler Syntax: bgt rA, rB, label

Example: bgt r6, r7, top_of_loop

Description: If (signed) rA > (signed) rB, then bgt transfers program control to the instruction at

label.

Pseudoinstruction: bgt is implemented with the blt instruction by swapping the register operands.

bgtu

branch if greater than unsigned

Operation: if ((unsigned) rA > (unsigned) rB)

then PC \leftarrow label else PC \leftarrow PC + 4

Assembler Syntax: bgtu rA, rB, label

Example: bgtu r6, r7, top_of_loop

Description: If (unsigned) rA > (unsigned) rB, then bgtu transfers program control to the

instruction at label.

Pseudoinstruction: bgtu is implemented with the bltu instruction by swapping the register operands.

ble

branch if less than or equal signed

Operation: if ((signed) rA <= (signed) rB)

then PC \leftarrow label else PC \leftarrow PC + 4

Assembler Syntax: ble rA, rB, label

Example: ble r6, r7, top_of_loop

Description: If (signed) rA <= (signed) rB, then ble transfers program control to the instruction at

label.

Pseudoinstruction: ble is implemented with the bge instruction by swapping the register operands.

bleu

branch if less than or equal to unsigned

Operation: if ((unsigned) rA <= (unsigned) rB)

then $PC \leftarrow label$ else $PC \leftarrow PC + 4$

Assembler Syntax: bleu rA, rB, label

Example: bleu r6, r7, top_of_loop

Description: If (unsigned) rA <= (unsigned) rB, then bleu transfers program counter to the

instruction at label.

Pseudoinstruction: bleu is implemented with the bgeu instruction by swapping the register operands.

blt

branch if less than signed

Operation: if ((signed) rA < (signed) rB)

then PC \leftarrow PC + 4 + σ (IMM16)

else PC \leftarrow PC + 4

Assembler Syntax: blt rA, rB, label

Example: blt r6, r7, top of loop

Description: If (signed) rA < (signed) rB, then blt transfers program control to the instruction at

label. In the instruction encoding, the offset given by IMM16 is treated as a signed number of bytes relative to the instruction immediately following blt. The two least-significant bits of IMM16 are always zero, because instruction addresses must be

word-aligned.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMI	/116										0>	(16		

bltu

branch if less than unsigned

Operation: if ((unsigned) rA < (unsigned) rB)

then PC \leftarrow PC + 4 + σ (IMM16)

else PC \leftarrow PC + 4

Assembler Syntax: bltu rA, rB, label

Example: bltu r6, r7, top of loop

Description: If (unsigned) rA < (unsigned) rB, then bltu transfers program control to the

instruction at label. In the instruction encoding, the offset given by IMM16 is treated as a signed number of bytes relative to the instruction immediately following bltu. The two least-significant bits of IMM16 are always zero, because instruction addresses

must be word-aligned.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

MM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	И16										0>	36		

bne

branch if not equal

Operation: if (rA != rB)

then PC \leftarrow PC + 4 + σ (IMM16)

else PC \leftarrow PC + 4

Assembler Syntax: bne rA, rB, label

Example: bne r6, r7, top of loop

Description: If rA!= rB, then bne transfers program control to the instruction at label. In the

instruction encoding, the offset given by IMM16 is treated as a signed number of bytes relative to the instruction immediately following bne. The two least-significant bits of IMM16 are always zero, because instruction addresses must be word-aligned.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31	30 29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	А	į.				В										IMI	/116										0>	(1e		

br

unconditional branch

Operation: $PC \leftarrow PC + 4 + \sigma (IMM16)$

Assembler Syntax: br label

Example: br top of loop

Description: Transfers program control to the instruction at label. In the instruction encoding, the

offset given by IMM16 is treated as a signed number of bytes relative to the instruction immediately following br. The two least-significant bits of IMM16 are always zero,

because instruction addresses must be word-aligned.

Instruction Type:

Instruction Fields: IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		0					0										IMI	/116										0>	(06		

break

debugging breakpoint

Operation: bstatus ←status

 $\begin{aligned} & PIE \leftarrow 0 \\ & U \leftarrow 0 \\ & ba \leftarrow PC + 4 \end{aligned}$

PC ← break handler address

Assembler Syntax: break

break imm5

Example: break

Description:Breaks program execution and transfers control to the debugger break-processing

routine. Saves the address of the next instruction in register ba and saves the contents of the status register in bstatus. Disables interrupts, then transfers execution to

the break handler.

The 5-bit immediate field imm5 is ignored by the processor, but it can be used by the

debugger.

break with no argument is the same as break 0.

Usage: break is used by debuggers exclusively. Only debuggers should place break in a

user program, operating system, or exception handler. The address of the break

handler is specified at system generation time.

Some debuggers support break and break 0 instructions in source code. These

debuggers treat the break instruction as a normal breakpoint.

Instruction Type: R

Instruction Fields: IMM5 = Type of breakpoint

bret

breakpoint return

Operation: status ← bstatus

 $PC \leftarrow ba$

Assembler Syntax: bret Example: bret

Description: Copies the value of bstatus into the status register, then transfers execution to

the address in ${\tt ba}$. In user mode, this instruction generates an access-violation

exception.

Usage: bret is used by debuggers exclusively and should not appear in user programs,

operating systems, or exception handlers.

Instruction Type: R
Instruction Fields: None

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	C)x1e	Э				0					0					0x	09					0					0>	За		

call

call subroutine

Operation: $ra \leftarrow PC + 4$

 $PC \leftarrow (PC_{31,28} : IMM26 \times 4)$

Assembler Syntax: call label

Example: call write char

Description: Saves the address of the next instruction in register ra, and transfers execution to the

instruction at address (PC $_{31..28}$: IMM26 \times 4).

Usage: call can transfer execution anywhere within the 256 MB range determined by

PC_{31..28}. The linker must handle cases in which the address is out of this range.

Instruction Type: J

Instruction Fields: IMM26 = 26-bit unsigned immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

IMM26 0

callr

call subroutine in register

Operation: $ra \leftarrow PC + 4$

 $\mathsf{PC} \leftarrow \mathsf{rA}$

Assembler Syntax: callr rA Example: callr r6

Description: Saves the address of the next instruction in the return-address register, and transfers

execution to the address contained in register rA.

Usage: callr is used to dereference C-language function pointers.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A 0 0x1f 0x1d 0 0x3a

cmpeq

compare equal

Operation: if (rA == rB)

then $rC \leftarrow 1$ else $rC \leftarrow 0$

Assembler Syntax: cmpeq rC, rA, rB

Example: cmpeq r6, r7, r8

Description: If rA == rB, then stores 1 to rC; otherwise, stores 0 to rC.

Usage: cmpeq performs the == operation of the C programming language. Also, cmpeq can

be used to implement the C logical-negation operator "!".

cmpeq rC, rA, r0 ; Implements rC = !rA

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

R B C Ox20 Ox20 Ox3a

cmpeqi

compare equal immediate

Operation: if $(rA \sigma(IMM16))$

then $rB \leftarrow 1$ else $rB \leftarrow 0$

Assembler Syntax: cmpeqi rB, rA, IMM16

Example: cmpeqi r6, r7, 100

Description: Sign-extends the 16-bit immediate value IMM16 to 32 bits and compares it to the value

of rA. If rA == σ (IMM16), cmpeqi stores 1 to rB; otherwise stores 0 to rB.

Usage: cmpeqi performs the == operation of the C programming language.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

cmpge

compare greater than or equal signed

Operation: if ((signed) rA >= (signed) rB)

then $rC \leftarrow 1$ else $rC \leftarrow 0$

Assembler Syntax: cmpge rC, rA, rB

Example: cmpge r6, r7, r8

Description: If rA >= rB, then stores 1 to rC; otherwise stores 0 to rC.

Usage: cmpge performs the signed >= operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В					С					0x	08					0					0х	За		

cmpgei

compare greater than or equal signed immediate

Operation: if ((signed) rA >= (signed) σ (IMM16))

then $rB \leftarrow 1$ else $rB \leftarrow 0$

Assembler Syntax: cmpgei rB, rA, IMM16

Example: cmpgei r6, r7, 100

Description: Sign-extends the 16-bit immediate value IMM16 to 32 bits and compares it to the value

of rA. If rA >= α (IMM16), then cmpgei stores 1 to rB; otherwise stores 0 to rB.

Usage: cmpgei performs the signed >= operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B IMM16 Ox08

cmpgeu

compare greater than or equal unsigned

Operation: if ((unsigned) rA >= (unsigned) rB)

then $rC \leftarrow 1$ else $rC \leftarrow 0$

Assembler Syntax: cmpgeu rC, rA, rB

Example: cmpgeu r6, r7, r8

Description: If $rA \ge rB$, then stores 1 to rC; otherwise stores 0 to rC.

Usage: cmpgeu performs the unsigned >= operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B C 0x28 0 0x3a

cmpgeui

compare greater than or equal unsigned immediate

Operation: if ((unsigned) $rA \ge (unsigned) (0x0000 : IMM16))$

then $rB \leftarrow 1$ else $rB \leftarrow 0$

Assembler Syntax: cmpgeui rB, rA, IMM16

Example: cmpgeui r6, r7, 100

Description: Zero-extends the 16-bit immediate value IMM16 to 32 bits and compares it to the value

of rA. If rA >= (0x0000 : IMM16), then cmpgeui stores 1 to rB; otherwise stores 0 to

rB.

Usage: cmpgeui performs the unsigned >= operation of the C programming language.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit unsigned immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B IMM16 Ox28

cmpgt

compare greater than signed

Operation: if ((signed) rA > (signed) rB)

then $rC \leftarrow 1$ else $rC \leftarrow 0$

Assembler Syntax: cmpgt rC, rA, rB

Example: cmpgt r6, r7, r8

Description: If rA > rB, then stores 1 to rC; otherwise stores 0 to rC.

Usage: cmpgt performs the signed > operation of the C programming language.

Pseudoinstruction: cmpgt is implemented with the cmplt instruction by swapping its rA and rB

operands.

cmpgti

compare greater than signed immediate

Operation: if ((signed) rA > (signed) IMMED)

then $rB \leftarrow 1$ else $rB \leftarrow 0$

Assembler Syntax: cmpgti rB, rA, IMMED Example: cmpgti r6, r7, 100

Description: Sign-extends the immediate value IMMED to 32 bits and compares it to the value of rA.

If rA > α (IMMED), then cmpgti stores 1 to rB; otherwise stores 0 to rB.

Usage: cmpqti performs the signed > operation of the C programming language. The

maximum allowed value of IMMED is 32766. The minimum allowed value is -32769.

Pseudoinstruction: cmpgti is implemented using a cmpgei instruction with an immediate value

IMMED + 1.

cmpgtu

compare greater than unsigned

Operation: if ((unsigned) rA > (unsigned) rB)

then $rC \leftarrow 1$ else $rC \leftarrow 0$

Assembler Syntax: cmpgtu rC, rA, rB
Example: cmpgtu r6, r7, r8

Description: If rA > rB, then stores 1 to rC; otherwise stores 0 to rC.

Usage: cmpgtu performs the unsigned > operation of the C programming language.

Pseudoinstruction: cmpgtu is implemented with the cmpltu instruction by swapping its rA and rB

operands.

cmpgtui

compare greater than unsigned immediate

Operation: if ((unsigned) rA > (unsigned) IMMED)

then $rB \leftarrow 1$ else $rB \leftarrow 0$

Assembler Syntax: cmpgtui rB, rA, IMMED

Example: cmpgtui r6, r7, 100

Description: Zero-extends the immediate value IMMED to 32 bits and compares it to the value of

rA. If rA > IMMED, then cmpgtui stores 1 to rB; otherwise stores 0 to rB.

Usage: cmpgtui performs the unsigned > operation of the C programming language. The

maximum allowed value of IMMED is 65534. The minimum allowed value is 0.

Pseudoinstruction: cmpgtui is implemented using a cmpgeui instruction with an immediate value

IMMED + 1.

cmple

compare less than or equal signed

Operation: if ((signed) rA <= (signed) rB)

then $rC \leftarrow 1$ else $rC \leftarrow 0$

Assembler Syntax: cmple rC, rA, rB

Example: cmple r6, r7, r8

Description: If rA <= rB, then stores 1 to rC; otherwise stores 0 to rC.

Usage: cmple performs the signed <= operation of the C programming language.

Pseudoinstruction: cmple is implemented with the cmpge instruction by swapping its rA and rB

operands.

cmplei

compare less than or equal signed immediate

Operation: if ((signed) rA < (signed) IMMED)

then $rB \leftarrow 1$ else $rB \leftarrow 0$

Assembler Syntax: cmplei rB, rA, IMMED Example: cmplei r6, r7, 100

Description: Sign-extends the immediate value IMMED to 32 bits and compares it to the value of

rA. If rA \leftarrow = σ (IMMED), then cmplei stores 1 to rB; otherwise stores 0 to rB.

Usage: cmplei performs the signed <= operation of the C programming language. The

maximum allowed value of IMMED is 32766. The minimum allowed value is -32769.

Pseudoinstruction: cmplei is implemented using a cmplti instruction with an immediate value

IMMED + 1.

cmpleu compare less than or equal unsigned

Operation: if ((unsigned) rA < (unsigned) rB)

then $rC \leftarrow 1$ else $rC \leftarrow 0$

Assembler Syntax: cmpleu rC, rA, rB

Example: cmpleu r6, r7, r8

Description: If rA <= rB, then stores 1 to rC; otherwise stores 0 to rC.

Usage: cmpleu performs the unsigned <= operation of the C programming language.

Pseudoinstruction: cmpleu is implemented with the cmpgeu instruction by swapping its rA and rB

operands.

cmpleui

compare less than or equal unsigned immediate

Operation: if ((unsigned) rA <= (unsigned) IMMED)

then $rB \leftarrow 1$ else $rB \leftarrow 0$

Assembler Syntax: cmpleui rB, rA, IMMED

Example: cmpleui r6, r7, 100

Description: Zero-extends the immediate value IMMED to 32 bits and compares it to the value of

rA. If rA <= IMMED, then cmpleui stores 1 to rB; otherwise stores 0 to rB.

Usage: cmpleui performs the unsigned <= operation of the C programming language. The

maximum allowed value of IMMED is 65534. The minimum allowed value is 0.

Pseudoinstruction: cmpleui is implemented using a cmpltui instruction with an immediate value

IMMED + 1.

cmplt

compare less than signed

Operation: if ((signed) rA < (signed) rB)

then $rC \leftarrow 1$ else $rC \leftarrow 0$

Assembler Syntax: cmplt rC, rA, rB Example: cmplt r6, r7, r8

Description: If rA < rB, then stores 1 to rC; otherwise stores 0 to rC.

Usage: cmplt performs the signed < operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В					С					0x	10					0					0x	За		

cmplti

compare less than signed immediate

Operation: if ((signed) rA < (signed) σ (IMM16))

then $rB \leftarrow 1$ else $rB \leftarrow 0$

Assembler Syntax: cmplti rB, rA, IMM16

Example: cmplti r6, r7, 100

Description: Sign-extends the 16-bit immediate value IMM16 to 32 bits and compares it to the value

of rA. If rA < σ (IMM16), then cmplti stores 1 to rB; otherwise stores 0 to rB.

Usage: cmplti performs the signed < operation of the C programming language.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

cmpltu

compare less than unsigned

Operation: if ((unsigned) rA < (unsigned) rB)

then $rC \leftarrow 1$ else $rC \leftarrow 0$

Assembler Syntax: cmpltu rC, rA, rB Example: cmpltu r6, r7, r8

Description: If rA < rB, then stores 1 to rC; otherwise stores 0 to rC.

Usage: cmpltu performs the unsigned < operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В					С					0x	30					0					0х	За		

cmpltui

compare less than unsigned immediate

Operation: if ((unsigned) rA < (unsigned) (0x0000 : IMM16))

then $rB \leftarrow 1$ else $rB \leftarrow 0$

Assembler Syntax: cmpltui rB, rA, IMM16

Example: cmpltui r6, r7, 100

Description: Zero-extends the 16-bit immediate value IMM16 to 32 bits and compares it to the value

of rA. If rA < (0x0000: IMM16), then cmpltui stores 1 to rB; otherwise stores 0 to rB.

Usage: cmpltui performs the unsigned < operation of the C programming language.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit unsigned immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMI	Л 16	i									0>	30		

cmpne

compare not equal

Operation: if (rA != rB)

then $rC \leftarrow 1$ else $rC \leftarrow 0$

Assembler Syntax: cmpne rC, rA, rB

Example: cmpne r6, r7, r8

Description: If rA!= rB, then stores 1 to rC; otherwise stores 0 to rC.

Usage: cmpne performs the != operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B C 0x18 0 0x3a

cmpnei

compare not equal immediate

Operation: if $(rA != \sigma(IMM16))$

then $rB \leftarrow 1$ else $rB \leftarrow 0$

Assembler Syntax: cmpnei rB, rA, IMM16

Example: cmpnei r6, r7, 100

Description: Sign-extends the 16-bit immediate value IMM16 to 32 bits and compares it to the value

of rA. If rA $!= \sigma$ (IMM16), then cmpnei stores 1 to rB; otherwise stores 0 to rB.

Usage: cmpnei performs the != operation of the C programming language.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B IMM16 Ox18

custom

custom instruction

Operation: if c == 1

then $rC \leftarrow f_N(rA, rB, A, B, C)$ else $\emptyset \leftarrow f_N(rA, rB, A, B, C)$

Assembler Syntax: custom N, xC, xA, xB

Where xA means either general purpose register rA, or custom register cA.

Example: custom 0, c6, r7, r8

Description: The custom opcode provides access to up to 256 custom instructions allowed by the

Nios II architecture. The function implemented by a custom instruction is user-defined and is specified at system generation time. The 8-bit immediate N field specifies which custom instruction to use. Custom instructions can use up to two parameters, xA and

xB, and can optionally write the result to a register xC.

Usage: To access a custom register inside the custom instruction logic, clear the bit readra,

readrb, or writerc that corresponds to the register field. In assembler syntax, the notation cN refers to register N in the custom register file and causes the assembler to clear the c bit of the opcode. For example, custom 0, c3, r5, r0 performs custom instruction 0, operating on general-purpose registers r5 and r0, and stores the

result in custom register 3.


Instruction Type: R

Instruction Fields: A = Register index of operand A

B = Register index of operand B C = Register index of operand C

N = 8-bit number that selects instruction readra = 1 if instruction uses rA, 0 otherwise readrb = 1 if instruction uses rB, 0 otherwise

writerc = 1 if instruction provides result for rC, 0 otherwise



div

divide

Operation: $rC \leftarrow rA \div rB$

Assembler Syntax: div rC, rA, rB Example: div r6, r7, r8

Description: Treating rA and rB as signed integers, this instruction divides rA by rB and then stores

the integer portion of the resulting quotient to rC. After attempted division by zero, the value of rC is undefined. There is no divide-by-zero exception. After dividing -2147483648 by -1, the value of rC is undefined (the number +2147483648 is not

representable in 32 bits). There is no overflow exception.

Nios II processors that do not implement the div instruction cause an

unimplemented-instruction exception.

Usage: Remainder of Division:

If the result of the division is defined, then the remainder can be computed in rD using

the following instruction sequence:

div rC, rA, rB ; The original div operation

mul rD, rC, rB

sub rD, rA, rD ; rD = remainder

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

Α	В	С	0x25	0	0x3a

divu

divide unsigned

Operation: $rC \leftarrow rA \div rB$

Assembler Syntax: divu rC, rA, rB Example: divu r6, r7, r8

Description: Treating rA and rB as unsigned integers, this instruction divides rA by rB and then

stores the integer portion of the resulting quotient to rC. After attempted division by

zero, the value of rC is undefined. There is no divide-by-zero exception.

Nios II processors that do not implement the divu instruction cause an

unimplemented-instruction exception.

Usage: Remainder of Division:

If the result of the division is defined, then the remainder can be computed in rD using

the following instruction sequence:

divu rC, rA, rB ; The original divu operation

mul rD, rC, rB

sub rD, rA, rD ; rD = remainder

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Γ			Α					В					С					0x	24					0					0>	κЗа		

eret

exception return

Operation: status ← estatus

 $PC \leftarrow ea$

Assembler Syntax: eret **Example:** eret

Description: Copies the value of estatus into the status register, and transfers execution to the

address in ea. In user mode, this instruction generates an access-violation exception.

Use eret to return from traps, external interrupts, and other exception-handling

routines. Note that before returning from hardware interrupt exceptions, the exception

handler must adjust the ea register.

Instruction Type: R
Instruction Fields: None

	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Ī		()x1	b				0					0					0x	01					0					0>	За		

flushd

flush data cache line

Operation: Flushes the data-cache line associated with address rA + σ (IMM16).

Assembler Syntax: flushd IMM16(rA)

Example: flushd -100(r6)

Description: flushd computes the effective address specified by the sum of rA and the signed 16-

bit immediate value. Ignoring the tag, ${\tt flushd}$ identifies the data-cache line associated with the computed effective address. Once ${\tt flushd}$ identifies the cache line, if the line is dirty, ${\tt flushd}$ writes the line back to memory and invalidates the line. A cache line is dirty when one or more words of the cache line have been modified by

the processor, but are not yet written to memory.

If the Nios II processor core does not have a data cache, the flushd instruction

performs no operation.

Usage: flushed flushes all dirty data in the cache line, even if the addressed memory location

is not in the cache. By contrast, the flushda instruction does nothing if the

addressed memory location is not in the cache.

For more information on data cache, see the Cache & Tightly-Coupled Memory

chapter in the Nios II Software Developer's Handbook.

Instruction Type:

Instruction Fields: A = Register index of operand rA

IMM16 = 16-bit signed immediate value

_	31	30	29	28	 26	25	24	23	22	21	20	 	17	16	15		13	12	• • •	10	Ü	8	 6	_	-			
			Δ				Λ									INAN	116									۸	/2h	

flushda

flush data-cache address

Operation: Flushes dirty data for address rA + σ (IMM16) out of memory.

Assembler Syntax: flushda IMM16(rA)

Example: flushda -100(r6)

Description: flushda computes the effective address specified by the sum of rA and the signed

16-bit immediate value. If the data cache contains dirty data for the effective address, flushda writes the dirty cache line back to memory and invalidates the line. If the data cache does not contain dirty data for the effective address, flushda does nothing. A cache line is dirty when one or more words of the cache line have been modified by the processor, but are not yet written to memory.

nounted by the processor, but are not yet written to memory.

If the Nios II processor core does not have a data cache, the flushda instruction

performs no operation.

Usage: flushda flushes the cache line only if the addressed memory location is dirty. By

contrast, the flushd instruction flushes all dirty data in the cache line, even if the

addressed memory location is not dirty.

For more information on data cache, see the Cache & Tightly-Coupled Memory

chapter in the Nios II Software Developer's Handbook.

Instruction Type:

Instruction Fields: A = Register index of operand rA

IMM16 = 16-bit signed immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

Α	0	IMM16	0x1b

flushi

flush instruction cache line

Operation: Flushes the instruction-cache line associated with address rA.

Assembler Syntax: flushi rA Example: flushi r6

Description: Ignoring the tag, flushi identifies the instruction-cache line associated with the byte

address in rA, and invalidates that line.

If the Nios II processor core does not have an instruction cache, the flushi

instruction performs no operation.

For more information on data cache, see the Cache & Tightly-Coupled Memory

chapter in the Nios II Software Developer's Handbook.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					0					0					0x	0с					0					0х	За		

flushp

flush pipeline

Operation: Flushes the processor pipeline of any pre-fetched instructions.

Assembler Syntax: flushp **Example:** flushp

Description: Ensures that any instructions pre-fetched after the flushp instruction are removed

from the pipeline.

Use flushp before transferring control to newly updated instruction memory.

Instruction Type: R
Instruction Fields: None

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		0					0					0					0x	04					0					0>	За		

initd

initialize data cache line

Operation: Initializes the data-cache line associated with address rA + σ (IMM16).

Assembler Syntax: initd IMM16(rA)

Example: initd 0(r6)

Description: initd computes the effective address specified by the sum of rA and the signed 16-

bit immediate value. Ignoring the tag, initd indentifies the data-cache line associated with the effective address, and then initd invalidates that line.

If the Nios II processor core does not have a data cache, the initd instruction

performs no operation.

In user mode, this instruction generates an access-violation exception.

Usage: The instruction is used to initialize the processor's data cache. After processor reset

and before accessing data memory, use initd to invalidate each line of the data

cache.

For more information on data cache, see the Cache & Tightly-Coupled Memory

chapter in the Nios II Software Developer's Handbook.

Instruction Type:

Instruction Fields: A = Register index of operand rA

IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					0										IMN	/116										0х	33		

initi

initialize instruction cache line

Operation: Initializes the instruction-cache line associated with address rA.

Assembler Syntax: initi rA Example: initi r6

Description: Ignoring the tag, initi identifies the instruction-cache line associated with the byte

address in ra, and initi invalidates that line.

If the Nios II processor core does not have an instruction cache, the initi instruction

performs no operation.

In user mode, this instruction generates an access-violation exception.

Usage: This instruction is used to initialize the processor's instruction cache. Immediately after

processor reset, use initi to invalidate each line of the instruction cache.

For more information on instruction cache, see the Cache & Tightly-Coupled Memory

chapter in the Nios II Software Developer's Handbook.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					0					0					0x	29					0					0>	За		

jmp

computed jump

Operation: $PC \leftarrow rA$ Assembler Syntax: jmp rAExample: jmp r12

Description: Transfers execution to the address contained in register rA.

Usage: It is illegal to jump to the address contained in register r31. To return from subroutines

called by call or callr, use ret instead of jmp.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					0					0					0x	0d					0					0>	За		

ldb / ldbio

load byte from memory or I/O peripheral

Operation: $rB \leftarrow \sigma (Mem8[rA + \sigma (IMM16)])$

Assembler Syntax: ldb rB, byte offset (rA)

ldbio rB, byte offset(rA)

Example: ldb r6, 100(r5)

Description: Computes the effective byte address specified by the sum of rA and the instruction's

signed 16-bit immediate value. Loads register rB with the desired memory byte, sign extending the 8-bit value to 32 bits. In Nios II processor cores with a data cache, this instruction may retrieve the desired data from the cache instead of from memory.

Use the ldbio instruction for peripheral I/O. In processors with a data cache, ldbio

bypasses the cache and is guaranteed to generate an Avalon data transfer. In

processors without a data cache, ldbio acts like ldb.

For more information on data cache, see the Cache & Tightly-Coupled Memory chapter

in the Nios II Software Developer's Handbook.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	<i>I</i> 116										0х	:07		

Instruction format for 1db

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	/116										0x	27		

Instruction format for ldbio

Idbu / Idbuio

load unsigned byte from memory or I/O peripheral

Operation: $rB \leftarrow 0x0000000 : Mem8[rA + \sigma(IMM16)]$

Assembler Syntax: ldbu rB, byte offset (rA)

ldbuio rB, byte offset(rA)

Example: ldbu r6, 100(r5)

Description: Computes the effective byte address specified by the sum of rA and the instruction's

signed 16-bit immediate value. Loads register rB with the desired memory byte, zero

extending the 8-bit value to 32 bits.

Usage: In processors with a data cache, this instruction may retrieve the desired data from the

cache instead of from memory. Use the ldbuio instruction for peripheral I/O. In processors with a data cache, ldbuio bypasses the cache and is guaranteed to generate an Avalon data transfer. In processors without a data cache, ldbuio acts

like 1dbu.

For more information on data cache, see the Cache & Tightly-Coupled Memory

chapter in the Nios II Software Developer's Handbook.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Ī			Α					В										IMN	/116										0>	:03		

Instruction format for ldbu

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	/116										0>	23		

Instruction format for ldbuio

Idh / Idhio

load halfword from memory or I/O peripheral

Operation: $rB \leftarrow \sigma \text{ (Mem16[rA + } \sigma \text{ (IMM16)])}$

Assembler Syntax: ldh rB, byte_offset(rA)

ldhio rB, byte offset(rA)

Example: ldh r6, 100(r5)

Description: Computes the effective byte address specified by the sum of rA and the instruction's

signed 16-bit immediate value. Loads register rB with the memory halfword located at the effective byte address, sign extending the 16-bit value to 32 bits. The effective byte address must be halfword aligned. If the byte address is not a multiple of 2, the

operation is undefined.

Usage: In processors with a data cache, this instruction may retrieve the desired data from the

cache instead of from memory. Use the <code>ldhio</code> instruction for peripheral I/O. In processors with a data cache, <code>ldhio</code> bypasses the cache and is guaranteed to generate an Avalon data transfer. In processors without a data cache, <code>ldhio</code> acts like

ldh.

For more information on data cache, see the Cache & Tightly-Coupled Memory chapter

in the Nios II Software Developer's Handbook.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	/116										0>	кOf		

Instruction format for 1dh

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	/116										02	c2f		

Instruction format for ldhio

Idhu / Idhuio

load unsigned halfword from memory or I/O peripheral

Operation: $rB \leftarrow 0x0000 : Mem16[rA + \sigma(IMM16)]$

Assembler Syntax: ldhu rB, byte offset (rA)

ldhuio rB, byte offset(rA)

Example: 1dhu r6, 100(r5)

Description: Computes the effective byte address specified by the sum of rA and the instruction's

signed 16-bit immediate value. Loads register rB with the memory halfword located at the effective byte address, zero extending the 16-bit value to 32 bits. The effective byte address must be halfword aligned. If the byte address is not a multiple of 2, the

operation is undefined.

Usage: In processors with a data cache, this instruction may retrieve the desired data from the

cache instead of from memory. Use the ldhuio instruction for peripheral I/O. In processors with a data cache, ldhuio bypasses the cache and is guaranteed to generate an Avalon data transfer. In processors without a data cache, ldhuio acts

like 1dhu.

For more information on data cache, see the Cache & Tightly-Coupled Memory

chapter in the Nios II Software Developer's Handbook.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB IMM16 = 16-bit signed immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

Α	В	IMM16	0x0b

Instruction format for ldhu

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	<i>I</i> 116										0>	(2b		

Instruction format for ldhuio

Idw / Idwio

load 32-bit word from memory or I/O peripheral

Operation: $rB \leftarrow Mem32[rA + \sigma(IMM14)]$

Assembler Syntax: ldw rB, byte offset(rA)

ldwio rB, byte offset(rA)

Example: ldw r6, 100(r5)

Description: Computes the effective byte address specified by the sum of rA and the instruction's

signed 16-bit immediate value. Loads register rB with the memory word located at the effective byte address. The effective byte address must be word aligned. If the byte

address is not a multiple of 4, the operation is undefined.

Usage: In processors with a data cache, this instruction may retrieve the desired data from the

cache instead of from memory. Use the ldwio instruction for peripheral I/O. In processors with a data cache, ldwio bypasses the cache and memory. Use the ldwio instruction for peripheral I/O. In processors with a data cache, ldwio bypasses the cache and is guaranteed to generate an Avalon data transfer. In

processors without a data cache, ldwio acts like ldw.

For more information on data cache, see the Cache & Tightly-Coupled Memory

chapter in the Nios II Software Developer's Handbook.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	<i>I</i> 116										0>	17		

Instruction format for ldw

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	/116										Ох	37		

Instruction format for ldwio

mov

move register to register

 $\textbf{Operation:} \qquad \qquad rC \leftarrow rA$

Assembler Syntax: mov rC, rA Example: mov r6, r7

Description: Moves the contents of rA to rC.

Pseudoinstruction: mov is implemented as add rC, rA, r0.

movhi

move immediate into high halfword

Operation: $rB \leftarrow (IMMED: 0x0000)$ Assembler Syntax:movhi rB, IMMEDExample:movhi r6, 0x8000

Description: Writes the immediate value IMMED into the high halfword of rB, and clears the lower

halfword of rB to 0x0000.

Usage: The maximum allowed value of IMMED is 65535. The minimum allowed value is 0. To

load a 32-bit constant into a register, first load the upper 16 bits using a movhi pseudoinstruction. The %hi() macro can be used to extract the upper 16 bits of a constant or a label. Then, load the lower 16 bits with an ori instruction. The %lo() macro can be used to extract the lower 16 bits of a constant or label as shown below.

movhi rB, %hi(value)
ori rB, rB, %lo(value)

An alternative method to load a 32-bit constant into a register uses the %hiadj() macro

and the addi instruction as shown below.

movhi rB, %hiadj(value)
addi rB, rB, %lo(value)

Pseudoinstruction: movhi is implemented as orhi rB, r0, IMMED.

movi move signed immediate into word

 $\begin{array}{lll} \text{Operation:} & rB \leftarrow \sigma \text{ (IMMED)} \\ \text{Assembler Syntax:} & \text{movi rB, IMMED} \\ \text{Example:} & \text{movi r6, -30} \\ \end{array}$

Description: Sign-extends the immediate value IMMED to 32 bits and writes it to rB.

Usage: The maximum allowed value of IMMED is 32767. The minimum allowed value is

-32768. To load a 32-bit constant into a register, see the movhi instruction.

Pseudoinstruction: movi is implemented as addi rB, r0, IMMED.

movia

move immediate address into word

Operation: $rB \leftarrow label$

Assembler Syntax: movia rB, label

Example: movia r6, function_address

Description: Writes the address of label to rB.

Pseudoinstruction: movia is implemented as:

orhi rB, r0, %hiadj(label)
addi rB, rB, %lo(label)

movui

move unsigned immediate into word

Operation: $rB \leftarrow (0x0000 : IMMED)$ Assembler Syntax: movui rB, IMMED
Example: movui r6, 100

Description: Zero-extends the immediate value IMMED to 32 bits and writes it to rB.

Usage: The maximum allowed value of IMMED is 65535. The minimum allowed value is 0. To

load a 32-bit constant into a register, see the movhi instruction.

Pseudoinstruction: movui is implemented as ori rB, r0, IMMED.

mul

multiply

Operation: $rC \leftarrow (rA \times rB)_{31..0}$ Assembler Syntax: mul rC, rA, rB
Example: mul r6, r7, r8

Description: Multiplies rA times rB and stores the 32 low-order bits of the product to rC. The result

is the same whether the operands are treated as signed or unsigned integers.

Nios II processors that do not implement the mul instruction cause an

unimplemented-instruction exception.

Usage: Carry Detection (unsigned operands):

Before or after the multiply operation, the carry out of the MSB of rC can be detected using the following instruction sequence:

The \mathtt{mulxuu} instruction writes a non-zero value into rD if the multiplication of unsigned numbers will generate a carry (unsigned overflow). If a 0/1 result is desired, follow the \mathtt{mulxuu} with the \mathtt{cmpne} instruction.

Overflow Detection (signed operands):

After the multiply operation, overflow can be detected using the following instruction sequence:

The cmplt-mulxss-add instruction sequence writes a non-zero value into rD if the product in rC cannot be represented in 32 bits (signed overflow). If a 0/1 result is desired, follow the instruction sequence with the cmpne instruction.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В					С					0x	27					0					0>	За		

muli

multiply immediate

Operation: $rB \leftarrow (rA \times \sigma(IMM16))_{31..0}$ Assembler Syntax: muli rB, rA, IMM16 Example: muli r6, r7, -100

Description: Sign-extends the 16-bit immediate value IMM16 to 32 bits and multiplies it by the value

of rA. Stores the 32 low-order bits of the product to rB. The result is independent of

whether rA is treated as a signed or unsigned number.

Nios II processors that do not implement the ${\tt muli}$ instruction cause an

unimplemented-instruction exception.

Carry Detection and Overflow Detection:

For a discussion of carry and overflow detection, see the mul instruction.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	<i>I</i> 116										0>	(24		

mulxss

multiply extended signed/signed

Operation: $rC \leftarrow ((signed) \ rA) \times ((signed) \ rB))_{63..32}$

Assembler Syntax: mulxss rC, rA, rB

Example: mulxss r6, r7, r8

Description: Treating rA and rB as signed integers, mulxss multiplies rA times rB, and stores the

32 high-order bits of the product to rC.

Nios II processors that do not implement the mulxss instruction cause an

unimplemented-instruction exception.

Use mulxss and mul to compute the full 64-bit product of two 32-bit signed integers.

Furthermore, mulxss can be used as part of the calculation of a 128-bit product of two 64-bit signed integers. Given two 64-bit integers, each contained in a pair of 32-bit registers, (S1: U1) and (S2: U2), their 128-bit product is (U1 \times U2) + ((S1 \times U2) << 32) + ((U1 \times S2) << 32) + ((S1 \times S2) << 64). The mulxss and mul instructions

are used to calculate the 64-bit product S1 \times S2.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

Α	В	С	0x1f	0	0x3a

mulxsu

multiply extended signed/unsigned

Operation: $rC \leftarrow ((signed) \ rA) \times ((unsigned) \ rB))_{63..32}$

Assembler Syntax: mulxsu rC, rA, rB

Example: mulxsu r6, r7, r8

Description: Treating rA as a signed integer and rB as an unsigned integer, mulxsu multiplies rA

times rB, and stores the 32 high-order bits of the product to rC.

Nios II processors that do not implement the mulxsu instruction cause an

unimplemented-instruction exception.

Usage: mulxsu can be used as part of the calculation of a 128-bit product of two 64-bit signed

integers. Given two 64-bit integers, each contained in a pair of 32-bit registers, (S1: U1) and (S2: U2), their 128-bit product is: $(U1 \times U2) + ((S1 \times U2) << 32) + ((U1 \times S2) << 32) + ((S1 \times S2) << 64)$. The mulxsu and mul instructions are used to calculate

the two 64-bit products S1 \times U2 and U1 \times S2.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В					С					0x	17					0					0>	За		

mulxuu

multiply extended unsigned/unsigned

Operation: $rC \leftarrow ((unsigned) \ rA) \times ((unsigned) \ rB))_{63,32}$

Assembler Syntax: mulxuu rC, rA, rB Example: mulxuu r6, r7, r8

Description: Treating rA and rB as unsigned integers, mulxuu multiplies rA times rB and

stores the 32 high-order bits of the product to rC.

Nios II processors that do not implement the mulxss instruction cause an

unimplemented-instruction exception.

Usage: Use mulxuu and mul to compute the 64-bit product of two 32-bit unsigned

> integers. Furthermore, mulxuu can be used as part of the calculation of a 128bit product of two 64-bit signed integers. Given two 64-bit signed integers, each contained in a pair of 32-bit registers, (S1: U1) and (S2: U2), their 128-bit product is (U1 \times U2) + ((S1 \times U2) << 32) + ((U1 \times S2) << 32) + ((S1 \times S2) << 64). The mulxuu and mul instructions are used to calculate the 64-bit product

 $U1 \times U2$

mulxuu also can be used as part of the calculation of a 128-bit product of two 64-bit unsigned integers. Given two 64-bit unsigned integers, each contained in a pair of 32-bit registers, (T1 : U1) and (T2 : U2), their 128-bit product is (U1 \times U2) + $((U1 \times T2) \ll 32)$ + $((T1 \times U2) \ll 32)$ + $((T1 \times T2) \ll 64)$. The mulxuu and mul instructions are used to calculate the four 64-bit products U1 × U2, U1

 \times T2, T1 \times U2, and T1 \times T2.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

> B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9

٠.	-00		 	 0		 	 		 •••	 	• •		 • • •	 •	_	•	•	 •	•		•	•
		Α			В			С			0x	07			0				0>	За		

nextpc

get address of following instruction

Operation: $rC \leftarrow PC + 4$ Assembler Syntax: $nextpc \ rC$ Example: $nextpc \ r6$

Description: Stores the address of the next instruction to register rC.

Usage: A relocatable code fragment can use nextpc to calculate the address of its data

segment. nextpc is the only way to access the PC directly.

Instruction Type: R

Instruction Fields: C = Register index of operand rC

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		0					0					С					0x	1c					0					0х	За		

nop

no operation

Operation: None
Assembler Syntax: nop
Example: nop

Description: nop does nothing.

Pseudoinstruction: nop is implemented as add r0, r0, r0.

nor

bitwise logical nor

 $\begin{array}{lll} \text{Operation:} & \text{rC} \leftarrow \sim (\text{rA} \mid \text{rB}) \\ \\ \text{Assembler Syntax:} & \text{nor rC, rA, rB} \\ \\ \text{Example:} & \text{nor r6, r7, r8} \\ \end{array}$

Description: Calculates the bitwise logical NOR of rA and rB and stores the result in rC.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В					С					0x	06					0					0	αЗа		

or

bitwise logical or

Operation: $rC \leftarrow rA \mid rB$

Assembler Syntax: or rC, rA, rB Example: or r6, r7, r8

Description: Calculates the bitwise logical OR of rA and rB and stores the result in rC.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B C Ox16 0 Ox3a

orhi

bitwise logical or immediate into high halfword

Operation: $rB \leftarrow rA \mid (IMM16:0x0000)$ Assembler Syntax:orhi rB, rA, IMM16Example:orhi r6, r7, 100

Description: Calculates the bitwise logical OR of rA and (IMM16 : 0x0000) and stores the result in

rB.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	И16										0>	(34		

ori

bitwise logical or immediate

 $\begin{tabular}{ll} \mbox{Operation:} & \mbox{rB} \leftarrow \mbox{rA} \mid (0x0000: \mbox{IMM16}) \\ \mbox{Assembler Syntax:} & \mbox{ori rB}, \mbox{rA}, \mbox{IMM16} \\ \end{tabular}$

Example: ori r6, r7, 100

Description: Calculates the bitwise logical OR of rA and (0x0000 : IMM16) and stores the result in

rB.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit unsigned immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B IMM16 0x14

rdctl

read from control register

Operation: $rC \leftarrow ctlN$

Assembler Syntax: rdctl rC, ctlN

Example: rdctl r3, ctl31

Description: Reads the value contained in control register ctIN and writes it to register rC. In user

mode, this instruction generates an access-violation exception.

Instruction Type: R

Instruction Fields: C = Register index of operand rC

N = Control register index of operand ctlN

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		0					0					С					0x	26					Ν					0>	За		

ret

return from subroutine

Operation: $PC \leftarrow ra$

Assembler Syntax: ret Example: ret

Description: Transfers execution to the address in ra.

Usage: Any subroutine called by call or callr must use ret to return.

Instruction Type: R
Instruction Fields: None

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	(0x1	f				0					0					0x	05					0					0х	За		

rol

rotate left

Operation: $rC \leftarrow rA$ rotated left $rB_{4..0}$ bit positions

Assembler Syntax: rol rC, rA, rB

Example: rol r6, r7, r8

Description: Rotates rA left by the number of bits specified in rB_{4.0} and stores the result in rC. The

bits that shift out of the register rotate into the least-significant bit positions. Bits 31-5

of rB are ignored.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B C 0x03 0 0x3a

roli

rotate left immediate

Operation: $rC \leftarrow rA$ rotated left IMM5 bit positions

Assembler Syntax: roli rC, rA, IMM5

Example: roli r6, r7, 3

Description: Rotates rA left by the number of bits specified in IMM5 and stores the result in rC. The

bits that shift out of the register rotate into the least-significant bit positions.

Usage: In addition to the rotate-left operation, roli can be used to implement a rotate-right

operation. Rotating left by (32 - IMM5) bits is the equivalent of rotating right by IMM5

bits.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

C = Register index of operand rC

IMM5 = 5-bit unsigned immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					0					С					0x	02				I	ΜN	15				0>	αЗа		

ror

rotate right

Operation: $rC \leftarrow rA$ rotated right $rB_{4..0}$ bit positions

Assembler Syntax: ror rC, rA, rB Example: ror r6, r7, r8

Description: Rotates rA right by the number of bits specified in rB_{4.0} and stores the result in rC. The

bits that shift out of the register rotate into the most-significant bit positions. Bits 31–5

of rB are ignored.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B C 0x0b 0 0x3a

sII

shift left logical

Description: Shifts rA left by the number of bits specified in rB_{4.0} (inserting zeroes), and then stores

the result in rC. sll performs the << operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B C 0x13 0 0x3a

slli

shift left logical immediate

Operation: $rC \leftarrow rA \ll IMM5$

Assembler Syntax: slli rC, rA, IMM5 Example: slli r6, r7, 3

Description: Shifts rA left by the number of bits specified in IMM5 (inserting zeroes), and then stores

the result in rC.

Usage: slli performs the << operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

C = Register index of operand rC

IMM5 = 5-bit unsigned immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					0					С					0x	12				ı	MM	15				0>	αЗа		

sra

shift right arithmetic

Operation: $rC \leftarrow (signed) \ rA >> ((unsigned) \ rB_{4..0})$

Assembler Syntax: sra rC, rA, rB Example: sra r6, r7, r8

Description: Shifts rA right by the number of bits specified in rB_{4.0} (duplicating the sign bit), and then

stores the result in rC. Bits 31-5 are ignored.

Usage: sra performs the signed >> operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B C 0x3b 0 0x3a

srai

shift right arithmetic immediate

Operation: $rC \leftarrow (signed) \ rA >> ((unsigned) \ IMM5)$

Assembler Syntax: srai rC, rA, IMM5 Example: srai r6, r7, 3

Description: Shifts rA right by the number of bits specified in IMM5 (duplicating the sign bit), and

then stores the result in rC.

Usage: srai performs the signed >> operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

C = Register index of operand rC

IMM5 = 5-bit unsigned immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					0					С					0x	За				I	MM	5				0>	За		

srl

shift right logical

Operation: $rC \leftarrow (unsigned) \ rA >> ((unsigned) \ rB_{4..0})$

Assembler Syntax: srl rC, rA, rB Example: srl r6, r7, r8

Description: Shifts rA right by the number of bits specified in rB_{4.0} (inserting zeroes), and then

stores the result in rC. Bits 31-5 are ignored.

Usage: srl performs the unsigned >> operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

R H

srli

shift right logical immediate

Operation: $rC \leftarrow (unsigned) rA >> ((unsigned) IMM5)$

Assembler Syntax: srli rC, rA, IMM5 Example: srli r6, r7, 3

Description: Shifts rA right by the number of bits specified in IMM5 (inserting zeroes), and then

stores the result in rC.

Usage: srli performs the unsigned >> operation of the C programming language.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

C = Register index of operand rC IMM5 = 5-bit unsigned immediate value

stb / stbio

store byte to memory or I/O peripheral

Operation: Mem8[rA + σ (IMM16)] \leftarrow rB_{7..0}

Assembler Syntax: stb rB, byte offset(rA)

stbio rB, byte offset (rA)

Example: stb r6, 100(r5)

Description: Computes the effective byte address specified by the sum of rA and the instruction's

signed 16-bit immediate value. Stores the low byte of rB to the memory byte specified

by the effective address.

Usage: In processors with a data cache, this instruction may not generate an Avalon bus cycle

to non-cache data memory immediately. Use the stbio instruction for peripheral I/O. In processors with a data cache, stbio bypasses the cache and is guaranteed to generate an Avalon data transfer. In processors without a data cache, stbio acts like

stb.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B IMM16

Instruction format for stb

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B IMM16

0x25

Instruction format for stbio

sth / sthio

store halfword to memory or I/O peripheral

Operation: $Mem16[rA + \sigma(IMM16)] \leftarrow rB_{15..0}$

Assembler Syntax: sth rB, byte offset(rA)

sthio rB, byte offset(rA)

Example: sth r6, 100(r5)

Description: Computes the effective byte address specified by the sum of rA and the instruction's

signed 16-bit immediate value. Stores the low halfword of rB to the memory location specified by the effective byte address. The effective byte address must be halfword

aligned. If the byte address is not a multiple of 2, the operation is undefined.

Usage: In processors with a data cache, this instruction may not generate an Avalon data

transfer immediately. Use the sthio instruction for peripheral I/O. In processors with a data cache, sthio bypasses the cache and is guaranteed to generate an Avalon data

transfer. In processors without a data cache, sthio acts like sth.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

А	В	IMM16	0x0d
---	---	-------	------

Instruction format for sth

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B IMM16 Ox2d

Instruction format for sthio

stw / stwio

store word to memory or I/O peripheral

Operation: Mem32[rA + σ (IMM16)] \leftarrow rB

Assembler Syntax: stw rB, byte_offset(rA)

stwio rB, byte offset(rA)

Example: stw r6, 100(r5)

Description: Computes the effective byte address specified by the sum of rA and the instruction's

signed 16-bit immediate value. Stores rB to the memory location specified by the effective byte address. The effective byte address must be word aligned. If the byte

address is not a multiple of 4, the operation is undefined.

Usage: In processors with a data cache, this instruction may not generate an Avalon data

transfer immediately. Use the stwio instruction for peripheral I/O. In processors with a data cache, stwio bypasses the cache and is guaranteed to generate an Avalon

bus cycle. In processors without a data cache, stwio acts like stw.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit signed immediate value

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	Л 16										0>	(15		

Instruction format for stw

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					В										IMN	<i>I</i> 116										0>	35		

Instruction format for stwio

Sub subtract

Operation: $rC \leftarrow rA - rB$ Assembler Syntax: sub rC, rA, rB
Example: sub r6, r7, r8

Description: Subtract rB from rA and store the result in rC.

Usage: Carry Detection (unsigned operands):

The carry bit indicates an unsigned overflow. Before or after a sub operation, a carry out of the MSB can be detected by checking whether the first operand is less than the second operand. The carry bit can be written to a register, or a conditional branch can be taken based on the carry condition. Both cases are shown below.

```
sub rC, rA, rB ; The original sub operation (optional)
cmpltu rD, rA, rB ; rD is written with the carry bit
sub rC, rA, rB ; The original sub operation (optional)
bltu rA, rB, label ; Branch if carry was generated
```

Overflow Detection (signed operands):

Detect overflow of signed subtraction by comparing the sign of the difference that is written to rC with the signs of the operands. If rA and rB have different signs, and the sign of rC is different than the sign of rA, an overflow occurred. The overflow condition can control a conditional branch, as shown below.

```
sub rC, rA, rB ; The original sub operation
xor rD, rA, rB ; Compare signs of rA and rB
xor rE, rA, rC ; Compare signs of rA and rC
and rD, rD, rE ; Combine comparisons
blt rD, r0, label ; Branch if overflow occurred
```

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Α							В					С					0x	39					0					0>	кЗа		

subi

subtract immediate

Operation: $rB \leftarrow rA - \sigma (IMMED)$

Assembler Syntax: subi rB, rA, IMMED

Example: subi r8, r8, 4

Description: Sign-extends the immediate value IMMED to 32 bits, subtracts it from the value of rA

and then stores the result in rB.

Usage: The maximum allowed value of IMMED is 32768. The minimum allowed value is

-32767.

Pseudoinstruction: subi is implemented as addi rB, rA, -IMMED

sync

memory synchronization

Operation: None
Assembler Syntax: sync
Example: sync

Description: Forces all pending memory accesses to complete before allowing execution of

subsequent instructions. In processor cores that support in-order memory accesses

only, this instruction performs no operation.

Instruction Type: R
Instruction Fields: None

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		0					0					0					0x	36					0					0>	За		

trap

Operation: estatus ← status

 $\begin{aligned} & \text{PIE} \leftarrow 0 \\ & \text{U} \leftarrow 0 \\ & \text{ea} \leftarrow \text{PC} + 4 \end{aligned}$

PC ← exception handler address

Assembler Syntax: trap **Example:** trap

Description: Saves the address of the next instruction in register ea, saves the contents of the

 $\verb|status| \ensuremath{\textit{register}} \ensuremath{\textit{in}} \ensuremath{\textit{estatus}}, \ensuremath{\textit{disables}} \ensuremath{\textit{interrupts}}, \ensuremath{\textit{forces}} \ensuremath{\textit{the}} \ensuremath{\textit{processor}} \ensuremath{\textit{into}} \ensuremath{\textit{estatus}}, \ensuremath{\textit{disables}} \ensuremath{\textit{interrupts}}, \ensuremath{\textit{forces}} \ensuremath{\textit{the}} \ensuremath{\textit{processor}} \ensuremath{\textit{into}} \ensuremath{\textit{estatus}} \ensuremath{\textit{estatus}$

supervisor mode, and transfers execution to the exception handler. The address of the

exception handler is specified at system generation time.

Usage: To return from the exception handler, execute an eret instruction.

Instruction Type: R
Instruction Fields: None

31 30 29 28 27	26 25 24 23 22	21 20 19 18 17	16 15 14 13 12 11	10 9 8 7 6	5 4 3 2 1 0
0	0	0x1d	0x2d	0	0x3a

wrctl

write to control register

Operation: $ctIN \leftarrow rA$

Assembler Syntax: wrctl ctlN, rA Example: wrctl ctl6, r3

Description: Writes the value contained in register rA to the control register ctlN. wrctl generates

an access-violation exception if issued in user mode.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

N = Control register index of operand ctlN

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		Α					0					0					0x	2e					Ν					0>	За		

xor

bitwise logical exclusive or

Operation: $rC \leftarrow rA \land rB$

Assembler Syntax: xor rC, rA, rB Example: xor r6, r7, r8

Description: Calculates the bitwise logical exclusive XOR of rA and rB and stores the result in rC.

Instruction Type: R

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB C = Register index of operand rC

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B C Ox1e O Ox3a

xorhi

bitwise logical exclusive or immediate into high halfword

Operation: $rB \leftarrow rA \land (IMM16:0x0000)$ Assembler Syntax: xorhi rB, rA, IMM16Example: xorhi r6, r7, 100

Description: Calculates the bitwise logical exclusive XOR of rA and (IMM16 : 0x0000) and stores

the result in rB.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit unsigned immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B B OX3c

xori

bitwise logical exclusive or immediate

Operation: $rB \leftarrow rA \land (0x0000 : IMM16)$ Assembler Syntax:xori rB, rA, IMM16Example:xori r6, r7, 100

Description: Calculates the bitwise logical exclusive or of rA and (0x0000: IMM16) and stores the

result in rB.

Instruction Type:

Instruction Fields: A = Register index of operand rA

B = Register index of operand rB

IMM16 = 16-bit unsigned immediate value

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

A B IMM16 Ox1c