UR3						
	CB3 P/N Description (EN)	Description (CN)				
	103303 Sealing set UR3, external 103413 Lid set complete UR3 incl. seal	UR3密封圈,外部用 UR3关节盖子,带密封圈				
Robot arm:	122020 Tool Mounting Bracket UR3	UR3法兰盘				
	122030 Base Mounting Bracket incl. Cable 6m UR3	UR3安装基座带6米电缆				
	124122 Joint Size 2 Base UR3	UR3基座				
	124222 Joint Size 2 Shoulder UR3	UR3肩部				
	124321 Joint Size 1 Elbow UR3	UR3肘部				
	124120 Joint Size 0 Wrist 1 UR3	UR3手腕1				
	124220 Joint Size 0 Wrist 2 UR3	UR3手腕2				
	124320 Joint Size 0 Wrist 3 UR3	UR3手腕3				
	104003 Elbow counterpart and lower arm kit UR3	UR3肘部连接主干				
	122973 Controller excl. Teach Pendant UR3	UR3控制箱, 不包含示教器				
	122091 Teach Pendant incl. Touch Screen & power cable	示教器, 带触摸屏和4.5米电缆				
	106800 Euromap E67 kit CB3	Euromap E67工具 CB3				
	122673 Euromap E67 module	Euromap E67模块				
	123670 Euromap E67 cable 6m	Euromap E67链接线				
	122671 Euromap E67 Bypass Plug	Euromap E67插头				
	122650 Motherboard kit 3.1	主机板3.1版				
	171031 RAM module DDR 3L	随机存储模块				
	171010 USB Flash 2 GB f. UR system SW	U盘2GB				
Controller:	177002 Power Supply Unit 12V	12V开关电源				
	177003 Power Supply Unit 48V	48V开关电源				
	172080 Current Distributor PCB	电流分配器				
	172290 Safety Controlboard Kit	安全板				
	107000 Safety Controlboard Terminal Kit	安全板接线端子				
	122745 Energy-eater incl. fan	风扇				
	177503 Filter kit for controller	随机存储模块				
	139033 Bracket f. Mounting Teach Pendant	触摸屏安装支架				
	132407 Bracket f. Mounting Controller	控制柜安装支架				
Tools:	109010 Service kit UR3/5/10 (kit includes all of the below part no.'s)	UR3/5/10工具套件(包括以下所有备件号)				
	109101 Spanner Hex 5,5mm	5.5mm超薄扳手				
	109102 Spanner Hex 7,0mm	7mm超薄扳手				
	109110 Spanner Hex 10,0mm	10mm超薄扳手				
	182200 Screwdriver Flat 2.5	关节盖子梅花螺丝刀 2.5号				
	109104 Torque screwdriver torx T8 +T10 - 0.4Nm	扭力螺丝刀torx T8 +T10 - 0.4Nm				
	109105 Torque wrench Hex 5,5mm Size 1 and Size 2 - 1.3Nm	5.5mm螺丝力矩扳手				
	109106 Torque wrench Hex 7,0mm Size 3 - 3.0Nm	7mm螺丝力矩扳手				
	109107 Torque wrench Hex 10,0mm Size 4 - 8.0Nm	10mm螺丝力矩扳手				
	109111 Torque screwdriver torx T10 - 1.3Nm	扭力螺丝刀torx T10 - 1.3Nm				
	109112 Torque screwdriver torx T20 - 3.0Nm	扭力螺丝刀torx T20 - 3.0Nm				
	109180 ESD Wrist strap	防静电手镯				
	164084 Bypass cable (for setting joint-ID)	485通讯线				
	185500 Dual calibration tool	双臂标定工具				
	131503 Bracket for mounting robotarm UR3 ( Item & BOSCH profile)	UR3安装法兰盘				
	173101 Cable for tool, angle: external	工具端10线缆				
	131095 Lid tool protective cap alu. f. tool connector	工具端接头保护帽				

	UR5						
	CB3 P/N	CB2 P/N Description (EN)	Description (CN)				
Robot arm:	103305	103305 Sealing set UR5, external	UR5密封圈, 外部用				
	103405	103405 Lid set complete UR5 incl. seal	UR5关节盖子,带密封圈				
	122041	122039 Tool Mounting Bracket UR5	UR5法兰盘				
	122050	122050 Base Mounting Bracket incl. Cable 6m UR5	UR5安装基座带6米电缆				
	122121	122011 Joint Size 1 Wrist 1 UR5	UR5手腕1				
	122123	122031 Joint Size 3 Base UR5	UR5基座				
	122221	122012 Joint Size 1 Wrist 2 UR5	UR5手腕2				
	122223	122032 Joint Size 3 Shoulder UR5	UR5肩部				
	122321	122013 Joint Size 1 Wrist 3 UR5	UR5手腕3				
	122323	122033 Joint Size 3 Elbow UR5	UR5肘部				
	123100	123100 Elbow counterpart and lower arm kit UR5	UR5肘部连接主干				
	122900	122500 Controller excl. Teach Pendant UR5	UR5控制箱, 不包含示教器				
	122091	122092 Teach Pendant incl. Touch Screen & power cable	示教器, 带触摸屏和4.5米电缆				
		106700 Euromap E67 kit CB2	Euromap E67工具 CB2				
	106800	Euromap E67 kit CB3	Euromap E67工具 CB3				
	122673	122672 Euromap E67 module	Euromap E67模块				
	123670	123670 Euromap E67 cable 6m	Euromap E67链接线				
	122671	122671 Euromap E67 Bypass Plug	Euromap E67插头				
		122700 Masterboard kit	主控板				
	122600	122600 Motherboard kit	主机板				
	171030	171030 RAM module	随机存储模块				
ntroller:	171022	171022 Flash card	闪存卡				
iiti olici .	177002	177002 Power Supply Unit 12V	<b>12V</b> 开关电源				
	177002	177003 Power Supply Unit 48V	48V开关电源				
	177003	172080 Current Distributor PCB	电流分配器				
	172000	Safety Controlboard Kit	安全板				
	107000	Safety Controlboard Terminal Kit	安全板接线端子				
	122745	122740 Energy-eater incl. fan	风扇				
	177503	177503 Filter kit for controller	随机存储模块				
	139033		触摸屏安装支架				
		139033 Bracket f. Mounting Teach Pendant					
	132407	132407 Bracket f. Mounting Controller	控制柜安装支架				
	109010	109010 Service kit UR3/5/10 (kit includes all of the below part no.'s)	UR3/5/10工具套件(包括以下所有备件号)				
	109101	109101 Spanner Hex 5,5mm	5.5mm超薄扳手				
	109102	109102 Spanner Hex 7,0mm	7mm超薄扳手				
	109110	109110 Spanner Hex 10,0mm	10mm超薄扳手				
	182200	182200 Screwdriver Flat 2.5	关节盖子梅花螺丝刀 2.5号				
	109104	109104 Torque screwdriver torx T8 +T10 - 0.4Nm	扭力螺丝刀torx T8 +T10 - 0.4Nm				
	109105	109105 Torque wrench Hex 5,5mm Size 1 and Size 2 - 1.3Nm	5.5mm螺丝力矩扳手				
	109106	109106 Torque wrench Hex 7,0mm Size 3 - 3.0Nm	7mm螺丝力矩扳手				
	109107	109107 Torque wrench Hex 10,0mm Size 4 - 8.0Nm	10mm螺丝力矩扳手				
Tools:	109111	109111 Torque screwdriver torx T10 - 1.3Nm	扭力螺丝刀torx T10 - 1.3Nm				
	109112	109112 Torque screwdriver torx T20 - 3.0Nm	扭力螺丝刀torx T20 - 3.0Nm				
	109180	109180 ESD Wrist strap	防静电手镯				
	164084	164084 Bypass cable (for setting joint-ID)	485通讯线				
	185500	Dual calibration tool	双臂标定工具				
	131501	131501 Bracket for mounting robotarm UR5 ( Item profile)	UR5安装法兰盘				
		, , ,	UR5安装法兰盘 (BOSCH)				
	131502	131502 Bracket for mounting robotarm UR5 ( BOSCH profile)	工具端IO线缆				
	173101	173101 Cable for tool, angle: external					
	131095	Lid tool protective cap alu. f. tool connector	工具端接头保护帽				

			UR10	
	CB3 P/N	CB2 P/N	Description (EN)	Description (CN)
	122061	103410 122059	Sealing set UR10, external Lid set complete UR10 incl. seal Tool Mounting Bracket UR10 Base Mounting Bracket UR10	UR10密封圈, 外部用 UR10关节盖子, 带密封圈 UR10法兰盘 UR10安装基座
Robot arm:	122122	122021	UR10 Base plug w/wire Joint Size 2 Wrist 1 UR10 Joint Size 4 Base UR10	UR10连接电缆 UR10手腕1 UR10基座
	122224	122043	Joint Size 2 Wrist 2 UR10 Joint Size 4 Shoulder UR10	UR10手腕2 UR10肩部
	122324	122034	Joint Size 2 Wrist 3 UR10 Joint Size 3 Elbow UR10	UR10手腕3 UR10肘部 UR10計部落接主工
	104001	104001	Elbow counterpart and lower arm kit UR10	UR10肘部连接主干
	122950 122091	122092	Controller excl. Teach Pendant UR10 Teach Pendant incl. Touch Screen & power cable	UR10控制箱,不包含示教器 示教器,带触摸屏和4.5米电缆
	106800	106700	Euromap E67 kit CB2 Euromap E67 kit CB3	Euromap E67工具 CB2 Euromap E67工具 CB3
			Euromap E67 module	Euromap E67模块
			Euromap E67 cable 6m	Euromap E67链接线
	122671	122700	Euromap E67 Bypass Plug Masterboard kit Motherboard kit	Euromap E67插头 主控板 主机板
			RAM module	随机存储模块
			Flash card	闪存卡
Controller:	177002	177002	Power Supply Unit 12V	12V开关电源
	177003	177003	Power Supply Unit 48V	48V开关电源
		172080	Current Distributor PCB	电流分配器
	172290		Safety Controlboard Kit	安全板
	107000	400740	Safety Controlboard Terminal Kit	安全板接线端子
			Energy-eater incl. fan	风扇 随机存储模块
			Filter kit for controller Bracket f. Mounting Teach Pendant	触摸屏安装支架
			Bracket f. Mounting Controller	控制柜安装支架
	164231		Cable Base to Controller UR10	控制器到机器人连接线
	109010		Service kit UR3/5/10 (kit includes all of the below part no.'s)	UR3/5/10工具套件(包括以下所有备件号)
			Spanner Hex 5,5mm	5.5mm超薄扳手
			Spanner Hex 7,0mm	7mm超薄扳手
			Spanner Hex 10,0mm	10mm超薄扳手
			Screwdriver Flat 2.5	关节盖子梅花螺丝刀 2.5号 扭力螺丝刀torx T8 +T10 - 0.4Nm
			Torque screwdriver torx T8 +T10 - 0.4Nm Torque wrench Hex 5,5mm Size 1 and Size 2 - 1.3Nm	五万縣丝万的X 18 + 110 - 0.4Nm 5.5mm螺丝力矩扳手
			Torque wrench Hex 7,0mm Size 3 - 3.0Nm	7mm螺丝力矩扳手
			Torque wrench Hex 10,0mm Size 4 - 8.0Nm	10mm螺丝力矩扳手
Tools:			Torque screwdriver torx T10 - 1.3Nm	扭力螺丝刀torx T10 - 1.3Nm
			Torque screwdriver torx T20 - 3.0Nm	扭力螺丝刀torx T20 - 3.0Nm
			ESD Wrist strap	防静电手镯
	164084	164084	Bypass cable (for setting joint-ID)	485通讯线
	185500		Dual calibration tool	双臂标定工具
	131510	131510	Bracket for mounting robotarm UR10 ( Item & BOSCH profile)	UR10安装法兰盘 (BOSCH)
	173101	173101	Cable for tool, angle: external	工具端IO线缆
	131095		Lid tool protective cap alu. f. tool connector	工具端接头保护帽