

ENTER A TO THE PARTY OF THE PAR

Porting Guide(Android O)

Revision 1.0 Jun 26, 2018

zillifizitet Zilife Zilife zilife i

Copyright @2017 Xradio Technology Co., Ltd. All Rights Reserved



Declaration

THIS DOCUMENTATION IS THE ORIGINAL WORK AND COPYRIGHTED PROPERTY OF XRADIO TECHNOLOGY ("XRADIO"). REPRODUCTION IN WHOLE OR IN PART MUST OBTAIN THE WRITTEN APPROVAL OF XRADIO AND GIVE CLEAR ACKNOWLEDGEMENT TO THE COPYRIGHT OWNER.

THE INFORMATION FURNISHED BY XRADIO IS BELIEVED TO BE ACCURATE AND RELIABLE. XRADIO RESERVES THE RIGHT TO MAKE CHANGES IN CIRCUIT DESIGN AND/OR SPECIFICATIONS AT ANY TIME WITHOUT NOTICE. XRADIO DOES NOT ASSUME ANY RESPONSIBILITY AND LIABILITY FOR ITS USE. NOR FOR ANY INFRINGEMENTS OF PATENTS OR OTHER RIGHTS OF THE THIRD PARTIES WHICH MAY RESULT FROM ITS USE. NO LICENSE IS GRANTED BY IMPLICATION OR OTHERWISE UNDER ANY PATENT OR PATENT RIGHTS OF XRADIO. THIS DATASHEET NEITHER STATES NOR IMPLIES WARRANTY OF ANY KIND, INCLUDING FITNESS FOR ANY PARTICULAR APPLICATION.

THIRD PARTY LICENCES MAY BE REQUIRED TO IMPLEMENT THE SOLUTION/PRODUCT. CUSTOMERS SHALL BE SOLELY RESPONSIBLE TO OBTAIN ALL APPROPRIATELY REQUIRED THIRD PARTY LICENCES. XRADIO SHALL NOT BE LIABLE FOR ANY LICENCE FEE OR ROYALTY DUE IN RESPECT OF ANY REQUIRED THIRD PARTY LICENCE. XRADIO SHALL HAVE NO WARRANTY, INDEMNITY OR OTHER OBLIGATIONS WITH RESPECT TO MATTERS COVERED UNDER ANY REQUIRED THIRD PARTY LICENCE.

WR829 WLAN Porting Guide (Revision 1.0) Copyright @2017 Xradio Technology Co., Ltd. All Rights Reserved.



Revision History

Revision History

Version	Data	Summary of Changes	- Friends	- (\$\frac{1}{2}\)
1.0	2018-06-16	Initial Version	·	

表 0-1 Revision History



XR829 WLAN Porting Guide (Revision 1.0)



泪 录

Declaration	••••••	••••••••••	2
Revision History			3
目 录			4
表			5
图			6
1 Linux kernel 移植	<u>.</u>		7 _s &
1 Linux kernel 移植	A SOLITAIN	A CONTRACTOR OF THE PARTY OF TH	7 Report of the second
1.2 配置 Xradio 内核编译			7
1.3 Xradio 平台配置	/. V		8
1.3.1 通用平台配置	A A A A A A A A A A A A A A A A A A A	E KIIII	EXIII.
1.3.2 Allwinner 平台配置			9
2 Android 移植			13
2.1 拷贝 xradio 移植文件包			13
2.2 xradio wifi-hal 厂商库配置			13
2.3 wlan 模组配置			14
2.4 初始化配置	i tri) july	15 _{titlei}
3 移植后检查点	R. I.		17
3 移植后检查点	开机加载		17
3.2 确认设备存在 fw、sdd 等文件	Mario ,		25
4 FAQ	-\T	77	19
4.1 无法正常打开 wifi			19
4.1.1 确认 xradio_wlan.ko 模块	正常加载		19
4.1.2 确认使用匹配的 SDD 文件			
4.1.3 确认 cfg80211 已经编译进	: linux 内核(lichee)		20
4.2 如何检查软件版本号	······································	٧	<u>21</u>
4.3 如何支持 wowlan 功能	.184 ¹⁷	Me link	21 2 Airline



图

图	1-1	选中 "Xradio WLAN support" 编译配置8	
图	1-2	选中 "Xradio MAC featrues"和 "Xradio Driver features"编译配置	
图	1-3	确认"Xradio MAC featrues"的编译配置8	
图	1-4	确认"Xradio Driver features"的编译配置8	
图	1-5	确认"Drvier debug features"的编译配置8	
图	1-6	确认"Allwinner rfkill driver"编译配置10	
图	1-7	PCB 原理图的 POWER TREE11	infel
图	1-8	PCB 原理图的 POWER TREE	F
图	1-9	PCB 原理图中 SDIO 配置 12	
图	3-1	确认设备开机加载 xradio_mac.ko 和 xradio_core.ko17	
图	3-2	确认设备存在 init.wireless.xradio.rc 脚本文件18	
图	3-3	确认设备存在 fw、sdd 等文件18	
图		正常加载 xradio_wlan.ko 的内核打印19	
图	4-2	使用 sddedit 工具查看/修改 sdd 文件20	
图	4-3	确认 cfg80211 已编译进内核20	
图	4-4	查看软件版本号21	
14 X	A THE	查看软件版本号	TH'S

A TOP TO THE PARTY OF THE PARTY

W. T. H.

A TITLE TIME



1 Linux kernel 移植

下面基于 32 位 Linux-4.9 内核版本 (其它平台移植可以参考此),给出具体的移植步骤。

1.1 添加 Xradio wlan 驱动

- (1) 把对应内核版本的 lichee/xradio 文件夹拷贝到以下路径: /lichee/linux-4.9/drivers/net/wireless/
- (2) 在内核编译的 Makefile 文件中,加入对驱动的编译语句。 修改 /lichee/linux-4.9/drivers/net/wireless/Makefile 文件,添加以下信息:

(3) 添加相关内核配置选项。

修改 /lichee/linux-4.9/drivers/net/wireless/Kconfig 文件,添加以下信息:

source "drivers/net/wireless/xradio/Kconfig"

1.2 配置 Xradio 内核编译

通过 Linux 配置界面进行手动逐项配置。在 Linux 的内核路径下(lichee/linux-4.9),使用 make ARCH=arm menuconfig 命令显示配置界面,进行以下配置:

(1)选中"Device Drivers --->Network device support --->Wireless LAN -->Xradio WLAN support":

```
Wireless LAN
  ADMtek devices
  Atheros/Qualcomm devices
  Atmel devices
  Broadcom devices
  Cisco devices
  Intel devices
  Intersil devices
  Marvell devices
  MediaTek devices
  Ralink devices
  Realtek devices
  Redpine Signals Inc devices
  STMicroelectronics devices
  Texas Instrument devices
  Broadcom FullMAC wireless cards support
  Realtek 8723C SDIO or SPI WiFi
  №ealtek 8723BS-VQQ:WiFi
```



×图 1-1 选中"Xradio WLAN support"编译配置

(2) 进入 Xradio WLAN support 子项目录,分别选中 Xradio MAC featrues 和 Xradio Driver features:

图 1-2 选中 "Xradio MAC featrues" 和 "Xradio Driver features" 编译配置

(3) 进入 Xradio MAC featrues 子项目录,确认默认情况如下选项被选中:

```
--- XRadio MAC features
(minstrel_ht) XRMAC_RC_DEFAULT
[] XRMAC_RC_PID
[*] XRMAC_RC_MINSTREL
[*] Minstrel 802.11m support
[*] XRMAC_DEBUGFS
```

图 1-3 确认 "Xradio MAC featrues" 的编译配置

(4) 返回上级 Xradio WLAN support 目录,再进入 Xradio Driver features 子项目录,确认默认情况如下选项被选中:

```
--- XRadio Driver features

[*] SDIO bus wlan module

[*] Platform supports non-power-of-two SDIO transfer

[*] Use GPIO interrupt

[] Wlan power off in suspend

[] Support extend suspend(both Wow and power off)

[] Support normal suspend(Wow for Single Crystal)

Driver debug features --->
```

图 1-4 确认 "Xradio Driver features" 的编译配置

(5) 进入 Drvier debug features 子目录,确认以下选项默认被选中。

```
[*] Enable XRADIO debug messages (DEVELOPMENT)

[*] XRADIO ETF Support for RF Test(DEVELOPMENT)

[ ] Dump kernel in case of critical error (DEVELOPMENT)

[*] Expose driver internals to DebugFS (DEVELOPMENT)
```

图 1-5 确认 "Drvier debug features" 的编译配置

1.3 Xradio 平台配置

1.3.1 通用平台配置

平台配置一般会涉及上电、中断等配置,此外,还涉及系统唤醒、SDIO 扫描相关的接口配置。在 xradio/wlan/platform.h 声明了 xradio 驱动所需要的平台配置接口,接口实现则在 xradio/wlan/platform.c 中(代码为 demo, 具体平台需重新实现)。具体说明如下表所示:



	- AVAL	- AXA-	WL AWL	
	接口名称	参数描述	功能描述	备注
	xradio_plat_init ***********************************	无 森州抗	用于平台配置的初始化, 在 xradio_wlan 模块加载 时被执行	操拥柏
	xradio_plat_deinit	无	用于平台配置的资源注销,在 xradio_wlan 模块卸载时被执行	
	xradio_sdio_detect	enable: 是否插入卡	进行 SDIO 的扫描检测	
	xradio_request_gpio_irq	dev: 注册中断的设备 sbus_priv: 中断处理函数以 及相关参数的结构指针	注册数据中断	中断类型必须为上 升沿触发,需支持 wow 功能则需支持 唤醒系统
	xradio_free_gpio_irq	dev: 注销中断的设备 sbus_priv: 已注册中断参数 的结构指针	注销数据中断	療制根持續性力
	xradio_wlan_power	on: 1为打开,0为关闭	xradio 芯片上电实现,包括电源的开关以及复位pin 脚的控制	上电 reset 时序, 0(2ms)->1(50ms)
	MCI_CHECK_READY	h:mmc_host, t:timeout	某些平台,需要用于 SDIO 数据传输后等待硬件是否 ready	A kintei

表 1-1 xradio 驱动平台配置接口

1.3.2 Allwinner 平台配置

1.3.2.1 上电控制模块修改

Allwinner 平台中, 上电控制模块的代码路径为: lichee/linux-4.9/drivers/misc/sunxi-rf/

(1) 配置使用外部的 32K 时钟。修改 sunxi-wlan.c 文件中的 sunxi wlan probe() 函数:

将 data->lpo = devm_clk_get(dev, NULL);

(2) 确认内核编译配置:



在 lichee/linux-4.9 目录下输入 make ARCH=arm menuconfig 命令,依次选择"Device Drivers -> Misc devices",确认"Allwinner rfkill driver"被选中,页面配置如下:

```
< > Analog Devices Digital Potentiometers
< > Dummy IRQ handler
< > Integrated Circuits ICS932S401
< > Enclosure Services
< > Medfield Avago APDS9802 ALS Sensor module
Intersil ISL29003 ambient light sensor
Intersil ISL29020 ambient light sensor
< > Taos TSL2550 ambient light sensor
< > BH1770GLC / SFH7770 combined ALS - Proximity sensor
< > APDS990X combined als and proximity sensors
< > Honeywell HMC6352 compass
< > Dallas DS1682 Total Elapsed Time Recorder with Alarm
< > Texas Instruments DAC7512
< > FSA9480 USB Switch
   Lattice ECP3 FPGA bitstream configuration via SP:
 lemeric on-chip SRAM driver
   Per-UID statistics
      Per-TASK statistics
<*> Memory freq/bandwidth time statistics
< > Silicon Labs 🗯 port support -
    EEPROM support
    Texas Instruments shared transport line discipline
< > STMicroeletronics LIS3LVO2Dx three-axis digital accelerometer (SPI)
< > STMicroeletronics LIS3LV02Dx three-axis digital accelerometer (I2C)
    *** Altera FPGA firmware download module ***
< > Altera FPGA firmware download module
    *** Intel MIC Bus Driver ***
    *** SCIF Bus Driver ***
    *** VOP Bus Driver ***
    *** Intel MIC Host Driver ***
    *** Intel MIC Card Driver ***
    *** SCIF Driver ***
    *** Intel MIC Coprocessor State Management (COSM) Drivers ***
    *** VOP Driver **
< > Line Echo Canceller support
   Allwinner rfkill driver
```

图 1-6 确认 "Allwinner rfkill driver"编译配置


1.3.2.2 板级 sys_config.fex 配置

需要结合 PCB 原理图进行相关的硬件板级配置,这里以 AllWinner A33G 平台为例,给出相关配置。配置文件路径为: lichee/tools/pack/chips/sun8iw15p1/configs/a3/sys config.fex

1.3.2.2.1 供电配置

(1) 查看 PCB 硬件原理图的 POWER TREE:





(2) 修改 sys_config.fex 文件,在[power_sply]元素中添加 dldo2_vol 和 dldo3 vol 的配置:

```
; power setting
;note:
;dcdc1_vol=1003300, mean set dcdc to 3300mV and enable this dc
;dcdc1 vol=3300, mean set dcdc to 3300mV but disable this dc
[power sply]
dc1sw vol
                 = 3300 🚳
;aldoI vol
                  = 3300
;c1do3_vol
                  = 1800
dcdc2_vol
                 = 100900
dcdc3 vol
                 ₹100900
dcdc5_vol
                 = 1001500
dldo2 vol
                 = 3300
dldo3 vol
                 = 3300
;aldo5 vol
                  = 2500
```

1.3.2.2.2 wlan 电源、中断等配置

(1) 查看 PCB 原理图:

```
PL5/S-JTAG-CK/S-PL-EINT5 D1 CPUS-TDO WL-PMU-EN 16 16 16 16 16 N5 CDI IS TON WL-WAKE-AP 16 16 16 N5 CDI IS TON WL-WAKE-AP 16 N5 CDI IS TON WL-
```



(2) 在 sys config.fex 文件中添加 wlan 电源、中断等配置:

```
;wlan configuration
                  0-not use, 1 use
;wlan used: 🏋
;wlan_busnum:
                  0- SDC0, 1- SDC1, 2- SDC2, 3- SDC3
                  wlan module power supply
;wlan power:
; wlan io regulator: wlan io power supply
;wlan regon:
                  wlan power on
;wlan hostwake:
                  wlan wakeup ap
compatible
                    "allwinner,sunxi-wlan"
wlan_used
wlan busnum
                    "vcc-wifi"
wlan power
wlan io regulator
                  = "vcc+wifi-io"
wlan regon
                  = port:PL05<1><default><default><0>
wlan hostwake
                  = port:PL06<6><default><default><0>
                   port:PL07<1><default><d>
chip en
```

1.3.2.2.3 SDIO 配置

(1) 查看 PCB 原理图中的 SDIO 配置:

```
VCC-PG
                                              P<sub>5</sub>
                                                   VCC-PG
                                  33R R0402
                                             R2
16
      WL-SDIO-CLK &
                                                   PG0/SDC1-CLK/PG-EINT0
                                             R3
      WL-SDIO-CMD (
16
                                                   PG1/SDC1-CMD/PG-EINT1
                                             M3
16
      WL-SDIO-D0
                                                   PG2/SDC1-D0/PG-EINT2
                                              T2
      W-SDIO-D1
16
                                                   PG3/SDC1-D1/PG-EINT3
                                             N<sub>2</sub>
      WL-SDIO-D2
16
                                                   PG4/SDC1-D2/PG-EINT4
      WL-SDIO-D3
                                                   PG5/SDC1-D3/PG-EINT5
                          图 1-9 PCB 原理图中 SDIO 配置
```

(2) 在 sys_config.fex 文件中进行以下配置:

All the light of the state of t



2 Android 移植

下面基于 AllWinner A33G 平台,给出 xradio wlan 在 Android 8.1 中的移植步骤。

2.1 拷贝 xradio 移植文件包

把对应 android 版本的 android/xradio 文件夹拷贝到 android/hardware/路径下。此目录包含 firmware、etf firmware、bootloader、sdd 等 bin 文件以及编译时使用的.mk 文件,驱动在初始化模组时会把这些文件下载到模组中。另外还包含了 wpa_supplicant_8_lib 文件夹和 wifi_hal 文件夹,用来生成函数库。

2.2 xradio wifi-hal 厂商库配置

(1) 文件路径: android/frameworks/opt/net/wifi/libwifi/hal/Android.mk

使用 xradio 实现的 wifi-hal 厂商库,添加以不高亮代码:

```
# Pick a vendor provided HAL implementation library.
LIB WIFI HAL := libwifi-hal-fallback
VENDOR LOCAL SHARED LIBRARIES :=
ifeq ($(BOARD WLAN DEVICE), bcmdhd)
 LIB WIFI HAL := libwifi-hal-bcm
else ifeq ($(BOARD WLAN DEVICE), qcwcn)
 LIB WIFI HAL := libwifi-hal-qcom
 VENDOR LOCAL SHARED LIBRARIES := libcl@80211
else ifeq ($(BOARD WLAN DEVICE), mrvl)
 # this is commented because none of the nexus devices
 # that sport Marvell's wifi have support for HAL
 # LIB WIFI HAL := libwifi-hal-mrvl
else ifeq ($(BOARD WLAN DEVICE), MediaTek)
 # support MTK WIFI HAL
 LIB WIFI HAL := libwifi-hal-mt66xx
else ifeq ($(BOARD WLAN DEVICE), realtek)
 # support Realtek WIFI HAL
 LIB WIFI HAL := libwifi-hal-rtk
```

else ifeq (\$(BOARD WLAN DEVICE), xradio)

support Xradio WIFI HAI

LIB WIFI HAL: = libwifi-hal-xradio

endif

2.3 wlan 模组配置

- 1.打开 android/device/softwinner/venus-a3/BoradConfig.mk 文件,
- (1) 修改 BOARD WIFI VENDOR 宏的值为 xradio
- (2) 添加 xradio wifi 配置

```
# wifi and bt configuration
```

1. Wifi Configuration

```
BOARD_WIFI_VENDOR := xradio
......

# 1.3 eagle wifi configuration
ifeq ($(BOARD_WIFI_VENDOR), eagle)

WPA_SUPPLICANT_VERSION := VER_0_8_X

BOARD_WPA_SUPPLICANT_DRIVER := NL80211

BOARD_WPA_SUPPLICANT_PRIVATE_LIB := lib_driver_cmd_eagle

BOARD_HOSTAPD_DRIVER := NL80211

BOARD_HOSTAPD_PRIVATE_LIB := lib_driver_cmd_eagle

BOARD_HOSTAPD_PRIVATE_LIB := lib_driver_cmd_eagle

BOARD_WLAN_DEVICE := esp8089

include hardware/espressif/wlan/firmware/esp8089/device-esp.mk
```

#1.4 xradio wifi config

endif

ifeq (\$(BOARD WIFI VENDOR), xradio)

WiFi Configuration

WPA SUPPLICANT VERSION := VER 0 8 X



```
BOARD_WPA_SUPPLICANT_DRIVER := NL80211

BOARD_HOSTAPD_DRIVER := NL80211

BOARD_HOSTAPD_PRIVATE_LIB := lib_driver_cmd_xr

BOARD_WLAN_DEVICE := xradio

WIFI_DRIVER_MODULE_PATH := "/system/vendor/modules/xradio_wlan.ko"

WIFI_DRIVER_MODULE_NAME := "xradio_wlan"

WIFI_DRIVER_MODULE_ARG_ := ""

include hardware/xradio/wlan/kernel-firmware/xradio-wlan.mk

endif
```

2.4 初始化配置

修改 android/device/softwinner/common/init.wireless.xradio.rc 文件:

- (1) 添加 xradio_umac 和 xradio_core 开机启动加载脚本
- (2) 添加 service wpa_supplicant 启动脚本

```
#xradio driver

insmod /system/vendor/modules/xradio mag.ko

insmod /system/vendor/modules/xradio_core.ko

insmod /system/vendor/modules/xradio_btlpm.ko

# bluetooth xradio firmware debugfs driver
insmod /system/vendor/modules/xradio_btfdi.ko

# UART device
chmod 0660 /dev/ttyS1
chown bluetooth net_bt_admin /dev/ttyS1
.....

# 1. xradio wifi service
```





移植后检查点

确认 xradio_mac、xradio_core 开机加载 3.1

xradio 的 wlan 驱动 2.0 版本分为三个模块: xradio_mac.ko、xradio_core.ko 和 xradio_wlan.ko, 这三个模块存 在于设备上的 /system/vendor/modules/ 目录下。其中 android 系统启动时会自动加载 xradio_mac.ko 和 xradio core.ko, 而当打开 wifi 时才会触发 xradio wlan.ko 的加载。通过以下命令确认是否开机加载了这两个 模块:

adb shell

```
lsmod
Module
                                   Used by
vin v4l2
gc0310_mipi
                           13720
                                   Θ
gc2355_mipi
                            8116
                                      vin_v4l2,gc0310_mipi,gc2355_mipi
                           46000
vin_10
videobuf2_v4l2
                           16405
                                      vin_v4l2
videobuf2_dma_contig
videobuf2_memops
videobuf2_core
                            10321
                                     1 vin_v4l2
                            2009
                                      videobuf2_dma_contig
                           30705
                                      vin_v4l2,videobuf2_v4l2
gslX680new
                          963052
                          309536
                                   15
xradio_btfdi
                           17225
xradio btlpm
xradio core
                          291170
                                     xradio_core
xradio mac
```

若没有开机加载上述两个模块,可能原因是<mark>设备上不存在 init.wireless.xradio.rc 脚本文件</mark>。该文件应存放在设备上的以下目录:/vendor/etc/init/,请使用 "ls-l"命令确认是否存在该文件。

XR829 WLAN Porting Guide (Revision 1.0)

Copyright @2017 Xradio Technology Co., Ltd. All Rights Reserved

Page 17



```
venus-a3:/vendor/etc/init # ls -l
total 100
                           574 2018-06-22 18:49 android.hardware.audio@2.0-service.rc
-rw-r--r--
              root
                           537 2018-06-22 18:49 android.hardware.bluetooth@1.0-service.rc
             root
                   root
                                                 android.hardware.camera.provider@2.4-service.rc
android.hardware.cas@1.0-service.rc
                           272 2018-06-22 18:49
            1
             root
                   root
                                           18:49
              root
                           181 2018-06-22
                   root
                                                 android.hardware.configstore@1.0-service.rc
                           141 2018-06-22
              root
                   root
                                           18:49
                           181 2018-06-22 18:49
                                                 android.hardware.drm@1.0-service.rc
              root
                   root
                                           18:49
              root
                   root
                           199
                               2018-06-22
                                                 android.hardware.drm@1.0-service.widevine.rc
                                                 android.hardware.gatekeeper@1.0-service.rc
                           125
                               2018-06-22
                                           18:49
              root
                   root
                                                 android.hardware.graphics.allocator@2.0-service.rc
                           212 2018-06-22 18:49
              root
                   root
                                                 android.hardware.graphics.composer@2.l-service.rc android.hardware.keymaster@3.0-service.rc
                           214 2018-06-22
                                           18:49
              root
                   root
              root
                   root
                           136 2018-06-22
                                          18:49
                                                 android.hardware.light@2.0-service.rc
                           118 2018-06-22 18:49
              root
                   root
                                           18:49
              root
                   root
                               2018-06-22
                                                 android.hardware.media.omx@1.0-service.rc
                           125 2018-06-22 18:49
                                                 android.hardware.memtrack@1.0-service.rc
              root
                   root
                           119 2018-06-22 18:49
              root
                   root
                                                 android.hardware.power@1.0-service.rc
                               2018-06-22
                           178
                                           18:49
                                                 android.hardware.sensors@1.0-service.rc
              root
                   root
                                                 android.hardware.wifi@1.0-service.rc
                   root
                           120
                               2018-06-22 18:49
              root
                            68 2018-06-22 18:49
                                                 android.supplicant@2.5-optee.rc
              root
                   root
                           512
                               2018-06-22
              root
                   root
                                           18:49
                                                 hostapd.android.rc
                   shell
                          4096
                               2018-06-22 18:49
           2
              root
                                                 hw
drwxr-xr-x
                            0 2018-06-22 18:49 init sensors
                          1859 2018-06-22 18:49 init.wireless.xradio.rc
           1 root
                   root
                           135 2018-06-22 18:49 radio_monitor.rc
                   root
              root
              root
                   root
                               2018-06-22
                                           18:49 rild.rc
                               2018-06-22 18:49 vndservicemanager.rc
                           199
           1 root root
venus-a3:/vendor/etc/init #
```

图 3-2 确认设备存在 init.wireless.xradio.rc 脚本文件

如果不存在此文件,是 Android 层移植出现问题,请确认是否已正确进行"2.3 wlan 模组配置"。另外,可 通过依次手动加载 xradio mac.ko 模块和 xradio core.ko 模块,确认是否能成功加载。

确认设备存在 fw、sdd 等文件 3.2

上述文件存放在设备上的 /vendor/etc/firmware/ 目录,使用 ls 和命令进行查看:

```
MR Villa Hinter
venus-a3:/vendor/etc/firmware # ls -l
ls -l
total 544
                         2184 2018-06-22 18:49 boot xr829.bin
           1 root root
           1 root root
                        73004 2018-06-22 18:49 etf xr829.bin
           1 root root 172332 2018-06-22 18:49 fw_xr829.bin
             root root 295500 2018-06-22 18:49 fw_xr829_bt.bin
                           744 2018-06-22 18:49 sdd xr829.bin
           1 root root
venus-a3:/vendor/etc/firmware #
```

图 3-3 确认设备存在 fw、sdd 等文件

如果不存在这些文件,是 Android 层移植出现问题。请按照第二章的移植步骤进行检查。



4 FAQ

4.1 无法正常打开 wifi

4.1.1 确认 xradio_wlan.ko 模块正常加载

在确保已经加载 xradio_mac.ko 和 xradio_core.ko 的前提下,手动加载 xradio_wlan.ko,查看内核打印信息,看是否有异常:

图 4-1 正常加载 xradio_wlan.ko 的内核打印

如有异常,请结合出错信息进行排查。

4.1.2 确认使用匹配的 SDD 文件

确认 wifi 芯片使用的晶振频率,并确认 android/hardware/xradio/wlan/kernel-firmware/中使用的 sdd 文件是否与之匹配。如平板或者盒子出现打开 wifi 后一直处于等待扫描结果,可能是 sdd 文件与晶振不匹配导致。可以使用提供的 sddedit.exe 工具打开 sdd 文件,查看或修改时钟配置:




图 4-2 使用 sddedit 工具查看/修改 sdd 文件

4.1.3 确认 cfg80211 已经编译进 linux 内核(lichee)

部分 SDK 中没有默认将 cfg80211 编进内核,导致在移植完成后不能正常使用 wifi 功能。如出现通过平板或盒子开关 wifi, driver 可以正常加载,但是 wifi 没有正常开启,请进行以下操作:

在 Linux 的内核路径下(lichee/linux-4.9),使用 make ARCH=arm menuconfig 命令显示配置界面,依次选中"Networking support ---> Wireless",确认 cfg80211 是否被选上:



4.2 如何检查软件版本号

软件版本号包括驱动和固件的版本号。本移植文档只适用的 driver 2.0 版本以上,请确认使用的 driver 版本。查看软件版本的方法为:打开 wifi,输入以下命令进行查看:

adb shell

cd/sys/kernel/debug/ieee80211/phy*/xradio

cat version

```
venus-a3:/ # cd /sys/kernel/debug/ieee80211/phy*/xradio
cd /sys/kernel/debug/ieee80211/phy*/xradio
venus-a3:/sys/kernel/debug/ieee80211/phy2/xradio # cat version
cat version
Driver Label:XR_V02.16.67_HT40_01.27    Jun 22 2018 18:43:28
Firmware Label:XR_C09.08.52.52_DBG_02.36 HT40 May 24 2018 10:44: 2
venus-a3:/sys/kernel/debug/ieee80211/phy2/xradio #
```

图 4-4 查看软件版本号

4.3 如何支持 wowlan 功能

在设备需要支持wowlan 功能时,检查 android\hardware/xradio/wlan/wpa_supplicant_conf 的wpa_supplicant_overlay.conf文件中是否配置了wowlan_triggers=any。在android5.0以上版本可以通过配置文件支持wowlan 功能,不需要修改源代码。

A fillight to the state of the