

Decument Title	Specification of MACsec Key
Document Title	Agreement
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	1066

Document Status	published
Part of AUTOSAR Standard	Classic Platform
Part of Standard Release	R23-11

Document Change History			
Date	Release	Changed by	Description
2023-11-23	R23-11	AUTOSAR Release Management	MKA Security Events incorporated
2022-11-24	R22-11	AUTOSAR Release Management	Initial release



Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.



Contents

1	Introduction and functional overview 6		
2	Acronyms and Abbreviations		
3	Related documentation		
	3.1 3.2	Input documents & related standards and norms	
4	Cons	traints and assumptions	9
	4.1 4.2	Limitations	
5	Depe	ndencies to other modules	10
	5.1 5.2	Connection to Ethernet Interface (EthIf)	
	5.3	Driver	
6	Requ	irements Tracing	12
7	Func	tional specification	14
	7.3 7.4 7.5 7.6 7.7	Background and rationale Motivation 7.2.1 Functional components 7.2.1.1 Port Access Entity (PAE) 7.2.1.2 MACsec Key Agreement Entity (KaY) General Requirements Limitations 7.4.1 Limitations on MKA Entity Cryptographic requirements Communication with MACsec Entity (SecY) Configurable behavior of MKA 7.7.1 MKA behavior 7.7.2 MKA Error Handling Error Classification 7.8.1 Development Errors 7.8.2 Runtime Errors 7.8.3 Transient Faults 7.8.4 Production Errors 7.8.5 Extended Production Errors 7.8.5.1 MKA_E_TIMEOUT_INSTANCE 7.8.5.2 MKA_E_KEY_NOT_PRESENT_INSTANCE 7.8.5.3 MKA_E_KEY_MISMATCH_INSTANCE	14 16 16 17 20 20 21 22 23 24 24 24 24 25 26 26
	7.9	7.8.5.4 MKA_E_ALGO_MISMATCH_INSTANCE	



8	API	specification	on 29
	8.1		I types
	8.2	Type def	initions
		8.2.1	Mka_MacSecConfigType
		8.2.2	Mka_ValidateFramesType
		8.2.3	Mka_ConfidentialityOffsetType
		8.2.4	Mka_Stats_Tx_SecYType
		8.2.5	Mka_Stats_Rx_SecYType
		8.2.6	Mka_Stats_Tx_ScType
		8.2.7	Mka_Stats_Rx_ScType
		8.2.8	Mka_SakKeyPtrType
		8.2.9	Mka_PermissiveModeType
		8.2.10	Mka_Stats_SecYType
		8.2.11	Mka_PaeStatusType
		8.2.12	Mka_MkaStatusType
		8.2.13	Mka_ConfigType
	8.3	Function	definitions
		8.3.1	Mka_Init
		8.3.2	Mka_GetVersionInfo
		8.3.3	Mka_SetCknStatus
		8.3.4	Mka_GetCknStatus
		8.3.5	Mka_SetEnable
		8.3.6	Mka_GetEnable
		8.3.7	Mka_GetPaeStatus
		8.3.8	Mka_SetPaePermissiveMode
		8.3.9	Mka_StartPae
		8.3.10	Mka_GetMacSecStatistics
		8.3.11	Mka_LinkStateChange
	8.4	Callback	notifications
		8.4.1	Mka_GetMacSecStatisticsNotification
		8.4.2	Mka_RxIndication
		8.4.3	Mka_TxConfirmation
		8.4.4	Mka_MacSecUpdateSecYNotification 46
		8.4.5	Mka_MacSecAddTxSaNotification
		8.4.6	Mka_MacSecAddRxSaNotification
	8.5	Schedule	ed functions
		8.5.1	Mka_MainFunction
	8.6	Expected	d interfaces
		8.6.1	Mandatory interfaces
		8.6.2	Optional interfaces
		8.6.3	Configurable interfaces
	8.7	Service I	nterfaces
9	Seq	uence diag	rams 50
	9.1	Commun	nication initialization with MACsec
	9.2		nication initialization with MACsec and Switch



10	Configuration	specification	53
	10.1 How to	read this chapter	53
	10.2 Contai	ners and configuration parameters	53
	10.2.1	Mka	53
	10.2.2	MkaGeneral	54
	10.2.3	MkaPaeConfiguration	57
	10.2.4	MkaCryptoAlgoConfig	60
	10.2.5	MkaCipherSuites	64
	10.2.6	MkaPaeInstance	65
	10.2.7	MkaKay	68
	10.2.8	MkaKayParticipant	71
	10.2.9	MkaKayDemEventParameterRefs	77
	10.2.10	MkaSecurityEventRefs	79
	10.3 Publish	ned Information	81
A	Not applicable	e requirements	82
В	Change histo	ry of AUTOSAR traceable items	83
	B.1 Tracea	ble item history of this document according to AUTOSAR Re-	
	lease F	R23-11	83
	B.1.1	Added Specification Items in R23-11	83
	B.1.2	Changed Specification Items in R23-11	83
	B.1.3	Deleted Specification Items in R23-11	84
	B.1.4	Added Constraints in R23-11	84
	B.1.5	Changed Constraints in R23-11	84
	B.1.6	Deleted Constraints in R23-11	84



1 Introduction and functional overview

This specification describes the functionality, API and the configuration for the AUTOSAR Basic Software module MKA.



2 Acronyms and Abbreviations

The glossary below includes acronyms and abbreviations relevant to the MKA module that are not included in the [1, AUTOSAR glossary].

Abbreviation / Acronym:	Description:	
AN	Association Number	
CA	Secure Connectivity Association	
CAK	Secure Connectivity Association Key	
DA	Destination Address	
ICV	Integrity Check Value	
KaY	MAC Security Key Agreement Entity	
MACsec	Media Access Control Security	
MKA	MACsec Key Agreement protocol (IEEE Std 802.1X)	
MKPDU	MACsec Key Agreement Protocol Data Unit	
MPDU	MACsec Protocol Data Unit	
PAE	Port Access Entity	
PN	Packet Number	
SA	Secure Association or Source Address, as applicable	
SAI	Secure Association Identifier	
SAK	Secure Association Key	
SC	Secure Channel	
SCI	Secure Channel Identifier	
SecTAG	MAC Security TAG	
SecY	MAC Security Entity	
SL	Short Length	
SSCI	Short Secure Channel Identifier	
TLV	Tag-Length-Value	

Table 2.1: Acronyms and abbreviations used in the scope of this Document



3 Related documentation

3.1 Input documents & related standards and norms

- [1] Glossary
 AUTOSAR_FO_TR_Glossary
- [2] General Specification of Basic Software Modules AUTOSAR CP SWS BSWGeneral
- [3] Requirements on MACsec AUTOSAR_FO_RS_MACsec
- [4] IEEE Standard for Local and metropolitan area networks-Media Access Control (MAC) Security https://ieeexplore.ieee.org/document/8585421
- [5] IEEE Standard for Local and Metropolitan Area Networks—Port-Based Network Access Control https://ieeexplore.ieee.org/document/9018454
- [6] Advanced Encryption Standard (AES) Key Wrap Algorithm https://tools.ietf.org/html/rfc3394

3.2 Related specification

AUTOSAR provides

- a General Specification on Basic Software modules [2, SWS BSW General], which is also valid for MKA.
- a MACsec Requirements Specification [3, RS MACsec] which is also valid for MKA.

Thus, the specification [2, SWS BSW General] shall be considered as additional and required specification for MKA.



4 Constraints and assumptions

4.1 Limitations

This document does not cover the integration neither requirements of the MACsec protocol as it is an IEEE published standard [4, IEEE 802.1AE-2018].

The AUTOSAR MACsec implementation currently has the following limitations:

- Only participants authentication based on Connectivity Association pre-shared keys (CAKs) is supported. (EAP-TLS, EAP-IKEv2, and other variants are not supported).
- Only MACsec between direct peers is supported (e.g. Point-to-Point configurations).
- Point-to-Multipoint configurations are not supported.
- In-service upgrades with EAPoL-MKA frames are not supported.
- Temporary suspension of MKA operation is not supported.
- MACsec Cipher Suites is the only currently supported EAPoL-Announcement TLV.

The following EAPoL Announcements are currently not required:

- Access Information → TLV Type 111
- Key Management Domain → TLV Type 113
- NID → TLV Type 114
- Dynamic Key Server election based on Key Server priority is not supported (Roles are set per configuration and fixed).
- The following MKPDU Parameter sets are currently not required:
 - Distributed CAK → Parameter set type 5
 - KMD → Parameter set type 6
 - ICV Indicator → Parameter set type 255

4.2 Applicability to car domains

Automotive systems require quicker start-up times for the devices connected to the on-board network, hence the protocol convergence time must be tuned accordingly.



5 Dependencies to other modules

The MACsec Key Agreement (MKA) Module has interfaces with the following modules:

- 1. EthIf \rightarrow To configure, control, and monitor the MACsec Entity (per SW or HW).
- 2. CSM:
 - Protect outgoing MKA messages and validate incoming MKA messages.
 - Generate, encrypt, and decrypt session keys (SAKs).

5.1 Connection to Ethernet Interface (Ethlf)

The MKA module and the Ethlf are connected in order to:

- Receive and send MKA messages.
- Provide MACsec specific parameters to the lower layers.
- Orchestrate the Link-Up and Link-Down signaling of the interfaces for upper layers (i.e. through the EthSM).

In case an Ethernet Interface is MACsec protected, it will use a specific MKA module instance to configure the MACsec Entities (HW or SW) for transmission and reception.

In case the MACsec protected Ethernet Interface is required to be ACTIVE by the EthSM, after the signaling of the physical Link-up from the specific transceiver or Switch port(ETH_MODE_ACTIVE), the EthIf will delegate the establishment of at least one Secure Channel with the communication peers, to the referred MKA instance. Once the MACsec Secure Channel is established and both participants can successfully receive and transmit, the Ethernet Interface will signal the Link-Up to the upper layers (e.g. through the Ethernet State Manager).

During the lifetime of the established SCs, the MKA module will maintain them alive by communicating with the MACsec Entities through the Ethernet Interface module. That means, updating the SC specific parameters in the MACsec Entities (Phy, Switch, or SW Entity).

Detailed information: The trigger to the MKA module to start the MACsec SC establishment is done after the EthTrcv or EthSwt mode indication to ACTIVE and before indicating this state to the EthSM (that means, the EthSM will stay in the ETHSM_STATE_WAIT_TRCVLINK state, as in this state the EthSM and the underlying EthIf is starting up the physical network interface, but the upper layer protocols (e.g., in TCP/IP) are not started yet).

Once triggered, the MKA module can start the needed actions to establish a MACsec



Secure Channel through the provided port. If MACsec is not configured in the port, the MKA module call will be skipped.

5.2 Indirect connection to EthDriver, EthSwitchDriver and Eth-TransceiverDriver

In case the MACsec Entity is offloaded to a HW device, the MKA module is indirectly connected to the EthDriver, EthSwitchDriver, and EthTranceiverDriver through the EthInterface. This connection is needed in order to establish, configure, and manage the needed MACsec Secure Channels. There are functions in the interface of the EthDriver, EthSwitchDriver and EthTransceiverDriver for that purpose.

Establishing a Secure Channel is done via the MACsec Key Agreement protocol, the MKA module will handle all protocol steps. These specific protocol datagrams are setup and organized by the MKA module. Thus, the MKA module provides via the existing function call the datagram to the Ethernet Interface, which then sends the datagram to the communication peer. This behavior is handled via a specific pair EtherType and message type, and is set via the interface. With this EtherType, the Ethernet Interface will handle the datagram on Rx and Tx trace.

5.3 Connection to Crypto Service Manager (CSM)

The MKA module requires a connection to the cryptographic BSW modules of AUTOSAR. This allows the MKA module to derive and use the needed keys and to interact with the cryptographic algorithms as specified in [5, IEEE-802.1X-2020] and [4, IEEE-802.1AE-2018].

For cryptographic usage, the MKA module needs following support from the BSW crypto:

- KDF (as described in [5, IEEE-802.1AE-2018] chapter 6.2.1) to derive ICK and KEK from CAK.
- AES-CMAC, which uses AES CMAC with 128bits, using ICK to generate and validate MKA message ICVs.
- A function to generate random data (for SAK and Member Identifier).
- AES-KEYWRAP based on [6, RFC 3394] to encrypt keys for transmission.



6 Requirements Tracing

The following tables reference the requirements specified in the documents listed in section 3.2 and links to the fulfillment of these. Please note that if column "Satisfied by" is empty for a specific requirement this means that this requirement is not fulfilled by this document.

Requirement	Description	Satisfied by
[FO_RS_MACsec 00001]	MACsec Protocol support	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00002]	MACsec Key Agreement Protocol support	[CP_SWS_Mka_00001] [CP_SWS_Mka_00002] [CP_SWS_Mka_00003] [CP_SWS_Mka_00004] [CP_SWS_Mka_00005] [CP_SWS_Mka_00006] [CP_SWS_Mka_00007] [CP_SWS_Mka_00008] [CP_SWS_Mka_00009] [CP_SWS_Mka_00011] [CP_SWS_Mka_00015] [CP_SWS_Mka_00016] [CP_SWS_Mka_00017] [CP_SWS_Mka_00024] [CP_SWS_Mka_00031] [CP_SWS_Mka_00032] [CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00003]	Using MACsec on external communication links	[CP_SWS_Mka_00001] [CP_SWS_Mka_00002] [CP_SWS_Mka_00006] [CP_SWS_Mka_00008] [CP_SWS_Mka_00024]
[FO_RS_MACsec 00004]	Configure which Ethernet ports use MACsec	[CP_SWS_Mka_00002]
[FO_RS_MACsec 00005]	MACsec status control	[CP_SWS_Mka_00026] [CP_SWS_Mka_00027] [CP_SWS_Mka_00028] [CP_SWS_Mka_00029] [CP_SWS_Mka_00030]
[FO_RS_MACsec 00006]	MACsec support for Adaptive AUTOSAR Platform	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00007] Configuration of unprotected traffic (for Software-based MACsec)		[CP_SWS_Mka_00003] [CP_SWS_Mka_00004]
[FO_RS_MACsec 00008] Configuration of unprotected traffic (for Hardware-based MACsec)		[CP_SWS_Mka_00003] [CP_SWS_Mka_00004]
[FO_RS_MACsec 00009]	MACsec Security Events	[CP_SWS_Mka_00025] [CP_SWS_Mka_00301] [CP_SWS_Mka_00303] [CP_SWS_Mka_00304] [CP_SWS_Mka_00305] [CP_SWS_Mka_00306] [CP_SWS_Mka_00307] [CP_SWS_Mka_00308]
[FO_RS_MACsec 00010]	Support of integrity and confidentiality	[CP_SWS_Mka_00008]
[FO_RS_MACsec 00011]	MAC Security TAG	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00012]	MACsec EtherType	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00017]	Support of Extended Packet Number (XPN)	[CP_SWS_Mka_00008]
[FO_RS_MACsec 00018]	Secure Channel Identifier (SCI)	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00019]	Secure Data	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00020]	Integrity Check Value (ICV)	[CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00021]	Protect function in software solution	[CP_SWS_Mka_00999]





 \triangle

B		Ontine district
Requirement	Description	Satisfied by
[FO_RS_MACsec 00022]	Validation function in software solution	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00023]	Support of MKA Packets	[CP_SWS_Mka_00001] [CP_SWS_Mka_00008]
[FO_RS_MACsec 00024]	Pre-shared key support	[CP_SWS_Mka_00001] [CP_SWS_Mka_00005] [CP_SWS_Mka_00016]
[FO_RS_MACsec 00025]	Key selection via CKN	[CP_SWS_Mka_00001] [CP_SWS_Mka_00005] [CP_SWS_Mka_00006]
[FO_RS_MACsec 00026]	GCM-based cipher support	[CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00027]	Support of AES ciphers with at least 128 bits of key length	[CP_SWS_Mka_00009] [CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00028]	Support of AES ciphers with 256 bits of key length	[CP_SWS_Mka_00009] [CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00029]	Support of Key Encryption Key (KEK)	[CP_SWS_Mka_00001] [CP_SWS_Mka_00006] [CP_SWS_Mka_00022] [CP_SWS_Mka_00023] [CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00030]	Support of Integrity Check Value Key (ICK)	[CP_SWS_Mka_00006] [CP_SWS_Mka_00022]
[FO_RS_MACsec 00031]	Support of Key Derivation Function (KDF)	[CP_SWS_Mka_00007]
[FO_RS_MACsec 00032]	List of minimal supported cipher suites	[CP_SWS_Mka_00009] [CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00033] Validation function for ICVs		[CP_SWS_Mka_00001] [CP_SWS_Mka_00006]
[FO_RS_MACsec 00034]	Generation function for ICVs	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00035]	Key Handling with combined HSM and MACsec functionality	[CP_SWS_Mka_00023]
[FO_RS_MACsec 00036]	Interframe gap configuration of Ethernet controller	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00037]	MACsec participants per link	[CP_SWS_Mka_00015]
[FO_RS_MACsec 00038]	MKA SC establishment retry phase	[CP_SWS_Mka_00012]
[FO_RS_MACsec 00039]	MKA rekey conditions	[CP_SWS_Mka_00013] [CP_SWS_Mka_00014]
[RS_lds_00810] Basic SW security events		[CP_SWS_Mka_00301] [CP_SWS_Mka_00302] [CP_SWS_Mka_00303]
[SRS_BSW_00323]	All AUTOSAR Basic Software Modules shall check passed API parameters for validity	[CP_SWS_Mka_91035]
[SRS_BSW_00337]	Classification of development errors	[CP_SWS_Mka_00200] [CP_SWS_Mka_00201] [CP_SWS_Mka_00202] [CP_SWS_Mka_00203] [CP_SWS_Mka_91035]
[SRS_BSW_00385]	List possible error notifications	[CP_SWS_Mka_00200] [CP_SWS_Mka_00201] [CP_SWS_Mka_00202] [CP_SWS_Mka_00203] [CP_SWS_Mka_91035]

Table 6.1: RequirementsTracing



7 Functional specification

7.1 Background and rationale

A detailed description of the MACsec and MACsec Key Agreement protocols is included in [3, RS MACsec] chapter 4.1.

7.2 Motivation

The aim of this document is to specify how to integrate the MKA Module in the Software Layered Architecture of the AUTOSAR Classic Platform.

The purpose of the MACsec Key Agreement Module is to provide a method for discovering MACsec peers and negotiate the security keys needed to secure the link. The MKA Module is responsible for:

- Generating (outgoing) and processing (incoming) MKPDUs.
- Identify and authenticate other partners belonging to the same Connectivity Association (CA).
- Configure and supply the parameters and cryptographic data to the MACsec Entity (per SW or HW) for the respective Secure Channel and Secure Associations established.
- Keep the established Secure Channel (SC) and Secure Association (SA) information updated.
- Refresh keys for an specific Secure Channel to allow exchanging Secure Association Keys (SAKs) without disrupting the communication channel.

The MKA module supports:

- The configuration, initialization, and maintenance of Port Access Entities (PAEs).
- The configuration, initialization, shutdown, and maintenance of MKA Entities (KaYs) which belong to an specific PAE.
- The communication with other AUTOSAR Modules to initialize, update, and shutdown MACsec related parameters into the MACsec Entity (SecY).

The limitations of the referred IEEE standards are included in chapter 4.

Figure 7.1 depicts the MACsec Key Agreement protocol parameter sets exchanged to establish a Secure Channel and finally enable MACsec protected secure communication.






Figure 7.1: fig: MACsec Key Agreement sequence with pre-shared key

Figure 7.2 provides an architecture overview of the AUTOSAR MKA module in the Layered Software Architecture.




Figure 7.2: MKA module in the SW Architecture of AUTOSAR CP



Based on the IEEE standards ([4, IEEE-802.1AE-2018] and [5, IEEE-802.1X-2020]), the system allows to configure, setup, and run integrity protected and/or encrypted data communication per Ethernet port. This implies that the architecture, specification, and the later implementation enables MACsec on each port when this is configured via AUTOSAR configuration. Additionally, this configuration is not only restricted towards ports. MACsec allows to "bypass" traffic based on EtherType or VLAN-ID. This means that MACsec lets selected traffic pass unprotected.

The usage of MACsec will be statically configured in advance for the entities supporting the protocol, the configuration will be based on rules. This includes rules for determining the bypassed traffic. Since the bypassed traffic can be based on VLAN IDs, the handling of MACsec protected networks interacts with VLAN-based communication. Bypassed traffic is available as soon as a link-up of the transceiver occurs, while protected traffic needs to wait for MACsec and its Key-Agreement sequence to finish first.

The Ethernet Interface will behave different for protected and unprotected traffic. The Ethernet Interface (EthIf) sequence is modified in case the controller (and therefore EthSwt and/or EthTrcv) has to deal with a MACsec protected port.

After receiving a Link-up indication from a MACsec protected port (which could be after a Switch), the Ethernet Interface will trigger the MKA Module to start the MKA Sequence for the corresponding port. Once the MKA module signals the success of the MKA sequence and therefore the proper configuration of MACsec on the port, the Link-Up is propagated to the upper layers (i.e., EthSM or others through the corresponding UL_LinkStateChg method). This is essential to start the upper layer protocols (e.g., SOME/IP-SD) as soon as the MACsec protected link is ready to be used.

This applies as well in case Groups of Ports are defined for the respective network.

7.2.1 Functional components

7.2.1.1 Port Access Entity (PAE)

In the [5, IEEE-802.1X-2020] standard the Port Access Entity (PAE) describes the (SW) entity that controls an Ethernet port. This includes allowing traffic to flow or not to flow but also controlling the MACsec functionality based on the MACsec Key Agreement protocol (MKA).

[5, IEEE-802.1X-2020] defines port based authentication over EAP and, as a particular use case, the MACsec Key Agreement protocol over EAP. In the current version of this document, authentication over EAP is not supported and therefore only authentication based on pre-shared CA Keys (CAKs) is relevant.

The PAE will take care of orchestrating the initialization and shutdown of MKA instances (defined in next section) and setting the status (enabled/disabled) of the physical or virtual controlled port based on the feedback provided by the underlying KaYs.



For a better understanding of the PAE structure, refer to [5, IEEE-802.1X-2020] chapter 12.

7.2.1.2 MACsec Key Agreement Entity (KaY)

Each PAE can have one or multiple MACsec Key Agreement participants (KaY participants) depending on the CKNs assigned to the Port Access Entity.

Each KaY is responsible of recognizing peers which belong to the same CA, distribute and/or install SAKs, and keep the MACsec information up to date during the SC lifetime.

The KaY handles the MKA protocol behavior, including the generation and process of MKPDUs, the control of the cipher suites to use and, the maintenance of the MACsec related parameters of the MACsec Entity (SecY), including Keys (SAKs).

7.3 General Requirements

[CP_SWS_Mka_00001]{DRAFT} [The MKA Module shall implement the EAP-MKA protocol version 3 as specified in [5, IEEE-802.1X-2020] chapter 9 and AU-TOSAR Foundation [3, RS_MACsec].](FO_RS_MACsec_00002, FO_RS_MACsec_00002, FO_RS_MACsec_00025, FO_RS_MACsec_00025, FO_RS_MACsec_00029, FO_RS_MACsec_00033)

Note: The MKA Module should be modeled as described in [5, IEEE-802.1X-2020] chapter 12.

For the excluded parts please refer to section 4.1.

[CP_SWS_Mka_00002]{DRAFT} [The MKA Module shall support 1 to n independent Port Access Entities (PAEs) running at the same time through different ports.] (FO_-RS_MACsec_00002, FO_RS_MACsec_00003, FO_RS_MACsec_00004)

Note: Each physical (Switch port or transceiver) or virtual (MACsec per SW) port will support 0 (No MACsec) or 1 PAE.

[CP_SWS_Mka_00003]{DRAFT} The MKA Module shall support a list of VLANs to get MACsec bypassed per PAE (i.e. per physical (Switch port or transceiver) or virtual (MACsec per SW) port).

The list of bypassed VLANs shall be provided per configuration (MkaBypassVlan).] (FO RS MACsec 00002, FO RS MACsec 00007, FO RS MACsec 00008)

Note: The MACsec by-passed traffic will be unprotected traffic through the port.

[CP_SWS_Mka_00004]{DRAFT} The MKA Module shall support a list of EtherTypes to get MACsec bypassed per PAE (i.e. per physical (Switch port or transceiver) or virtual (MACsec per SW) port).

The list of bypassed EtherTypes shall be provided per configuration (MkaBypas-



sEtherType).] (FO_RS_MACsec_00002, FO_RS_MACsec_00007, FO_RS_MACsec_00008)

Note: The MACsec bypassed traffic will be unprotected traffic through the port.

[CP_SWS_Mka_00005]{DRAFT} The MKA Module shall support configuring 1 to n CKNs in an specific Port Access Entity (PAE).

Each configured CKN will start a parallel MACsec participant entity (i.e. MkaKayParticipant) through the mentioned PAE.

Repeated CKNs shall be treated as one for an specific PAE. \(\(\) (FO_RS_MACsec_00002, FO_RS_MACsec_00024, FO_RS_MACsec_00025)

Note: It is recommended to implement a configuration check to avoid duplicated CKNs referred under the same MkaKay instance.

[CP_SWS_Mka_00006]{DRAFT} [An MKA KaY participant (MkaKayParticipant) shall not start transmitting or processing MKPDUs until its respective CAK is available and the derived keys (ICK and KEK) are ready.](FO_RS_MACsec_00002, FO_RS_MACsec_00003, FO_RS_MACsec_00025, FO_RS_MACsec_00029, FO_RS_MACsec_00030, FO_RS_MACsec_00033)

[CP_SWS_Mka_00007]{DRAFT} The MKA Module shall support generation of SAKs based on:

- Key Derivation Function (KDF), see [5, IEEE-802.1X-2020] chapter 9.8.1.
- Random Number Generator (RNG)

(FO RS MACsec 00002, FO RS MACsec 00031)

[CP_SWS_Mka_00008]{DRAFT} [The MKA Module shall support the following MKPDU Parameter sets:

- Basic Parameter Set
- Live Peer List → Parameter set type 1
- Potential Peer List → Parameter set type 2
- MACsec SAK Use → Parameter set type 3
- Distributed SAK → Parameter set type 4
- Announcement → Parameter set type 7
- XPN → Parameter set type 8

[FO_RS_MACsec_00002, FO_RS_MACsec_00003, FO_RS_MACsec_00010, FO_RS_MACsec_00017, FO_RS_MACsec_00023]

[CP_SWS_Mka_00009]{DRAFT} [The MKA Module shall implement the EAPoL-MKA-Announcement with TLV type 112 (MACsec cipher suites) as specified in [5, IEEE-



802.1X-2020] chapter 11.12.3. [FO_RS_MACsec_00002, FO_RS_MACsec_00027, FO_RS_MACsec_00028, FO_RS_MACsec_00032)

Note: The MACsec cipher suite announcement serves for the Key Server to recognize the ciphers supported by the other end.

The EAPoL-Announcement TLV shall be transmitted as a parameter on an EAPoL-MKA Announcement Parameter Set as defined in Figure 11-15 of [5, IEEE-802.1X-2020].

[CP_SWS_Mka_00011]{DRAFT} [The role of an MKA instance (MkaKay) shall be set per configuration (i.e. MKA_KEY_SERVER or MKA_PEER) (MkaRole).

The Key Server priority shall be configurable (MkaKeyServerPriority), in case it is not specifically provided in configuration the following values shall be used:

- Key Server = 0
- Peer = 255

(FO RS MACsec 00002, FO RS MACsec 00003)

[CP_SWS_Mka_00012]{DRAFT} The MKA Module shall support retry for the MKA sequence.

If an MKA KaY participant (MkaKayParticipant) cannot successfully identify or successfully establish a SC with any participant in the link, it should retry the MKA sequence following a per configuration parametrized retry base delay with Exponential Back-off (MkaRetryBaseDelay) until a retry cyclic delay (MkaRetryCyclicDelay). | (FO_RS_MACsec_00038)

Note: As an example, in case MkaRetryBaseDelay = 0.02 and MkaRetryCyclicDelay = 0.5, the retry sequence will be as follows 20ms, 40ms, 80ms, 160ms, 320ms, 500ms, 500ms, ...

[CP_SWS_Mka_00013]{DRAFT} [The MKA Instances (MkaKay) configured with the Key Server (MKA_KEY_SERVER) role shall support re-keying distributed SAKs after a configurable time span (MkaSakRekeyTimeSpan).|(FO RS MACsec 00039)

Note: The time span is set per configuration.

[CP_SWS_Mka_00014]{DRAFT} [The MKA Instances configured with the Key Server (MKA_KEY_SERVER) role shall rekey distributed SAKs in case the packet number space of one direction (sending or receiving) exceeds:

- 0xC000 0000 for 32-bit PNs.
- 0xC000 0000 0000 0000 for 64-bit PNs (XPN mode).

(FO RS MACsec 00039)

Note: This is required in the [5, IEEE-802.1X-2020] standard, chapter 9.8.



[CP_SWS_Mka_00015]{DRAFT} [Each MKA instance shall assume exactly two participants per link. Therefore, having exactly one peer.] (FO_RS_MACsec_00002, FO_-RS_MACsec_00037)

Note: This implies, that one must take the Key Server role and the other the peer role. This requirement permits a MKA instance to immediately continue with the MKA sequence after detecting and successfully authenticating another participant in the link which belongs to the same CA, avoiding start-up delays.

7.4 Limitations

An overview of non-supported features can be found in chapter 4.

7.4.1 Limitations on MKA Entity

[CP_SWS_Mka_00016]{DRAFT} [The MKA Module may support authentication based on EAP as detailed in [5, IEEE-802.1X-2020] chapter 8.] (FO_RS_MACsec_-00002, FO_RS_MACsec_00024)

Note: Authentication based on EAP is not required as the mutual authentication of participants is achieved based on pre-shared Keys.

[CP_SWS_Mka_00017]{DRAFT} [The MKA Module shall support only one MKA Participant (MkaKayParticipant) to success per port (i.e. per PAE MkaPaeInstance). If one KaY participant is able to correctly establish a SC, the other started participants (MkaKayParticipant) of the same PAE shall give up. | (FO RS MACsec 00002)

Note: As specified in [CP_SWS_Mka_00005], a PAE instance can initiate 1 to n MKA participant instances (MkaKayParticipant) but only one of them shall succeed configuring a Secure Channel in the port (Point-to-Multipoint architecture is not supported).

7.5 Cryptographic requirements

[CP_SWS_Mka_CONSTR_00019]{DRAFT} The MKA Module shall support the following Cipher suites to be configured in the MACsec Entity (either per SW or HW):

- GCM-AES-128
- GCM-AES-256
- GCM-AES-XPN-128
- GCM-AES-XPN-256



[FO_RS_MACsec_00002, FO_RS_MACsec_00020, FO_RS_MACsec_00026, FO_RS_MACsec_00027, FO_RS_MACsec_00028, FO_RS_MACsec_00029, FO_RS_MACsec_00032)

Note: The MKA Module shall support announcing and configuring the listed ciphers (MkaMacSecCipherSuite).

Detailed information can be found in [5, IEEE-802.1X-2020] Figure 11-12 and [4, IEEE-802.1AE-2018] chapter 14.3.

[CP_SWS_Mka_CONSTR_00020]{DRAFT} [The MKA Module shall support configuring 1 to 4 cipher suites per MkaCryptoAlgoConfig, each of them with an unique MkaMacSecCipherSuitePrio.

The MkaMacSecCipherSuitePrio shall accept the value 1 to 4, being 1 the higher priority and 4 the lowest priority.] (FO_RS_MACsec_00002, FO_RS_MACsec_00020, FO_RS_MACsec_00026, FO_RS_MACsec_00027, FO_RS_MACsec_00028, FO_RS_MACsec_00029, FO_RS_MACsec_00032)

Note: The MkaMacSecCipherSuitePrio parameter shall be used by a MkaKay-Participant with MkaRole = MKA_KEY_SERVER to select the cipher suite to use for MACsec with the other participant within the common cipher suites supported (shared with the EAPoL-MKA-Announcement "MACsec cipher suites").

The cryptographic operations like the derivation of MACsec keys and authentication based on CAK pre-shared keys should be delegated to the CSM Module.

Note: For detailed information, refer to [5, IEEE-802.1X-2020] chapter 9.3.

[CP_SWS_Mka_00022]{DRAFT} [Derived keys (specifically ICKs and KEKs) may get pre-calculated and stored in tamper proof manner to optimize the initialization time of the module.

SAKs are implicitly excluded from this requirement. SAKs must not be pre-calculated neither reused. | (FO RS MACsec 00029, FO RS MACsec 00030)

[CP_SWS_Mka_00023]{DRAFT} [It shall be supported that Secure Association Keys (SAKs) can directly be installed from a HSM to a MACsec Entity (SecY).](FO_RS_-MACsec 00029, FO RS MACsec 00035)

7.6 Communication with MACsec Entity (SecY)

The MKA Module, and particularly a specific MKA Entity (KaY) running over a PAE, shall initialize and maintain a Secure Channel for MACsec over an specific MACsec Entity (SecY). The mentioned MACsec Entity can be a SW implementation of MACsec in lower layers or a HW implementation in a Phy or Switch.

This shall be achieved with the API specified in chapter 8.



[CP_SWS_Mka_00024]{DRAFT} The MKA Module shall propagate the MACsec Entity specific parameters as needed by means of the EthIf API.

This requirement applies for the initialization, shutdown and, maintenance of MACsec related parameters. | (FO_RS_MACsec_00002, FO_RS_MACsec_00003)

[CP_SWS_Mka_00025]{DRAFT} The MKA Module shall collect the MACsec Entity (SecY) statistics when requested by means of the EthIf API.] (FO_RS_MACsec_00009)

Note: Other modules may request port specific MACsec statistics in order to set DTCs, answer to Diagnostics, and for monitoring.

7.7 Configurable behavior of MKA

[CP_SWS_Mka_00026]{DRAFT} [The status and behavior of a specific MkaPaeIn-stance shall be configurable per initial configuration. | (FO_RS_MACsec_00005)

Note: In case the proposal from [5, IEEE-802.1X-2020] chapter 12.5 is used, the variable *useEAP* is currently not supported (that means, the value shall be per default set to *Never*).

[CP_SWS_Mka_00027]{DRAFT} [It shall be possible to set the configuration of a specific PAE dynamically through the MKA module API.

The change shall apply in the next power cycle.

If a configuration parameter (e.g. through Mka_SetPaePermissiveMode, Mka_-SetCknStatus, or Mka_SetEnable) is changed by means of the API, the original per configuration set value shall be ignored and the in NVRAM persisted value shall be used from the next power cycle onwards. $(FO_RS_MACsec_00005)$

[CP_SWS_Mka_00028]{DRAFT} [In case MkaOnFailPermissiveMode == TIME-OUT and MkaParticipantActivate == TRUE for a specific MkaKayParticipant, it shall determine that the MKA has failed when all these conditions are met:

- MKA sequence did not succeed → The participants could not reach the state in which the SAK is installed for Rx and Tx.
- MKA timeout (MkaOnFailPermissiveModeTimeout) is exceeded.

If all these conditions are met, the error MKA_E_TIMEOUT shall be triggered. (FO_-RS_MACsec_00005)

Note: The MKA timeout value is set per configuration with the MkaOnFailPermissiveModeTimeout parameter.

[CP_SWS_Mka_00029]{DRAFT} [The MKA timer for MkaOnFailPermissiveMode-Timeout shall start counting after LinkUp (ETH_MODE_ACTIVE) of the referred physical or virtual port.] (FO_RS_MACsec_00005)

[CP_SWS_Mka_00030]{DRAFT} [The MkaOnFailPermissiveModeTimeout value shall be reset if any of the following conditions is met:



- After start up.
- On the transition from LinkDown (*ETH_MODE_DOWN*) to LinkUp (*ETH_MODE_ACTIVE*) of the referred physical or virtual port.

(FO RS MACsec 00005)

7.7.1 MKA behavior

[CP_SWS_Mka_00031]{DRAFT} [A MKA Entity (KaY) shall start the MKA sequence(s) through the referred EthIf (MkaEthIfControllerRef) immediately after receiving the port link-up signal with the Mka_LinkStateChange function.] (FO_RS_-MACsec 00002)

[CP_SWS_Mka_00032]{DRAFT} [A MKA Entity (KaY) shall signal the successful configuration of the MACsec protected port to the Ethlf with the Ethlf_MacSecOperational or Ethlf_SwitchMacSecOperational function.] (FO_RS_MACsec_-00002)

Note: A MKA Entity determines that the MACsec protected port is successfully configured as soon as MACsec protected frames can be transmitted and received from both participants.

7.7.2 MKA Error Handling

To ease complexity of the implementation, the MKA module may heal certain extended production errors automatically at start-up.

[CP_SWS_Mka_00033]{DRAFT} [If one or more CAKs referenced by MkaCryptoCk-nCakKeyRef is/are not initialized, MKA_E_KEY_NOT_PRESENT_INSTANCE shall be set to "Fail".]()

Note: Also see CSM Return Code CRYPTO E KEY NOT AVAILABLE.

[CP_SWS_Mka_00034]{DRAFT} [If the verification of the ICV of MKPDUs or the unwrapping of keys fails for one or more CKNs because of a wrong key, MKA E KEY MISMATCH INSTANCE shall be set to "Fail". | ()

[CP_SWS_Mka_00035]{DRAFT} [If the MKA peer only supports incompatible cipher suites, MKA_E_ALGO_MISMATCH_INSTANCE shall be set to "Fail".]()



Note: If an implementer chooses to not implement [CP_SWS_Mka_00036], the mentioned errors shall be healed on start-up of the MKA module.

7.8 Error Classification

Section "Error Handling" of the document [2] "General Specification of Basic Software Modules" describes the error handling of the Basic Software in detail. Above all, it constitutes a classification scheme consisting of five error types which may occur in BSW modules.

Based on this foundation, the following section specifies particular errors arranged in the respective subsections below.

7.8.1 Development Errors

[CP_SWS_Mka_91035]{DRAFT} Definition of development errors in module Mka

Type of error	Related error code	Error value
MKA Component initiated with null configuration	MKA_E_CFG_NULL_PTR	0x01
API called with invalid parameter value.	MKA_E_INVALID_PARAMETER	0x04
API called with a NULL pointer.	MKA_E_PARAM_POINTER	0x05
API called prior module is initialized.	MKA_E_UNINIT	0x06

(SRS BSW 00337, SRS BSW 00385, SRS BSW 00323)

7.8.2 Runtime Errors

There are no runtime errors.

7.8.3 Transient Faults

There are no transient faults.

7.8.4 Production Errors

There are no production errors.



7.8.5 Extended Production Errors

7.8.5.1 MKA_E_TIMEOUT_INSTANCE

[CP_SWS_Mka_00200] [

Error Name:	MKA_E_TIM	EOUT_INSTANCE	
Short Description:	MKA timeout while negotiating with remote peer.		
Long Description:	MKA timeout while negotiating with remote peer.		
	In case MkaO	nFailPermissiveMode == TIMEOUT and	
	MkaOnFailP	PermissiveModeTimeout is overflowed, the error	
	will be set.		
Detection Criteria:	Fail	If the PAE instance's	
		MkaOnFailPermissiveMode == TIMEOUT and	
		MkaOnFailPermissiveModeTimeout is	
		overflowed, the error will be set.	
	Pass	If the PAE instance's	
		MkaOnFailPermissiveMode == NEVER	
		or	
		If the PAE instance's	
		MkaOnFailPermissiveMode == TIMEOUT,	
		and the MkaKay could establish a transmission	
		and reception SC with a peer before	
		MkaOnFailPermissiveModeTimeout is	
		reached,	
	the error is not set.		
Secondary	Not Applicable		
Parameters:			
Time Required:	The time to detect the error is linked to the		
	MkaOnFailPermissiveMode and		
	MkaOnFailPermissiveModeTimeout.		
Monitor Frequency:	Once after port's link-up per port.		
MIL illumination:	Not Applicable		

\(\((SRS_BSW_00385, SRS_BSW_00337\)\)



7.8.5.2 MKA_E_KEY_NOT_PRESENT_INSTANCE

[CP_SWS_Mka_00201] [

Error Name:	MKA_E_KEY	MKA_E_KEY_NOT_PRESENT_INSTANCE	
Short Description:	Necessary ke	Necessary keys not present to initiate MKA negotiation.	
Long Description:	Pre-shared keys (i.e. CAK, ICK or KEK) to start the MKA sequence are not present in at least one of the active configured Kay Participants.		
Detection Criteria:	Fail The pre-shared keys of an active MkaKayParticipant are not present.		
	Pass	All Kay participants have the needed pre-shared keys present.	
Secondary	Not Applicable		
Parameters:			
Time Required:	0.5		
Monitor Frequency:	once-per-trip		
MIL illumination:	Not Applicabl	Not Applicable.	

(SRS_BSW_00385, SRS_BSW_00337)

7.8.5.3 MKA E KEY MISMATCH INSTANCE

[CP_SWS_Mka_00202] [

Error Name:	MKA_E_KEY_MISMATCH_INSTANCE		
Short Description:	MKA negotiation failed due to key mismatch with remote peer (MKPDUs ICV mismatch).		
Long Description:	MKA negotiation failed due to key mismatch with remote peer (MKPDUs ICV mismatch). Triggered in case MKPDU cannot be validated for received MKPDUs which distribute a matching CKN.		
Detection Criteria:	Fail A received MKPDU with matching CKN cannot be successfully validated.		
	Pass All received MKPDUs with matching CKN are successfully validated.		
Secondary Parameters:	Not Applicable		
Time Required:	Not Applicable.		
Monitor Frequency:	Continuous		
MIL illumination:	Not Applicable.		

(SRS_BSW_00385, SRS_BSW_00337)



7.8.5.4 MKA_E_ALGO_MISMATCH_INSTANCE

[CP_SWS_Mka_00203] [

Error Name:	MKA_E_ALGO_MISMATCH_INSTANCE		
Short Description:	MKA negotiation failed due to incompatible cipher suite with remote peer.		
Long Description:	MKA Negotiation failed due to incompatible cipher suite with remote peer. Triggered in case the participants in the MKA communication do not support any MACsec cipher suite in common and therefore cannot distribute neither install a valid SAK.		
Detection Criteria:	Fail The KaY participants of a communication (local and remote) do not support a common MACsec cipher suite.		
	Pass The KaY participants of a communication (local and remote) support one or more common MACsec cipher suites.		
Secondary Parameters:	Not Applicable		
Time Required:	Not Applicable.		
Monitor Frequency:	Continuous		
MIL illumination:	Not Applicable	е.	

(SRS_BSW_00385, SRS_BSW_00337)

7.9 Security Events

[CP_SWS_Mka_00301]{DRAFT} [If security event reporting has been enabled for the MKA module (MkaEnableSecurityEventReporting = true) the security events shall be reported to the IdsM via the interfaces defined in AUTOSAR SWS BSWGeneral.c|(RS Ids 00810, FO RS MACsec 00009)

[CP_SWS_Mka_00302] Security events for Mka

Name	Description	ID
SEV_MKA_AUTHENTICATION_FAILURE	Event triggered when the authentication during the MKA communication has failed (wrong CKN/CAK)	78
SEV_MKA_TIMEOUT	Event triggered when the timeout for the MKA communication has expired	79
SEV_MKA_PORT_NOT_ENABLED	Event triggered when the indicated port for the MKA communication is not enable	80
SEV_MKA_CIPHER_SUITE_NOT_ SUPPORTED	Event triggered when there is no Cipher Suite supported	81
SEV_MKA_PORT_NUMBER_CHANGE	Event triggered when during the MKA communication the port number has changed	82

(RS Ids 00810)



The following table describes the context data which shall be reported for the respective security events:

[CP_SWS_Mka_00303]{DRAFT}

Security Event	Context Data
SEV_MKA_AUTHENTICATION_FAILURE	Port ID
	• CKN
	MACAdress of peer
SEV_MKA_TIMEOUT	Port ID
	• CKN
	MACAdress of peer
SEV_MKA_PORT_NOT_ENABLED	Port ID
	• CKN
	MACAdress of peer
SEV_MKA_CIPHER_SUITE_NOT_SUPPORTED	Port ID
	• CKN
	MACAdress of peer
SEV_MKA_PORT_NUMBER_CHANGE	Port ID
	• CKN
	MACAdress of peer

Context data of respective security events of MKA and MACsec

(RS_lds_00810, FO_RS_MACsec_00009)

[CP_SWS_Mka_00304]{DRAFT} [MKA shall raise the SEv SEV_MKA_AUTHENTICATION_FAILURE to the IdsM ([RS_lds_00810]), when MKA module dropped a packet, because of authentication failure. | (FO_RS_MACsec_00009)

[CP_SWS_Mka_00305]{DRAFT} [MKA module shall raise the SEv SEV_MKA_TIME-OUT to the IdsM ([RS_lds_00810]), when MkaOnFailPermissiveModeTimeout has expired without receiving an MKA packet. | (FO RS MACsec 00009)

[CP_SWS_Mka_00306]{DRAFT} [MKA module shall raise the SEv_MKA_-PORT_NOT_ENABLED to the IdsM ([RS_Ids_00810]), when MKA module cannot communicate with the assigned port anymore.|(FO_RS_MACsec_00009)

[CP_SWS_Mka_00307]{DRAFT} [MKA module shall raise the SEv SEV_MKA_CIPHER_SUITE_NOT_SUPPORTED to the IdsM ([RS_Ids_00810]), when during the MKA communication, the MKA module detects a usage of a non supported Cipher Suite.] (FO_RS_MACsec_00009)

[CP_SWS_Mka_00308]{DRAFT} [MKA module shall raise the SEv_SEV_MKA_-PORT_NUMBER_CHANGE to the IdsM ([RS_Ids_00810]), when during an established MKA communication, the MKA module detects that the used port from the peer has changed.] (FO_RS_MACsec_00009)



8 API specification

8.1 Imported types

In this chapter all types included from the following files are listed.

$\begin{subarray}{ll} \cite{CP_SWS_Mka_91005]} \end{subarray} \begin{subarray}{ll} \cite{DRAFT} \end{subarray} \begin{subarray}{ll} \$

Module	Header File	Imported Type
ComStack_Types	ComStack_Types.h	BufReq_ReturnType
Eth	Eth_GeneralTypes.h	Eth_BufldxType
	Eth_GeneralTypes.h	Eth_FrameType
EthSwt	Eth_GeneralTypes.h	EthSwt_MgmtInfoType
EthTrcv	Eth_GeneralTypes.h	EthTrcv_LinkStateType
IdsM	ldsM_Types.h	ldsM_SecurityEventIdType
NvM	Rte_NvM_Type.h	NvM_BlockIdType
Std	Std_Types.h	Std_ReturnType
	Std_Types.h	Std_VersionInfoType

10

8.2 Type definitions

8.2.1 Mka_MacSecConfigType

[CP_SWS_Mka_91002]{DRAFT} Definition of datatype Mka_MacSecConfigType

Name	Mka_MacSecConfig	Mka_MacSecConfigType (DRAFT)	
Kind	Structure	Structure	
Elements	ProtectFrames		
Liements	Туре	boolean	
	Comment	Indicates status if the MACsec protection of the frames is active or not	
	ReplayProtect		
	Туре	boolean	
	Comment	Indicates status if replay protection is enable or disable	
	ReplayWindow		
	Туре	uint32	
	Comment	If ReplayProtect is enable, indicates the used replay protect window	
	ValidateFrames		
	Туре	Type Mka_ValidateFramesType	
	Comment	Status of the validation of the frames. See Mka_ValidateFramesType for possible values	
	CurrentCipherSuite		





 \triangle

	Туре	uint64
	Comment	Indicates which cipher suite is used in the SecY to update.
	ConfidentialityOffset	
	Туре	Mka_ConfidentialityOffsetType
	Comment	Set the Confidentiality Offset. See Mka_ConfidentialityOffsetType for possible values
	ControlledPortEnabled	
	Туре	boolean
	Comment	Status if the controlled port is enabled or disabled
	BypassedVlanPtrs	
	Туре	const uint16*
	Comment Pointer to the list of bypassed VLANs	
	BypassedVlansLength	
	Type uint8	
	Comment Length of the list of bypassed VLANs	
	BypassedEtherTypesPtr	
	Туре	const uint16*
	Comment	Pointer to the list of the bypassed Ethernet Types
	BypassedEtherTypesLen	gth
	Type uint8	
	Comment	Length of the list of the bypassed Ethernet Types
Description	Structure to configure a referred SecY	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()

8.2.2 Mka_ValidateFramesType

$\begin{tabular}{ll} $[CP_SWS_Mka_91004]$ {\tt DRAFT}$ & Definition of datatype $Mka_ValidateFramesType $$ $[CP_SWS_Mka_91004]$ {\tt DRAFT}$ & $[CP_SWS_Mka_91004]$ {\tt DRAFT}$ & $[CP_SWS_Mka_91004]$ {\tt DRAFT}$ & $[CP_SWS_Mka_91004]$ & $[CP_SWS_Mka_91004]$$

Name	Mka_ValidateFramesType (DRAFT)			
Kind	Enumeration	Enumeration		
Range	MKA_VALIDATE_ 0 Disable validation, remove SecTAGs and ICVs (if present) from received frames.			
	MKA_VALIDATE_ CHECKED	1	Enable validation, do not discard invalid frames	
	MKA_VALIDATE_STRICT	2	Enable validation and discard invalid frames	
Description	Controls validation of received frames			
	Tags: atp.Status=DRAFT			
Available via	Mka.h			



8.2.3 Mka_ConfidentialityOffsetType

[CP_SWS_Mka_91003]{DRAFT} Definition of datatype Mka_ConfidentialityOffset Type [

Name	Mka_ConfidentialityOffsetType (DRAFT)		
Kind	Enumeration		
Range	MKA_CONFIDENTIALITY_ 0 Confidentiality protection dis		Confidentiality protection disabled
	MKA_CONFIDENTIALITY_ OFFSET_0	1	Zero initial octets of each user data without confidentiality protection
	MKA_CONFIDENTIALITY_ OFFSET_30	2	30 initial octets of each user data without confidentiality protection
	MKA_CONFIDENTIALITY_ OFFSET_50	3	50 initial octets of each user data without confidentiality protection
Description	Indicates the offset in case of integrity with confidentiality		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

]()

8.2.4 Mka_Stats_Tx_SecYType

[CP_SWS_Mka_91008]{DRAFT} Definition of datatype Mka_Stats_Tx_SecYType

Name	Mka_Stats_Tx_SecYType (DRAFT)		
Kind	Structure		
Elements	OutPkts_Untagged		
	Туре	uint64	
	Comment	The number of packets transmitted without a SecTAG	
	OutPkts_TooLong		
	Туре	uint64	
	Comment The number of transmitted packets discarded because their length is greater than the accepted maximum length (mtu) of the Port		
	OutOctets_Protected		
	Type uint64		
	Comment	The number of plain text octets integrity protected but not encrypted in transmitted frames	
	OutOctets_Encrypted		
	Type uint64		
	Comment	The number of plain text octets integrity protected and encrypted in transmitted frames	
Description	MACsec Entity (SecY) transmission statistics		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		



8.2.5 Mka_Stats_Rx_SecYType

[CP_SWS_Mka_91010]{DRAFT} Definition of datatype Mka_Stats_Rx_SecYType

Name	Mka_Stats_Rx_Sec	Mka_Stats_Rx_SecYType (DRAFT)		
Kind	Structure	Structure		
	InPkts_Untagged	InPkts_Untagged		
Elements	Туре	uint64		
	Comment	The number of packets without the MACsec tag (SecTAG) received if Mka_ValidateFrames was not 'MKA_VALIDATE_STRICT'		
	InPkts_NoTag			
	Туре	uint64		
	Comment	The number of received packets without a SecTAG discarded because Mka_ValidateFrames was 'MKA_VALIDATE_STRICT'		
	InPkts_BadTag			
	Туре	uint64		
	Comment	The number of received packets discarded with an invalid SecTAG, zero value PN, or invalid ICV		
	InPkts_NoSa			
	Туре	uint64		
	Comment	The number of received packets with an unknown SCI or for an unused SA by the security entity		
	InPkts_NoSaError	InPkts_NoSaError		
	Туре	uint64		
	Comment	The number of packets discarded because the received SCI is unknown or the SA is not in use		
	InPkts_Overrun			
	Туре	uint64		
	Comment	The number of packets discarded because they exceeded cryptographic performance capabilities		
	InOctets_Validated			
	Туре	uint64		
	Comment	The number of plaintext octets recovered from packets that were integrity protected but not encrypted		
	InOctets_Decrypted			
	Туре	uint64		
	Comment	The number of plaintext octets recovered from packets that were integrity protected and encrypted		
Description	MACsec Entity (Sec)	Y) reception statistics		
	Tags: atp.Status=DF	Tags: atp.Status=DRAFT		
Available via	Mka.h			



8.2.6 Mka_Stats_Tx_ScType

[CP_SWS_Mka_91009]{DRAFT} Definition of datatype Mka_Stats_Tx_ScType [

Name	Mka_Stats_Tx_ScType (DRAFT)			
Kind	Structure			
Elements	OutPkts_Protected			
	Туре	uint64		
	Comment The number of integrity protected but not encrypted packets for this transmit SC			
	OutPkts_Encrypted			
	Type uint64			
	Comment The number of integrity protected and encrypted packets for this transmit SC			
Description	Secure Channel transmission statistics			
	Tags: atp.Status=DRAFT			
Available via	Mka.h			

]()

8.2.7 Mka_Stats_Rx_ScType

$\textbf{[CP_SWS_Mka_91011]} \{ \texttt{DRAFT} \} \ \textbf{Definition of datatype Mka_Stats_Rx_ScType} \ \lceil$

Name	Mka_Stats_Rx_ScType (DRAFT)		
Kind	Structure		
Elements	InPkts_Ok		
Liements	Туре	uint64	
	Comment	The number of packets received for this secure channel successfully validated and within the replay window	
	InPkts_Unchecked		
	Туре	uint64	
	Comment	The number of packets received for this secure channel, if Mka_ ValidateFrames was 'MKA_VALIDATE_DISABLED'	
	InPkts_Delayed		
	Туре	uint64	
	Comment	The number of received packets, for this secure channel, with packet number (PN) lower than the lowest acceptable packet number (Lowes Pn) and ReplayProtect was false	
	InPkts_Late		
	Туре	uint64	
	Comment	The number of packets discarded, for this secure channel, because the received packet number (PN) was lower than the lowest acceptable packet number (LowestPn) and ReplayProtect was true	
	InPkts_Invalid		
	Туре	uint64	





 \triangle

	Comment	The number of packets, for this secure channel, that failed validation but could be received because ValidateFrames was 'MKA_VALIDATE_CHECKED' and the data was not encrypted (so the original frame could be recovered)	
	InPkts_NotValid		
	Туре	uint64	
	Comment	The number of packets discarded, for this secure channel, because validation failed and ValidateFrames was 'MKA_VALIDATE_STRICT' or the data was encrypted (so the original frame could not be recovered)	
Description	Secure Channel reception statistics		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

]()

8.2.8 Mka_SakKeyPtrType

[CP_SWS_Mka_91013]{DRAFT} Definition of datatype Mka_SakKeyPtrType |

Name	Mka_SakKeyPtrType (DRAFT)		
Kind	Structure		
Elements	HashKeyPtr		
	Туре	const uint8*	
	Comment	Pointer to the Hash Key	
	SakKeyPtr		
	Туре	const uint8*	
	Comment	Pointer to the SAK	
	SaltKeyPtr		
	Туре	const uint8*	
	Comment	Pointer to the Salt	
Description	SAK key reference		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

10



8.2.9 Mka_PermissiveModeType

$\begin{tabular}{ll} [CP_SWS_Mka_91012] {\sf DRAFT} & \textbf{Definition of datatype Mka_PermisiveModeType} \\ \end{tabular}$

Name	Mka_PermisiveModeType (DRAFT)		
Kind	Enumeration		
Range	NEVER	0	The controlled port will never be set to enabled if the participants cannot establish and successfully use a MACsec Secure Channel.
	TIMEOUT	1	The controlled port will be set to enabled and MACsec will not be used in the referred port if the timeout value (MkaOnFailPermissive Mode Timeout) is reached and none MKA instance under the PAE instance could success the following conditions: - A participant belonging to the same CA was recognized and authenticated A secure channel could be established Both participants can transmit and receive MACsec protected traffic through the SC.
Description	Permissive modes of MKA		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

]()

8.2.10 Mka_Stats_SecYType

[CP_SWS_Mka_91028]{DRAFT} Definition of datatype Mka_Stats_SecYType [

Name	Mka_Stats_SecYType (DRAFT)			
Kind	Structure			
Elements	StatsTxPhy			
	Туре	Mka_Stats_Tx_SecYType		
	Comment	Set of statistics in the Security Entity Phy by transmision		
	StatsRxPhy			
	Type Mka_Stats_Rx_SecYType			
	Comment Set of statistics in the Security Entity Phy by reception			
	StatsTxSc			
	Type Mka_Stats_Tx_ScType Comment Set of statistics in the Security Entity's Secure Channel by reception			
	StatsRxSc Type Mka_Stats_Rx_ScType			
	Comment	Set of statistics in the Security Entity's Secure Channel by reception		
Description	Security Entity statistics			
	Tags: atp.Status=DRAFT			
Available via	Mka.h			

10



8.2.11 Mka_PaeStatusType

[CP_SWS_Mka_91027]{DRAFT} Definition of datatype Mka_PaeStatusType

Name	Mka_PaeStatusType (DRAFT)			
Kind	Structure			
Elements	ConnectionStatus			
	Туре	Mka_MkaStatus		
	Comment Status of the MKA			
	PeerSci			
	Type uint64			
	Comment SCI includes the peer's MAC and port			
	CknInUse			
	Type Array of unsigned char[32]			
	Size	ize 32		
	Comment	CKN used for the establishment of the MACsec Secure Channel		
Description	Structure with the specific information of a PAE			
	Tags: atp.Status=DRAFT			
Available via	Mka.h			

]()

8.2.12 Mka_MkaStatusType

[CP_SWS_Mka_91025]{DRAFT} Definition of datatype Mka_MkaStatus

Name	Mka_MkaStatus (DRAFT)		
Kind	Enumeration		
Range	MKA_STATUS_MACSEC_ RUNNING	0	MKA session key has been agreed and MACsec link is currently up
	MKA_STATUS_WAITING_ PEER_LINK	1	MKA is waiting for a link up of the underlying device to begin negotiation
	MKA_STATUS_WAITING_ PEER	2	MKA is waiting for a remote peer to transmit MKPDU's to begin negotiation
	MKA_STATUS_IN_ PROGRESS	3	MKA negotiation is ongoing
	MKA_STATUS_AUTH_ FAIL_UNKNOWN_PEER	4	MKA negotiation is not possible because ICV's of remote peer are invalid (ICK and therefore CAK keys are different)
	MKA_STATUS_ UNDEFINED	0xFF	Undefined state, reported when the given bus is disabled
Description	Status of the MKA instance.		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		



8.2.13 Mka_ConfigType

[CP_SWS_Mka_91026]{DRAFT} Definition of datatype Mka_ConfigType [

Name	Mka_ConfigType (DRAFT)	
Kind	Structure	
Description	Implementation specific structure of the post build configuration	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()

8.3 Function definitions

8.3.1 Mka_Init

[CP_SWS_Mka_91001]{DRAFT} Definition of API function Mka_Init [

Service Name	Mka_Init (DRAFT)	
Syntax	Std_ReturnType Mka_Init (const Mka_ConfigType* ConfigPtr)	
Service ID [hex]	0x1	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	ConfigPtr Points to the implementation specific structure	
Parameters (inout)	None	
Parameters (out)	None	
Return value	Std_ReturnType E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	
Description	Initializes the MKA module	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()

8.3.2 Mka GetVersionInfo

[CP_SWS_Mka_91014]{DRAFT} Definition of API function Mka_GetVersionInfo

Service Name	Mka_GetVersionInfo (DRAFT)
Syntax	Std_ReturnType Mka_GetVersionInfo (Std_VersionInfoType* VersionInfoPtr)
Service ID [hex]	0x2





- /	١.
/	\
\angle	_

Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (in)	None	
Parameters (inout)	None	
Parameters (out)	VersionInfoPtr Version information of this module	
Return value	Std_ReturnType	
Description	Returns the version information of this module	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

10

8.3.3 Mka SetCknStatus

[CP_SWS_Mka_91015]{DRAFT} Definition of API function Mka_SetCknStatus

Service Name	Mka_SetCknStatus (DRAF	Mka_SetCknStatus (DRAFT)	
Syntax	Std_ReturnType Mka_SetCknStatus (uint8 MkaPaeIdx, boolean Enable, const uint8* Ckn, uint8 CknLength)		
Service ID [hex]	0x3		
Sync/Async	Synchronous		
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx		
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module	
	Enable	Boolean to control the Mka Participant Activate status.	
		True -> The MKA Participant exchanges MKPDUs.	
		False -> The MKA Participant does not exchange MKPDUs.	
	Ckn Connectivity Association Key Name to identify the Ka		
	CknLength Length of the CKN parameter provided		
Parameters (inout)	None		
Parameters (out)	None		
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	
Description	Set status of a CKN from a PAE		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

10

[CP_SWS_Mka_01001]{DRAFT} [The function $Mka_SetCknStatus$ shall set the activation status of the MkaKayParticipant which contains the provided Ckn under the provided MkaPaeIdx.

The new activation status shall be persistently stored in NVM and used from next power cycle onwards (as required in [CP_SWS_Mka_00030]).



The per configuration provided activation status (MkaParticipantActivate) of the MkaKayParticipant shall not be used if a valid value is stored on the NVM.]()

8.3.4 Mka_GetCknStatus

[CP_SWS_Mka_91016]{DRAFT} Definition of API function Mka_GetCknStatus

Service Name	Mka_GetCknStatus (DRAF	T)	
Syntax	Std_ReturnType Mka_GetCknStatus (uint8 MkaPaeIdx, const uint8* Ckn, uint8 CknLength, boolean* EnablePtr)		
Service ID [hex]	0x4		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Reentrant for different Mkal	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module	
	Ckn Connectivity Association Key Name to identify the KaY participant CknLength Length of the CKN parameter provided		
Parameters (inout)	None		
Parameters (out)	EnablePtr	Pointer to the Mka Participant activation status	
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	
Description	Get Status of a CKN from a PAE		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

10

8.3.5 Mka_SetEnable

[CP_SWS_Mka_91020]{DRAFT} Definition of API function Mka_SetEnable [

Service Name	Mka_SetEnable (DRAFT)	Mka_SetEnable (DRAFT)	
Syntax	Std_ReturnType Mka_SetEnable (uint8 MkaPaeIdx, boolean Enable)		
Service ID [hex]	0x8	0x8	
Sync/Async	Synchronous	Synchronous	
Reentrancy	Reentrant for different Mka	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module	
	Enable	Boolean to control the Mka activation of a PAE.	
Parameters (inout)	None		
Parameters (out)	None		





Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted
Description	Set the MKA activation status of a PAE	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

10

[CP_SWS_Mka_01002]{DRAFT} [The function $Mka_SetEnable$ shall set the activation status of the MkaKay of the provided MkaPaeIdx.

The new activation status shall be persistently stored in NVM and used from next power cycle onwards (as required in [CP_SWS_Mka_00030]).|()

8.3.6 Mka GetEnable

[CP_SWS_Mka_91017]{DRAFT} Definition of API function Mka_GetEnable [

Service Name	Mka_GetEnable (DRAFT)	
Syntax	Std_ReturnType Mka_GetEnable (uint8 MkaPaeIdx, boolean* EnablePtr)	
Service ID [hex]	0x5	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx Index of the PAE within the context of the MKA module	
Parameters (inout)	None	
Parameters (out)	EnablePtr	Pointer to the Mka activation status of a PAE.
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted
Description	Get the MKA activation status of a PAE	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()

8.3.7 Mka GetPaeStatus

[CP_SWS_Mka_91018]{DRAFT} Definition of API function Mka_GetPaeStatus [

Service Name	Mka_GetPaeStatus (DRAFT)
Syntax	<pre>Std_ReturnType Mka_GetPaeStatus (uint8 MkaPaeIdx, Mka_PaeStatusType* PaeStatusPtr)</pre>





Service ID [hex]	0x6	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different MkaF	Paeldx, Non reentrant for the same MkaPaeldx
Parameters (in)	MkaPaeldx Index of the PAE within the context of the MKA module	
Parameters (inout)	None	
Parameters (out)	PaeStatusPtr	Pointer to the status structure, which includes detailed information of a PAE.
Return value	Std_ReturnType	
Description	Get detailed information of a PAE	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

10

8.3.8 Mka SetPaePermissiveMode

[CP_SWS_Mka_91021]{DRAFT} Definition of API function Mka_SetPaePermissive Mode [

Service Name	Mka_SetPaePermissiveMode (DRAFT)		
Syntax	Std_ReturnType Mka_SetPaePermissiveMode (uint8 MkaPaeIdx, Mka_PermisiveModeType PermisiveMode)		
Service ID [hex]	0x9		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Reentrant for different MkaF	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module	
	PermisiveMode	Permissive mode to set in the PAE.	
Parameters (inout)	None		
Parameters (out)	None		
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	
Description	Set Permissive Mode of a KaY		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

10

The new PermisiveMode shall be persistently stored in NVM and used from next power cycle onwards (as required in [CP SWS Mka 00030]).

The per configuration provided MkaOnFailPermissiveMode of the MkaPaeInstance shall not be used if a valid value is stored on the NVM. | ()



8.3.9 Mka StartPae

[CP_SWS_Mka_91022]{DRAFT} Definition of API function Mka_StartPae

Service Name	Mka_StartPae (DRAFT)	
Syntax	Std_ReturnType Mka_StartPae (uint8 MkaPaeIdx)	
Service ID [hex]	0x10	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module
Parameters (inout)	None	
Parameters (out)	None	
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted
Description	Manual start of the PAE instace. (In case MkaPaeConfiguration.Autostart = False this method starts the PAE operation)	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

 $\rfloor ()$

[CP_SWS_Mka_01004]{DRAFT} [The function Mka_StartPae shall start the operation of the MkaPaeInstance referred with the MkaPaeIdx if the MkaAutoStart configuration parameter is TRUE.

If the MkaAutoStart configuration parameter is FALSE, $Mka_StartPae$ will not have any effect on the referred MkaPaeInstance. ()

8.3.10 Mka_GetMacSecStatistics

[CP_SWS_Mka_91019]{DRAFT} Definition of API function Mka_GetMacSecStatistics \lceil

Service Name	Mka_GetMacSecStatistics (DRAFT)	
Syntax	<pre>Std_ReturnType Mka_GetMacSecStatistics (uint8 MkaPaeIdx, const uint8* Ckn, uint8 CknLength)</pre>	
Service ID [hex]	0x7	
Sync/Async	Asynchronous	
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module
	Ckn	Connectivity Association Key Name to identify the KaY participant
	CknLength	Length of the CKN parameter provided
Parameters (inout)	None	
Parameters (out)	None	





Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted
Description	Get Statistics of a PAE	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()

8.3.11 Mka_LinkStateChange

$\begin{tabular}{ll} \begin{tabular}{ll} \be$

Service Name	Mka_LinkStateChange ([Mka_LinkStateChange (DRAFT)	
Syntax	uint8 MkaPaeIdx,	Std_ReturnType Mka_LinkStateChange (uint8 MkaPaeIdx, EthTrcv_LinkStateType TransceiverLinkState)	
Service ID [hex]	0x1d		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Reentrant for different Mk	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module	
	TransceiverLinkState	The Ethernet link state of a physical Ethernet connection.	
Parameters (inout)	None	None	
Parameters (out)	None	None	
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	
Description	To inform MKA that a dec	To inform MKA that a dedicated Trcv/Switch/PAC port link state has changed	
	Tags: atp.Status=DRAFT	Tags: atp.Status=DRAFT	
Available via	Mka.h		

10

8.4 Callback notifications

This is a list of functions provided for other modules.



8.4.1 Mka GetMacSecStatisticsNotification

[CP_SWS_Mka_91024]{DRAFT} Definition of callback function Mka_GetMacSec StatisticsNotification \lceil

Service Name	Mka_GetMacSecStatisticsN	Notification (DRAFT)	
Syntax	<pre>void Mka_GetMacSecStatisticsNotification (uint8 MkaPaeIdx, const Mka_Stats_SecYType* MacSecStatsPtr)</pre>		
Service ID [hex]	0x1e		
Sync/Async	Synchronous		
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx		
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module	
	MacSecStatsPtr	Pointer to a structure including the MACsec statistics of an MKA participant	
Parameters (inout)	None		
Parameters (out)	None	None	
Return value	None		
Description	Callback to notify that Mka_GetMacSecStatistics finished and provide the requested statistics.		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

10

8.4.2 Mka_RxIndication

$\textbf{[CP_SWS_Mka_91029]} \\ \textbf{\{DRAFT\} Definition of callback function Mka_RxIndication Black function Black function$

Service Name	Mka_RxIndication (DRAFT)	
Syntax	<pre>void Mka_RxIndication (uint8 CtrlIdx, Eth_FrameType FrameType, boolean IsBroadcast, const uint8* PhysAddrPtr, const uint8* DataPtr, uint16 LenByte)</pre>	
Service ID [hex]	0x1f	
Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (in)	Ctrlldx	Index of the physical Ethernet controller within the context of the Ethernet Interface
	FrameType Frame type of received Ethernet frame	
	IsBroadcast parameter to indicate a broadcast frame	
	PhysAddrPtr Pointer to Physical source address (MAC address in network bytorder) of received Ethernet frame	
	DataPtr	Pointer to payload of received Ethernet frame.





	LenByte	Length (bytes) of the payload in received frame.
Parameters (inout)	None	
Parameters (out)	None	
Return value	None	
Description	To inform Mka about the reception of MKA Frames	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()

8.4.3 Mka_TxConfirmation

[CP_SWS_Mka_91030]{DRAFT} Definition of callback function Mka_TxConfirmation \lceil

Service Name	Mka_TxConfirmation (DRAF	-T)
Syntax	<pre>void Mka_TxConfirmation (uint8 CtrlIdx, Eth_BufIdxType BufIdx, Std_ReturnType Result)</pre>	
Service ID [hex]	0x20	
Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (in)	Ctrlldx	Index of the physical Ethernet controller within the context of the Ethernet Interface
	Bufldx	Index of the transmitted buffer
	Result	E_OK: The transmission was successful E_NOT_OK: The transmission failed.
Parameters (inout)	None	
Parameters (out)	None	
Return value	None	
Description	To inform MKA about the correct transmition of MKA Frames.	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()



8.4.4 Mka_MacSecUpdateSecYNotification

[CP_SWS_Mka_91031]{DRAFT} Definition of callback function Mka_MacSecUpdateSecYNotification \lceil

Service Name	Mka_MacSecUpdateSecYNotification (DRAFT)		
Syntax	void Mka_MacSecUpdateSecYNotification (uint8 MkaPaeIdx)		
Service ID [hex]	0x21		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx		
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module	
Parameters (inout)	None		
Parameters (out)	None		
Return value	None		
Description	Callback to notify that Ehtlf_MacSecUpdateSecY finished.		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

10

8.4.5 Mka MacSecAddTxSaNotification

[CP_SWS_Mka_91032]{DRAFT} Definition of callback function Mka_MacSecAdd TxSaNotification \lceil

Service Name	Mka_MacSecAddTxSaNotification (DRAFT)	
Syntax	void Mka_MacSecAddTxSaNotification (uint8 MkaPaeIdx)	
Service ID [hex]	0x22	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module
Parameters (inout)	None	
Parameters (out)	None	
Return value	None	
Description	Callback to notify that Ethlf_MacSecAddTxSa finished.	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()



8.4.6 Mka MacSecAddRxSaNotification

[CP_SWS_Mka_91033]{DRAFT} Definition of callback function Mka_MacSecAdd RxSaNotification \lceil

Service Name	Mka_MacSecAddRxSaNotification (DRAFT)		
Syntax	void Mka_MacSecAddRxSaNotification (uint8 MkaPaeIdx)		
Service ID [hex]	0x23		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx		
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module	
Parameters (inout)	None		
Parameters (out)	None		
Return value	None		
Description	Callback to notify that EthIf_MacSecAddRxSa finished.		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

10

8.5 Scheduled functions

These functions are directly called by Basic Software Scheduler. The following functions shall have no return value and no parameter. All functions shall be non reentrant.

8.5.1 Mka_MainFunction

[CP_SWS_Mka_91034]{DRAFT} Definition of scheduled function Mka_MainFunction \lceil

Service Name	Mka_MainFunction (DRAFT)
Syntax	<pre>void Mka_MainFunction (void)</pre>
Service ID [hex]	0x24
Description	Main function for cyclic call.
	Tags: atp.Status=DRAFT
Available via	Mka.h

10

[CP_SWS_Mka_01005]{DRAFT} [The frequency of invocations of Mka_MainFunction is determined by the configuration parameter MkaMainFunctionPeriod. | ()



8.6 Expected interfaces

In this chapter all interfaces required from other modules are listed.

8.6.1 Mandatory interfaces

Note: This section defines all interfaces, which are required to fulfill the core functionality of the module.

$\label{eq:cp_sws_mka_91006} \mbox{[CP_SWS_Mka_91006]{DRAFT}} \ \mbox{Definition of mandatory interfaces in module Mka}$

API Function	Header File	Description
EthIf_ProvideTxBuffer	Ethlf.h	Provides access to a transmit buffer of the specified Ethernet controller.
EthIf_Transmit	Ethlf.h	Triggers transmission of a previously filled transmit buffer
NvM_EraseNvBlock	NvM.h	Service to erase a NV block.
NvM_ReadBlock	NvM.h	Service to copy the data of the NV block to its corresponding RAM block.
NvM_WriteBlock	NvM.h	Service to copy the data of the RAM block to its corresponding NV block.

10

8.6.2 Optional interfaces

This section defines all interfaces, which are required to fulfill an optional functionality of the module.

[CP_SWS_Mka_91007]{DRAFT} Definition of optional interfaces in module Mka

API Function	Header File	Description
Det_ReportError	Det.h	Service to report development errors.
Det_ReportRuntimeError	Det.h	Service to report runtime errors. If a callout has been configured then this callout shall be called.
EthIf_GetPhysAddr	Ethlf.h	Obtains the physical source address used by the indexed controller
EthIf_SetSwitchMgmtInfo	Ethlf.h	Provides additional management information along to an Ethernet frame that requires special treatment within the Switch. It has to be called between EthIf_ProvideTxBuffer() and EthIf_Transmit() of the related frame.
IdsM_SetSecurityEvent	ldsM.h	This API is the application interface to report security events to the IdsM.

10



8.6.3 Configurable interfaces

There are no configurable interfaces defined.

8.7 Service Interfaces

There are no service interfaces defined.



9 Sequence diagrams

The sequence diagrams show the basic operations carried out during operation. The purpose of the sequence diagrams is to depict the expected behavior of the communication stack at a glance.

The communication initialization sequence diagrams illustrate how the MKA module gets involved in the Ethernet stack start-up including upper and lower layer modules.



9.1 Communication initialization with MACsec




Figure 9.1: Communication initialization with MACsec protected Ethlf



9.2 Communication initialization with MACsec and Switch




Figure 9.2: Communication initialization with MACsec protected Ethlf and Switch



10 Configuration specification

In general, this chapter defines configuration parameters and their clustering into containers. In order to support the specification Chapter 10.1 describes fundamentals. It also specifies a template (table) you shall use for the parameter specification. We intend to leave Chapter 10.1 in the specification to guarantee comprehension.

Chapter 10.2 specifies the structure (containers) and the parameters of the module MKA.

Chapter 10.3 specifies published information of the module MKA.

10.1 How to read this chapter

For details refer to the chapter 10.1 "Introduction to configuration specification" in SWS BSWGeneral.

10.2 Containers and configuration parameters

The following chapters summarize all configuration parameters. The detailed meanings of the parameters describe Chapter 7 and Chapter 8.

10.2.1 Mka

SWS Item	[ECUC_Mka_00001]
Module Name	Mka
Description	Configuration of the MACsec Key Agreement module.
Post-Build Variant Support	false
Supported Config Variants	VARIANT-PRE-COMPILE

Included Containers				
Container Name	Multiplicity	Scope / Dependency		
MkaCryptoAlgoConfig	1255	Cryptography configuration for MACsec.		
		Tags: atp.Status=draft		
MkaGeneral	1	This container holds the general parameters of the MKA protocol which apply to ports that are referencing this container.		
		Tags: atp.Status=draft		
MkaPaeConfiguration	1255	Common MKA configuration for a PAE.		
		Tags: atp.Status=draft		
MkaPaeInstance	1255	MKA configuration of a controlled port.		
		Tags: atp.Status=draft		






Figure 10.1: Mka

10.2.2 MkaGeneral

SWS Item	[ECUC_Mka_00002]
Container Name	MkaGeneral
Parent Container	Mka
Description	This container holds the general parameters of the MKA protocol which apply to ports that are referencing this container.
	Tags: atp.Status=draft
Configuration Parameters	

SWS Item	[ECUC_Mka_00034]		
Parameter Name	MkaDevErrorDetect		
Parent Container	MkaGeneral		
Description	Switches the development error detection and notification on or off true: detection and notification is enabled false: detection and notification is disabled.		
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	EcucBooleanParamDef		
Default value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	-	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00061]
Parameter Name	MkaEnableSecurityEventReporting
Parent Container	MkaGeneral
Description	Switches the reporting of security events to the ldsM: - true: reporting is enabled false: reporting is disabled
	Tags: atp.Status=draft
Multiplicity	1





Туре	EcucBooleanParamDef		
Default value	false		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00007]			
Parameter Name	MkaHelloTime	MkaHelloTime		
Parent Container	MkaGeneral			
Description	Interval [s] between MKPDUs when two participants have an active MKA communication (the participants are included in the Live Peer list of each other).			
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	EcucFloatParamDef			
Range	[0 INF]			
Default value	2			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00009]			
Parameter Name	MkaLifeTime	MkaLifeTime		
Parent Container	MkaGeneral			
Description	Time span [s] since last MKPDU was received from the other participant, to consider it alive. \newline In case no valid MKPDU from the other participant is received after Mka LifeTime, the Secure Channel is shut down.			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	EcucFloatParamDef			
Range	[0 INF]			
Default value	6	•		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00035]	
Parameter Name	MkaMainFunctionPeriod	
Parent Container	MkaGeneral	
Description	The cycle time of the periodic main function of MKA. Defined in seconds.	
	Tags: atp.Status=draft	
Multiplicity	1	
Туре	EcucFloatParamDef	
Range	[0 INF]	







Default value	-		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00010]	[ECUC_Mka_00010]		
Parameter Name	MkaSakRetireTime	MkaSakRetireTime		
Parent Container	MkaGeneral			
Description	During an SAK rekey, time [s] to retire the p	revious SAK in use.	
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	EcucFloatParamDef	EcucFloatParamDef		
Range	[0 INF]	[0 INF]		
Default value	3	3		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00036]			
Parameter Name	MkaVersionInfoApi			
Parent Container	MkaGeneral			
Description	Enables / Disables version info API.			
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	EcucBooleanParamDef			
Default value	false			
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: local			

Included Containers			
Container Name	Multiplicity	Scope / Dependency	
MkaSecurityEventRefs	01	Container for the references to IdsMEvent elements representing the security events that the Mka module shall report to the IdsM in case the corresponding security related event occurs (and if MkaEnableSecurityEventReporting is set to "true"). The standardized security events in this container can be extended by vendor-specific security events. Tags: atp.Status=draft	






Figure 10.2: MkaGeneral

10.2.3 MkaPaeConfiguration

SWS Item	[ECUC_Mka_00033]
Container Name	MkaPaeConfiguration
Parent Container	Mka
Description	Common MKA configuration for a PAE.
	Tags: atp.Status=draft
Configuration Parameters	



SWS Item	[ECUC_Mka_00012]			
Parameter Name	MkaAutoStart	MkaAutoStart		
Parent Container	MkaPaeConfiguration			
Description	Autostart or manual start of the PAE Instance. True := Autostart False := Manual Start If Autostart = False, the method Mka_StartPae is used to start the PAE instance.			
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	EcucBooleanParamDef			
Default value	true			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00037]			
Parameter Name	MkaPaeConfigurationIdx	MkaPaeConfigurationIdx		
Parent Container	MkaPaeConfiguration	MkaPaeConfiguration		
Description	Instance ID of the MkaPaeConfigura	Instance ID of the MkaPaeConfiguration.		
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	EcucIntegerParamDef (Symbolic Name generated for this parameter)			
Range	0 255			
Default value	-			
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00004]	[ECUC_Mka_00004]		
Parameter Name	MkaRetryBaseDelay	MkaRetryBaseDelay		
Parent Container	MkaPaeConfiguration			
Description	back off delay (1x base delay	The base delay in seconds for the retry phase of MKA. The retry have an exponential back off delay (1x base delay, 2x base delay, 4x base delay,) until the retry delay overflows the MkaRetryCyclicDelay value.		
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	EcucFloatParamDef	EcucFloatParamDef		
Range	[0 INF]			
Default value	-	•		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00005]
Parameter Name	MkaRetryCyclicDelay
Parent Container	MkaPaeConfiguration





Specification of MACsec Key Agreement AUTOSAR CP R23-11

\triangle

Description	Interval in seconds between retries after base delay with exponential back off.		
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	EcucFloatParamDef		
Range	[0 INF]		
Default value	-		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00024]	[ECUC_Mka_00024]		
Parameter Name	MkaSakRekeyTimeSpan	MkaSakRekeyTimeSpan		
Parent Container	MkaPaeConfiguration			
Description	Time [s] to trigger the rekey of a after a time span.	Time [s] to trigger the rekey of an in use SAK. If set to 0, the rekey will not be triggered after a time span.		
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	EcucFloatParamDef			
Range	[0 INF]	[0 INF]		
Default value	_	•		
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local		_	

No Included Containers






Figure 10.3: MkaPaeConfiguration

10.2.4 MkaCryptoAlgoConfig

SWS Item	[ECUC_Mka_00021]
Container Name	MkaCryptoAlgoConfig
Parent Container	Mka
Description	Cryptography configuration for MACsec.
	Tags: atp.Status=draft
Configuration Parameters	

SWS Item	[ECUC_Mka_00053]			
Parameter Name	MkaCryptoAlgoConfigIdx	MkaCryptoAlgoConfigldx		
Parent Container	MkaCryptoAlgoConfig			
Description	Instance ID of the configured Crypto	configur	ation.	
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1			
Туре	EcucIntegerParamDef (Symbolic Name generated for this parameter)			
Range	0 255			
Default value	_			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		





	Post-build time	ı	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00025]			
Parameter Name	MkaMacSecCapability			
Parent Container	MkaCryptoAlgoConfig			
Description	MACsec capability to use for MACs	ec.		
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	EcucEnumerationParamDef			
Range	INTEGRITY_AND_ CONFIDENTIALITY	- Tags: a	atp.Status=draft	
	INTEGRITY_WITHOUT_ CONFIDENTIALITY	- Tags: atp.Status=draft		
Default value	INTEGRITY_WITHOUT_CONFIDE	NTIALITY	,	
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00026]			
Parameter Name	MkaMacSecConfidentialityOffset			
Parent Container	MkaCryptoAlgoConfig			
Description	The confidentiality Offset is only applicable if "Integrity and confidentiality" with a non-XPN cipher suite is selected.			
	Tags: atp.Status=draft			
Multiplicity	01			
Туре	EcucEnumerationParamDef			
Range	CONFIDENTIALITY_OFFSET_0	-		
		Tags: atp.Status=draft		
	CONFIDENTIALITY_OFFSET_30	-		
		Tags: atp.Status=draft		
	CONFIDENTIALITY_OFFSET_50	-		
		Tags: atp.Status=draft		
Default value	CONFIDENTIALITY_OFFSET_0	•		
Value Configuration Class	Pre-compile time	X All Variants		
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local		·	

SWS Item	[ECUC_Mka_00027]
Parameter Name	MkaMacSecReplayProtection
Parent Container	MkaCryptoAlgoConfig







Description	MACsec replay protection parameter for MACsec.\newline The Replay Protection parameter is defined in the IEEE 802.1AE-2018 document, on chapter 10.4. It enables the replay protection if a packet is received with PacketNumber outside of the Window = PN - ProtectionWindow.			
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	EcucBooleanParamDef			
Default value	false	false		
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time	-		
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00028]			
Parameter Name	MkaMacSecReplayProtectionWindo	MkaMacSecReplayProtectionWindow		
Parent Container	MkaCryptoAlgoConfig			
Description	In case replay protection is active, replay protection window. The Protection Window is a positive integer between 0 and 2^32-1 (No XPN) or 2^30-1 (XPN).			
	Tags: atp.Status=draft			
Multiplicity	01			
Туре	EcucIntegerParamDef			
Range	0 18446744073709551615			
Default value	_			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: local		·	

Included Containers		
Container Name	Multiplicity	Scope / Dependency
MkaCipherSuites	14	Cipher Suite configuration to use with MACsec. MkaCipherSuite Prio is present in case the MKA instance acts as a Key Server to select the cipher suite to use for MACsec.






Figure 10.4: MkaCryptoAlgoConfig



10.2.5 MkaCipherSuites

SWS Item	[ECUC_Mka_00050]
Container Name	MkaCipherSuites
Parent Container	MkaCryptoAlgoConfig
Description	Cipher Suite configuration to use with MACsec. MkaCipherSuitePrio is present in case the MKA instance acts as a Key Server to select the cipher suite to use for MACsec.
Configuration Parameters	

SWS Item	[ECUC_Mka_00052]			
Parameter Name	MkaMacSecCipherSuite			
Parent Container	MkaCipherSuites			
Description	Cipher Suite to use for MACsec.			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	EcucEnumerationParamDef			
Range	GCM_AES_128	28 –		
		Tags: atp.Status=draft		
	GCM_AES_256	-		
		Tags: atp.Status=draft		
	GCM_AES_XPN_128	-		
		Tags: atp.Status=draft		
	GCM_AES_XPN_256	-		
		Tags: atp.Status=draft		
Default value	GCM_AES_128			
Value Configuration Class	Pre-compile time	X All Variants		
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00051]	[ECUC_Mka_00051]		
Parameter Name	MkaMacSecCipherSuitePrio			
Parent Container	MkaCipherSuites			
Description	Suite to use with MACsec from	In case the MKA instance acts as a Key Server, the priority is used to select the Cipher Suite to use with MACsec from the common supported Ciphers (with the client in the link). Value of 1 means the highest priority. Value of 4 means the lowest priority.		
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	1 4			
Default value	-	-		
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time	_		
	Post-build time	-		
Scope / Dependency	scope: local			

No Included Containers



10.2.6 MkaPaeInstance

SWS Item	[ECUC_Mka_00003]
Container Name	MkaPaeInstance
Parent Container	Mka
Description	MKA configuration of a controlled port.
	Tags: atp.Status=draft
Configuration Parameters	

SWS Item	[ECUC_Mka_00018]		
Parameter Name	MkaOnFailPermissiveMode		
Parent Container	MkaPaeInstance		
Description	Sets the behavior of the PAE in case	e MKA do	es not succeed when MKA is enabled.
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	EcucEnumerationParamDef		
Range	NEVER	The controlled port will never be set to enabled the participants cannot establish and successfully use a MACsec Secure Channel.	
		Tags: atp.Status=draft	
	TIMEOUT	The controlled port will be set to enabled and MACsec will not be used in the referred port if the timeout value (MkaOnFailPermissiveMode Timeout) is reached and none MKA instance under the PAE instance could success the following conditions: - A participant belonging to the same CA was recognized and authenticated - A secure channel could be established Both participants can transmit and receive MACsec protected traffic through the SC.	
Value Configuration Class	Pre-compile time	Tags: atp.Status=draft X All Variants	
value Configuration Class	Link time	_	, in variatio
	Post-build time		
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00019]			
Parameter Name	MkaOnFailPermissiveModeTimeou	MkaOnFailPermissiveModeTimeout		
Parent Container	MkaPaeInstance			
Description	Timeout in seconds to enable the controlled port in case MkaOnFailPermissiveMode is set to Timeout.			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	EcucFloatParamDef			
Range	[0 INF]			
Default value	255			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			



SWS Item	[ECUC_Mka_00011]			
Parameter Name	MkaPaeldx	MkaPaeldx		
Parent Container	MkaPaeInstance			
Description	Instance ID of the configured PAE.			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	EcucIntegerParamDef (Symbolic Name generated for this parameter)			
Range	0 255			
Default value	-			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00013]			
Parameter Name	MkaEthIfControllerRef	MkaEthlfControllerRef		
Parent Container	MkaPaeInstance	MkaPaeInstance		
Description	A reference to the EthIfController which is used for transmitting / receiving EAP frames (to configure the controlled port).			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	Symbolic name reference to EthIfController			
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00054]	[ECUC_Mka_00054]		
Parameter Name	MkaPaeConfRef	MkaPaeConfRef		
Parent Container	MkaPaeInstance	MkaPaeInstance		
Description	Reference to the applicable	PAE configurat	ion.	
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1			
Туре	Reference to MkaPaeConfiguration			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local	•		

SWS Item	[ECUC_Mka_00014]
Parameter Name	MkaSwitchPortRef
Parent Container	MkaPaeInstance
Description	A reference to the EthSwtPort enabled and set only in case PAE is attached to a switch port.
	Tags: atp.Status=draft
Multiplicity	01
Туре	Symbolic name reference to EthSwtPort





Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local	-	

Included Containers			
Container Name	Multiplicity	Scope / Dependency	
MkaKay	1	MKA instance (KaY) for a controlled port (PaE).	
		Tags: atp.Status=draft	




Figure 10.5: MkaPaeInstance



10.2.7 MkaKay

SWS Item	[ECUC_Mka_00017]	
Container Name	MkaKay	
Parent Container	MkaPaeInstance	
Description	MKA instance (KaY) for a controlled port (PaE).	
	Tags: atp.Status=draft	
Configuration Parameters		

SWS Item	[ECUC_Mka_00016]			
Parameter Name	MkaBypassEtherType	MkaBypassEtherType		
Parent Container	MkaKay	MkaKay		
Description	Bypassed EtherType. The EtherTyp	Bypassed EtherType. The EtherTypes included will not be MACsec protected.		
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	0255			
Туре	EcucIntegerParamDef			
Range	0 65535			
Default value	-			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local	·		

SWS Item	[ECUC_Mka_00015]			
Parameter Name	MkaBypassVlan			
Parent Container	MkaKay	MkaKay		
Description	Bypassed VLAN-ID. The VLAN-IDs included will not be MACsec protected. (VLAN-ID 0 is interpreted as no-VLAN -> Bypass untagged traffic)			
	Tags: atp.Status=draft			
Multiplicity	0255			
Туре	EcucIntegerParamDef			
Range	0 4094			
Default value	_			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00032]
Parameter Name	MkaDstMacAddress
Parent Container	MkaKay
Description	Destination MAC address to use by the MKA instance. The destination MAC addresses to use are defined in the IEEE 802.1X-2020 chapter 11.1.1 (Table 11-1).
	Tags: atp.Status=draft
Multiplicity	1
Туре	EcucStringParamDef
Default value	-





Regular Expression	-		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		_

SWS Item	[ECUC_Mka_00022]			
Parameter Name	MkaKeyServerPriority			
Parent Container	MkaKay	MkaKay		
Description	Key Server Priority of the MKA participants. In case it is not provided, the default value is 0 for an MKA_KEY_SERVER and 255 for an MKA_PEER.			
	Tags: atp.Status=draft			
Multiplicity	01			
Туре	EcucIntegerParamDef			
Range	0 255			
Default value	-			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00029]			
Parameter Name	MkaRole			
Parent Container	MkaKay			
Description	Role of the MKA instance.	Role of the MKA instance.		
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	EcucEnumerationParamDef			
Range	MKA_KEY_SERVER	RVER –		
		Tags: atp.Status=draft		
	MKA_PEER	-		
		Tags: atp.Status=draft		
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00031]	
Parameter Name	MkaSrcMacAddress	
Parent Container	MkaKay	
Description	Source MAC address to use by the MKA instance.	
	Tags: atp.Status=draft	
Multiplicity	1	
Туре	EcucStringParamDef	
Default value	-	
Regular Expression	-	





Specification of MACsec Key Agreement AUTOSAR CP R23-11

Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	-	
	Post-build time	-	
Scope / Dependency	scope: local		

Included Containers				
Container Name	Multiplicity	Scope / Dependency		
MkaKayDemEventParameterRefs	1	Container for the references to DemEventParameter elements which shall be invoked using the API Dem_SetEventStatus in case the corresponding error occurs. The EventId is taken from the referenced DemEventParameter's DemEventId symbolic value. The standardized errors are provided in this container and can be extended by vendor-specific error references. Tags: atp.Status=draft		
MkaKayParticipant	1255	MKA participant configuration.		
		Tags: atp.Status=draft		






Figure 10.6: MkaKay

10.2.8 MkaKayParticipant

SWS Item	[ECUC_Mka_00038]
Container Name	MkaKayParticipant
Parent Container	MkaKay
Description	MKA participant configuration.
	Tags: atp.Status=draft
Configuration Parameters	



SWS Item	[ECUC_Mka_00049]		
Parameter Name	MkaParticipantActivate		
Parent Container	MkaKayParticipant		
Description	Enabled/Disabled status of the MKA participant True = The MKA Participant exchanges MKPDUs - False = The MKA participant does not exchange MKPDUs. Tags: atp.Status=draft		
Multiplicity	1		
Туре	EcucBooleanParamDef		
Default value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		·

SWS Item	[ECUC_Mka_00048]			
Parameter Name	MkaCryptoAlgoRef			
Parent Container	MkaKayParticipant	MkaKayParticipant		
Description	Reference to the cryptography to use (MkaAlgoConfiguration Container).			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	Reference to MkaCryptoAlgoConfig			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00040]		
Parameter Name	MkaCryptoCknCakKeyRef		
Parent Container	MkaKayParticipant		
Description	Reference to the CKN (min. 1 & max. 32 characters) assigned to the KaY Participant in the CSM.		
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	Symbolic name reference to CsmKey		
Value Configuration Class	Pre-compile time X All Variants		
	Link time	-	
	Post-build time	_	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00042]	
Parameter Name	MkaCryptolckDeriveJobRef	
Parent Container	MkaKayParticipant	
Description	Reference to a CSM job for ICK Derivation.	
	Tags: atp.Status=draft	
Multiplicity	1	
Туре	Symbolic name reference to CsmJob	







Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local	-	

SWS Item	[ECUC_Mka_00043]			
Parameter Name	MkaCryptolcvGenerateJobRef			
Parent Container	MkaKayParticipant			
Description	Reference to a CSM job for ICV generation (according to IEEE_802.x ICV is always 128 bits).			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	Symbolic name reference to CsmJo	Symbolic name reference to CsmJob		
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local	scope: local		

SWS Item	[ECUC_Mka_00044]			
Parameter Name	MkaCryptolcvVerifyJobRef			
Parent Container	MkaKayParticipant			
Description	Reference to a CSM job for ICV verification (according to IEEE_802.x ICV is always 128 bits).			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	Symbolic name reference to CsmJo	Symbolic name reference to CsmJob		
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00045]		
Parameter Name	MkaCryptoKekDeriveJobRef		
Parent Container	MkaKayParticipant		
Description	Reference to a CSM job for KEK Derivation. (Note: CAK needs to be set as the KEK Derive job CsmJobKeyRef)		
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	Symbolic name reference to CsmJob		
Value Configuration Class	Pre-compile time X All Variants		
	Link time –		
	Post-build time –		
Scope / Dependency	scope: local		



SWS Item	[ECUC_Mka_00060]			
Parameter Name	MkaCryptoKeyUnwrapJobRef			
Parent Container	MkaKayParticipant	MkaKayParticipant		
Description	Reference to a CSM job for SAK ur	wrap (to	perform the Decrypt part of RFC3394).	
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	Symbolic name reference to CsmJob			
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00047]			
Parameter Name	MkaCryptoKeyWrapJobRef	MkaCryptoKeyWrapJobRef		
Parent Container	MkaKayParticipant	MkaKayParticipant		
Description	Reference to a CSM job for SA	Reference to a CSM job for SAK wrap (to perform the Encrypt part of RFC3394).		
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	Symbolic name reference to C	Symbolic name reference to CsmJob		
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00041]				
Parameter Name	MkaCryptoRandomJobRef				
Parent Container	MkaKayParticipant	MkaKayParticipant			
Description	Reference to a CSM job for random	Reference to a CSM job for random number generation.			
	Tags: atp.Status=draft				
Multiplicity	1				
Туре	Symbolic name reference to CsmJob				
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants			
	Link time –				
	Post-build time –				
Scope / Dependency	scope: local				

SWS Item	[ECUC_Mka_00046]			
Parameter Name	MkaCryptoSakKeyRef			
Parent Container	MkaKayParticipant	MkaKayParticipant		
Description	Reference to a CSM key where SAK shall be stored.			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	Symbolic name reference to CsmKey			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time	_		





Specification of MACsec Key Agreement AUTOSAR CP R23-11

 \triangle

Scope / Dependency scope: local	
---------------------------------	--

No Included Containers






Figure 10.7: MkaKayParticipant



10.2.9 MkaKayDemEventParameterRefs

SWS Item	[ECUC_Mka_00055]	
Container Name	MkaKayDemEventParameterRefs	
Parent Container	MkaKay	
Description	Container for the references to DemEventParameter elements which shall be invoked using the API Dem_SetEventStatus in case the corresponding error occurs. The Event Id is taken from the referenced DemEventParameter's DemEventId symbolic value. The standardized errors are provided in this container and can be extended by vendor-specific error references.	
	Tags: atp.Status=draft	
Configuration Parameters		

SWS Item	[ECUC_Mka_00059]		
Parameter Name	MKA_E_ALGO_MISMATCH_INSTANCE		
Parent Container	MkaKayDemEventParameterF	Refs	
Description	Reference to the DemEventParameter which shall be issued when the MkaKay Instance does not successfully agree on MACsec keys and at least one MkaKay Participant does not support a common MACsec cipher suite. Tags: atp.Status=draft		
Multiplicity	01		
Туре	Symbolic name reference to DemEventParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time –		
Value Configuration Class	Pre-compile time X All Variants		
	Link time -		
	Post-build time –		
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00058]			
Parameter Name	MKA_E_KEY_MISMATCH_INSTANCE			
Parent Container	MkaKayDemEventParameterRefs	MkaKayDemEventParameterRefs		
Description	Reference to the DemEventParameter which shall be issued when the MkaKay Instance does not successfully agree on MACsec keys and at least one exchange for this MkaKay Instance encounters an ICV validation failure.			
	Tags: atp.Status=draft			
Multiplicity	01			
Туре	Symbolic name reference to DemEventParameter			
Post-Build Variant Multiplicity	false			
Post-Build Variant Value	false			
Multiplicity Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time –			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		
	Post-build time	_		







Scope / Dependency	scope: local
--------------------	--------------

SWS Item	[ECUC_Mka_00057]		
Parameter Name	MKA_E_KEY_NOT_PRESENT_INSTANCE		
Parent Container	MkaKayDemEventParameterF	Refs	
Description	Reference to the DemEventParameter which shall be issued when the MkaKay Instance does not successfully agree on MACsec keys and at least one of the keys (CAK) for this MkaKay Instance is not present.		
	Tags: atp.Status=draft		
Multiplicity	01		
Туре	Symbolic name reference to DemEventParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	-	
	Post-build time	_	
Value Configuration Class	Pre-compile time X All Variants		
	Link time	-	
	Post-build time	_	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00056]			
Parameter Name	MKA_E_TIMEOUT_INSTANCE			
Parent Container	MkaKayDemEventParameterRefs			
Description	Reference to the DemEventParameter which shall be issued when the MkaKay Instance does not successfully agree on MACsec keys and at least one exchange for this MkaKay Instance encounters a timeout.			
	Tags: atp.Status=draft			
Multiplicity	01			
Туре	Symbolic name reference to DemE	Symbolic name reference to DemEventParameter		
Post-Build Variant Multiplicity	false	false		
Post-Build Variant Value	false			
Multiplicity Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

No Included Containers



10.2.10 MkaSecurityEventRefs

SWS Item	[ECUC_Mka_00062]		
Container Name	MkaSecurityEventRefs		
Parent Container	MkaGeneral		
Description	Container for the references to IdsMEvent elements representing the security events that the Mka module shall report to the IdsM in case the corresponding security related event occurs (and if MkaEnableSecurityEventReporting is set to "true"). The standardized security events in this container can be extended by vendor-specific security events. Tags: atp.Status=draft		
Post-Build Variant Multiplicity	false	_	
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	-	
Configuration Parameters			

SWS Item	[ECUC_Mka_00063]			
Parameter Name	SEV_MKA_AUTHENTICATION_FAILURE			
Parent Container	MkaSecurityEventRefs			
Description	Event triggered when the authentication during the MKA communication has failed (wrong CKN/CAK)			
	Tags: atp.Status=draft			
Multiplicity	01			
Туре	Symbolic name reference to IdsMEvent			
Post-Build Variant Multiplicity	false	false		
Post-Build Variant Value	false			
Multiplicity Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time	_		
	Post-build time	_		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00066]		
Parameter Name	SEV_MKA_CIPHER_SUITE_NOT	SUPPO	RTED
Parent Container	MkaSecurityEventRefs		
Description	Event triggered when there is no C	ipher Sui	te supported
	Tags: atp.Status=draft		
Multiplicity	01		
Туре	Symbolic name reference to IdsMEvent		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	_	
Value Configuration Class	Pre-compile time	X	All Variants





	Link time	_	
	Post-build time	-	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00065]		
Parameter Name	SEV_MKA_PORT_NOT_ENABLED	1	
Parent Container	MkaSecurityEventRefs		
Description	Event triggered when the indicated	port for th	ne MKA communication is not enabled
	Tags: atp.Status=draft		
Multiplicity	01		
Туре	Symbolic name reference to IdsMEv	/ent	
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Value Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00067]			
Parameter Name	SEV_MKA_PORT_NUMBER_CHANGE			
Parent Container	MkaSecurityEventRefs			
Description	Event triggered when during the MK	(A comm	unication the port number has changed	
	Tags: atp.Status=draft			
Multiplicity	01			
Туре	Symbolic name reference to IdsME	/ent		
Post-Build Variant Multiplicity	false	false		
Post-Build Variant Value	false			
Multiplicity Configuration Class	Pre-compile time X All Variants			
	Link time	_		
	Post-build time	_		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00064]
Parameter Name	SEV_MKA_TIMEOUT
Parent Container	MkaSecurityEventRefs
Description	Event triggered when the timeout for the MKA communication has expired
	Tags: atp.Status=draft
Multiplicity	01
Туре	Symbolic name reference to IdsMEvent
Post-Build Variant Multiplicity	false





Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	-	
	Post-build time	-	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	-	
	Post-build time	-	
Scope / Dependency	scope: local		

No Included Containers




Figure 10.8: MkaSecurityEventRefs

10.3 Published Information

For details refer to the chapter 10.3 "Published Information" in SWS_BSWGeneral.



A Not applicable requirements

[CP_SWS_Mka_00999] [These requirements are not applicable to this specification.] (FO_RS_MACsec_00001, FO_RS_MACsec_00006, FO_RS_MACsec_00011, FO_RS_MACsec_00012, FO_RS_MACsec_00018, FO_RS_MACsec_00019, FO_RS_MACsec_00021, FO_RS_MACsec_00022, FO_RS_MACsec_00034, FO_RS_MACsec_00036)



B Change history of AUTOSAR traceable items

Please note that the lists in this chapter also include traceable items that have been removed from the specification in a later version. These items do not appear as hyperlinks in the document.

B.1 Traceable item history of this document according to AU-TOSAR Release R23-11

B.1.1 Added Specification Items in R23-11

Number	Heading
[CP_SWS_Mka 00301]	
[CP_SWS_Mka 00302]	Security events for Mka
[CP_SWS_Mka 00303]	
[CP_SWS_Mka 00304]	
[CP_SWS_Mka 00305]	
[CP_SWS_Mka 00306]	
[CP_SWS_Mka 00307]	
[CP_SWS_Mka 00308]	

Table B.1: Added Specification Items in R23-11

B.1.2 Changed Specification Items in R23-11

Number	Heading
[CP_SWS_Mka 91001]	Definition of API function Mka_Init
[CP_SWS_Mka 91014]	Definition of API function Mka_GetVersionInfo
[CP_SWS_Mka 91015]	Definition of API function Mka_SetCknStatus





Number	Heading
[CP_SWS_Mka 91016]	Definition of API function Mka_GetCknStatus
[CP_SWS_Mka 91017]	Definition of API function Mka_GetEnable
[CP_SWS_Mka 91018]	Definition of API function Mka_GetPaeStatus
[CP_SWS_Mka 91019]	Definition of API function Mka_GetMacSecStatistics
[CP_SWS_Mka 91020]	Definition of API function Mka_SetEnable
[CP_SWS_Mka 91021]	Definition of API function Mka_SetPaePermissiveMode
[CP_SWS_Mka 91022]	Definition of API function Mka_StartPae
[CP_SWS_Mka 91023]	Definition of API function Mka_LinkStateChange

Table B.2: Changed Specification Items in R23-11

B.1.3 Deleted Specification Items in R23-11

none

B.1.4 Added Constraints in R23-11

none

B.1.5 Changed Constraints in R23-11

none

B.1.6 Deleted Constraints in R23-11

none