

```
U1
     Z80A-CPU
U2
     MK2716 (@0000)
U3
     MK2716 (@0800) – empty
U4
     TMM2016 (@1000)
U5
     TMM2016 (@1800)
U6
     74LS245
U7
     74LS245
U8
     74S163
U9
     74S04
U10
     74LS138
U11
     74LS139
U12
     Z80A-CTC
U13
    Z80A-SIO/0
U14
     Z80A-PIO
U15
    Z80A-PIO
U16
     HDSP-2111 (5x7 8-char display)
     20.000MHz Oscillator
U17
U18 Discrete components:
           R1:
                1,16 330 R
           R2:
                2,15 33K R
           D1:
                +3,14 D
           R3:
                4,13 68 R
                +5,12 C (electrolytic)
           C1:
                6,11 empty
                7,10 5.6K R
           R4:
                8,9
                      empty
U19
    74LS14
U20
    74LS08
U21
    74LS32
U22
    MC1489
U23
    MC1488
SW1 SPDT pushbutton – RESET
SW2 SPDT pushbutton – NMI
SW3 SPDT toggle – 4800/9600 (up/down)
SW4 SPDT toggle
SW5 SPDT toggle
SW6 SPDT toggle
Ρ1
     DIP14 socket – I/O expansion
P2
     DIP14 socket – I/O expansion
P3
     FCC50-M - GPIO (Z80A-PIOs)
P4
     DIP14 socket – RS-232
```