


SERIES 706/707

This series of equipment enables any Series 700 Calculator user to utilize a teletype as an input/output writer for the calculator. Optional equipment in this series provides an unlimited number of equipment setup configurations. No limit is placed on the number of teletype terminals that can be interfaced to the calculator. Physical locations of the teletypes can be dictated by the user's needs


through the use of conventional telephone lines, special communication lines, or extension cables. By using a data set and acoustic couplers, communications between a teletype and calculator is simply a matter of dialing the data set number and cradling the telephone in an acoustic coupler. A few of the more common configurations are shown below.



BASIC TELETYPE CONFIGURATION



TYPICAL REMOTE TELETYPE CONFIGURATION



MULTIPLE TELETYPE CONFIGURATION