

# **OPERATION MANUAL**

CAPCOM®


CARREST REDGE DEL SAL ENERGIE ACCADAME CALL LAU CHANGE DAL LAWNER CALL STY SAL AUG BAZ SAT US DAS ESSUE OPCB CONNECTOR

JAMMA STANDARD

OCRT MONITOR

HORIZONTAL SCREEN

OCONTROL PANEL








WAY JOYSTICK


**\*2-PLAYER SIMULTANEOUS** 

- O8-WAY JOYSTICK
  MOVE PLAYER/CURSOR FOR SELECTION
  OF PLAYERS
- OBUTTON A

  NORMAL SHOT AND SHOT FROM AUXILIARY
  ROCKETS LAUNCHER
- OBUTTON B SUPER WEAPON
- MAXIMAM CREDITS: 9
- OPOSITIONS OF DIP SW

(THERE ARE 2 TYPES OF PCB)





#### JAMMA STANDARD

SOLDER SIDE			COMPONENTS SIDE
GND	A	1	The second secon
GND	В	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
N.C.	E	5	N.C.
+12V	F	6	+12V
	H	7	
COIN COUNTER 2	J	8	COIN COUNTER 1
(COIN LOCK OUT 2)	K	9	(COIN LOCK OUT 1)
SP(-)	L	10	SP(+)
N.C.	M	11	N.C.
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
N.C.	S	15	TEST_SW
COIN SW 2	T	16	COIN SW 1
START SW 2	U	17	START SW 1
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P PUSH 1	Z	22	1P PUSH 1
2P PUSH 2	a	23	1P PUSH 2
N.C.	b	24	N.C.
N.C.	c	25	N.C.
N.C.	d	26	N.C.
GND	e	27	GND
GND	f	28	GND

• PARTS NAME

CR7E-56DA-3.96E: (HIROSE)

OR

1168-056-009

:(KEL)

### ODIP SW(A)

ITEM	DESCRIPTION	1	2	3	4 8	5	6	7.7	8
	1COIN 1CREDIT		617	(e)= =		iper) [			
	1COIN 2CREDITS	ON	OFF	OFF		and I			
	1COIN 3CREDITS	OFF	ON	OFF		444			16
COIN 1	1COIN 4CREDITS	ON	ON	OFF					
COIN 1	1COIN 6CREDITS	OFF	OFF	ON					1
	2COINS 1CREDIT	ON	OFF	ON		A TOTAL			
	3COINS 1CREDIT	OFF	ON	ON					
	4COINS 1CREDIT	ON	ON-	ON					
	1COIN 1CREDIT			1000000	(elij)	i de	(e) <del>4</del> 7 .		
	1COIN 2CREDITS				ON	OFF	OFF		
	1COIN 3CREDITS	- P			OFF	ON	OFF		
	1COIN 4CREDITS				ON	ON	OFF		
COIN 2	1COIN 6CREDITS				OFF	OFF	ON	37100	
	2COINS 1CREDIT				ON	OFF	ON	FILE	
	3COINS 1CREDIT			1.5	OFF	ON	ON		
	4COINS 1CREDIT				ON	ON	ON	11/4	1.42
20110111112	NORMAL				AHLAS			·ja:	10860
CONTINUE	CONTINUE			57	ARTE	101-6	141	ON	

<sup>\*</sup>WHEN CONTINUE IS ON, GAME STARTS WITH 2 COINS AND CONTINUES WITH 1 COIN. IN THIS CASE, SETTINGS OF COIN 1 AND COIN 2 ARE MEANINGLESS.

## ODIP SW(B)

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
	EASY	OFF	OFF	OFF				Albert 1	
DIFFICULTY 1 (ADJUST STRENGTH) OF ENEMIES		ON	OFF	OFF					
	LATE SEEDS	OFF	ON	OFF					
	NORMAL	*1		7117					
		OFF	OFF	ON				OND	
		ON	OFF	ON	Marie				
		OFF	ON	ON		华,镇铁			
	DIFFICULT	ON	ОŅ	ON					
DIDDIGUIANI	EASY				OFF	ON			
DIFFICULTY 2	NORMAL				2) 1	*ijaja			
(ADJUST STRENGTH) OF PLAYER	100 0000				ON	OFF			
(OF TEATER )	DIFFICULT		10		ON	ON			

\*DIFFICULTY LEVEL IS SET TO NORMAL AT THE TIME OF DELIVERY.

ODIP SW(C)

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
EDEE DI AM	NOT FREE PLAY								
FREE PLAY	FREE PLAY		531 14 1	ON	Secretary.			OFF	
CORPEN CTOR	NORMAL			CAR B grille in colorida conservation (print)	274				
SCREEN STOP	PAUSE			*20.8	ON			OFF	
COPEN FIID	NORMAL					(w)=(-)			
SCREEN FLIP	FLIP					ON	to all is	OFF	
SOUND DURING	OFF			Chi			13:11		
DEMONSTRATION MODE	ON						ON	OFF	
CONTINUE	OFF					00 8 1		OFF	
MODE	ON WEST					DAV.	Ne s	OFF	
mpom MODE	GAME MODE				111	CTE I	48		
TEST MODE	TEST MODE					OFF			ON

\*BOLDFACE INDICATES FACTORY SETTING.

the state of the large per called a separate state of the large state

6 M

THE PARTY OF THE CASE AND THE CASE WHEN AND E

\*POWER DOWN AFTER CHANGING DIP SWITCHES.

## CAPCOM® CO.,LTD.

ON

北部別

CAPCOM BLDG. NO. 4-12, OHTEDORI 1-CHOME, CHUO-KU, OSAKA 540, JAPAN TEL (06) 947-1156 (FAX NO. 06-946-6657) G

Wähle Deinen Flugzeugtyp und die entsprechende Bewaffnung und besiege die Invasoren. Symbole geben Dir zusätzliche Kräfte.

Der zweite Spieler kann sich jederzeit ins Spielgeschehen einschalten.

Viel Glück!

Taste 1. schießen

Taste 2. Bomben

ODP SW	3 CARRIER	R AIRWING	X	i La Mallion I	· •		111503
упем.	DESCRIPTION	边沟镇24	3 40	4 5	6	7.默	[88]
New York	COUNTY CREDIT	OFF OFF	OFF	排放的 建等	24		訓練
	1 CON 2 CREDITS	ON OFF	OFF	3 2			
	1 CON 3 CREDITS	OFF ON	OFF.	facility of		一樂	
COIN 1	1 COIN 4 CREDITS	ON ON	OFF		۶		
00	1 COIN 6 CREDITS	OFF OFF	ON				1
	2 CDINS 1 CREDIT	ON OFF	ON		4		
	3 COINS 1 CREDIT	OFF ON	ON		1 1		
	4 COINS 1 CREDIT	ON ON	.OX	100			
CONTINUE	NORMAL					OFF	
COUN	- CONTINUE					ON	

\*IF CONTINUE COIN MODE IS ON. CAME STARTS WITH 2 CORNS AND CONTINUES WITH 1 COIN.

#### ODP SW. 2

ITEM	DESCRIPTION	12	5	3	4	5	6	7	8
	EASY	OFF	OFF	OFF					-
		ON	OFF	.OFF					
		OFF	ON	OFF	19				
DIFFICULTI	NORMAL	ON	ON	OFF				2.3	
LEVEL		OFF	-OFF	ON			-		
		ON	OFF	ON				2	2
the grant of	1	OFF	·OX	ON		-	3		
	DIFFICULT	NO.	ON	ON		_ !		. *	i
C0.27	3-CORNS	1			OFF-	- )			-
SELECTOR	1 COIN				03	/		•	
PLAYER	3 PLAYERS.			+	1	OFF			
MODE	2 PLAYERS					ON		119	1.

\*3 COIN MODE AND 2 PLAYERS MODE MAY NOT BE USED TOGETHER.

#### ODIP SW! /

ITEM	DESCRIPTION	I	1	2	1	3	¦ 4	5	6.	7	8
SCREEN	NO YES						OFF.				
SCREEN .	NO YES			lite	7.5			OFF ON			
DEMOR- STRATION SOUND	NO YES								OFF		
COSTRICE	NO YES									OFF	
MODE	CAME MODE TEST MODE										OFF ON

\*HIGHLICHTED CHARACTER INDICATES FACTORY SETTING.

\*RESTART WHEN MP SW. RESET.

CAPCOM® CO.,LTD.

CAPCOM BLDG. NO. 4-12, OHTEDCRI 1-CHOME. CHUO-KUL OSAKA 5-10, JAPAN TEL DEI 947-1156 FFAX NC. 08-948-5657 carrier Airwing

DIP SW (#) 2

TTEM	DESCRIPTION		1	2	3	4	5	6	7	8
,	EASY	0	OFF	OFF	OFF					
		1	ON	OFF	OFF	11				
	NORMAL.	2	OFF	ON.	440				*	1
		3	ON	ON	OFF					Phi s
DIFFICULTY		1	OFF	OFF	ON					
•		5	NO.	OFF	ON					
		6	OFF	ON	ON.					
	DIFFICULT	7	0.1	ON	ON	12:15				

&DIFFICULTY LEVEL IS SET TO NORMAL AT THE TIME OF DELIVERY. WHOLDFACE INDICATES FACTORY SETTING.

ODIP SW ( )

TUEN	DESCRIPTION	1	2	1 3	1	5	6	7	8
	NOT FREE PLAY		36 \$ +- 4 made \$ \$ 4 4 4 m	OFF					
FREE PLAY	FREE PLAY			ON				DVP	
SCREEN STOP	NORMAL PAUSE				OFF ON				٠
SCREEN FLIP	NORMAL, FLIP					OFF			
BOUZD DURING	OFF		-:-				OFF		
DEMONSTRATION ANDE	U.N	NORMAL PAUSE NORMAL FLIP OFF ON OFF		41 4100			ON		
	OFF							OFF	
CONTINUE MODE	app I			ÓΝ					
	GAME MODE							AHAKE	OFF
TEST MODE	TEST MODE								ON

#BOLDFACE INDICATES FACTORY BETTING,
#RPOWER DOWN AFTER CHANGING DIP SWITCHES.

#MAKE SURE THE POWER IS OFF BEFORE CHANGING DIP SWITCHES.

#RNO USE DIP SWITCH SHOULD BE KEPT ON "OFF".

CAPPONICO.,LTD.

No. 1-12, TOKIWAMACHI 2-CHOME, CHUO-KU, OBAKA 540, JAPAN TEL (08) 946-2058 (FAX NO. 00-946-6657)