SoftingOPCToolboxClient ::AeEvent::getActorld

SoftingOPCToolboxClient :::AeCondition::getConditionName

SoftingOPCToolboxClient ::AeEvent::getMessage

SoftingOPCToolboxClient ::AeEvent::getOcurrenceTime

SoftingOPCToolboxClient ::AeEvent::getSeverity

SoftingOPCToolboxClient ::AeEvent::getSourcePath

SoftingOPCToolboxClient ::AeCondition::getState

MyAeSubscription::getState ToString

SoftingOPCToolboxClient ::AeCondition::getSubConditionName

DateTime::toString

MyAeSubscription::handle AeConditionsChanged