Laboratory Exercise 6

Using Interrupts with Assembly Language Code

The purpose of this exercise is to investigate the use of interrupts for the ARM* processor, using assembly-language code. To do this exercise you need to be familiar with the exceptions processing mechanisms for the ARM processor, and with the operation of the ARM Generic Interrupt Controller (GIC). These concepts are discussed in the tutorials *Introduction to the ARM Processor*, and *Using the ARM Generic Interrupt Controller*. We assume that you are using the DE1-SoC Computer (emulated using CPUlator) to implement the solutions to this exercise. It may be useful to read the parts of the documentation for this computer system that pertains to the use of exceptions and interrupts, and to carefully review the lectures on this topic. We recognize that there is significant complexity to the set up and running of Interrupts and Exceptions, and so this exercise does provide some of the needed code.

Part I

Consider the main program shown in Figure 1. The code first sets the exceptions vector table for the ARM processor using a code section called *vectors*. Then, in the *text* section the main program needs to set up the stack pointers (for both interrupt mode and supervisor mode), initialize the generic interrupt controller (GIC), configure the KEY pushbuttons port to generate interrupts, and finally enable interrupts in the processor. You are to fill in the code that is not shown in the figure.

The function of your program is to show the numbers 0 to 3 on the *HEX*0 to *HEX*3 displays, respectively, when a corresponding KEY pushbutton is pressed. Since the main program simply "idles" in an endless loop, as shown in Figure 1, you have to control the displays by using an interrupt service routine for the KEY pushbuttons port.

Perform the following:

- 1. Create a new folder to hold your solution for this part. Create a file called *part1.s*, and type your assembly language code into this file. You may want to begin by copying the file named *part1.s* that is provided with the design files for this exercise.
- 2. Since CPUlator only allows you to have one source-code file, you'll need to put all of your source code in *part1.s*. You will need to include the code for the subroutine *CONFIG_GIC* that initializes the GIC. This code is included in the file *part1.s* that is provided with the design files for this exercise. It sets up the GIC to send interrupts to the ARM processor from the KEY pushbuttons port.
- 3. The bottom part of Figure 1 gives the code required for the interrupt handler, called *IRQ_HANDLER*. You have to write the code for the *KEY_ISR* interrupt service routine. Your code should show the digit 0 on the *HEX*0 display when *KEY*₀ is pressed, and then if *KEY*₀ is pressed again the display should be "blank". You should toggle the *HEX*0 display between 0 and "blank" in this manner each time *KEY*₀ is pressed. Similarly, toggle between "blank" and 1, 2, or 3 on the *HEX*1 to *HEX*3 displays each time *KEY*₁, *KEY*₂, or *KEY*₃ is pressed, respectively.
- 4. Compile, test and run your program on CPUlator.

```
/********************************
 * Initialize the exception vector table
 *************************
           .section .vectors, "ax"
                               // reset vector
                  _start
                               // undefined instruction vector
                  0
           .word
                0
                               // software interrrupt vector
           .word
                              // aborted prefetch vector
                0
           .word
                              // aborted data vector
           .word 0
                               // unused vector
           .word 0
           B IRQ_HANDLER // IRQ interrupt vector
           .word 0
                                // FIQ interrupt vector
* Main program
 ******************************
           .text
           .global _start
_start:
           /* Set up stack pointers for IRQ and SVC processor modes */
           ... Code not shown
           BL
                  CONFIG_GIC // configure generic interrupt controller
           // Configure the KEY pushbutton port to generate interrupts
           ... Code not shown
           // enable IRQ interrupts in the processor
           ... Code not shown
IDLE:
                  IDLE
                           // main program simply idles
\{R0-R7, LR\}
IRO HANDLER:
           PUSH
           /* Read the ICCIAR in the CPU interface */
           LDR R4, =0xFFFEC100
           LDR
                 R5, [R4, #0x0C] // read the interrupt ID
           CMP R5, #73
BNE UNEXPECT
CHECK_KEYS:
UNEXPECTED:
                 UNEXPECTED
                            // if not recognized, stop here
           BL KEY_ISR
EXIT_IRQ:
           /* Write to the End of Interrupt Register (ICCEOIR) */
           STR
                 R5, [R4, #0x10]
           POP
                 \{R0-R7, LR\}
           SUBS
                  PC, LR, #4
```

Figure 1: Main program and interrupt service routine.

Part II

In this part you'll build an interrupt-based program that controls the LEDR lights. Consider the main program shown in Figure 2. The code has to set up the ARM stack pointers for interrupt and supervisor modes, and then enable interrupts. A subroutine *CONFIG_GIC* is provided for your use in the design file called *part2.s*. It enables two types of interrupts in the GIC: the A9 Private Timer and the KEY pushbuttons. The main program calls the subroutines *CONFIG_PRIV_TIMER* and *CONFIG_KEYS* to set up the two ports. You are to write each of these subroutines. In *CONFIG_PRIV_TIMER* set up the *A9 Private Timer*, which you learned about in Lab Exercise 5, to generate one interrupt every 0.25 seconds. To see how to enable interrupts from this timer, you may want to read Section 2.4.1 in the *DE1-SoC Computer System* documentation.

In Figure 2 the main program executes an endless loop writing the value of the global variable COUNT to the red lights LEDR. You have to write an interrupt service routine for the timer, and a new interrupt service routine (different from the one you wrote in Part I) for the KEYs. Also, you will need to modify your $IRQ_HANDLER$ so that it calls the appropriate interrupt service routine, depending on whether an interrupt is caused by the timer or the KEYs port. In the interrupt service routine for the timer you are to increment the variable COUNT by the value of the RUN global variable, which should be either 1 or 0. You are to toggle the value of the RUN global variable in the interrupt service routine for the KEYs, each time a KEY is pressed. When RUN = 0, the main program will display a static count on the red lights, and when RUN = 1, the count shown on the red lights will increment every 0.25 seconds.

Make a new folder (*part2*) and file (*part2.s*) for this part; you may want to begin by copying the file named *part2.s* that is provided with the design files for this exercise. Write your code for this part, and then assemble, run, test and debug it. As noted above, since CPUlator only allows you to have one source-code file, you'll need to put all of your source code in *part2.s*.

Part III

Modify your program from Part II (in a file called *part3.s*) so that you can vary the speed at which the counter displayed on the red lights is incremented. All of your changes for this part should be made in the interrupt service routine for the KEYs. The main program and the rest of your code should not be changed.

Implement the following behavior: When *KEY* ois pressed, the value of the *RUN* variable should be toggled, as in Part II. Hence, pressing *KEY* ostops/runs the incrementing of the *COUNT* variable. When *KEY* 1 is pressed, the rate at which *COUNT* is incremented should be doubled, and when *KEY* 2 is pressed the rate should be halved. You should implement this feature by stopping the A9 Private Timer within the KEYs interrupt service routine, modifying the load value used in the timer, and then restarting the timer.

```
.section .vectors, "ax"
                  ... code not shown
                  .text
                  .global _start
_start:
/* Set up stack pointers for IRQ and SVC processor modes */
                 ... code not shown
                         CONFIG_GIC
                                             // configure the ARM generic
                                             // interrupt controller
                 BL
                          CONFIG_PRIV_TIMER // configure A9 Private Timer
                 _{\mathrm{BL}}
                          CONFIG_KEYS
                                             // configure the pushbutton
                                             // KEYs port
/\star Enable IRQ interrupts in the ARM processor \star/
                  ... code not shown
                      R5, =0xFF200000 // LEDR base address
                 LDR
LOOP:
                          R3, COUNT
                 LDR
                                          // global variable
                 STR
                          R3, [R5]
                                           // write to the LEDR lights
                          LOOP
/* Configure the A9 Private Timer to create interrupts at 0.25 second intervals */
CONFIG_PRIV_TIMER:
                 ... code not shown
                 MOV PC, LR
/* Configure the pushbutton KEYS to generate interrupts */
CONFIG_KEYS:
                  ... code not shown
                 MOV PC, LR
/* Global variables */
                 .global COUNT
                                          // used by timer
COUNT:
                 .word
                          0x0
                 .global RUN
                                           // used by pushbutton KEYs
                 .word 0x1
RUN:
                                           // initial value to increment
                                           // COUNT
                  .end
```

Figure 2: Main program for Part II.

Part Part IV: Optional

This part of the lab is entirely optional. You should do this part only if it is of *interest* to you. For this part you are to add a third source of interrupts to your program, using the Interval Timer, which is implemented within the FPGA in the DE1-SoC Computer. To learn how to use this timer, please refer to Section 2.11 of the DE1-SoC Computer documentation. Set up the timer to provide an interrupt every 1/100 of a second. Use this timer to increment a global variable called TIME. You should use the TIME variable as a real-time clock that is shown on the seven-segment displays HEX3 - 0. Use the format SS:DD, where SS are seconds and DD are hundredths of a second. You should be able to stop/run the clock by pressing pushbutton KEY_3 . When the clock reaches 59:99, it should wrap around to 00:00.

Make a new file, part4.s, to hold your entire solution for this part; you may wish to start by copying the part4.s file that is provided as part of the design files for this exercise. Modify the main program from Part III to call a new subroutine, named $CONFIG_TIMER$, which sets up the Interval Timer to generate the required 1/100 second interrupts. To show the TIME variable in the real-time clock format SS:DD, you can use the same approach that was followed for Part 4 of Lab Exercise 4. In that previous exercise you used polled I/O (with the A9 Private Timer), whereas now you are using interrupts (from the Interval Timer). One possible way to structure your code is illustrated in Figure 3. In this version of the code, the endless loop in the main program writes the value of a variable named HEX_code to the HEX3 - 0 displays.

Using the scheme in Figure 3, the interrupt service routine for the Interval Timer has to increment the *TIME* variable, and also update the *HEX_code* variable that is being written to the 7-segment displays by the main program.

Compile, load, test and debug your program.

```
.text
                    .global _start
_start:
/* Set up stack pointers for IRQ and SVC processor modes */
                    ... code not shown
                    _{\mathrm{BL}}
                            CONFIG_GIC
                                                 // configure the ARM generic
                                                 // interrupt controller
                            CONFIG_PRIV_TIMER
                                                // configure the private timer
                            CONFIG_TIMER
                    _{\mathrm{BL}}
                                                 // configure the Interval Timer
                            CONFIG_KEYS
                                                 // configure the pushbutton
                    _{\mathrm{BL}}
                                                 // KEYs port
/* Enable IRQ interrupts in the ARM processor */
                    ... code not shown
                    LDR
                            R5, =0xFF200000
                                                // LEDR base address
                                                // HEX3-0 base address
                            R6, =0xFF200020
                    LDR
LOOP:
                            R4, COUNT
                    LDR
                                                // global variable
                            R4, [R5]
                                                // light up the red lights
                    STR
                    LDR
                            R4, HEX_code
                                                // global variable
                            R4, [R6]
                                                 // show the time in format
                    STR
                                                 // SS:DD
                            LOOP
/st Configure the A9 Private Timer to create interrupts every 0.25 seconds st/
CONFIG_PRIV_TIMER:
                    ... code not shown
                    MOV
                           PC, LR
/* Configure the FPGA Interval Timer to create interrupts every 0.01 seconds */
CONFIG_TIMER:
                    ... code not shown
                    MOV PC, LR
/* Configure the pushbutton KEYS to generate interrupts */
CONFIG_KEYS:
                    ... code not shown
                    MOV
                           PC, LR
/* Global variables */
                    .global COUNT
                                      // used by timer
COUNT:
                    .word 0x0
                    .global RUN
                                      // used by pushbutton KEYs
RUN:
                    .word 0x1
                                      // initial value to increment COUNT
                    .global TIME
TIME:
                    .word 0x0
                                      // used for real-time clock
                    .global HEX_code
HEX_code:
                    .word 0x0
                                      // used for 7-segment displays
                    .end
```

Figure 3: Main program for Part IV.