

O&M manual — Compressor - 500-01

OM-C-500193 Rev 0 2026-04-18

Page 1

1. Equipment

Rosedale Instruments model M841, serial SN14603, tag C-500193.

2. Safety

Isolate and lock out all energy sources before work. Follow the site permit-to-work system.

3. Installation and preservation

Keep the equipment covered and dry until installation. Rotate shafts and check desiccant at the intervals in the preservation procedure.

4. Operation

Start, run and stop the equipment as described here and in the operating procedures for the system.

5. Maintenance

Planned maintenance intervals are loaded into VissRadCMMS as job plans. Record readings and findings on the work order.

6. Spare parts

See the vendor spare parts list for part numbers and recommended holdings.