

NAME

mbhysweeppreprocess – performs preprocessing of multibeam data in the Hysweep HSX format (**MBIO** format 201).

VERSION

Version 5.0

SYNOPSIS

mbhysweeppreprocess [-**A**offsettype/x/y/z/t -**B**rollbias/pitchbias/headingbias -**D**sonardepthfile -**F**format -**G**platformfile -**I**datalist -**J**projection -**K**klugemode -**L** -**M**navformat -**N**navfile -**O**outfile -**T**timelag -**H** -**V**]

DESCRIPTION

mbhysweeppreprocess reads a Hysweep HSX (format 201) file, interpolates the asynchronous navigation and attitude onto the multibeam data, and writes a new HSX file with that information correctly embedded in the multibeam data. The user must specify a projection for the easting-northing navigation used in HSX files. This program can also fix various problems with multibeam data, and allows for lever arm correction of offsets between the sonar, the motion sensor, and the positioning sensor (provided the navigation and attitude data included in the HSX file are uncorrected for sensor offsets)..

MB-SYSTEM AUTHORSHIP

David W. Caress
 Monterey Bay Aquarium Research Institute
 Dale N. Chayes
 Center for Coastal and Ocean Mapping
 University of New Hampshire
 Christian do Santos Ferreira
 MARUM - Center for Marine Environmental Sciences
 University of Bremen

OPTIONS

- A** *type/offsetx/offsety/offsetz/offsett*
 This option sets the spatial and time offset for a sensor relative to a reference point on the survey platform (by convention usually close to the center of mass and rotation). If *type* = 1, the offsets pertain to the survey sonar. If *type* = 2, the offsets pertain to the source of the attitude data, usually an MRU or INS. If *type* = 3, the offsets pertain to the source of the position or navigation data. The time offsets are referenced against the sonar data, thus the sonar time offset will usually be zero. If any of these offsets are defined, then **mbhysweeppreprocess** will use lever arm calculations to determine the x, y, and z offsets associated with the platform attitude for each ping, and add those to the sonar navigation and depth values.
- B** *rollbias/pitchbias/headingbias*
 This option sets roll, pitch, and heading bias values to be applied before merging the attitude and heading data with the sonar data while calculating bathymetry.
- D** *sonardepthfile*
 This option causes **mbhysweeppreprocess** to read a sonar depth time series from the specified file and use that data in place of any sonar depth (DFT) records present in the HSX file. The sonar depth data must be in an ascii format of the form:
 yyyy:mm:dd:hh:mm:ss.sss zzzz.zzz
 where yyyy=year, mm=month, dd=day, hh=hour, mm=minute, ss.sss = seconds, and zzzz.zzz = sonar depth in meters.

- F** *format*
 Sets the format of the input file specified with the **-I** option. This is normally omitted unless the input filename does not conform to the **MB-System** file naming conventions. For this program, the only relevant options are *format* = 201 for an HSX format file, or *format*= -1 for a datalist referencing multiple format 201 files.
- G** *platformfile*
 This option specifies a platform offset file, in the format read by **mb_platform_read**, defining the geometric relationships among the sonar, motion sensor, and navigation sensor. If specified, this platform definition is used in place of any offsets set with the **-A** and **-B** options.
- H** This "help" flag cause the program to print out a description of its operation and then exit immediately.
- I** *infile*
 Sets the input file path. If *format* > 0 (set with the **-f** option or **mbdefaults**) then the swath sonar data contained in *infile* is read and processed. If *format* < 0, then *infile* is assumed to be an ascii file containing a list of the input swath sonar data files to be processed and their formats. The program will read the data in each one of these files. In the *infile* file, each data file should be followed by a data format identifier, e.g.:
 datafile1 201
 datafile2 201
 This program only reads Hysweep HSX format data files (**MBIO** format 201).
- J** *projection*
 The Hypack and Hysweep software packages operate with navigation in a user-defined projected coordinate system. Resultantly, HSX format files contain positions in a projected coordinate system rather than longitude and latitude in geographic coordinates. Generally, the HSX files do not contain any description of the projection used to obtain the eastings and northings in those files. This option allows a user to specify the projection used to translate the eastings and northings back into longitude and latitude. If this option is not specified, **MB-System** will assume the data are associated with UTM zone 1 north. The projection identifier must conform to the same usage as with projections specified for **mbgrid**. For instance, to fully specify a particular northern UTM zone, set projection = UTMXXN where XX gives the UTM zone (defined from 01 to 60). As an example, a northern UTM zone 12 projection can be specified using -JUTM12N. Southern UTM zones are specified as UTMXXS. The European Petroleum Survey Group (EPSG) has defined a large number of PCS's used worldwide and assigned number id's to each; one can also specify the northern UTM zone 12 projection using its EPSG designation, or -Jepsg32612. The complete list of projected coordinate systems supported by **MB-System** is given in the **mbgrid** manual page.
- K** *klugemode*
 This option enables one of two "kluge" modes that correct problems with the way attitude data are applied to the raw beam angles. If *klugemode* = 1, roll and pitch attitude compensation of the beam angles is forced even when the raw multibeam (RMB) data records indicate that the sonar has already applied that compensation. If *klugemode* = 2, the sign of the roll and pitch values in the attitude (HCP) data records is reversed before use.
- L** This option causes the program to list the timetags of bathymetry, navigation, attitude, and other data records.
- M** *navformat*
 Sets the input navigation file format used by the file specified with the **-N** option.
 At present, the only option for the navigation file format is *navformat*=1:
 yyyy:mm:dd:hh:mm:ss.sss sssss.sss eeeeeeee.eee nnnnnnnnn.nnn zzzz.zzz aaa.aaa hhh.hhh
 where yyyy=year, mm=month, dd=day, hh=hour, mm=minute, ss.sss = seconds, sssss.sss = seconds from the start of the year, eeeeeeee.eee = easting in meters, nnnnnnnnn.nnn = northing in meters,

zzzz.zzz = sonar depth in meters, and hhh.hhh = heading in degrees. Default: *navformat*=1.

- N *navfile*
The program will read navigation from the file *navfile* and merge those data with the multibeam data in the HSX file. If a *timelag* model is specified using **-Ttimelag**, the time lag will be applied to the navigation and attitude data before merging with the sonar data. The navigation and attitude data from *navfile* will also be embedded in asynchronous data records in the output format 201 data. Any pre-existing navigation data records will remain unchanged in the data stream. However, the HSX file header will be altered to show the newly merged data as "enabled" and the original, asynchronous data as not enabled.
- O *outfile*
This option is intended to set the path of the output data file, but currently has no effect: **mbhysweeppreprocess** always constructs the output file name automatically from the input file name.
- T *timelag*
This option specifies a *timelag* value in seconds to be applied to the navigation and attitude data prior to it being merged with the bathymetry. If *timelag* is a valid path to a file containing time stamp and time lag pairs, then these data will be read and the time lag applied to particular records will be interpolated by time.
- V This option increases the verbosity of **mbhysweeppreprocess** with respect to informational output to the shell.

EXAMPLES

Suppose that one has logged a set of five HSX files incorporating multibeam sonar data, navigation, attitude, heading, and altitude data, but not sonar depth data, all from an ROV platform. Further suppose that a datalist file named *datalist_hsx.mb-1* references those files, and that a separate text file named *ROVnav.txt* includes an improved vehicle navigation, including the sonar depth. Finally, suppose that the existing sensor offsets are known, but have not been applied to any of the existing data

In order to merge the better navigation and sonar depth before starting MB-System processing, do something like:

```
mbhysweeppreprocess      -I      datalist_hsx.mb-1      -A1/0.42/2.005/-1.34/0.0
-A2/0.46/0.22/0.55/0.0  -A3/0.46/0.22/0.55/0.0      -JUTM01N -NROVnav.txt
```

The program will output something like the following:

Data available for merging:

Navigation (northing easting sonardepth altitude heading): 120959

Sonar depth (sonardepth): 0

Time lag: 0

Offsets to be applied:

X (m) Y (m) Z (m) T (sec)

Roll bias: 0.000

Pitch bias: 0.000

Heading bias: 0.000

Sonar: 0.420 2.005 -1.340 0.000

MRU: 0.420 2.005 -1.340 0.000

Nav: 0.420 2.005 -1.340 0.000

Data records read from: 000_2004.HSX

Positions (POS): 2651

Positions ignored (POS): 0

Heading (GYR): 19486

Attitude (HCP): 15752

Echosounder (altitude) (EC1): 2651

Dynamic draft (DFT): 0
Raw multibeam (RMB): 24438
Other: 64978

Data records read from: 000_2048.HSX

Positions (POS): 2967
Positions ignored (POS): 0
Heading (GYR): 21942
Attitude (HCP): 17771
Echosounder (altitude) (EC1): 2967
Dynamic draft (DFT): 0
Raw multibeam (RMB): 25363
Other: 71010

Data records read from: 000_2138.HSX

Positions (POS): 2573
Positions ignored (POS): 0
Heading (GYR): 18936
Attitude (HCP): 15307
Echosounder (altitude) (EC1): 2573
Dynamic draft (DFT): 0
Raw multibeam (RMB): 23398
Other: 62787

Data records read from: 000_2221.HSX

Positions (POS): 2824
Positions ignored (POS): 0
Heading (GYR): 20863
Attitude (HCP): 16907
Echosounder (altitude) (EC1): 2824
Dynamic draft (DFT): 0
Raw multibeam (RMB): 23993
Other: 67411

Data records read from: 000_2308.HSX

Positions (POS): 2657
Positions ignored (POS): 0
Heading (GYR): 19571
Attitude (HCP): 15818
Echosounder (altitude) (EC1): 2657
Dynamic draft (DFT): 0
Raw multibeam (RMB): 24009
Other: 64712

Total data records read from: datalist_hsx.mb-1

Positions (POS): 13672
Positions ignored (POS): 0
Heading (GYR): 100798
Attitude (HCP): 81555
Echosounder (altitude) (EC1): 13672
Dynamic draft (DFT): 0
Raw multibeam (RMB): 121201
Other: 330898

Data records written to: 000_2004.mb201

Positions (POS):	2651
Positions ignored (POS):	0
Heading (GYR):	19486
Attitude (HCP):	15752
Echosounder (altitude) (EC1):	2651
Dynamic draft (DFT):	0
Raw multibeam (RMB):	24438
Other:	0

Data records written to: 000_2048.mb201

Positions (POS):	2967
Positions ignored (POS):	0
Heading (GYR):	21942
Attitude (HCP):	17771
Echosounder (altitude) (EC1):	2967
Dynamic draft (DFT):	0
Raw multibeam (RMB):	25363
Other:	0

Data records written to: 000_2138.mb201

Positions (POS):	2573
Positions ignored (POS):	0
Heading (GYR):	18936
Attitude (HCP):	15307
Echosounder (altitude) (EC1):	2573
Dynamic draft (DFT):	0
Raw multibeam (RMB):	23398
Other:	0

Data records written to: 000_2221.mb201

Positions (POS):	2824
Positions ignored (POS):	0
Heading (GYR):	20863
Attitude (HCP):	16907
Echosounder (altitude) (EC1):	2824
Dynamic draft (DFT):	0
Raw multibeam (RMB):	23993
Other:	0

Data records written to: 000_2308.mb201

Positions (POS):	2657
Positions ignored (POS):	0
Heading (GYR):	19571
Attitude (HCP):	15818
Echosounder (altitude) (EC1):	2657
Dynamic draft (DFT):	0
Raw multibeam (RMB):	24009
Other:	0

Total data records written from: datalist_hsx.mb-1

Positions (POS):	13672
Positions ignored (POS):	0

Heading (GYR):	100798
Attitude (HCP):	81555
Echosounder (altitude) (EC1):	13672
Dynamic draft (DFT):	0
Raw multibeam (RMB):	121201
Other:	0

SEE ALSO**mbsystem(1), mbformat(1), mbinfo(1)****BUGS**

At this point, the HSX i/o module and preprocessor are only tested with a single survey of R2Sonic data.