

SAMS MAPPER

In map mode the mapper register setup is equivalent to: EXAMPLE2

mapper address		mapper	page num		address range
HEX	Dec		HEX	Dec	memory area
>4004	= 16388	is MR02	= >62	= 98	points to >2000 - >2FFF range
>4006	= 16390	is MR03	= >63	= 99	points to >3000 - >3FFF range
>4014	= 16404	is MR10	= >64	= 100	points to >A000 - >AFFF range
>4016	= 16406	is MR11	= >65	= 101	points to >B000 - >BFFF range
>4018	= 16408	is MR12	= >66	= 102	points to >C000 - >CFFF range
>401A	= 16410	is MR13	= >67	= 103	points to >D000 - >DFFF range
>401C	= 16412	is MR14	= >68	= 104	points to >E000 - >EFFF range
>401E	= 16414	is MR15	= >69	= 105	points to >F000 - >FFFF range

(MR=Mapper Register)

In MAP mode the mapper register setup is equivalent to: EXAMPLE3

mapper address		mapper	page num		address range
HEX	Dec		HEX	Dec	memory area
>4004	=16388	is MR02	=>1FF9	= 8185	points to >2000 - >2FFF range
>4006	=16390	is MR03	=>1FFA	= 8186	points to >3000 - >3FFF range
>4014	=16404	is MR10	=>1FFB	= 8187	points to >A000 - >AFFF range
>4016	=16406	is MR11	=>1FFC	= 8188	points to >B000 - >BFFF range
>4018	=16408	is MR12	=>1FFD	= 8189	points to >C000 - >CFFF range
>401A	=16410	is MR13	=>1FFE	= 8190	points to >D000 - >DFFF range
>401C	=16412	is MR14	=>1FFF	= 8191	points to >E000 - >EFFF range
>401E	=16414	is MR15	=>2000	= 8192	points to >F000 - >FFFF range

(MR=Mapper Register)