
## Wiping and Resetting Cisco Switches (Layer 2 & 3)



Select which type of Cisco switch you plan to use,

Make sure the switch has power and a console cable connection.

- **1.** Use a terminal (Putty) to console into the switch.
- 2. Once you recieve confirmation that you can view the switch hold down the mode button until the password-recovery mechanism enables. Switch>
- 3. You will see something of the following:

The system has been interrupted prior to initializing the flash file system.

The following commands will initialize the flash filesystem, and finish loading the operating system software:

flash\_init load\_helper boot

**7.** To reset the password we need to change the name of the config.text file to config.old (or something else of your choosing).

switch: rename flash:config.text flash:config.old

**4.** Enter flash\_init to initialize Flash...

switch: flash\_init Initializing Flash...

5. Enter load helper

switch: load helper

**6.** Enter dir flash: following by / to see the files in the configuration switch: dir flash:

Directory of flash:/

2 856 <date> vlan.dat -rwx 3 1193 <date> -rwx config.text 5 drwx 192 <date> c3560-ipbase-mz.122-25.SEE2 410 -rwx 5 <date> private-config.text

7842816 bytes available (8156160 bytes used) **10.** System Configuration Dialog prompts: (Answer: No)

Would you like to enter the initial configuration dialog? [yes/no]: no

switch: dir flash:
Directory of flash:/

2 -rwx 856 <date> vlan.dat

3 -rwx 1193 <date>

config.old

5 drwx 192 <date>

c3560-ipbase-mz.122-25.SEE2

410 -rwx 5 <date> private-config.text

7842816 bytes available (8156160 bytes used)

**8.** Reload the up to date flash file. This will reset everything.

switch: boot

**9.** Press RETURN (Enter) once prompted.

Press RETURN to get started!

Would you like to terminate auto install? [yes]: no

**11.** The Switch has been reset. Most of the time this will work, unless two or more additional files are preventing your changes.

Switch>

Switch>enable

Switch#config t

Switch(config)#

12. Your switch has been reset to default.