



Talk Light Trigger

Quick reference — controls & first-run setup

Listens to a talkback mic/bus input and fires a dLive Scene recall whenever the level crosses a threshold — one Scene while quiet, a different one while talkback is active. Point each Scene's Surface Illumination at a different colour and the console's lights flash with talkback.

Menu bar icon

Click	Show / hide the control panel.
Right-click	Quit the app (there's no Dock icon or app menu — this is the only way to quit).
Icon colour	Grey = stopped. Blue = running, listening (quiet). Bright = talkback active.

Connection

Choose one. Both reach the console the same way underneath — pick whichever needs less new software.

Direct TCP	Opens its own connection to the MixRack. Enter the console's IP (Host) — Port defaults to 51325.
Existing MIDI Port	Sends over a MIDI port already routed to the console — most easily the free dLive MIDI Bridge , or A&H's driver / loopMIDI / IAC. Pick it from the dropdown. When the port is dLive MIDI Bridge, this app identifies itself by name ("Talk Light Trigger") in the bridge's MIDI Monitor instead of showing as a generic connection.
Base MIDI Channel	Must match Utility → Control → MIDI on the console.

Audio Input

Device	The audio interface carrying the talkback signal.
Channel	Which input channel on that device to listen to.

Scenes

Quiet Scene #	Scene recalled while the input is below threshold.
Talkback Scene #	Scene recalled while talkback is active.

Important — on the console, save two Scenes with different dimmer values in Surface → Control → Dimmer. Both Scenes must have their Recall Filter restricted to Surface Illumination only. Without this, recalling either Scene changes the whole mix, not just the lights.

Sensitivity

Threshold	Level the input has to cross to count as "talking."
Attack Time	Time above Threshold required before it triggers (avoids brief noise/breath sounds).
Release	How far below Threshold the level must drop before counting as quiet again (avoids flicker at the edge).
Min Retrigger	Minimum time between Scene recalls, even if the level keeps crossing back and forth.



Running it

Start / Stop	Opens (or closes) the audio input and begins (or stops) watching the level.
Status tile	Stopped / Quiet / Active — mirrors the menu bar icon colour.
First launch	macOS will prompt for microphone access the first time you click Start — allow it, or the app won't receive any audio.

What's new in v1.0.3

- New: a footer link to the app's Quick Reference guide, so the guide is always a click away instead of only being on the disk image.
- New: send feedback from inside the app — a short message straight to me, no email client or web form needed.
- New: a link to the other dLive utilities.
- Fixed: a stray highlight box that appeared around the first section heading when the window opened.