



Console Control

Quick reference — show automation for Allen & Heath dLive

Discrete cues on a timecode ruler, fired at the console through the dLive MIDI Bridge, programmed against your own show recordings. Full manual: docs/REFERENCE.md.

Transport & sync

Space / Cmd+R / Home	Play-stop / record armed reference tracks / go to start.
SYNC button	Next to record. Label = source (LTC/MTC). Dimmed = sync off · red = no signal · amber = freewheel · green = locked. Click toggles sync; right-click picks Internal / LTC / MTC.
[and]	Step the playhead through markers, region edges, audio clip edges and the project start.
Loop	Drag along the ruler's time row. Click the blue band to arm/disarm, double-click to clear. Wraps on the internal clock only.
Scrub	Grab the playhead line in the ruler; a plain ruler click locates.

Cues

Insert strip	U (unity) · $-\infty$ · V (value...) · M (mute) · slashed M (unmute) · S (scene...) · A (action...). Multi-selected tracks insert together, one undo step.
One selection	Click selects a cue · Cmd-click toggles more · a background drag's time selection selects everything it covers (its height picks the tracks; Cmd-drag adds).
Move	Drag any selected cue — the whole set moves with ghost previews. Scene/action cues drag by their small marker; the label text is not a click target.
Nudge	Opt+Left / Opt+Right by the amount selector: 1/5/10/25 frames, 1 second, or Beat × div.
Snap	Free · Frame · Grid (the lines you can see) · Beat (tempo grid at the note-value subdivision).
Esc	Clears cue + time selection; a second Esc clears the loop.

Fired vs pending

Plain readout	That value was actually transmitted to the console.
Dot on the readout	Resolved at the playhead but NOT sent (chase off, or moved without a conform).
Conform Console	Cmd+Shift+C — transmits everything pending in one pass; usable live at any moment.
CHASE	Global button suspends all transmission; each lane's CHASE badge toggles that lane (applies across selected tracks).

Import a show recording

Import Audio (Cmd+I)	Up to 12 files. Roles are guessed from CONTENT: LTC / mix with embedded LTC / mix / click; chunked recordings (-001, -002...) join automatically.
Offline conform	Every span of continuous timecode is decoded and placed at its timecode — one clip per song on Mix and Click tracks, each outlined as a region.
Rate mismatch	The report offers “change the project to N fps and place” in one step.
Media	Files copy into the show bundle; 48 kHz copies are bit-identical.



Tempo & markers

Detect BPM	Select a steady click section → the tempo button → Detect. The tempo applies where that click clip exists, anchored ON the clicks. Detect each song separately; elsewhere is free time.
Markers	Shift+M at the playhead; Cmd+Shift+M named. Lanes show/hide from the pills; double-click pills and labels on the ruler to edit.
Regions	Shift+R from the time selection; drag edges on the ruler; double-click to edit. Edit → Regions from Audio Clips outlines a track's clips.
List panel	Editable markers / regions / tempo spans with per-lane colour.

Console data

Show-file import	File → Import Console Show File... (.tar.gz or Director CSV): scene NAMES (the only automated source), channel names + colours — matched by console address, cues untouched, one undo step.
Scenes / Actions	+ Track also creates extra Scenes tracks (independent categories) and Actions tracks (auto-claims the next CC). The gear on an action lane opens its configuration.
Preflight (Cmd+P)	Every before-doors check at once, with the exact reason anything fails.

Output

Export Audio (Cmd+E)	Mixdown / per-track stems / ref+LTC pair (generated timecode) — over the selection, one region, or every region with audio. 48 kHz/24-bit BWF, timestamped.
Recording	Armed tracks capture to <Track>-001.wav (incrementing) at the timeline position.
Save guard	Close / New / Open / Open Recent / RPP import all warn before discarding changes; autosave interval in Settings.

The bridge line (bottom of the window)

Green	Console connected through the dLive MIDI Bridge (IP shown).
Amber	Bridge running, console unreachable — check the console IP in the bridge, the network, and MIDI-over-TCP on the console.
Red	Start the dLive MIDI Bridge app.

Console Control never opens its own console connection — the bridge owns the console's single MIDI-over-TCP socket.

If something goes wrong

Export log	Click Export log in the panel footer. A copy of this session's log lands on your Desktop as a text file — send that with your report. Every launch is logged automatically to ~/Library/Logs/dylanmaudio/Console Control/; nothing to switch on.
Send feedback	Also in the footer — a short message straight to me, no email client needed.



What's new in v0.1.18

- This is a beta. It works in full until 31 October 2026, and the window shows that date from the first launch; for the last two weeks it also warns every time it opens. After that date Console Control still opens and edits your shows, but sends nothing to the console until you install a newer beta. Nothing is locked away, and the date is only checked when the app starts, so a show that runs past midnight is never interrupted.
- Each dylanmaudio app now has its own identity for macOS's Local Network permission; macOS had been mistaking them for one another.
- New: send levels — the console side. Console Control can now put a send level on the wire: input → aux, FX, UFX and matrix; group → matrix; aux → matrix. Sends use the same dB law as the fader, which the 5 September console sweep measured as identical at all 128 steps, so a send cue reads and behaves exactly like a fader cue.
- New: send lanes. Right-click a track → Add send lane... and pick the destination (the list only offers what that channel type can send to on the console). With several tracks selected the lane goes on all of them at once — "Aux 5 on every input". A send lane reads "→ Mono aux 3", takes the same Insert unity / -inf / value cues as the fader (on whichever lane is selected), conforms and chases like one, and has a X to remove it (undo brings it back). Preflight now flags a send lane whose destination the console cannot route.
- New: edit while latched. When the playhead is following timecode (LTC or MTC), clicking the timeline, [and], and the marker list now move an edit cursor (a dashed line, with its timecode next to the main readout) instead of the playhead — so cues, markers and pastes can be placed on the fly while the show runs, and the playhead never leaves the code. Stop hands the playhead back and the cursor goes away.
- Companion can now bring the Console Control window forward.