



Console Control

Quick reference — show automation for Allen & Heath dLive

Discrete cues on a timecode ruler, fired at the console through the dLive MIDI Bridge, programmed against your own show recordings. Full manual: docs/REFERENCE.md.

Transport & sync

Space / Cmd+R / Home	Play-stop / record armed reference tracks / go to start.
SYNC button	Next to record. Label = source (LTC/MTC). Dimmed = sync off · red = no signal · amber = freewheel · green = locked. Click toggles sync; right-click picks Internal / LTC / MTC.
[and]	Step the playhead through markers, region edges, audio clip edges and the project start.
Loop	Drag along the ruler's time row. Click the blue band to arm/disarm, double-click to clear. Wraps on the internal clock only.
Scrub	Grab the playhead line in the ruler; a plain ruler click locates.

Cues

Insert strip	U (unity) · $-\infty$ · V (value...) · M (mute) · slashed M (unmute) · S (scene...) · A (action...). Multi-selected tracks insert together, one undo step.
One selection	Click selects a cue · Cmd-click toggles more · a background drag's time selection selects everything it covers (its height picks the tracks; Cmd-drag adds).
Move	Drag any selected cue — the whole set moves with ghost previews. Scene/action cues drag by their small marker; the label text is not a click target.
Nudge	Opt+Left / Opt+Right by the amount selector: 1/5/10/25 frames, 1 second, or Beat × div.
Snap	Free · Frame · Grid (the lines you can see) · Beat (tempo grid at the note-value subdivision).
Esc	Clears cue + time selection; a second Esc clears the loop.

Fired vs pending

Plain readout	That value was actually transmitted to the console.
Dot on the readout	Resolved at the playhead but NOT sent (chase off, or moved without a conform).
Conform Console	Cmd+Shift+C — transmits everything pending in one pass; usable live at any moment.
CHASE	Global button suspends all transmission; each lane's CHASE badge toggles that lane (applies across selected tracks).

Import a show recording

Import Audio (Cmd+I)	Up to 12 files. Roles are guessed from CONTENT: LTC / mix with embedded LTC / mix / click; chunked recordings (-001, -002...) join automatically.
Offline conform	Every span of continuous timecode is decoded and placed at its timecode — one clip per song on Mix and Click tracks, each outlined as a region.
Rate mismatch	The report offers “change the project to N fps and place” in one step.
Media	Files copy into the show bundle; 48 kHz copies are bit-identical.



Tempo & markers

Detect BPM	Select a steady click section → the tempo button → Detect. The tempo applies where that click clip exists, anchored ON the clicks. Detect each song separately; elsewhere is free time.
Markers	Shift+M at the playhead; Cmd+Shift+M named. Lanes show/hide from the pills; double-click pills and labels on the ruler to edit.
Regions	Shift+R from the time selection; drag edges on the ruler; double-click to edit. Edit → Regions from Audio Clips outlines a track's clips.
List panel	Editable markers / regions / tempo spans with per-lane colour.

Console data

Show-file import	File → Import Console Show File... (.tar.gz or Director CSV): scene NAMES (the only automated source), channel names + colours — matched by console address, cues untouched, one undo step.
Scenes / Actions	+ Track also creates extra Scenes tracks (independent categories) and Actions tracks (auto-claims the next CC). The gear on an action lane opens its configuration.
Preflight (Cmd+P)	Every before-doors check at once, with the exact reason anything fails.

Output

Export Audio (Cmd+E)	Mixdown / per-track stems / ref+LTC pair (generated timecode) — over the selection, one region, or every region with audio. 48 kHz/24-bit BWF, timestamped.
Recording	Armed tracks capture to <Track>-001.wav (incrementing) at the timeline position.
Save guard	Close / New / Open / Open Recent / RPP import all warn before discarding changes; autosave interval in Settings.

The bridge line (bottom of the window)

Green	Console connected through the dLive MIDI Bridge (IP shown).
Amber	Bridge running, console unreachable — check the console IP in the bridge, the network, and MIDI-over-TCP on the console.
Red	Start the dLive MIDI Bridge app.

Console Control never opens its own console connection — the bridge owns the console's single MIDI-over-TCP socket.

What's new in v0.1.2

- New: a footer link to the app's Quick Reference guide, so the guide is always a click away instead of only being on the disk image.
- New: send feedback from inside the app — a short message straight to me, no email client or web form needed.
- New: a link to the other dLive utilities.
- Fixed: a stray highlight box that appeared around the first section heading when the window opened.