

Dual-screen return button — before / after (AYN Thor lower screen, 1240x1080)

Before: 0.6.66 RC, the wide '← Twin desk' pill in the bottom-left corner beside / over the dock. After (v0.6.67 staging): a compact button at the end of the header row.


Before (0.6.66 RC)



After — same layout




After — header close-up



After: all five two-screen layouts, dashboard open

Layout-styled: round for Twin desk / icons / showcase, square pixel button for Pocket classic / ribbon. Dock, tabs and page arrows clear.

Twin desk



Twin icons



Twin showcase



Pocket classic



Pocket ribbon



After: other pages keep the button clear (a swipe on the lower screen)

Games, Art, Video, Details, Achievements, Music pages — header-only, never over the content or the dock.

Twin desk — next page



Twin icons — next page




Twin showcase — next page



Pocket classic — next page




Pocket ribbon — next page




Touch and D-pad: back to the layout

Tap on the button: every layout's lower part comes back (top row). D-pad (Pocket classic): ▲ from the dock lights the button (pixel brackets), A goes back.

Twin desk — after tap




Twin showcase — after tap




Pocket ribbon — after tap



D-pad: lit on the dock (gear)




D-pad: ▲▲▲▲ → button lit



Profile picker on the AYN Thor (sample profiles; your profile untouched)

Default for this existing install: Midnight blue (saved once). QA picker detection (D144) by the app's own mark: all six looks PICKER → HOME on Thor and GT78.

Aurora glass




Minimal OLED




Midnight blue



PIN pad (OLED)



Touch pick animation



Your profile (Midnight)

