



# Trim Sheet & Re-ballasting

The [tank procedure](#) tells you what the glider weighs and displaces *today*. Most real ballasting work, though, is about **change**: a new sensor bolted on, a battery or VBD swapped at refurbishment, a fairing upgrade, or simply a mission in water that is heavier or lighter than the last one. This page covers the bookkeeping tool that handles those changes — the trim sheet — and how to move a glider from one target density to another without guessing.



## Source

Distilled from several years of service and support correspondence between Seaglider operators, refurbishment teams, and the vehicle's original designers (2016–2024), cross-checked against the [Ballasting Procedure](#) and [Trim & Flight Model](#) pages. Numbers are worked examples from real gliders, not specifications — your vehicle's own sheet and tank results always win.

---

## The trim sheet

Every Seaglider is normally delivered (and returned from service) with a **trim sheet**: a per-vehicle spreadsheet that lists every part on the glider with its mass, volume, and position along the hull, and from those sums predicts how the vehicle will sit in water of a given density. Layouts vary between versions, but the useful pieces are the same: