

IE55 Installation Instructions

Quick-reference mating and inspection procedure for the **Teledyne Impulse IE55 subminiature** connector.

Source: *Teledyne Impulse IE55 inspection instructions.*

Read before mating

1. Before engaging the connector, the parts **must be lubricated** using **3M Silicon Lubricant** or **Silicon Pump Spray Connector Lubricant** supplied by Teledyne Impulse.
2. The locking sleeve should **NOT** be used to engage the parts — only to hold the parts together **after** they are fully engaged.

Mating Procedure

1. Align the keyway

The connector must be aligned with the **D-shaped neoprene keyway** before pushing the parts together. Confirm alignment **visually** (if accessible) or **by feel** (if hidden).

IMPORTANT:

- A. Before engaging the connector, the parts must be lubricated using **3M Silicon Lubricant** or **Silicon Pump Spray Connector Lubricant** supplied by Teledyne Impulse.
- B. The locking sleeve should **NOT** be used to engage the parts, but as a way of holding the parts together after being fully engaged.

1. The connector must be aligned with the D-Shaped neoprene keyway before pushing the parts together.

Confirm alignment visually (if accessible) or by feel (if hidden).

