

SubConn® Installation Instructions

Quick-reference handling instructions for MacArtney **SubConn®** underwater connectors. Follow these carefully to ensure correct use and a reliable seal.

Source: MacArtney SubConn® handling instructions, Edition 5.1.2.

Handling

- Connectors must be greased with **MOLYKOTE® 44 Medium** before every mating.
 - Always grease O-rings on **BH, BCR, and FCR** connectors with **Molykote 111**.
 - Disconnect by pulling **straight out**, not at an angle.
 - Do **not** pull on the cable, and avoid sharp bends at the cable entry.
 - When using a bulkhead connector, ensure there are **no angular loads**.
 - Apply the **recommended torque** when tightening bulkhead nuts.
 - Do not expose connectors to extended heat or direct sunlight. If a connector becomes very dry, soak it in fresh water before use.
 - All current ratings are based on the connector being **submerged in water**.
 - The locking sleeve must be **hand-tightened only**.
-