

Slocum Altimeter One-Pager

Source

Paraphrased and consolidated from the *Slocum G3 Glider Maintenance Manual*, the TWR *Slocum Glider RS-232 Altimeter Guide* (Rev. 2022-03-10), TWR altimeter wiring/diagnostics notes, the Teledyne Webb Research (TWR) user forum, and the UG2 community Slack. This is a condensed field reference — always defer to official Teledyne documentation and contact Glider Support before changing altimeter behaviour on a deployed vehicle.

Hardware

Spec	Value
Frequency	170 kHz (same on G1, G2, and G3)
TVR	156 dB
Max SPL	204.3 dB (max PCB output $\approx$ 260 V rms)
Beam pattern (-3 dB)	18°
Operating interval	Every 4 seconds (downcast only)

The transducer is a **custom AIRMAR design built for Teledyne Webb** — it is not a catalogue part you can source directly from AIRMAR. The externally mounted transducer is the **same across board generations**; what changed over time is the control board inside the forward section (see below).