

Seaglider One-Pager

Quick-reference notes for common Seaglider basestation and piloting operations.
This page grows over time – add notes as new important reminders are identified.

Source

Paraphrased from the APL-UW IOP *Basestation3 and seaglider.pub Best Practices* note, the *Extended PicoDOS Reference Manual*, the *Seaglider Piloting Parameters* guide, IOP PLOCAN training material, and pilot working notes. Always confirm against the [Parameter Reference Manual](#) and defer to APL-UW IOP documentation.

Basestation Shortcuts

Command	What it does
<code>gcd sgXXX</code>	Jump straight to glider <code>sgXXX</code> 's current mission directory.
<code>basepy</code> <code><script>.py --</code> <code>help</code>	Run a basestation3 script with the correct interpreter (<code>/opt/basestation/bin/python3</code>) without typing the full paths.
<code>tail -f comm.log</code>	Watch a glider's call-in log live as it happens.