



# Seaglider Maintenance Schedule

This page organizes maintenance by **when** it needs doing, not by which component it touches — the detailed how-to for each item lives on the relevant [Glider Components](#) page or checklist; this is the index that tells you when to go read it.



## Shorter than the Slocum page, for now

Fewer Seaglider component pages exist on this site so far (Batteries, Altimeter, VBD) — this schedule will grow as more are added. See the [Glider Components](#) section for what currently exists.



## Source

Synthesized from facts already established across this site's Seaglider pages — see those pages for sourcing and full detail.

---