

Electronics

The main electronics board runs everything on a Seaglider: the motors, the VBD, navigation, comms, the pressure sensor, and every sensor port. Two generations are in service:

- **Rev B** — built around a **TT8** processor with a Persistor CF2 and a CompactFlash card. Its firmware lineage is 66.x.
- **Rev E** — an **ARM**-based board with an SD card. Its firmware lineage is 67.x. Existing gliders can be upgraded to it.

Most day-to-day differences between the two (firmware files, menus, parameters, basestation versions) are documented by APL-UW IOP. **For firmware versions, release notes and update procedures, use the IOP pages rather than this wiki:**

- [Seaglider firmware \(seaglider.pub\)](#)
- [Rev E software notes \(APL-UW IOP, PDF\)](#)

This page covers the hardware side and the lessons from operating and servicing both boards.

Source

Paraphrased from 2016–2024 correspondence between Seaglider operators, APL-UW IOP, the manufacturer and service providers (main-board failures and replacements, Rev E upgrades, CF card corruption, 15 V conversions). Board revisions and factory configurations vary — defer to APL-UW IOP and your glider's documentation.

Where the settings live

A glider's configuration is split between two places, and mixing them up is the most common mistake when a board is replaced: