SUBJECT		Equipment Data Mapping							
		CIM Equipment spec.							
		Doc. No.:							
		PLC Start Adress	DM10000						
		Modbus Start Adress	40001						
PLC Address	Modbus Adress	Name Designation	Permission	Format(F->0)				Description	Annotation
[遠端指令PP_Select : RemoteCMD PP_Select]									
DM10100	40101	RecipeID Loader	L->L	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Loader	UINT(1) 1~65535
DM10101	40102	RecipeID Pickling	L->D	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Pickling	UINT(1) 1~65535
DM10102	40103	RecipeID Unloader	L->UL	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Unloader	UINT(1) 1~65535
DM10103	40104	Spare							
DM10104	40105	Spare							
DM10105	40106	Spare							
DM10106	40107	Spare							
DM10107	40108	Spare							
DM10108	40109	Spare							
DM10109	40110	Spare							
DM10110	40111	Current RecipeID Loader	Common	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Loader	UINT(1) 1~65535
DM10111	40112	Current RecipeID Pickling	Common	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Pickling	UINT(1) 1~65535
DM10112	40113	Current RecipeID Unloader	Common	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Unloader	UINT(1) 1~65535
DM10113	40114	Spare							
DM10114	40115	Spare							
DM10115	40116	Spare							
DM10116	40117	Spare							
DM10117	40118	Spare							
DM10118	40119	Spare							
DM10119	40120	Spare							
[共用資料區 : Common Data Area]									
DM10120	40121	WorkOrder_1	Common	2nd Char	1st Char			Work Order 1 Number	String (10) ASCII
DM10121	40122			4th Char	3rd Char				
DM10122	40123			6th Char	5th Char				
DM10123	40124			8th Char	7th Char				
DM10124	40125			10th Char	9th Char				
DM10125	40126			12th Char	11th Char				
DM10126	40127			14th Char	13th Char				
DM10127	40128			16th Char	15th Char				
DM10128	40129			18th Char	17th Char				
DM10129	40130			20th Char	19th Char				
DM10130	40131	WorkOrder_2	Common	2nd Char	1st Char			Work Order 2 Number	String (10) ASCII
DM10131	40132			4th Char	3rd Char				
DM10132	40133			6th Char	5th Char				
DM10133	40134			8th Char	7th Char				
DM10134	40135			10th Char	9th Char				
DM10135	40136			12th Char	11th Char				
DM10136	40137			14th Char	13th Char				
DM10137	40138			16th Char	15th Char				
DM10138	40139			18th Char	17th Char				
DM10139	40140			20th Char	19th Char				
DM10140	40141	WorkOrder_3	Common	2nd Char	1st Char			Work Order 3 Number	String (10) ASCII
DM10141	40142			4th Char	3rd Char				
DM10142	40143			6th Char	5th Char				
DM10143	40144			8th Char	7th Char				
DM10144	40145			10th Char	9th Char				
DM10145	40146			12th Char	11th Char				
DM10146	40147			14th Char	13th Char				
DM10147	40148			16th Char	15th Char				
DM10148	40149			18th Char	17th Char				
DM10149	40150			20th Char	19th Char				
DM10150	40151	WorkOrder_4	Common	2nd Char	1st Char			Work Order 4 Number	String (10) ASCII
DM10151	40152			4th Char	3rd Char				
DM10152	40153			6th Char	5th Char				
DM10153	40154			8th Char	7th Char				
DM10154	40155			10th Char	9th Char				
DM10155	40156			12th Char	11th Char				
DM10156	40157			14th Char	13th Char				
DM10157	40158			16th Char	15th Char				
DM10158	40159			18th Char	17th Char				
DM10159	40160			20th Char	19th Char				
DM10160	40161	WorkOrder_5	Common	2nd Char	1st Char			Work Order 5 Number	String (10) ASCII
DM10161	40162			4th Char	3rd Char				
DM10162	40163			6th Char	5th Char				
DM10163	40164			8th Char	7th Char				
DM10164	40165			10th Char	9th Char				
DM10165	40166			12th Char	11th Char				
DM10166	40167			14th Char	13th Char				
DM10167	40168			16th Char	15th Char				
DM10168	40169			18th Char	17th Char				
DM10169	40170			20th Char	19th Char				
DM10170	40171	WorkOrder_6	Common	2nd Char	1st Char			Work Order 6 Number	String (10) ASCII
DM10171	40172			4th Char	3rd Char				
DM10172	40173			6th Char	5th Char				
DM10173	40174			8th Char	7th Char				
DM10174	40175			10th Char	9th Char				
DM10175	40176			12th Char	11th Char				
DM10176	40177			14th Char	13th Char				
DM10177	40178			16th Char	15th Char				
DM10178	40179			18th Char	17th Char				
DM10179	40180			20th Char	19th Char				
DM10180	40181	WorkOrder_7	Common	2nd Char	1st Char			Work Order 7 Number	String (10) ASCII
DM10181	40182			4th Char	3rd Char				
DM10182	40183			6th Char	5th Char				
DM10183	40184			8th Char	7th Char				
DM10184	40185			10th Char	9th Char				
DM10185	40186			12th Char	11th Char				
DM10186	40187			14th Char	13th Char				
DM10187	40188			16th Char	15th Char				
DM10188	40189			18th Char	17th Char				
DM10189	40190			20th Char	19th Char				
DM10190	40191	WorkOrder_8	Common	2nd Char	1st Char			Work Order 8 Number	String (10) ASCII
DM10191	40192			4th Char	3rd Char				
DM10192	40193			6th Char	5th Char				
DM10193	40194			8th Char	7th Char				
DM10194	40195			10th Char	9th Char				
DM10195	40196			12th Char	11th Char				
DM10196	40197			14th Char	13th Char				
DM10197	40198			16th Char	15th Char				
DM10198	40199			18th Char	17th Char				
DM10199	40200			20th Char	19th Char				
DM10200	40201	WorkOrder_9	Common	2nd Char	1st Char			Work Order 9 Number	String (10) ASCII
DM10201	40202			4th Char	3rd Char				
DM10202	40203			6th Char	5th Char				
DM10203	40204			8th Char	7th Char				
DM10204	40205			10th Char	9th Char				
DM10205	40206			12th Char	11th Char				
DM10206	40207			14th Char	13th Char				
DM10207	40208			16th Char	15th Char				
DM10208	40209			18th Char	17th Char				
DM10209	40210			20th Char	19th Char				
DM10210	40211	WorkOrder_10	Common	2nd Char	1st Char			Work Order 10 Number	String (10) ASCII
DM10211	40212			4th Char	3rd Char				
DM10212	40213			6th Char	5th Char				
DM10213	40214			8th Char	7th Char				
DM10214	40215			10th Char	9th Char				
DM10215	40216			12th Char	11th Char				
DM10216	40217			14th Char	13th Char				
DM10217	40218			16th Char	15th Char				
DM10218	40219			18th Char	17th Char				
DM10219	40220			20th Char	19th Char				
DM10220	40221	Spare							
DM10221	40222	Spare							
DM10222	40223	Spare							
DM10223	40224	Spare							
DM10224	40225	Spare							
DM10225	40226	Spare							
DM10226	40227	Spare							
DM10227	40228	Spare							
DM10228	40229	Spare							
DM10229	40230	Spare							
DM10230	40231	Spare							
DM10231	40232	Spare							
DM10232	40233	Spare							
DM10233	40234	Spare							
DM10234	40235	Spare							
DM10235	40236	Spare							
DM10236	40237	Spare							
DM10237	40238	Spare							
DM10238	40239	Spare							
DM10239	40240	Spare							
DM10240	40241	Spare							
DM10241	40242	Spare							
DM10242	40243	Spare							
DM10243	40244	Spare							
DM10244	40245	Spare							
DM10245	40246	Spare							
DM10246	40247	Spare							
DM10247	40248	Spare							
DM10248	40249	Spare							
DM10249	40250	Spare							
DM10250	40251	Spare							
DM10251	40252	Spare							
DM10252	40253	Spare							
DM10253	40254	Spare							
DM10254	40255	Spare							
DM10255	40256	Spare							
DM10256	40257	Spare							
DM10257	40258	Spare							
DM10258	40259	Spare							
DM10259	40260	Spare							
DM10260	40261	Spare							
DM10261	40262	Spare							
DM10262	40263	Spare							
DM10263	40264	Spare							
DM10264	40265	Spare							
DM10265	40266	Spare							
DM10266	40267	Spare							
DM10267	40268	Spare							
DM10268	40269	Spare							
DM10269	40270	Spare							
DM10270	40271	Spare							
DM10271	40272	Spare							
DM10272	40273	Spare							
DM10273	40274	Spare							
DM10274	40275	Spare							
DM10275	40276	Spare							
DM10276	40277	Spare							
DM10277	40278	Spare							
DM10278	40279	Spare							
DM10279	40280	Spare							
DM10280	40281	Spare							
DM10281	40282	Spare							
DM10282	40283	Spare							
DM10283	40284	Spare							
DM10284	40285	Spare							
DM10285	40286	Spare							
DM10286	40287	Spare							
DM10287	40288	Spare							
DM10288	40289	Spare							
DM10289	40290	Spare							
DM10290	40291	Spare							
DM10291	40292	Spare							
DM10292	40293	Spare							
DM10293	40294	Spare							
DM10294	40295	Spare							
DM10295	40296	Spare							
DM10296	40297	Spare							
DM10297	40298	Spare							
DM10298	40299	Spare							
DM10299	40300	Spare							

SUBJECT		Equipment Data Mapping
	Doc. No. :	CIM Equipment spec.

PLC Start Adress DM11000
Modbus Start Adress 41001

PLC Address	Modbus Adress	Name	Designation	Permission	Format(F->0)	Description	Annotation
[報警訊號 : Request and Ack]							
DM11000	41001	Equipment Event Request		EQ->EAP	0000 0000 000e dcba	a : UserID_Verify b : TrackInReq c : AlarmReport d : StatusChangeReport e : PanelInReport	(binary)
DM11001	41002	EAP Event Ack		EAP->EQ	0000 0000 000e dcba	a : UserID_Verify b : TrackInReq c : AlarmReport d : StatusChangeReport e : PanelInReport	(binary)
DM11002	41003	EAP CMD Request		EAP->EQ	p000 0000 0000 000a	a : RemoteCMD (PP_SELECT)	
DM11003	41004	Equipment CMD Ack		EQ->EAP	0000 0000 0000 000a	a : RemoteCMD (PP_SELECT)	
DM11004	41005	AliveCheck (EQ Startup)		EQ->EAP	0000 0000 0000 000a	a : AliveCheck (EQ Startup) · ON/OFF once every 15 seconds.	
DM11005	41006	AliveCheck (EAP StartUp)		EAP->EQ	0000 0000 0000 000a	a : AliveCheck (EAP StartUp) · ON/OFF once every 15 seconds.	
[人員登入驗證 : UserID_Verify Area]							
DM11100	41101				2nd Char 1st Char		
DM11101	41102	Machine		EQ->EAP	4th Char 3rd Char	Machine ID	String (3) ASCII
DM11102	41103				6th Char 5th Char		
DM11103	41104				y(2st Char) y(1st Char)		
DM11104	41105				y(4st Char) y(3st Char)		
DM11105	41106				M(2st Char) M(1st Char)		
DM11106	41107	DATE		EQ->EAP	d(2st Char) d(1st Char)	yyyyMMddHHmmss	String (7) ASCII
DM11107	41108				H(2st Char) H(1st Char)		
DM11108	41109				m(2st Char) m(1st Char)		
DM11109	41110				s(2st Char) s(1st Char)		
DM11110	41111				2nd Char 1st Char		
DM11111	41112	UserID		EQ->EAP	4th Char 3rd Char	User ID	String (3) ASCII
DM11112	41113				6th Char 5th Char		
DM11113	41114				2nd Char 1st Char		
DM11114	41115				4th Char 3rd Char		
DM11115	41116				6th Char 5th Char		
DM11116	41117				8th Char 7th Char		
DM11117	41118				10th Char 9th Char		
DM11118	41119				12th Char 11th Char		
DM11119	41120				14th Char 13th Char		
DM11120	41121				16th Char 15th Char		
DM11121	41122				18th Char 17th Char		
DM11122	41123				20th Char 19th Char		
DM11123	41124				22nd Char 21st Char		
DM11124	41125	Barcode		EQ->EAP	24th Char 23rd Char	Barcode	String (24) ASCII
DM11125	41126				26th Char 25th Char		
DM11126	41127				28th Char 27th Char		
DM11127	41128				30th Char 29th Char		
DM11128	41129				32th Char 31th Char		
DM11129	41130				34th Char 33th Char		
DM11130	41131				36th Char 35th Char		
DM11131	41132				38th Char 37th Char		
DM11132	41133				40th Char 39th Char		
DM11133	41134				42th Char 41th Char		
DM11134	41135				44th Char 43th Char		
DM11135	41136				46th Char 45th Char		
DM11136	41137				48th Char 47th Char		
DM11137	41138	Spare					
DM11138	41139	Spare					
DM11139	41140	Spare					
DM11140	41141	Spare					
DM11141	41142	Spare					
DM11142	41143	Spare					
DM11143	41144	RtnResult		EAP->EQ	0000 0000 0000 00aa	1 : PASS / 2 :FAIL	INT(1)
DM11144	41145	RtnCode		EAP->EQ	0000 0000 hhhh hhhh	PASS : 0 / FAIL : 1~99	INT(2)
DM11145	41146	Spare					
DM11146	41147	Spare					
DM11147	41148	Spare					
DM11148	41149	Spare					
DM11149	41150	Spare					
[工單建立 : TrackInReq]							
DM11150	41151				2nd Char 1st Char		
DM11151	41152	Machine		EQ->EAP	4th Char 3rd Char	Machine ID	String (3) ASCII
DM11152	41153				6th Char 5th Char		
DM11153	41154				y(2st Char) y(1st Char)		
DM11154	41155				y(4st Char) y(3st Char)		
DM11155	41156				M(2st Char) M(1st Char)		
DM11156	41157	DATE		EQ->EAP	d(2st Char) d(1st Char)	yyyyMMddHHmmss	String (7) ASCII
DM11157	41158				H(2st Char) H(1st Char)		
DM11158	41159				m(2st Char) m(1st Char)		
DM11159	41160				s(2st Char) s(1st Char)		
DM11160	41161				2nd Char 1st Char		
DM11161	41162	UserID		EQ->EAP	4th Char 3rd Char	User ID	String (3) ASCII
DM11162	41163				6th Char 5th Char		
DM11163	41164				2nd Char 1st Char		
DM11164	41165				4th Char 3rd Char		
DM11165	41166				6th Char 5th Char		
DM11166	41167				8th Char 7th Char		
DM11167	41168	MaterialID		EQ->EAP	10th Char 9th Char	Material ID	String (10) ASCII
DM11168	41169				12th Char 11th Char		
DM11169	41170				14th Char 13th Char		
DM11170	41171				16th Char 15th Char		
DM11171	41172				18th Char 17th Char		
DM11172	41173				20th Char 19th Char		
DM11173	41174				2nd Char 1st Char		
DM11174	41175				4th Char 3rd Char		
DM11175	41176				6th Char 5th Char		
DM11176	41177				8th Char 7th Char		
DM11177	41178	CassetteID		EQ->EAP	10th Char 9th Char	Cassette ID	String (10) ASCII
DM11178	41179				12th Char 11th Char		
DM11179	41180				14th Char 13th Char		
DM11180	41181				16th Char 15th Char		
DM11181	41182				18th Char 17th Char		
DM11182	41183				20th Char 19th Char		
DM11183	41184				2nd Char 1st Char		
DM11184	41185				4th Char 3rd Char		
DM11185	41186				6th Char 5th Char		
DM11186	41187				8th Char 7th Char		
DM11187	41188	WorkOrder		EQ->EAP	10th Char 9th Char	Work Order Number	String (10) ASCII
DM11188	41189				12th Char 11th Char		
DM11189	41190				14th Char 13th Char		
DM11190	41191				16th Char 15th Char		
DM11191	41192				18th Char 17th Char		
DM11192	41193				20th Char 19th Char		
DM11193	41194				2nd Char 1st Char		
DM11194	41195				4th Char 3rd Char		
DM11195	41196				6th Char 5th Char		
DM11196	41197				8th Char 7th Char		
DM11197	41198	ToolingID		EQ->EAP	10th Char 9th Char	Tooling ID	String (10) ASCII
DM11198	41199				12th Char 11th Char		
DM11199	41200				14th Char 13th Char		
DM11200	41201				16th Char 15th Char		
DM11201	41202				18th Char 17th Char		
DM11202	41203				20th Char 19th Char		
DM11203	41204		Qty	EQ->EAP	uuuu uuuu uuuu uuuu	Quantity	UINT(0~65535)
DM11204	41205	Spare					
DM11205	41206	Spare					
DM11206	41207	Spare					
DM11207	41208	Spare					
DM11208	41209	Spare					
DM11209	41210	Spare					
DM11210	41211	Spare					
DM11211	41212	Spare					
DM11212	41213	Spare					
DM11213	41214	Spare					
DM11214	41215	Spare					
DM11215	41216	RtnResult		EAP->EQ	0000 0000 0000 00ba	1 : PASS / 2 :FAIL	INT(1)
DM11216	41217	RtnCode		EAP->EQ	0000 0000 hhhh hhhh	PASS : 0 / FAIL : 1~99	INT(2)
DM11217	41218				2nd Char 1st Char		
DM11218	41219				4th Char 3rd Char		
DM11219	41220				6th Char 5th Char		
DM11220	41221				8th Char 7th Char		
DM11221	41222	PanelList[0]		EAP->EQ	10th Char 9th Char	Panel List [0]	String (10) ASCII
DM11222	41223				12th Char 11th Char		
DM11223	41224				14th Char 13th Char		
DM11224	41225				16th Char 15th Char		
DM11225	41226				18th Char 17th Char		
DM11226	41227				20th Char 19th Char		
DM11227	41228				2nd Char 1st Char		
DM11228	41229				4th Char 3rd Char		
DM11229	41230				6th Char 5th Char		
DM11230	41231				8th Char 7th Char		
DM11231	41232	PanelList[1]		EAP->EQ	10th Char 9th Char	Panel List [1]	String (10) ASCII
DM11232	41233				12th Char 11th Char		
DM11233	41234				14th Char 13th Char		

SUBJECT		Equipment Data Mapping								
		Doc. No. :			CIM Equipment spec.					
		PLC Start Adress		DM11000						
		Modbus Start Adress		41001						
PLC Address	Modbus Address	Name	Designation	Permission	Format(F->0)				Description	Annotation
DM11234	41235				16th Char	15th Char				
DM11235	41236				18th Char	17th Char				
DM11236	41237				20th Char	19th Char				
DM11237	41238				2nd Char	1st Char				
DM11238	41239				4th Char	3rd Char				
DM11239	41240				6th Char	5th Char				
DM11240	41241				8th Char	7th Char				
DM11241	41242		PanelList[2]	EAP->EQ	10th Char	9th Char			Panel List [2]	String (10) ASCII
DM11242	41243				12th Char	11th Char				
DM11243	41244				14th Char	13th Char				
DM11244	41245				16th Char	15th Char				
DM11245	41246				18th Char	17th Char				
DM11246	41247				20th Char	19th Char				
DM11247	41248				2nd Char	1st Char				
DM11248	41249				4th Char	3rd Char				
DM11249	41250				6th Char	5th Char				
DM11250	41251				8th Char	7th Char				
DM11251	41252		PanelList[3]	EAP->EQ	10th Char	9th Char			Panel List [3]	String (10) ASCII
DM11252	41253				12th Char	11th Char				
DM11253	41254				14th Char	13th Char				
DM11254	41255				16th Char	15th Char				
DM11255	41256				18th Char	17th Char				
DM11256	41257				20th Char	19th Char				
DM11257	41258				2nd Char	1st Char				
DM11258	41259				4th Char	3rd Char				
DM11259	41260				6th Char	5th Char				
DM11260	41261				8th Char	7th Char				
DM11261	41262		PanelList[4]	EAP->EQ	10th Char	9th Char			Panel List [4]	String (10) ASCII
DM11262	41263				12th Char	11th Char				
DM11263	41264				14th Char	13th Char				
DM11264	41265				16th Char	15th Char				
DM11265	41266				18th Char	17th Char				
DM11266	41267				20th Char	19th Char				
DM11267	41268				2nd Char	1st Char				
DM11268	41269				4th Char	3rd Char				
DM11269	41270				6th Char	5th Char				
DM11270	41271				8th Char	7th Char				
DM11271	41272		PanelList[5]	EAP->EQ	10th Char	9th Char			Panel List [5]	String (10) ASCII
DM11272	41273				12th Char	11th Char				
DM11273	41274				14th Char	13th Char				
DM11274	41275				16th Char	15th Char				
DM11275	41276				18th Char	17th Char				
DM11276	41277				20th Char	19th Char				
DM11277	41278				2nd Char	1st Char				
DM11278	41279				4th Char	3rd Char				
DM11279	41280				6th Char	5th Char				
DM11280	41281				8th Char	7th Char				
DM11281	41282		PanelList[6]	EAP->EQ	10th Char	9th Char			Panel List [6]	String (10) ASCII
DM11282	41283				12th Char	11th Char				
DM11283	41284				14th Char	13th Char				
DM11284	41285				16th Char	15th Char				
DM11285	41286				18th Char	17th Char				
DM11286	41287				20th Char	19th Char				
DM11287	41288				2nd Char	1st Char				
DM11288	41289				4th Char	3rd Char				
DM11289	41290				6th Char	5th Char				
DM11290	41291				8th Char	7th Char				
DM11291	41292		PanelList[7]	EAP->EQ	10th Char	9th Char			Panel List [7]	String (10) ASCII
DM11292	41293				12th Char	11th Char				
DM11293	41294				14th Char	13th Char				
DM11294	41295				16th Char	15th Char				
DM11295	41296				18th Char	17th Char				
DM11296	41297				20th Char	19th Char				
DM11297	41298				2nd Char	1st Char				
DM11298	41299				4th Char	3rd Char				
DM11299	41300				6th Char	5th Char				
DM11300	41301				8th Char	7th Char				
DM11301	41302		PanelList[8]	EAP->EQ	10th Char	9th Char			Panel List [8]	String (10) ASCII
DM11302	41303				12th Char	11th Char				
DM11303	41304				14th Char	13th Char				
DM11304	41305				16th Char	15th Char				
DM11305	41306				18th Char	17th Char				
DM11306	41307				20th Char	19th Char				
DM11307	41308				2nd Char	1st Char				
DM11308	41309				4th Char	3rd Char				
DM11309	41310				6th Char	5th Char				
DM11310	41311				8th Char	7th Char				
DM11311	41312		PanelList[9]	EAP->EQ	10th Char	9th Char			Panel List [9]	String (10) ASCII
DM11312	41313				12th Char	11th Char				
DM11313	41314				14th Char	13th Char				
DM11314	41315				16th Char	15th Char				
DM11315	41316				18th Char	17th Char				
DM11316	41317				20th Char	19th Char				
DM11317	41318	Spare								
DM11318	41319	Spare								
DM11319	41320	Spare								
DM11320	41321	Spare								
DM11321	41322	Spare								
DM11322	41323	Spare								
DM11323	41324	Spare								
DM11324	41325	Spare								
DM11325	41326	Spare								
DM11326	41327	Spare								
DM11327	41328	Spare								
DM11328	41329	Spare								
DM11329	41330	Spare								
DM11330	41331	Spare								
DM11331	41332	Spare								
DM11332	41333	Spare								
DM11333	41334	Spare								
DM11334	41335	Spare								
DM11335	41336	Spare								
DM11336	41337	Spare								
DM11337	41338	Spare								
DM11338	41339	Spare								
DM11339	41340	Spare								
DM11340	41341	Spare								
DM11341	41342	Spare								
DM11342	41343	Spare								
DM11343	41344	Spare								
DM11344	41345	Spare								
DM11345	41346	Spare								
DM11346	41347	Spare								
DM11347	41348	Spare								
DM11348	41349	Spare								
DM11349	41350	Spare								
[警報レポート : AlarmReport]										
DM11350	41351				2nd Char	1st Char				
DM11351	41352		Machine	EQ->EAP	4th Char	3rd Char			Machine ID	String (3) ASCII
DM11352	41353				6th Char	5th Char				
DM11353	41354				y(2st Char)	y(1st Char)				
DM11354	41355				y(4st Char)	y(3st Char)				
DM11355	41356				M(2st Char)	M(1st Char)				
DM11356	41357		DATE	EQ->EAP	d(2st Char)	d(1st Char)			yyyyMMddHHmmss	String (7) ASCII
DM11357	41358				H(2st Char)	H(1st Char)				
DM11358	41359				m(2st Char)	m(1st Char)				
DM11359	41360				s(2st Char)	s(1st Char)				
DM11360	41361		AlarmStatus	EQ->EAP	0000	0000	0000	00aa	1 : S / 2 : E	INT(1)
DM11361	41362		AlarmType	EQ->EAP	0000	0000	0000	00aa	1 : Alarm / 2 :Warning	INT(1)
DM11362	41363		AlarmCode	EQ->EAP	2nd Char		1st Char		Alarm Code	String (2) ASCII
DM11363	41364				4th Char		3rd Char			
DM11364	41365	Spare								
DM11365	41366	Spare								
DM11366	41367	Spare								
DM11367	41368	Spare								
DM11368	41369	Spare								
DM11369	41370	Spare								
DM11370	41371	Spare								
DM11371	41372		RtnResult	EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)
DM11372	41373		RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)
DM11373	41374				4th		3rd			
DM11374	41375				6th		5th			
DM11375	41376				8th		7th			
DM11376	41377	Spare								
DM11377	41378	Spare								
DM11378	41379	Spare								
DM11379	41380	Spare								
[状態変更 : StatusChange]										
DM11380	41381				2nd Char		1st Char			
DM11381	41382		Machine	EQ->EAP	4th Char		3rd Char		Machine ID	String (3) ASCII
DM11382	41383				6th Char		5th Char			
DM11383	41384				y(2st Char)		y(1st Char)			
DM11384	41385				y(4st Char)		y(3st Char)			
DM11385	41386		DATE	EQ->EAP	M(2st Char)		M(1st Char)		yyyyMMddHHmmss	String (7) ASCII
DM11386	41387				d(2st Char)		d(1st Char)			
DM11387	41388				H(2st Char)		H(1st Char)			
DM11388	41389				m(2st Char)		m(1st Char)			
DM11389	41390				s(2st Char)		s(1st Char)			
DM11390	41391		OldStatus	EQ->EAP	0000	0000	0000	dcba	Old Status	INT(1) 0~10
DM11391	41392		NewStatus	EQ->EAP	0000	0000	0000	dcba	New Status	INT(1) 0~10
DM11392	41393	Spare								
DM11393	41394	Spare								
DM11394	41395	Spare								
DM11395	41396		RtnResult	EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)
DM11396	41397		RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)
DM11397	41398	Spare								
DM11398	41399	Spare								
DM11399	41400	Spare								
[搬送入料 : Panel In]										
DM11400	41401				2nd Char		1st Char			
DM11401	41402		Machine	EQ->EAP	4th Char		3rd Char		Machine ID	String (3) ASCII
DM11402	41403				6th Char		5th Char			
DM11403	41404				y(2st Char)		y(1st Char)			
DM11404	41405				y(4st Char)		y(3st Char)			
DM11405	41406				M(2st Char)		M(1st Char)			
DM11406	41407		DATE	EQ->EAP	d(2st Char)		d(1st Char)		yyyyMMddHHmmss	String (7) ASCII
DM11407	41408				H(2st Char)		H(1st Char)			
DM11408	41409				m(2st Char)		m(1st Char)			
DM11409	41410				s(2st Char)		s(1st Char)			
DM11410	41411				2nd Char		1st Char			
DM11411	41412				4th Char		3rd Char			
DM11412	41413				6th Char		5th Char			
DM11413	41414				8th Char		7th Char			
DM11414	41415		CassetteID	EQ->EAP	10th Char		9th Char		Cassette ID	String (10) ASCII
DM11415	41416				12th Char		11th Char			
DM11416	41417				14th Char		13th Char			
DM11417	41418				16th Char		15th Char			
DM11418	41419				18th Char		17th Char			
DM11419	41420				20th Char		19th Char			
DM11420	41421				2nd Char		1st Char			
DM11421	41422				4th Char		3rd Char			
DM11422	41423				6th Char		5th Char			
DM11423	41424				8th Char		7th Char			
DM11424	41425		PanelID	EQ->EAP	10th Char		9th Char		Panel ID	String (10) ASCII
DM11425	41426				12th Char		11th Char			
DM11426	41427				14th Char		13th Char			
DM11427	41428				16th Char		15th Char			
DM11428	41429				18th Char		17th Char			
DM11429	41430				20th Char		19th Char			

SUBJECT		Equipment Data Mapping								
		Doc. No. :			CIM Equipment spec.					
		PLC Start Adress		DM11000						
		Modbus Start Adress		41001						
PLC Address	Modbus Adress	Name	Designation	Permission	Format(F->0)				Description	Annotation
DM11430	41431	SlotNo		EQ->EAP	uuuu	uuuu	uuuu	uuuu	Slot Number(Calculations begin at the bottom)	UINT(1) 1~65535
DM11431	41432	Spare								
DM11432	41433	Spare								
DM11433	41434	Spare								
DM11434	41435	Spare								
DM11435	41436	RtnResult		EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)
DM11436	41437	RtnCode		EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)
DM11437	41438	Spare								
DM11438	41439	Spare								
DM11439	41440	Spare								
[8][8][8][3]PP_Select : RemoteCMD PP_Select]										
DM11440	41441	Machine		EAP->EQ	2nd Char		1st Char		Machine ID	String (3) ASCII
DM11441	41442				4th Char		3rd Char			
DM11442	41443				6th Char		5th Char			
DM11443	41444	DATE		EAP->EQ	y(2st Char)		y(1st Char)		yyyyMMddHHmmss	String (7) ASCII
DM11444	41445				y(4st Char)		y(3st Char)			
DM11445	41446				M(2st Char)		M(1st Char)			
DM11446	41447				d(2st Char)		d(1st Char)			
DM11447	41448				H(2st Char)		H(1st Char)			
DM11448	41449				m(2st Char)		m(1st Char)			
DM11449	41450				s(2st Char)		s(1st Char)			
DM11450	41451	RecipeID_Loader		EAP->EQ	uuuu	uuuu	uuuu	uuuu	RecipeID for Loader	UINT(1) 1~65535
DM11451	41452	RecipeID_Development		EAP->EQ	uuuu	uuuu	uuuu	uuuu	RecipeID for Development	UINT(1) 1~65535
DM11452	41453	RecipeID_Unloader		EAP->EQ	uuuu	uuuu	uuuu	uuuu	RecipeID for Unloader	UINT(1) 1~65535
DM11453	41454	Spare								
DM11454	41455	Spare								
DM11455	41456	Spare								
DM11456	41457	Spare								
DM11457	41458	Spare								
DM11458	41459	Spare								
DM11459	41460	Spare								
DM11460	41461	Spare								
DM11461	41462	Spare								
DM11462	41463	Spare								
DM11463	41464	Spare								
DM11464	41465	Spare								
DM11465	41466	Spare								
DM11466	41467	Spare								
DM11467	41468	Spare								
DM11468	41469	Spare								
DM11469	41470	Spare								
DM11470	41471	Spare								
DM11471	41472	Spare								
DM11472	41473	Spare								
DM11473	41474	Spare								
DM11474	41475	RtnResult		EQ->EAP	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)
DM11475	41476	RtnCode		EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)
DM11476	41477	Spare								
DM11477	41478	Spare								
DM11478	41479	Spare								
DM11479	41480	Spare								

SUBJECT	Equipment Data Mapping
Doc. No. :	CIM Equipment spec.

PLC Start Adress DM12000
Modbus Start Adress 42001

PLC Address	Modbus Adress	Name Designation	Permission	Format(F->0)	Description	Annotation	
[報告回覆 Request and Ack]							
DM12000	42001	Equipment Event Request	EQ->EAP	0000 0000 0000 00ba	a : AlarmReport b : StatusChangeReport	(binary)	000
DM12001	42002	EAP Event Ack	EAP->EQ	0000 0000 0000 00ba	a : AlarmReport b : StatusChangeReport	(binary)	001
DM12002	42003	EAP CMD Request	EAP->EQ	0000 0000 0000 0000			002
DM12003	42004	Equipment CMD Ack	EQ->EAP	0000 0000 0000 0000			003
DM12004	42005	AliveCheck (EQ Startup)	EQ->EAP	0000 0000 0000 000a	a : AliveCheck (EQ Startup) · ON/OFF once every 15 seconds.		004
DM12005	42006	AliveCheck (EAP StartUp)	EAP->EQ	0000 0000 0000 000a	a : AliveCheck (EAP StartUp) · ON/OFF once every 15 seconds.		005
[報告上報 : AlarmReport]							
DM12100	42101	Machine	EQ->EAP	2nd Char 1st Char	Machine ID	String (3) ASCII	100
DM12101	42102			4th Char 3rd Char			101
DM12102	42103			6th Char 5th Char			102
DM12103	42104	DATE	EQ->EAP	y(2st Char) y(1st Char)	yyyyMMddHHmmss	String (7) ASCII	103
DM12104	42105			y(4st Char) y(3st Char)			104
DM12105	42106			M(2st Char) M(1st Char)			105
DM12106	42107			d(2st Char) d(1st Char)			106
DM12107	42108			H(2st Char) H(1st Char)			107
DM12108	42109			m(2st Char) m(1st Char)			108
DM12109	42110			s(2st Char) s(1st Char)			109
DM12110	42111	AlarmStatus	EQ->EAP	0000 0000 0000 00aa	1 : S / 2 : E	INT(1)	110
DM12111	42112	AlarmType	EQ->EAP	0000 0000 0000 00aa	1 : Alarm / 2 :Warning	INT(1)	111
DM12112	42113	AlarmCode	EQ->EAP	2nd Char 1st Char	Alarm Code	String (2) ASCII	112
DM12113	42114			4th Char 3rd Char			113
DM12114	42115	Spare					114
DM12115	42116	Spare					115
DM12116	42117	Spare					116
DM12117	42118	Spare					117
DM12118	42119	Spare					118
DM12119	42120	Spare					119
DM12120	42121	Spare					120
DM12121	42122	RtnResult	EAP->EQ	0000 0000 0000 00aa	1 : PASS / 2 :FAIL	INT(1)	121
DM12122	42123	RtnCode	EAP->EQ	0000 0000 hhhh hhhh	PASS : 0 / FAIL : 1~99	INT(2)	122
DM12123	42124			4th 3rd			123
DM12124	42125			6th 5th			124
DM12125	42126			8th 7th			125
DM12126	42127	Spare					126
DM12127	42128	Spare					127
DM12128	42129	Spare					128
DM12129	42130	Spare					129
[狀態變更 : StatusChange]							
DM12130	42131	Machine	EQ->EAP	2nd Char 1st Char	Machine ID	String (3) ASCII	130
DM12131	42132			4th Char 3rd Char			131
DM12132	42133			6th Char 5th Char			132
DM12133	42134	DATE	EQ->EAP	y(2st Char) y(1st Char)	yyyyMMddHHmmss	String (7) ASCII	133
DM12134	42135			y(4st Char) y(3st Char)			134
DM12135	42136			M(2st Char) M(1st Char)			135
DM12136	42137			d(2st Char) d(1st Char)			136
DM12137	42138			H(2st Char) H(1st Char)			137
DM12138	42139			m(2st Char) m(1st Char)			138
DM12139	42140			s(2st Char) s(1st Char)			139
DM12140	42141	OldStatus	EQ->EAP	0000 0000 0000 dcba	Old Status	INT(1) 0~10	140
DM12141	42142	NewStatus	EQ->EAP	0000 0000 0000 dcba	New Status	INT(1) 0~10	141
DM12142	42143	Spare					142
DM12143	42144	Spare					143
DM12144	42145	Spare					144
DM12145	42146	RtnResult	EAP->EQ	0000 0000 0000 00aa	1 : PASS / 2 :FAIL	INT(1)	145
DM12146	42147	RtnCode	EAP->EQ	0000 0000 hhhh hhhh	PASS : 0 / FAIL : 1~99	INT(2)	146
DM12147	42148	Spare					147
DM12148	42149	Spare					148
DM12149	42150	Spare					149

SUBJECT	Equipment Data Mapping
Doc. No. :	CIM Equipment spec.

PLC Start Adress DM13000
Modbus Start Adress 43001

PLC Address	Modbus Adress	Name Designation	Permission	Format(F->0)	Description	Annotation	
[EAP 回覆 Request and Ack]							
DM13000	43001	Equipment Event Request	EQ->EAP	0000 0000 000e dcba	a : UserID_Verify b : TrackOutReq c : AlarmReport d : StatusChangeReport e : PanelOutReport	(binary)	000
DM13001	43002	EAP Event Ack	EAP->EQ	0000 0000 000e dcba	a : UserID_Verify b : TrackOutReq c : AlarmReport d : StatusChangeReport e : PanelOutReport	(binary)	001
DM13002	43003	EAP CMD Request	EAP->EQ	0000 0000 0000 0000			002
DM13003	43004	Equipment CMD Ack	EQ->EAP	0000 0000 0000 0000			003
DM13004	43005	AliveCheck (EQ Startup)	EQ->EAP	0000 0000 0000 000a	a : AliveCheck (EQ Startup) · ON/OFF once every 15 seconds.		004
DM13005	43006	AliveCheck (EAP StartUp)	EAP->EQ	0000 0000 0000 000a	a : AliveCheck (EAP StartUp) · ON/OFF once every 15 seconds.		005
[人員登入區段 : UserID_Verify Area]							
DM13100	43101			2nd Char 1st Char			100
DM13101	43102	Machine	EQ->EAP	4th Char 3rd Char	Machine ID	String (3) ASCII	101
DM13102	43103			6th Char 5th Char			102
DM13103	43104			y(2st Char) y(1st Char)			103
DM13104	43105			y(4st Char) y(3st Char)			104
DM13105	43106			M(2st Char) M(1st Char)			105
DM13106	43107	DATE	EQ->EAP	d(2st Char) d(1st Char)	yyyyMMddHHmmss	String (7) ASCII	106
DM13107	43108			H(2st Char) H(1st Char)			107
DM13108	43109			m(2st Char) m(1st Char)			108
DM13109	43110			s(2st Char) s(1st Char)			109
DM13110	43111			2nd Char 1st Char			110
DM13111	43112	UserID	EQ->EAP	4th Char 3rd Char	User ID	String (3) ASCII	111
DM13112	43113			6th Char 5th Char			112
DM13113	43114			2nd Char 1st Char			113
DM13114	43115			4th Char 3rd Char			114
DM13115	43116			6th Char 5th Char			115
DM13116	43117			8th Char 7th Char			116
DM13117	43118			10th Char 9th Char			117
DM13118	43119			12th Char 11th Char			118
DM13119	43120			14th Char 13th Char			119
DM13120	43121			16th Char 15th Char			120
DM13121	43122			18th Char 17th Char			121
DM13122	43123			20th Char 19th Char			122
DM13123	43124			22nd Char 21st Char			123
DM13124	43125			24th Char 23rd Char			124
DM13125	43126	Barcode	EQ->EAP	26th Char 25th Char	Barcode	String (24) ASCII	125
DM13126	43127			28th Char 27th Char			126
DM13127	43128			30th Char 29th Char			127
DM13128	43129			32th Char 31th Char			128
DM13129	43130			34th Char 33th Char			129
DM13130	43131			36th Char 35th Char			130
DM13131	43132			38th Char 37th Char			131
DM13132	43133			40th Char 39th Char			132
DM13133	43134			42th Char 41th Char			133
DM13134	43135			44th Char 43th Char			134
DM13135	43136			46th Char 45th Char			135
DM13136	43137			48th Char 47th Char			136
DM13137	43138	Spare					137
DM13138	43139	Spare					138
DM13139	43140	Spare					139
DM13140	43141	Spare					140
DM13141	43142	Spare					141
DM13142	43143	Spare					142
DM13143	43144	RtnResult	EAP->EQ	0000 0000 0000 00aa	1 : PASS / 2 :FAIL	INT(1)	143
DM13144	43145	RtnCode	EAP->EQ	0000 0000 hhhh hhhh	PASS : 0 / FAIL : 1~99	INT(2)	144
DM13145	43146	Spare					145
DM13146	43147	Spare					146
DM13147	43148	Spare					147
DM13148	43149	Spare					148
DM13149	43150	Spare					149
[工單回報 : TrackOutReq]							
DM13150	43151			2nd Char 1st Char			150
DM13151	43152	Machine	EQ->EAP	4th Char 3rd Char	Machine ID	String (3) ASCII	151
DM13152	43153			6th Char 5th Char			152
DM13153	43154			y(2st Char) y(1st Char)			153
DM13154	43155			y(4st Char) y(3st Char)			154
DM13155	43156			M(2st Char) M(1st Char)			155
DM13156	43157	DATE	EQ->EAP	d(2st Char) d(1st Char)	yyyyMMddHHmmss	String (7) ASCII	156
DM13157	43158			H(2st Char) H(1st Char)			157
DM13158	43159			m(2st Char) m(1st Char)			158
DM13159	43160			s(2st Char) s(1st Char)			159
DM13160	43161			2nd Char 1st Char			160
DM13161	43162	UserID	EQ->EAP	4th Char 3rd Char	User ID	String (3) ASCII	161
DM13162	43163			6th Char 5th Char			162
DM13163	43164			2nd Char 1st Char			163
DM13164	43165			4th Char 3rd Char			164
DM13165	43166			6th Char 5th Char			165
DM13166	43167			8th Char 7th Char			166
DM13167	43168	MaterialID	EQ->EAP	10th Char 9th Char	Material ID	String (10) ASCII	167
DM13168	43169			12th Char 11th Char			168
DM13169	43170			14th Char 13th Char			169
DM13170	43171			16th Char 15th Char			170
DM13171	43172			18th Char 17th Char			171
DM13172	43173			20th Char 19th Char			172
DM13173	43174			2nd Char 1st Char			173
DM13174	43175			4th Char 3rd Char			174
DM13175	43176			6th Char 5th Char			175
DM13176	43177			8th Char 7th Char			176
DM13177	43178	CassetteID	EQ->EAP	10th Char 9th Char	Cassette ID	String (10) ASCII	177
DM13178	43179			12th Char 11th Char			178
DM13179	43180			14th Char 13th Char			179
DM13180	43181			16th Char 15th Char			180
DM13181	43182			18th Char 17th Char			181
DM13182	43183			20th Char 19th Char			182
DM13183	43184			2nd Char 1st Char			183
DM13184	43185			4th Char 3rd Char			184
DM13185	43186			6th Char 5th Char			185
DM13186	43187			8th Char 7th Char			186
DM13187	43188	WorkOrder	EQ->EAP	10th Char 9th Char	Work Order Number	String (10) ASCII	187
DM13188	43189			12th Char 11th Char			188
DM13189	43190			14th Char 13th Char			189
DM13190	43191			16th Char 15th Char			190
DM13191	43192			18th Char 17th Char			191
DM13192	43193			20th Char 19th Char			192
DM13193	43194			2nd Char 1st Char			193
DM13194	43195			4th Char 3rd Char			194
DM13195	43196			6th Char 5th Char			195
DM13196	43197			8th Char 7th Char			196
DM13197	43198	ToolingID	EQ->EAP	10th Char 9th Char	Tooling ID	String (10) ASCII	197
DM13198	43199			12th Char 11th Char			198
DM13199	43200			14th Char 13th Char			199
DM13200	43201			16th Char 15th Char			200
DM13201	43202			18th Char 17th Char			201
DM13202	43203			20th Char 19th Char			202
DM13203	43204	Qty	EQ->EAP	0000 0000 0000 00aa	Quantity	UINT(0~65535)	203
DM13204	43205	Result	EQ->EAP	0000 0000 0000 00aa	1 : PASS / 2 :FAIL	INT(1)	204
DM13205	43206			2nd Char 1st Char			205
DM13206	43207			4th Char 3rd Char			206
DM13207	43208			6th Char 5th Char			207
DM13208	43209			8th Char 7th Char			208
DM13209	43210	NGCode	EQ->EAP	10th Char 9th Char	NG Reason Code	String (10) ASCII	209
DM13210	43211			12th Char 11th Char			210
DM13211	43212			14th Char 13th Char			211
DM13212	43213			16th Char 15th Char			212
DM13213	43214			18th Char 17th Char			213
DM13214	43215			20th Char 19th Char			214
DM13215	43216			2nd Char 1st Char			215
DM13216	43217			4th Char 3rd Char			216
DM13217	43218			6th Char 5th Char			217
DM13218	43219			8th Char 7th Char			218
DM13219	43220	PanelList[0]	EQ->EAP	10th Char 9th Char	Panel List [0]	String (10) ASCII	219
DM13220	43221			12th Char 11th Char			220
DM13221	43222			14th Char 13th Char			221
DM13222	43223			16th Char 15th Char			222
DM13223	43224			18th Char 17th Char			223
DM13224	43225			20th Char 19th Char			224
DM13225	43226			2nd Char 1st Char			225
DM13226	43227			4th Char 3rd Char			226
DM13227	43228			6th Char 5th Char			227
DM13228	43229			8th Char 7th Char			228
DM13229	43230	PanelList[1]	EQ->EAP	10th Char 9th Char	Panel List [1]	String (10) ASCII	229
DM13230	43231			12th Char 11th Char			230
DM13231	43232			14th Char 13th Char			231
DM13232	43233			16th Char 15th Char			232
DM13233	43234			18th Char 17th Char			233
DM13234	43235			20th Char 19th Char			234
DM13235	43236			2nd Char 1st Char			235
DM13236	43237			4th Char 3rd Char			236
DM13237	43238			6th Char 5th Char			237
DM13238	43239			8th Char 7th Char			238
DM13239	43240	PanelList[2]	EQ->EAP	10th Char 9th Char	Panel List [2]	String (10) ASCII	239
DM13240	43241			12th Char 11th Char			240
DM13241	43242			14th Char 13th Char			241

SUBJECT		Equipment Data Mapping								
		Doc. No. : CIM Equipment spec.								
		PLC Start Adress	DM13000							
		Modbus Start Adress	43001							
PLC Address	Modbus Adress	Name Designation	Permission	Format(F->0)				Description	Annotation	
DM13242	43243			16th Char	15th Char					242
DM13243	43244			18th Char	17th Char					243
DM13244	43245			20th Char	19th Char					244
DM13245	43246			2nd Char	1st Char					245
DM13246	43247			4th Char	3rd Char					246
DM13247	43248			6th Char	5th Char					247
DM13248	43249			8th Char	7th Char					248
DM13249	43250	PanelList[3]	EQ->EAP	10th Char	9th Char			Panel List [3]	String (10) ASCII	249
DM13250	43251			12th Char	11th Char					250
DM13251	43252			14th Char	13th Char					251
DM13252	43253			16th Char	15th Char					252
DM13253	43254			18th Char	17th Char					253
DM13254	43255			20th Char	19th Char					254
DM13255	43256			2nd Char	1st Char					255
DM13256	43257			4th Char	3rd Char					256
DM13257	43258			6th Char	5th Char					257
DM13258	43259			8th Char	7th Char					258
DM13259	43260	PanelList[4]	EQ->EAP	10th Char	9th Char			Panel List [4]	String (10) ASCII	259
DM13260	43261			12th Char	11th Char					260
DM13261	43262			14th Char	13th Char					261
DM13262	43263			16th Char	15th Char					262
DM13263	43264			18th Char	17th Char					263
DM13264	43265			20th Char	19th Char					264
DM13265	43266			2nd Char	1st Char					265
DM13266	43267			4th Char	3rd Char					266
DM13267	43268			6th Char	5th Char					267
DM13268	43269			8th Char	7th Char					268
DM13269	43270	PanelList[5]	EQ->EAP	10th Char	9th Char			Panel List [5]	String (10) ASCII	269
DM13270	43271			12th Char	11th Char					270
DM13271	43272			14th Char	13th Char					271
DM13272	43273			16th Char	15th Char					272
DM13273	43274			18th Char	17th Char					273
DM13274	43275			20th Char	19th Char					274
DM13275	43276			2nd Char	1st Char					275
DM13276	43277			4th Char	3rd Char					276
DM13277	43278			6th Char	5th Char					277
DM13278	43279			8th Char	7th Char					278
DM13279	43280	PanelList[6]	EQ->EAP	10th Char	9th Char			Panel List [6]	String (10) ASCII	279
DM13280	43281			12th Char	11th Char					280
DM13281	43282			14th Char	13th Char					281
DM13282	43283			16th Char	15th Char					282
DM13283	43284			18th Char	17th Char					283
DM13284	43285			20th Char	19th Char					284
DM13285	43286			2nd Char	1st Char					285
DM13286	43287			4th Char	3rd Char					286
DM13287	43288			6th Char	5th Char					287
DM13288	43289			8th Char	7th Char					288
DM13289	43290	PanelList[7]	EQ->EAP	10th Char	9th Char			Panel List [7]	String (10) ASCII	289
DM13290	43291			12th Char	11th Char					290
DM13291	43292			14th Char	13th Char					291
DM13292	43293			16th Char	15th Char					292
DM13293	43294			18th Char	17th Char					293
DM13294	43295			20th Char	19th Char					294
DM13295	43296			2nd Char	1st Char					295
DM13296	43297			4th Char	3rd Char					296
DM13297	43298			6th Char	5th Char					297
DM13298	43299			8th Char	7th Char					298
DM13299	43300	PanelList[8]	EQ->EAP	10th Char	9th Char			Panel List [8]	String (10) ASCII	299
DM13300	43301			12th Char	11th Char					300
DM13301	43302			14th Char	13th Char					301
DM13302	43303			16th Char	15th Char					302
DM13303	43304			18th Char	17th Char					303
DM13304	43305			20th Char	19th Char					304
DM13305	43306			2nd Char	1st Char					305
DM13306	43307			4th Char	3rd Char					306
DM13307	43308			6th Char	5th Char					307
DM13308	43309			8th Char	7th Char					308
DM13309	43310	PanelList[9]	EQ->EAP	10th Char	9th Char			Panel List [9]	String (10) ASCII	309
DM13310	43311			12th Char	11th Char					310
DM13311	43312			14th Char	13th Char					311
DM13312	43313			16th Char	15th Char					312
DM13313	43314			18th Char	17th Char					313
DM13314	43315			20th Char	19th Char					314
DM13315	43316	Spare								315
DM13316	43317	Spare								316
DM13317	43318	Spare								317
DM13318	43319	Spare								318
DM13319	43320	Spare								319
DM13320	43321	Spare								320
DM13321	43322	Spare								321
DM13322	43323	Spare								322
DM13323	43324	Spare								323
DM13324	43325	Spare								324
DM13325	43326	Spare								325
DM13326	43327	Spare								326
DM13327	43328	Spare								327
DM13328	43329	Spare								328
DM13329	43330	Spare								329
DM13330	43331	Spare								330
DM13331	43332	Spare								331
DM13332	43333	Spare								332
DM13333	43334	Spare								333
DM13334	43335	Spare								334
DM13335	43336	Spare								335
DM13336	43337	Spare								336
DM13337	43338	Spare								337
DM13338	43339	Spare								338
DM13339	43340	Spare								339
DM13340	43341	Spare								340
DM13341	43342	Spare								341
DM13342	43343	Spare								342
DM13343	43344	RtnResult	EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	343
DM13344	43345	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)	344
DM13345	43346	Spare								345
DM13346	43347	Spare								346
DM13347	43348	Spare								347
DM13348	43349	Spare								348
DM13349	43350	Spare								349
[報告上報 : AlarmReport]										
DM13350	43351			2nd Char	1st Char					350
DM13351	43352	Machine	EQ->EAP	4th Char	3rd Char			Machine ID	String (3) ASCII	351
DM13352	43353			6th Char	5th Char					352
DM13353	43354			y(2st Char)	y(1st Char)					353
DM13354	43355			y(4st Char)	y(3st Char)					354
DM13355	43356			M(2st Char)	M(1st Char)					355
DM13356	43357	DATE	EQ->EAP	d(2st Char)	d(1st Char)			yyyyMMddHHmmss	String (7) ASCII	356
DM13357	43358			H(2st Char)	H(1st Char)					357
DM13358	43359			m(2st Char)	m(1st Char)					358
DM13359	43360			s(2st Char)	s(1st Char)					359
DM13360	43361	AlarmStatus	EQ->EAP	0000	0000	0000	00ba	1 : S / 2 : E	INT(1)	360
DM13361	43362	AlarmType	EQ->EAP	0000	0000	0000	00ba	1 : Alarm / 2 :Warning	INT(1)	361
DM13362	43363	AlarmCode	EQ->EAP	2nd Char	1st Char			Alarm Code	String (2) ASCII	362
DM13363	43364			4th Char	3rd Char					363
DM13364	43365	Spare								364
DM13365	43366	Spare								365
DM13366	43367	Spare								366
DM13367	43368	Spare								367
DM13368	43369	Spare								368
DM13369	43370	Spare								369
DM13370	43371	Spare								370
DM13371	43372	RtnResult	EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	371
DM13372	43373	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)	372
DM13373	43374			4th	3rd					373
DM13374	43375			6th	5th					374
DM13375	43376			8th	7th					375
DM13376	43377	Spare								376
DM13377	43378	Spare								377
DM13378	43379	Spare								378
DM13379	43380	Spare								379
[狀態變更 : StatusChange]										
DM13380	43381			2nd Char	1st Char					380
DM13381	43382	Machine	EQ->EAP	4th Char	3rd Char			Machine ID	String (3) ASCII	381
DM13382	43383			6th Char	5th Char					382
DM13383	43384			y(2st Char)	y(1st Char)					383
DM13384	43385			y(4st Char)	y(3st Char)					384
DM13385	43386			M(2st Char)	M(1st Char)					385
DM13386	43387	DATE	EQ->EAP	d(2st Char)	d(1st Char)			yyyyMMddHHmmss	String (7) ASCII	386
DM13387	43388			H(2st Char)	H(1st Char)					387
DM13388	43389			m(2st Char)	m(1st Char)					388
DM13389	43390			s(2st Char)	s(1st Char)					389
DM13390	43391	OldStatus	EQ->EAP	0000	0000	0000	dcba	Old Status	INT(1) 0~10	390
DM13391	43392	NewStatus	EQ->EAP	0000	0000	0000	dcba	New Status	INT(1) 0~10	391
DM13392	43393	Spare								392
DM13393	43394	Spare								393
DM13394	43395	Spare								394
DM13395	43396	RtnResult	EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	395
DM13396	43397	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)	396
DM13397	43398			4th	3rd					397
DM13398	43399			6th	5th					398
DM13399	43400			8th	7th					399
[進板信息 : Panel Out]										
DM13400	43401			2nd Char	1st Char					400
DM13401	43402	Machine	EQ->EAP	4th Char	3rd Char			Machine ID	String (3) ASCII	401
DM13402	43403			6th Char	5th Char					402
DM13403	43404			y(2st Char)	y(1st Char)					403
DM13404	43405			y(4st Char)	y(3st Char)					404
DM13405	43406			M(2st Char)	M(1st Char)					405
DM13406	43407	DATE	EQ->EAP	d(2st Char)	d(1st Char)			yyyyMMddHHmmss	String (7) ASCII	406
DM13407	43408			H(2st Char)	H(1st Char)					407
DM13408	43409			m(2st Char)	m(1st Char)					408
DM13409	43410			s(2st Char)	s(1st Char)					409
DM13410	43411			2nd Char	1st Char					410
DM13411	43412			4th Char	3rd Char					411
DM13412	43413			6th Char	5th Char					412
DM13413	43414			8th Char	7th Char					413
DM13414	43415	CassetteID	EQ->EAP	10th Char	9th Char			Cassette ID	String (10) ASCII	414
DM13415	43416			12th Char	11th Char					415
DM13416	43417			14th Char	13th Char					416
DM13417	43418			16th Char	15th Char					417
DM13418	43419			18th Char	17th Char					418
DM13419	43420			20th Char	19th Char					419
DM13420	43421			2nd Char	1st Char					420
DM13421	43422			4th Char	3rd Char					421
DM13422	43423			6th Char	5th Char					422
DM13423	43424			8th Char	7th Char					423
DM13424	43425	PanelID	EQ->EAP	10th Char	9th Char			Panel ID	String (10) ASCII	424
DM13425	43426			12th Char	11th Char					425
DM13426	43427			14th Char	13th Char					426
DM13427	43428			16th Char	15th Char					427
DM13428	43429			18th Char	17th Char					428
DM13429	43430			20th Char	19th Char					429
DM13430	43431	SlotNo	EQ->EAP	uuuu	uuuu	uuuu	uuuu	Slot Number(Calculations begin at the bottom)	UINT(1) 1~65535	430
DM13431	43432	Result	EQ->EAP	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	431
DM13432	43433	Spare								432
DM13433	43434	Spare								433
DM13434	43435	Spare								434
DM13435	43436	RtnResult	EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	435
DM13436	43437	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)	436
DM13437	43438	Spare								437
DM13438	43439	Spare								438
DM13439	43440	Spare								439