SUBJECT	Equipment Data Mapping									
	Doc. No.:	CIM Equipment spec.								
	PLC Start Adress	DM12000								
PLC Address	Name Designation	Permission	Format(F->0)					Description	Annotation	
[觸發訊號 : Request and Ack]										
DM12000	Equipment Event Request	EQ->EAP	0000	0000	0000	0cba		a : AlarmReport b : StatusChangeReport c : KeyParametersReport	(binary)	000
DM12001	EAP Event Ack	EAP->EQ	0000	0000	0000	0cba		a : AlarmReport b : StatusChangeReport c : KeyParametersReport	(binary)	001
DM12002	EAP CMD Request	EAP->EQ	0000	0000	0000	0000				002
DM12003	Equipment CMD Ack	EQ->EAP	0000	0000	0000	0000				003
DM12004	AliveCheck (EQ Startup)	EQ->EAP	0000	0000	0000	000a		a : AliveCheck (EQ Startup) · ON/OFF once every 15 seconds.		004
DM12005	AliveCheck (EAP StartUp)	EAP->EQ	0000	0000	0000	000a		a : AliveCheck (EAP StartUp) · ON/OFF once every 15 seconds.		005
[警報上報 : AlarmReport]										
DM12100	Machine	EQ->EAP	2nd Char		1st Char			Machine ID	String (3) ASCII	100
DM12101			4th Char		3rd Char					101
DM12102			6th Char		5th Char					102
DM12103	DATE	EQ->EAP	y(2st Char)		y(1st Char)			yyyyMMddHHmmss	String (7) ASCII	103
DM12104			y(4st Char)		y(3st Char)					104
DM12105			M(2st Char)		M(1st Char)					105
DM12106			d(2st Char)		d(1st Char)					106
DM12107			H(2st Char)		H(1st Char)					107
DM12108			m(2st Char)		m(1st Char)					108
DM12109			s(2st Char)		s(1st Char)					109
DM12110	AlarmStatus	EQ->EAP	0000	0000	0000	00aa		1 : S / 2 : E	INT(1)	110
DM12111	AlarmType	EQ->EAP	0000	0000	0000	00aa		1 : Alarm / 2 :Warning	INT(1)	111
DM12112	AlarmCode	EQ->EAP	2nd Char		1st Char			Alarm Code	String (2) ASCII	112
DM12113			4th Char		3rd Char					113
DM12114	Spare									114
DM12115	Spare									115
DM12116	Spare									116
DM12117	Spare									117
DM12118	Spare									118
DM12119	Spare									119
DM12120	Spare									120
DM12121	RtnResult	EAP->EQ	0000	0000	0000	00aa		1 : PASS / 2 :FAIL	INT(1)	121
DM12122	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh		PASS : 0 / FAIL : 1~99	INT(2)	122
DM12123	Spare									123
DM12124	Spare									124
DM12125	Spare									125
DM12126	Spare									126
DM12127	Spare									127
DM12128	Spare									128
DM12129	Spare									129
[狀態變更 : StatusChange]										
DM12130	Machine	EQ->EAP	2nd Char		1st Char			Machine ID	String (3) ASCII	130
DM12131			4th Char		3rd Char					131
DM12132			6th Char		5th Char					132
DM12133	DATE	EQ->EAP	y(2st Char)		y(1st Char)			yyyyMMddHHmmss	String (7) ASCII	133
DM12134			y(4st Char)		y(3st Char)					134
DM12135			M(2st Char)		M(1st Char)					135
DM12136			d(2st Char)		d(1st Char)					136
DM12137			H(2st Char)		H(1st Char)					137
DM12138			m(2st Char)		m(1st Char)					138
DM12139			s(2st Char)		s(1st Char)					139
DM12140	OldStatus	EQ->EAP	0000	0000	0000	dcba		Old Status	INT(1) 0~10	140
DM12141	NewStatus	EQ->EAP	0000	0000	0000	dcba		New Status	INT(1) 0~10	141
DM12142	Spare									142
DM12143	Spare									143
DM12144	Spare									144
DM12145	RtnResult	EAP->EQ	0000	0000	0000	00aa		1 : PASS / 2 :FAIL	INT(1)	145
DM12146	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh		PASS : 0 / FAIL : 1~99	INT(2)	146
DM12147	Spare									147
DM12148	Spare									148
DM12149	Spare									149
[關鍵參數上報 : KeyParametersReport]										
DM12150	Machine	EQ->EAP	2nd Char		1st Char			Machine ID	String (3) ASCII	150
DM12151			4th Char		3rd Char					151
DM12152			6th Char		5th Char					152
DM12153	DATE	EQ->EAP	y(2st Char)		y(1st Char)			yyyyMMddHHmmss	String (7) ASCII	153
DM12154			y(4st Char)		y(3st Char)					154
DM12155			M(2st Char)		M(1st Char)					155
DM12156			d(2st Char)		d(1st Char)					156
DM12157			H(2st Char)		H(1st Char)					157
DM12158			m(2st Char)		m(1st Char)					158
DM12159			s(2st Char)		s(1st Char)					159
DM12160	Para1_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	160
DM12161	Para1_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	161
DM12162	Para1_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	162
DM12163	Para2_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	163
DM12164	Para2_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	164
DM12165	Para2_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	165
DM12166	Para3_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	166
DM12167	Para3_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	167
DM12168	Para3_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	168
DM12169	Para4_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	169
DM12170	Para4_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	170
DM12171	Para4_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	171
DM12172	Para5_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	172
DM12173	Para5_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	173
DM12174	Para5_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	174
DM12175	Para6_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	175
DM12176	Para6_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	176
DM12177	Para6_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	177
DM12178	Para7_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	178
DM12179	Para7_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	179
DM12180	Para7_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	180
DM12181	Para8_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	181
DM12182	Para8_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	182
DM12183	Para8_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	183
DM12184	Para9_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	184
DM12185	Para9_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	185
DM12186	Para9_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	186
DM12187	Para10_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	187
DM12188	Para10_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	188
DM12189	Para10_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	189
DM12190	Para11_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	190
DM12191	Para11_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	191
DM12192	Para11_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	192
DM12193	Para12_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	193
DM12194	Para12_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	194
DM12195	Para12_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	195
DM12196	Para13_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	196
DM12197	Para13_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	197
DM12198	Para13_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	198
DM12199	Para14_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	199
DM12200	Para14_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	200
DM12201	Para14_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	201
DM12202	Para15_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	202
DM12203	Para15_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	203
DM12204	Para15_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	204
DM12205	Para16_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	205
DM12206	Para16_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	206
DM12207	Para16_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	207
DM12208	Para17_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	208
DM12209	Para17_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	209
DM12210	Para17_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	210
DM12211	Para18_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	211
DM12212	Para18_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	212
DM12213	Para18_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	213
DM12214	Para19_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	214
DM12215	Para19_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	215
DM12216	Para19_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	216
DM12217	Para20_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	217
DM12218	Para20_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	218
DM12219	Para20_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	219
DM12220	Para21_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	220
DM12221	Para21_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	221
DM12222	Para21_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	222

SUBJECT	Equipment Data Mapping									
	Doc. No. :	CIM Equipment spec.								
	PLC Start Adress	DM12000								
PLC Address	Name Designation	Permission	Format(F->0)					Description	Annotation	
DM12223	Para22_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	223
DM12224	Para22_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	224
DM12225	Para22_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	225
DM12226	Para23_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	226
DM12227	Para23_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	227
DM12228	Para23_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	228
DM12229	Para24_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	229
DM12230	Para24_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	230
DM12231	Para24_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	231
DM12232	Para25_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	232
DM12233	Para25_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	233
DM12234	Para25_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	234
DM12235	Para26_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	235
DM12236	Para26_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	236
DM12237	Para26_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	237
DM12238	Para27_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	238
DM12239	Para27_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	239
DM12240	Para27_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	240
DM12241	Para28_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	241
DM12242	Para28_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	242
DM12243	Para28_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	243
DM12244	Para29_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	244
DM12245	Para29_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	245
DM12246	Para29_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	246
DM12247	Para30_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	247
DM12248	Para30_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	248
DM12249	Para30_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	249
DM12250	Para31_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	250
DM12251	Para31_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	251
DM12252	Para31_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	252
DM12253	Para32_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	253
DM12254	Para32_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	254
DM12255	Para32_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	255
DM12256	Para33_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	256
DM12257	Para33_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	257
DM12258	Para33_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	258
DM12259	Para34_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	259
DM12260	Para34_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	260
DM12261	Para34_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	261
DM12262	Para35_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	262
DM12263	Para35_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	263
DM12264	Para35_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	264
DM12265	Para36_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	265
DM12266	Para36_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	266
DM12267	Para36_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	267
DM12268	Para37_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	268
DM12269	Para37_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	269
DM12270	Para37_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	270
DM12271	Para38_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	271
DM12272	Para38_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	272
DM12273	Para38_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	273
DM12274	Para39_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	274
DM12275	Para39_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	275
DM12276	Para39_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	276
DM12277	Para40_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	277
DM12278	Para40_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	278
DM12279	Para40_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	279
DM12280	Para41_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	280
DM12281	Para41_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	281
DM12282	Para41_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	282
DM12283	Para42_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	283
DM12284	Para42_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	284
DM12285	Para42_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	285
DM12286	Para43_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	286
DM12287	Para43_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	287
DM12288	Para43_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	288
DM12289	Para44_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	289
DM12290	Para44_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	290
DM12291	Para44_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	291
DM12292	Para45_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	292
DM12293	Para45_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	293
DM12294	Para45_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	294
DM12295	Para46_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	295
DM12296	Para46_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	296
DM12297	Para46_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	297
DM12298	Para47_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	298
DM12299	Para47_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	299
DM12300	Para47_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	300
DM12301	Para48_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	301
DM12302	Para48_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	302
DM12303	Para48_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	303
DM12304	Para49_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	304
DM12305	Para49_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	305
DM12306	Para49_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	306
DM12307	Para50_Value	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	307
DM12308	Para50_LSL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	308
DM12309	Para50_USL	EQ->EAP	eeee	eeee	eeee	eeee		16bit	UINT(0~9999)	309
DM12310	Spare									310
DM12311	Spare									311
DM12312	Spare									312
DM12313	Spare									313
DM12314	Spare									314
DM12315	Spare									315
DM12316	Spare									316
DM12317	Spare									317
DM12318	Spare									318
DM12319	Spare									319
DM12320	Spare									320
DM12321	Spare									321
DM12322	Spare									322
DM12323	Spare									323
DM12324	Spare									324
DM12325	Spare									325
DM12326	Spare									326
DM12327	Spare									327
DM12328	RtnResult	EAP->EQ	0000	0000	0000	00aa		1 : PASS / 2 :FAIL	INT(1)	328
DM12329	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh		PASS : 0 / FAIL : 1~99	INT(2)	329