SUBJECT	Equipment Data Mapping
	Doc. No. : CIM Equipment spec.
	PLC Start Adress DM10000

PLC Address	Name Designation	Permission	Format(F->0)				Description	Annotation	
[遠端指令PP_Select : RemoteCMD PP_Select]									
DM10000	RecipeID Loader	L->L	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Loader	UINT(1) 1~65535	0
DM10001	RecipeID Pickling	L->D	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Pickling	UINT(1) 1~65535	1
DM10002	RecipeID Unloader	L->UL	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Unloader	UINT(1) 1~65535	2
DM10003	Spare								3
DM10004	Spare								4
DM10005	Spare								5
DM10006	Spare								6
DM10007	Spare								7
DM10008	Spare								8
DM10009	Spare								9
DM10010	Current RecipeID Loader	Common	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Loader	UINT(1) 1~65535	10
DM10011	Current RecipeID Pickling	Common	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Pickling	UINT(1) 1~65535	11
DM10012	Current RecipeID Unloader	Common	uuuu	uuuu	uuuu	uuuu	RecipeID Change for Unloader	UINT(1) 1~65535	12
DM10013	Spare								13
DM10014	Spare								14
DM10015	Spare								15
DM10016	Spare								16
DM10017	Spare								17
DM10018	Spare								18
DM10019	Spare								19
[共用資料區 : Common Data Area]									
DM10020	WorkOrder_1	Common	2nd Char		1st Char		Work Order 1 Number	String (10) ASCII	20
DM10021			4th Char		3rd Char				21
DM10022			6th Char		5th Char				22
DM10023			8th Char		7th Char				23
DM10024			10th Char		9th Char				24
DM10025			12th Char		11th Char				25
DM10026			14th Char		13th Char				26
DM10027			16th Char		15th Char				27
DM10028			18th Char		17th Char				28
DM10029			20th Char		19th Char				29
DM10030	WorkOrder_2	Common	2nd Char		1st Char		Work Order 2 Number	String (10) ASCII	30
DM10031			4th Char		3rd Char				31
DM10032			6th Char		5th Char				32
DM10033			8th Char		7th Char				33
DM10034			10th Char		9th Char				34
DM10035			12th Char		11th Char				35
DM10036			14th Char		13th Char				36
DM10037			16th Char		15th Char				37
DM10038			18th Char		17th Char				38
DM10039			20th Char		19th Char				39
DM10040	WorkOrder_3	Common	2nd Char		1st Char		Work Order 3 Number	String (10) ASCII	40
DM10041			4th Char		3rd Char				41
DM10042			6th Char		5th Char				42
DM10043			8th Char		7th Char				43
DM10044			10th Char		9th Char				44
DM10045			12th Char		11th Char				45
DM10046			14th Char		13th Char				46
DM10047			16th Char		15th Char				47
DM10048			18th Char		17th Char				48
DM10049			20th Char		19th Char				49
DM10050	WorkOrder_4	Common	2nd Char		1st Char		Work Order 4 Number	String (10) ASCII	50
DM10051			4th Char		3rd Char				51
DM10052			6th Char		5th Char				52
DM10053			8th Char		7th Char				53
DM10054			10th Char		9th Char				54
DM10055			12th Char		11th Char				55
DM10056			14th Char		13th Char				56
DM10057			16th Char		15th Char				57
DM10058			18th Char		17th Char				58
DM10059			20th Char		19th Char				59
DM10060	WorkOrder_5	Common	2nd Char		1st Char		Work Order 5 Number	String (10) ASCII	60
DM10061			4th Char		3rd Char				61
DM10062			6th Char		5th Char				62
DM10063			8th Char		7th Char				63
DM10064			10th Char		9th Char				64
DM10065			12th Char		11th Char				65
DM10066			14th Char		13th Char				66
DM10067			16th Char		15th Char				67
DM10068			18th Char		17th Char				68
DM10069			20th Char		19th Char				69
DM10070	WorkOrder_6	Common	2nd Char		1st Char		Work Order 6 Number	String (10) ASCII	70
DM10071			4th Char		3rd Char				71
DM10072			6th Char		5th Char				72
DM10073			8th Char		7th Char				73
DM10074			10th Char		9th Char				74
DM10075			12th Char		11th Char				75
DM10076			14th Char		13th Char				76
DM10077			16th Char		15th Char				77
DM10078			18th Char		17th Char				78
DM10079			20th Char		19th Char				79
DM10080	WorkOrder_7	Common	2nd Char		1st Char		Work Order 7 Number	String (10) ASCII	80
DM10081			4th Char		3rd Char				81
DM10082			6th Char		5th Char				82
DM10083			8th Char		7th Char				83
DM10084			10th Char		9th Char				84
DM10085			12th Char		11th Char				85
DM10086			14th Char		13th Char				86
DM10087			16th Char		15th Char				87
DM10088			18th Char		17th Char				88
DM10089			20th Char		19th Char				89
DM10090	WorkOrder_8	Common	2nd Char		1st Char		Work Order 8 Number	String (10) ASCII	90
DM10091			4th Char		3rd Char				91
DM10092			6th Char		5th Char				92
DM10093			8th Char		7th Char				93
DM10094			10th Char		9th Char				94
DM10095			12th Char		11th Char				95
DM10096			14th Char		13th Char				96
DM10097			16th Char		15th Char				97
DM10098			18th Char		17th Char				98
DM10099			20th Char		19th Char				99
DM10100	WorkOrder_9	Common	2nd Char		1st Char		Work Order 9 Number	String (10) ASCII	100
DM10101			4th Char		3rd Char				101
DM10102			6th Char		5th Char				102
DM10103			8th Char		7th Char				103
DM10104			10th Char		9th Char				104
DM10105			12th Char		11th Char				105
DM10106			14th Char		13th Char				106
DM10107			16th Char		15th Char				107
DM10108			18th Char		17th Char				108
DM10109			20th Char		19th Char				109
DM10110	WorkOrder_10	Common	2nd Char		1st Char		Work Order 10 Number	String (10) ASCII	110
DM10111			4th Char		3rd Char				111
DM10112			6th Char		5th Char				112
DM10113			8th Char		7th Char				113
DM10114			10th Char		9th Char				114
DM10115			12th Char		11th Char				115
DM10116			14th Char		13th Char				116
DM10117			16th Char		15th Char				117
DM10118			18th Char		17th Char				118
DM10119			20th Char		19th Char				119
DM10120	Spare								120
DM10121	Spare								121
DM10122	Spare								122
DM10123	Spare								123
DM10124	Spare								124
DM10125	Spare								125
DM10126	Spare								126
DM10127	Spare								127
DM10128	Spare								128
DM10129	Spare								129
DM10130	Spare								130
DM10131	Spare								131
DM10132	Spare								132
DM10133	Spare								133
DM10134	Spare								134
DM10135	Spare								135
DM10136	Spare								136
DM10137	Spare								137
DM10138	Spare								138
DM10139	Spare								139
DM10140	Spare								140
DM10141	Spare								141
DM10142	Spare								142
DM10143	Spare								143
DM10144	Spare								144
DM10145	Spare								145
DM10146	Spare								146
DM10147	Spare								147
DM10148	Spare								148
DM10149	Spare								149
DM10150	Spare								150
DM10151	Spare								151
DM10152	Spare								152
DM10153	Spare								153
DM10154	Spare								154
DM10155	Spare								155
DM10156	Spare								156
DM10157	Spare								157
DM10158	Spare								158
DM10159	Spare								159
DM10160	Spare								160
DM10161	Spare								161
DM10162	Spare								162
DM10163	Spare								163
DM10164	Spare								164
DM10165	Spare								165
DM10166	Spare								166
DM10167	Spare								167
DM10168	Spare								168
DM10169	Spare								169
DM10170	Spare								170
DM10171	Spare								171
DM10172	Spare								172
DM10173	Spare								173
DM10174	Spare								174
DM10175	Spare								175
DM10176	Spare								176
DM10177	Spare								177
DM10178	Spare								178
DM10179	Spare								179
DM10180	Spare								180
DM10181	Spare								181
DM10182	Spare								182
DM10183	Spare								183

SUBJECT	Equipment Data Mapping
	Doc. No. : CIM Equipment spec.

PLC Start Adress DM10000

PLC Address	Name Designation	Permission	Format(F->0)				Description	Annotation	
DM10184	Spare								184
DM10185	Spare								185
DM10186	Spare								186
DM10187	Spare								187
DM10188	Spare								188
DM10189	Spare								189
DM10190	Spare								190
DM10191	Spare								191
DM10192	Spare								192
DM10193	Spare								193
DM10194	Spare								194
DM10195	Spare								195
DM10196	Spare								196
DM10197	Spare								197
DM10198	Spare								198
DM10199	Spare								199

SUBJECT	Equipment Data Mapping
	Doc. No. : CIM Equipment spec.

PLC Start Adress DM11000

PLC Address	Name Designation	Permission	Format(F->0)				Description	Annotation	
[觸發訊號 : Request and Ack]									
DM11000	Equipment Event Request	EQ->EAP	0000	0000	000e	dcba	a : UserID_Verify b : TrackInReq c : AlarmReport d : StatusChangeReport e : PanelInReport	(binary)	000
DM11001	EAP Event Ack	EAP->EQ	0000	0000	000e	dcba	a : UserID_Verify b : TrackInReq c : AlarmReport d : StatusChangeReport e : PanelInReport	(binary)	001
DM11002	EAP CMD Request	EAP->EQ	p000	0000	0000	000a	a : RemoteCMD (PP_SELECT)		002
DM11003	Equipment CMD Ack	EQ->EAP	0000	0000	0000	000a	a : RemoteCMD (PP_SELECT)		003
DM11004	AliveCheck (EQ Startup)	EQ->EAP	0000	0000	0000	000a	a : AliveCheck (EQ Startup) · ON/OFF once every 15 seconds.		004
DM11005	AliveCheck (EAP StartUp)	EAP->EQ	0000	0000	0000	000a	a : AliveCheck (EAP StartUp) · ON/OFF once every 15 seconds.		005
[人員登入驗證 : UserID_Verify Area]									
DM11100	Machine	EQ->EAP	2nd Char		1st Char		Machine ID	String (3) ASCII	100
DM11101			4th Char		3rd Char				101
DM11102			6th Char		5th Char				102
DM11103	DATE	EQ->EAP	y(2st Char)		y(1st Char)		yyyyMMddHHmmss	String (7) ASCII	103
DM11104			y(4st Char)		y(3st Char)				104
DM11105			M(2st Char)		M(1st Char)				105
DM11106			d(2st Char)		d(1st Char)				106
DM11107			H(2st Char)		H(1st Char)				107
DM11108			m(2st Char)		m(1st Char)				108
DM11109			s(2st Char)		s(1st Char)				109
DM11110	UserID	EQ->EAP	2nd Char		1st Char		User ID	String (3) ASCII	110
DM11111			4th Char		3rd Char				111
DM11112			6th Char		5th Char				112
DM11113	Barcode	EQ->EAP	2nd Char		1st Char		Barcode	String (24) ASCII	113
DM11114			4th Char		3rd Char				114
DM11115			6th Char		5th Char				115
DM11116			8th Char		7th Char				116
DM11117			10th Char		9th Char				117
DM11118			12th Char		11th Char				118
DM11119			14th Char		13th Char				119
DM11120			16th Char		15th Char				120
DM11121			18th Char		17th Char				121
DM11122			20th Char		19th Char				122
DM11123			22nd Char		21st Char				123
DM11124			24th Char		23rd Char				124
DM11125			26th Char		25th Char				125
DM11126			28th Char		27th Char				126
DM11127			30th Char		29th Char				127
DM11128			32th Char		31th Char				128
DM11129			34th Char		33th Char				129
DM11130			36th Char		35th Char				130
DM11131			38th Char		37th Char				131
DM11132			40th Char		39th Char				132
DM11133			42th Char		41th Char				133
DM11134			44th Char		43th Char				134
DM11135			46th Char		45th Char				135
DM11136			48th Char		47th Char				136
DM11137	Spare								137
DM11138	Spare								138
DM11139	Spare								139
DM11140	Spare								140
DM11141	Spare								141
DM11142	Spare								142
DM11143	RtnResult	EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	143
DM11144	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)	144
DM11145	Spare								145
DM11146	Spare								146
DM11147	Spare								147
DM11148	Spare								148
DM11149	Spare								149
[工單進站 : TrackInReq]									
DM11150	Machine	EQ->EAP	2nd Char		1st Char		Machine ID	String (3) ASCII	150
DM11151			4th Char		3rd Char				151
DM11152			6th Char		5th Char				152
DM11153	DATE	EQ->EAP	y(2st Char)		y(1st Char)		yyyyMMddHHmmss	String (7) ASCII	153
DM11154			y(4st Char)		y(3st Char)				154
DM11155			M(2st Char)		M(1st Char)				155
DM11156			d(2st Char)		d(1st Char)				156
DM11157			H(2st Char)		H(1st Char)				157
DM11158			m(2st Char)		m(1st Char)				158
DM11159			s(2st Char)		s(1st Char)				159
DM11160	UserID	EQ->EAP	2nd Char		1st Char		User ID	String (3) ASCII	160
DM11161			4th Char		3rd Char				161
DM11162			6th Char		5th Char				162
DM11163	MaterialID	EQ->EAP	2nd Char		1st Char		Material ID	String (10) ASCII	163
DM11164			4th Char		3rd Char				164
DM11165			6th Char		5th Char				165
DM11166			8th Char		7th Char				166
DM11167			10th Char		9th Char				167
DM11168			12th Char		11th Char				168
DM11169			14th Char		13th Char				169
DM11170			16th Char		15th Char				170
DM11171			18th Char		17th Char				171
DM11172			20th Char		19th Char				172
DM11173	CassetteID	EQ->EAP	2nd Char		1st Char		Cassette ID	String (10) ASCII	173
DM11174			4th Char		3rd Char				174
DM11175			6th Char		5th Char				175
DM11176			8th Char		7th Char				176
DM11177			10th Char		9th Char				177
DM11178			12th Char		11th Char				178
DM11179			14th Char		13th Char				179
DM11180			16th Char		15th Char				180
DM11181			18th Char		17th Char				181
DM11182			20th Char		19th Char				182
DM11183	WorkOrder	EQ->EAP	2nd Char		1st Char		Work Order Number	String (10) ASCII	183
DM11184			4th Char		3rd Char				184
DM11185			6th Char		5th Char				185
DM11186			8th Char		7th Char				186
DM11187			10th Char		9th Char				187
DM11188			12th Char		11th Char				188
DM11189			14th Char		13th Char				189
DM11190			16th Char		15th Char				190
DM11191			18th Char		17th Char				191
DM11192			20th Char		19th Char				192
DM11193	ToolingID	EQ->EAP	2nd Char		1st Char		Tooling ID	String (10) ASCII	193
DM11194			4th Char		3rd Char				194
DM11195			6th Char		5th Char				195
DM11196			8th Char		7th Char				196
DM11197			10th Char		9th Char				197
DM11198			12th Char		11th Char				198
DM11199			14th Char		13th Char				199
DM11200			16th Char		15th Char				200
DM11201			18th Char		17th Char				201
DM11202			20th Char		19th Char				202
DM11203	Qty	EQ->EAP	uuuu	uuuu	uuuu	uuuu	Quantity	UINT(0~65535)	203
DM11204	Spare								204
DM11205	Spare								205
DM11206	Spare								206
DM11207	Spare								207
DM11208	Spare								208
DM11209	Spare								209
DM11210	Spare								210
DM11211	Spare								211
DM11212	Spare								212
DM11213	Spare								213
DM11214	Spare								214
DM11215	RtnResult	EAP->EQ	0000	0000	0000	00ba	1 : PASS / 2 :FAIL	INT(1)	215
DM11216	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)	216
DM11217	PanelList[0]	EAP->EQ	2nd Char		1st Char		Panel List [0]	String (10) ASCII	217
DM11218			4th Char		3rd Char				218
DM11219			6th Char		5th Char				219
DM11220			8th Char		7th Char				220
DM11221			10th Char		9th Char				221
DM11222			12th Char		11th Char				222

SUBJECT	Equipment Data Mapping
	Doc. No. : CIM Equipment spec.
	PLC Start Adress DM11000

PLC Address	Name Designation	Permission	Format(F->0)				Description	Annotation	
DM11223			14th Char		13th Char				223
DM11224			16th Char		15th Char				224
DM11225			18th Char		17th Char				225
DM11226			20th Char		19th Char				226
DM11227	PanelList[1]	EAP->EQ	2nd Char		1st Char		Panel List [1]	String (10) ASCII	227
DM11228			4th Char		3rd Char				228
DM11229			6th Char		5th Char				229
DM11230			8th Char		7th Char				230
DM11231			10th Char		9th Char				231
DM11232			12th Char		11th Char				232
DM11233			14th Char		13th Char				233
DM11234			16th Char		15th Char				234
DM11235			18th Char		17th Char				235
DM11236			20th Char		19th Char				236
DM11237	PanelList[2]	EAP->EQ	2nd Char		1st Char		Panel List [2]	String (10) ASCII	237
DM11238			4th Char		3rd Char				238
DM11239			6th Char		5th Char				239
DM11240			8th Char		7th Char				240
DM11241			10th Char		9th Char				241
DM11242			12th Char		11th Char				242
DM11243			14th Char		13th Char				243
DM11244			16th Char		15th Char				244
DM11245			18th Char		17th Char				245
DM11246			20th Char		19th Char				246
DM11247	PanelList[3]	EAP->EQ	2nd Char		1st Char		Panel List [3]	String (10) ASCII	247
DM11248			4th Char		3rd Char				248
DM11249			6th Char		5th Char				249
DM11250			8th Char		7th Char				250
DM11251			10th Char		9th Char				251
DM11252			12th Char		11th Char				252
DM11253			14th Char		13th Char				253
DM11254			16th Char		15th Char				254
DM11255			18th Char		17th Char				255
DM11256			20th Char		19th Char				256
DM11257	PanelList[4]	EAP->EQ	2nd Char		1st Char		Panel List [4]	String (10) ASCII	257
DM11258			4th Char		3rd Char				258
DM11259			6th Char		5th Char				259
DM11260			8th Char		7th Char				260
DM11261			10th Char		9th Char				261
DM11262			12th Char		11th Char				262
DM11263			14th Char		13th Char				263
DM11264			16th Char		15th Char				264
DM11265			18th Char		17th Char				265
DM11266			20th Char		19th Char				266
DM11267	PanelList[5]	EAP->EQ	2nd Char		1st Char		Panel List [5]	String (10) ASCII	267
DM11268			4th Char		3rd Char				268
DM11269			6th Char		5th Char				269
DM11270			8th Char		7th Char				270
DM11271			10th Char		9th Char				271
DM11272			12th Char		11th Char				272
DM11273			14th Char		13th Char				273
DM11274			16th Char		15th Char				274
DM11275			18th Char		17th Char				275
DM11276			20th Char		19th Char				276
DM11277	PanelList[6]	EAP->EQ	2nd Char		1st Char		Panel List [6]	String (10) ASCII	277
DM11278			4th Char		3rd Char				278
DM11279			6th Char		5th Char				279
DM11280			8th Char		7th Char				280
DM11281			10th Char		9th Char				281
DM11282			12th Char		11th Char				282
DM11283			14th Char		13th Char				283
DM11284			16th Char		15th Char				284
DM11285			18th Char		17th Char				285
DM11286			20th Char		19th Char				286
DM11287	PanelList[7]	EAP->EQ	2nd Char		1st Char		Panel List [7]	String (10) ASCII	287
DM11288			4th Char		3rd Char				288
DM11289			6th Char		5th Char				289
DM11290			8th Char		7th Char				290
DM11291			10th Char		9th Char				291
DM11292			12th Char		11th Char				292
DM11293			14th Char		13th Char				293
DM11294			16th Char		15th Char				294
DM11295			18th Char		17th Char				295
DM11296			20th Char		19th Char				296
DM11297	PanelList[8]	EAP->EQ	2nd Char		1st Char		Panel List [8]	String (10) ASCII	297
DM11298			4th Char		3rd Char				298
DM11299			6th Char		5th Char				299
DM11300			8th Char		7th Char				300
DM11301			10th Char		9th Char				301
DM11302			12th Char		11th Char				302
DM11303			14th Char		13th Char				303
DM11304			16th Char		15th Char				304
DM11305			18th Char		17th Char				305
DM11306			20th Char		19th Char				306
DM11307	PanelList[9]	EAP->EQ	2nd Char		1st Char		Panel List [9]	String (10) ASCII	307
DM11308			4th Char		3rd Char				308
DM11309			6th Char		5th Char				309
DM11310			8th Char		7th Char				310
DM11311			10th Char		9th Char				311
DM11312			12th Char		11th Char				312
DM11313			14th Char		13th Char				313
DM11314			16th Char		15th Char				314
DM11315			18th Char		17th Char				315
DM11316			20th Char		19th Char				316
DM11317	Spare								317
DM11318	Spare								318
DM11319	Spare								319
DM11320	Spare								320
DM11321	Spare								321
DM11322	Spare								322
DM11323	Spare								323
DM11324	Spare								324
DM11325	Spare								325
DM11326	Spare								326
DM11327	Spare								327
DM11328	Spare								328
DM11329	Spare								329
DM11330	Spare								330
DM11331	Spare								331
DM11332	Spare								332
DM11333	Spare								333
DM11334	Spare								334
DM11335	Spare								335
DM11336	Spare								336
DM11337	Spare								337
DM11338	Spare								338
DM11339	Spare								339
DM11340	Spare								340
DM11341	Spare								341
DM11342	Spare								342
DM11343	Spare								343
DM11344	Spare								344
DM11345	Spare								345
DM11346	Spare								346
DM11347	Spare								347
DM11348	Spare								348
DM11349	Spare								349
[警報上報 : AlarmReport]									
DM11350	Machine	EQ->EAP	2nd Char		1st Char		Machine ID	String (3) ASCII	350
DM11351			4th Char		3rd Char				351
DM11352			6th Char		5th Char				352
DM11353	DATE	EQ->EAP	y(2st Char)		y(1st Char)		yyyyMMddHHmmss	String (7) ASCII	353
DM11354			y(4st Char)		y(3st Char)				354
DM11355			M(2st Char)		M(1st Char)				355
DM11356			d(2st Char)		d(1st Char)				356
DM11357			H(2st Char)		H(1st Char)				357
DM11358			m(2st Char)		m(1st Char)				358
DM11359			s(2st Char)		s(1st Char)				359
DM11360	AlarmStatus	EQ->EAP	0000	0000	0000	00aa	1 : S / 2 : E	INT(1)	360
DM11361	AlarmType	EQ->EAP	0000	0000	0000	00aa	1 : Alarm / 2 :Warning	INT(1)	361
DM11362	AlarmCode	EQ->EAP	2nd Char		1st Char		Alarm Code	String (2) ASCII	362
DM11363			4th Char		3rd Char				363
DM11364	Spare								364
DM11365	Spare								365
DM11366	Spare								366
DM11367	Spare								367
DM11368	Spare								368
DM11369	Spare								369
DM11370	Spare								370
DM11371	RtnResult	EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	371
DM11372	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)	372
DM11373			4th		3rd				373
DM11374			6th		5th				374
DM11375			8th		7th				375
DM11376	Spare								376
DM11377	Spare								377
DM11378	Spare								378
DM11379	Spare								379
[狀態變更 : StatusChange]									
DM11380	Machine	EQ->EAP	2nd Char		1st Char		Machine ID	String (3) ASCII	380
DM11381			4th Char		3rd Char				381
DM11382			6th Char		5th Char				382
DM11383	DATE	EQ->EAP	y(2st Char)		y(1st Char)		yyyyMMddHHmmss	String (7) ASCII	383
DM11384			y(4st Char)		y(3st Char)				384
DM11385			M(2st Char)		M(1st Char)				385
DM11386			d(2st Char)		d(1st Char)				386
DM11387			H(2st Char)		H(1st Char)				387
DM11388			m(2st Char)		m(1st Char)				388
DM11389			s(2st Char)		s(1st Char)				389
DM11390	OldStatus	EQ->EAP	0000	0000	0000	dcba	Old Status	INT(1) 0~10	390
DM11391	NewStatus	EQ->EAP	0000	0000	0000	dcba	New Status	INT(1) 0~10	391
DM11392	Spare								392
DM11393	Spare								393
DM11394	Spare								394
DM11395	RtnResult	EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	395
DM11396	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)	396
DM11397	Spare								397
DM11398	Spare								398
DM11399	Spare								399
[載板入料 : Panel In]									
DM11400	Machine	EQ->EAP	2nd Char		1st Char		Machine ID	String (3) ASCII	400
DM11401			4th Char		3rd Char				401
DM11402			6th Char		5th Char				402
DM11403	DATE	EQ->EAP	y(2st Char)		y(1st Char)		yyyyMMddHHmmss	String (7) ASCII	403
DM11404			y(4st Char)		y(3st Char)				404
DM11405			M(2st Char)		M(1st Char)				405

SUBJECT	Equipment Data Mapping
Doc. No. :	CIM Equipment spec.

PLC Start Adress DM11000

PLC Address	Name Designation	Permission	Format(F->0)				Description	Annotation	
DM11406	DATE	EQ->EAP	d(2st Char)		d(1st Char)		yyyyMMddHHmmss	String (7) ASCII	406
DM11407			H(2st Char)		H(1st Char)				407
DM11408			m(2st Char)		m(1st Char)				408
DM11409			s(2st Char)		s(1st Char)				409
DM11410	CassetteID	EQ->EAP	2nd Char		1st Char		Cassette ID	String (10) ASCII	410
DM11411			4th Char		3rd Char				411
DM11412			6th Char		5th Char				412
DM11413			8th Char		7th Char				413
DM11414			10th Char		9th Char				414
DM11415			12th Char		11th Char				415
DM11416			14th Char		13th Char				416
DM11417			16th Char		15th Char				417
DM11418			18th Char		17th Char				418
DM11419			20th Char		19th Char				419
DM11420	PanelID	EQ->EAP	2nd Char		1st Char		Panel ID	String (10) ASCII	420
DM11421			4th Char		3rd Char				421
DM11422			6th Char		5th Char				422
DM11423			8th Char		7th Char				423
DM11424			10th Char		9th Char				424
DM11425			12th Char		11th Char				425
DM11426			14th Char		13th Char				426
DM11427			16th Char		15th Char				427
DM11428			18th Char		17th Char				428
DM11429			20th Char		19th Char				429
DM11430	SlotNo	EQ->EAP	uuuu	uuuu	uuuu	uuuu	Slot Number(Calculations begin at the bottom)	UINT(1) 1~65535	430
DM11431	Spare								431
DM11432	Spare								432
DM11433	Spare								433
DM11434	Spare								434
DM11435	RtnResult	EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	435
DM11436	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)	436
DM11437	Spare								437
DM11438	Spare								438
DM11439	Spare								439
[遠端指令PP_Select : RemoteCMD PP_Select]									
DM11440	Machine	EAP->EQ	2nd Char		1st Char		Machine ID	String (3) ASCII	440
DM11441			4th Char		3rd Char				441
DM11442			6th Char		5th Char				442
DM11443	DATE	EAP->EQ	y(2st Char)		y(1st Char)		yyyyMMddHHmmss	String (7) ASCII	443
DM11444			y(4st Char)		y(3st Char)				444
DM11445			M(2st Char)		M(1st Char)				445
DM11446			d(2st Char)		d(1st Char)				446
DM11447			H(2st Char)		H(1st Char)				447
DM11448			m(2st Char)		m(1st Char)				448
DM11449			s(2st Char)		s(1st Char)				449
DM11450	RecipeID_Loader	EAP->EQ	uuuu	uuuu	uuuu	uuuu	RecipeID for Loader	UINT(1) 1~65535	450
DM11451	RecipeID_Development	EAP->EQ	uuuu	uuuu	uuuu	uuuu	RecipeID for Development	UINT(1) 1~65535	451
DM11452	RecipeID_Unloader	EAP->EQ	uuuu	uuuu	uuuu	uuuu	RecipeID for Unloader	UINT(1) 1~65535	452
DM11453	Spare								453
DM11454	Spare								454
DM11455	Spare								455
DM11456	Spare								456
DM11457	Spare								457
DM11458	Spare								458
DM11459	Spare								459
DM11460	Spare								460
DM11461	Spare								461
DM11462	Spare								462
DM11463	Spare								463
DM11464	Spare								464
DM11465	Spare								465
DM11466	Spare								466
DM11467	Spare								467
DM11468	Spare								468
DM11469	Spare								469
DM11470	Spare								470
DM11471	Spare								471
DM11472	Spare								472
DM11473	Spare								473
DM11474	RtnResult	EQ->EAP	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	474
DM11475	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)	475
DM11476	Spare								476
DM11477	Spare								477
DM11478	Spare								478
DM11479	Spare								479

SUBJECT Equipment Data Mapping
Doc. No. : CIM Equipment spec.
PLC Start Adress DM12000

PLC Address	Name Designation	Permission	Format(F->0)		Description	Annotation	
[觸發訊號 : Request and Ack]							
DM12000	Equipment Event Request	EQ->EAP	0000 0000	0000 00ba	a : AlarmReport b : StatusChangeReport	(binary)	000
DM12001	EAP Event Ack	EAP->EQ	0000 0000	0000 00ba	a : AlarmReport b : StatusChangeReport	(binary)	001
DM12002	EAP CMD Request	EAP->EQ	0000 0000	0000 0000			002
DM12003	Equipment CMD Ack	EQ->EAP	0000 0000	0000 0000			003
DM12004	AliveCheck (EQ Startup)	EQ->EAP	0000 0000	0000 000a	a : AliveCheck (EQ Startup) · ON/OFF once every 15 seconds.		004
DM12005	AliveCheck (EAP StartUp)	EAP->EQ	0000 0000	0000 000a	a : AliveCheck (EAP StartUp) · ON/OFF once every 15 seconds.		005
[警報上報 : AlarmReport]							
DM12100	Machine	EQ->EAP	2nd Char	1st Char	Machine ID	String (3) ASCII	100
DM12101			4th Char	3rd Char			101
DM12102			6th Char	5th Char			102
DM12103	DATE	EQ->EAP	y(2st Char)	y(1st Char)	yyyyMMddHHmmss	String (7) ASCII	103
DM12104			y(4st Char)	y(3st Char)			104
DM12105			M(2st Char)	M(1st Char)			105
DM12106			d(2st Char)	d(1st Char)			106
DM12107			H(2st Char)	H(1st Char)			107
DM12108			m(2st Char)	m(1st Char)			108
DM12109			s(2st Char)	s(1st Char)			109
DM12110	AlarmStatus	EQ->EAP	0000 0000	0000 00aa	1 : S / 2 : E	INT(1)	110
DM12111	AlarmType	EQ->EAP	0000 0000	0000 00aa	1 : Alarm / 2 :Warning	INT(1)	111
DM12112	AlarmCode	EQ->EAP	2nd Char	1st Char	Alarm Code	String (2) ASCII	112
DM12113			4th Char	3rd Char			113
DM12114	Spare						114
DM12115	Spare						115
DM12116	Spare						116
DM12117	Spare						117
DM12118	Spare						118
DM12119	Spare						119
DM12120	Spare						120
DM12121	RtnResult	EAP->EQ	0000 0000	0000 00aa	1 : PASS / 2 :FAIL	INT(1)	121
DM12122	RtnCode	EAP->EQ	0000 0000	hhhh hhhh	PASS : 0 / FAIL : 1~99	INT(2)	122
DM12123			4th	3rd			123
DM12124			6th	5th			124
DM12125			8th	7th			125
DM12126	Spare						126
DM12127	Spare						127
DM12128	Spare						128
DM12129	Spare						129
[狀態變更 : StatusChange]							
DM12130	Machine	EQ->EAP	2nd Char	1st Char	Machine ID	String (3) ASCII	130
DM12131			4th Char	3rd Char			131
DM12132			6th Char	5th Char			132
DM12133	DATE	EQ->EAP	y(2st Char)	y(1st Char)	yyyyMMddHHmmss	String (7) ASCII	133
DM12134			y(4st Char)	y(3st Char)			134
DM12135			M(2st Char)	M(1st Char)			135
DM12136			d(2st Char)	d(1st Char)			136
DM12137			H(2st Char)	H(1st Char)			137
DM12138			m(2st Char)	m(1st Char)			138
DM12139			s(2st Char)	s(1st Char)			139
DM12140	OldStatus	EQ->EAP	0000 0000	0000 dcba	Old Status	INT(1) 0~10	140
DM12141	NewStatus	EQ->EAP	0000 0000	0000 dcba	New Status	INT(1) 0~10	141
DM12142	Spare						142
DM12143	Spare						143
DM12144	Spare						144
DM12145	RtnResult	EAP->EQ	0000 0000	0000 00aa	1 : PASS / 2 :FAIL	INT(1)	145
DM12146	RtnCode	EAP->EQ	0000 0000	hhhh hhhh	PASS : 0 / FAIL : 1~99	INT(2)	146
DM12147	Spare						147
DM12148	Spare						148
DM12149	Spare						149

SUBJECT	Equipment Data Mapping
Doc. No. :	CIM Equipment spec.
PLC Start Adress	DM13000

PLC Address	Name Designation	Permission	Format(F->0)		Description	Annotation	
[觸發訊號 : Request and Ack]							
DM13000	Equipment Event Request	EQ->EAP	0000 0000	000e dcba	a : UserID_Verify b : TrackOutReq c : AlarmReport d : StatusChangeReport e : PanelOutReport	(binary)	000
DM13001	EAP Event Ack	EAP->EQ	0000 0000	000e dcba	a : UserID_Verify b : TrackOutReq c : AlarmReport d : StatusChangeReport e : PanelOutReport	(binary)	001
DM13002	EAP CMD Request	EAP->EQ	0000 0000	0000 0000			002
DM13003	Equipment CMD Ack	EQ->EAP	0000 0000	0000 0000			003
DM13004	AliveCheck (EQ Startup)	EQ->EAP	0000 0000	0000 000a	a : AliveCheck (EQ Startup) · ON/OFF once every 15 seconds.		004
DM13005	AliveCheck (EAP StartUp)	EAP->EQ	0000 0000	0000 000a	a : AliveCheck (EAP StartUp) · ON/OFF once every 15 seconds.		005
[人員登入驗證 : UserID_Verify Area]							
DM13100	Machine	EQ->EAP	2nd Char	1st Char	Machine ID	String (3) ASCII	100
DM13101			4th Char	3rd Char			101
DM13102			6th Char	5th Char			102
DM13103	DATE	EQ->EAP	y(2st Char)	y(1st Char)	yyyyMMddHHmmss	String (7) ASCII	103
DM13104			y(4st Char)	y(3st Char)			104
DM13105			M(2st Char)	M(1st Char)			105
DM13106			d(2st Char)	d(1st Char)			106
DM13107			H(2st Char)	H(1st Char)			107
DM13108			m(2st Char)	m(1st Char)			108
DM13109			s(2st Char)	s(1st Char)			109
DM13110	UserID	EQ->EAP	2nd Char	1st Char	User ID	String (3) ASCII	110
DM13111			4th Char	3rd Char			111
DM13112			6th Char	5th Char			112
DM13113	Barcode	EQ->EAP	2nd Char	1st Char	Barcode	String (24) ASCII	113
DM13114			4th Char	3rd Char			114
DM13115			6th Char	5th Char			115
DM13116			8th Char	7th Char			116
DM13117			10th Char	9th Char			117
DM13118			12th Char	11th Char			118
DM13119			14th Char	13th Char			119
DM13120			16th Char	15th Char			120
DM13121			18th Char	17th Char			121
DM13122			20th Char	19th Char			122
DM13123			22nd Char	21st Char			123
DM13124			24th Char	23rd Char			124
DM13125			26th Char	25th Char			125
DM13126			28th Char	27th Char			126
DM13127			30th Char	29th Char			127
DM13128			32th Char	31th Char			128
DM13129			34th Char	33th Char			129
DM13130			36th Char	35th Char			130
DM13131			38th Char	37th Char			131
DM13132			40th Char	39th Char			132
DM13133			42th Char	41th Char			133
DM13134			44th Char	43th Char			134
DM13135			46th Char	45th Char			135
DM13136			48th Char	47th Char			136
DM13137	Spare						137
DM13138	Spare						138
DM13139	Spare						139
DM13140	Spare						140
DM13141	Spare						141
DM13142	Spare						142
DM13143	RtnResult	EAP->EQ	0000 0000	0000 00aa	1 : PASS / 2 :FAIL	INT(1)	143
DM13144	RtnCode	EAP->EQ	0000 0000	hhhh hhhh	PASS : 0 / FAIL : 1~99	INT(2)	144
DM13145	Spare						145
DM13146	Spare						146
DM13147	Spare						147
DM13148	Spare						148
DM13149	Spare						149
[工單出站 : TrackOutReq]							
DM13150	Machine	EQ->EAP	2nd Char	1st Char	Machine ID	String (3) ASCII	150
DM13151			4th Char	3rd Char			151
DM13152			6th Char	5th Char			152
DM13153	DATE	EQ->EAP	y(2st Char)	y(1st Char)	yyyyMMddHHmmss	String (7) ASCII	153
DM13154			y(4st Char)	y(3st Char)			154
DM13155			M(2st Char)	M(1st Char)			155
DM13156			d(2st Char)	d(1st Char)			156
DM13157			H(2st Char)	H(1st Char)			157
DM13158			m(2st Char)	m(1st Char)			158
DM13159			s(2st Char)	s(1st Char)			159
DM13160	UserID	EQ->EAP	2nd Char	1st Char	User ID	String (3) ASCII	160
DM13161			4th Char	3rd Char			161
DM13162			6th Char	5th Char			162
DM13163	MaterialID	EQ->EAP	2nd Char	1st Char	Material ID	String (10) ASCII	163
DM13164			4th Char	3rd Char			164
DM13165			6th Char	5th Char			165
DM13166			8th Char	7th Char			166
DM13167			10th Char	9th Char			167
DM13168			12th Char	11th Char			168
DM13169			14th Char	13th Char			169
DM13170			16th Char	15th Char			170
DM13171			18th Char	17th Char			171
DM13172			20th Char	19th Char			172
DM13173	CassetteID	EQ->EAP	2nd Char	1st Char	Cassette ID	String (10) ASCII	173
DM13174			4th Char	3rd Char			174
DM13175			6th Char	5th Char			175
DM13176			8th Char	7th Char			176
DM13177			10th Char	9th Char			177
DM13178			12th Char	11th Char			178
DM13179			14th Char	13th Char			179
DM13180			16th Char	15th Char			180
DM13181			18th Char	17th Char			181
DM13182			20th Char	19th Char			182
DM13183	WorkOrder	EQ->EAP	2nd Char	1st Char	Work Order Number	String (10) ASCII	183
DM13184			4th Char	3rd Char			184
DM13185			6th Char	5th Char			185
DM13186			8th Char	7th Char			186
DM13187			10th Char	9th Char			187
DM13188			12th Char	11th Char			188
DM13189			14th Char	13th Char			189
DM13190			16th Char	15th Char			190
DM13191			18th Char	17th Char			191
DM13192			20th Char	19th Char			192
DM13193	ToolingID	EQ->EAP	2nd Char	1st Char	Tooling ID	String (10) ASCII	193
DM13194			4th Char	3rd Char			194
DM13195			6th Char	5th Char			195
DM13196			8th Char	7th Char			196
DM13197			10th Char	9th Char			197
DM13198			12th Char	11th Char			198
DM13199			14th Char	13th Char			199
DM13200			16th Char	15th Char			200
DM13201			18th Char	17th Char			201
DM13202			20th Char	19th Char			202
DM13203	Qty	EQ->EAP	0000 0000	0000 00aa	Quantity	UINT(0~65535)	203
DM13204	Result	EQ->EAP	0000 0000	0000 00aa	1 : PASS / 2 :FAIL	INT(1)	204
DM13205	NGCode	EQ->EAP	2nd Char	1st Char	NG Reason Code	String (10) ASCII	205
DM13206			4th Char	3rd Char			206
DM13207			6th Char	5th Char			207
DM13208			8th Char	7th Char			208
DM13209			10th Char	9th Char			209
DM13210			12th Char	11th Char			210
DM13211			14th Char	13th Char			211
DM13212			16th Char	15th Char			212
DM13213			18th Char	17th Char			213
DM13214			20th Char	19th Char			214
DM13215	PanelList[0]	EQ->EAP	2nd Char	1st Char	Panel List [0]	String (10) ASCII	215
DM13216			4th Char	3rd Char			216
DM13217			6th Char	5th Char			217
DM13218			8th Char	7th Char			218
DM13219			10th Char	9th Char			219
DM13220			12th Char	11th Char			220
DM13221			14th Char	13th Char			221
DM13222			16th Char	15th Char			222

SUBJECT	Equipment Data Mapping
	Doc. No. : CIM Equipment spec.

PLC Start Adress DM13000

PLC Address	Name	Designation	Permission	Format(F->0)		Description	Annotation	
DM13223				18th Char	17th Char			223
DM13224				20th Char	19th Char			224
DM13225		PanelList[1]	EQ->EAP	2nd Char	1st Char	Panel List [1]	String (10) ASCII	225
DM13226				4th Char	3rd Char			226
DM13227				6th Char	5th Char			227
DM13228				8th Char	7th Char			228
DM13229				10th Char	9th Char			229
DM13230				12th Char	11th Char			230
DM13231				14th Char	13th Char			231
DM13232				16th Char	15th Char			232
DM13233				18th Char	17th Char			233
DM13234				20th Char	19th Char			234
DM13235		PanelList[2]	EQ->EAP	2nd Char	1st Char	Panel List [2]	String (10) ASCII	235
DM13236				4th Char	3rd Char			236
DM13237				6th Char	5th Char			237
DM13238				8th Char	7th Char			238
DM13239				10th Char	9th Char			239
DM13240				12th Char	11th Char			240
DM13241				14th Char	13th Char			241
DM13242				16th Char	15th Char			242
DM13243				18th Char	17th Char			243
DM13244				20th Char	19th Char			244
DM13245		PanelList[3]	EQ->EAP	2nd Char	1st Char	Panel List [3]	String (10) ASCII	245
DM13246				4th Char	3rd Char			246
DM13247				6th Char	5th Char			247
DM13248				8th Char	7th Char			248
DM13249				10th Char	9th Char			249
DM13250				12th Char	11th Char			250
DM13251				14th Char	13th Char			251
DM13252				16th Char	15th Char			252
DM13253				18th Char	17th Char			253
DM13254				20th Char	19th Char			254
DM13255		PanelList[4]	EQ->EAP	2nd Char	1st Char	Panel List [4]	String (10) ASCII	255
DM13256				4th Char	3rd Char			256
DM13257				6th Char	5th Char			257
DM13258				8th Char	7th Char			258
DM13259				10th Char	9th Char			259
DM13260				12th Char	11th Char			260
DM13261				14th Char	13th Char			261
DM13262				16th Char	15th Char			262
DM13263				18th Char	17th Char			263
DM13264				20th Char	19th Char			264
DM13265		PanelList[5]	EQ->EAP	2nd Char	1st Char	Panel List [5]	String (10) ASCII	265
DM13266				4th Char	3rd Char			266
DM13267				6th Char	5th Char			267
DM13268				8th Char	7th Char			268
DM13269				10th Char	9th Char			269
DM13270				12th Char	11th Char			270
DM13271				14th Char	13th Char			271
DM13272				16th Char	15th Char			272
DM13273				18th Char	17th Char			273
DM13274				20th Char	19th Char			274
DM13275		PanelList[6]	EQ->EAP	2nd Char	1st Char	Panel List [6]	String (10) ASCII	275
DM13276				4th Char	3rd Char			276
DM13277				6th Char	5th Char			277
DM13278				8th Char	7th Char			278
DM13279				10th Char	9th Char			279
DM13280				12th Char	11th Char			280
DM13281				14th Char	13th Char			281
DM13282				16th Char	15th Char			282
DM13283				18th Char	17th Char			283
DM13284				20th Char	19th Char			284
DM13285		PanelList[7]	EQ->EAP	2nd Char	1st Char	Panel List [7]	String (10) ASCII	285
DM13286				4th Char	3rd Char			286
DM13287				6th Char	5th Char			287
DM13288				8th Char	7th Char			288
DM13289				10th Char	9th Char			289
DM13290				12th Char	11th Char			290
DM13291				14th Char	13th Char			291
DM13292				16th Char	15th Char			292
DM13293				18th Char	17th Char			293
DM13294				20th Char	19th Char			294
DM13295		PanelList[8]	EQ->EAP	2nd Char	1st Char	Panel List [8]	String (10) ASCII	295
DM13296				4th Char	3rd Char			296
DM13297				6th Char	5th Char			297
DM13298				8th Char	7th Char			298
DM13299				10th Char	9th Char			299
DM13300				12th Char	11th Char			300
DM13301				14th Char	13th Char			301
DM13302				16th Char	15th Char			302
DM13303				18th Char	17th Char			303
DM13304				20th Char	19th Char			304
DM13305		PanelList[9]	EQ->EAP	2nd Char	1st Char	Panel List [9]	String (10) ASCII	305
DM13306				4th Char	3rd Char			306
DM13307				6th Char	5th Char			307
DM13308				8th Char	7th Char			308
DM13309				10th Char	9th Char			309
DM13310				12th Char	11th Char			310
DM13311				14th Char	13th Char			311
DM13312				16th Char	15th Char			312
DM13313				18th Char	17th Char			313
DM13314				20th Char	19th Char			314
DM13315	Spare							315
DM13316	Spare							316
DM13317	Spare							317
DM13318	Spare							318
DM13319	Spare							319
DM13320	Spare							320
DM13321	Spare							321
DM13322	Spare							322
DM13323	Spare							323
DM13324	Spare							324
DM13325	Spare							325
DM13326	Spare							326
DM13327	Spare							327
DM13328	Spare							328
DM13329	Spare							329
DM13330	Spare							330
DM13331	Spare							331
DM13332	Spare							332
DM13333	Spare							333
DM13334	Spare							334
DM13335	Spare							335
DM13336	Spare							336
DM13337	Spare							337
DM13338	Spare							338
DM13339	Spare							339
DM13340	Spare							340
DM13341	Spare							341
DM13342	Spare							342
DM13343		RtnResult	EAP->EQ	0000 0000	0000 00aa	1 : PASS / 2 :FAIL	INT(1)	343
DM13344		RtnCode	EAP->EQ	0000 0000	hhhh hhhh	PASS : 0 / FAIL : 1~99	INT(2)	344
DM13345	Spare							345
DM13346	Spare							346
DM13347	Spare							347
DM13348	Spare							348
DM13349	Spare							349
[警報上報 : AlarmReport]								
DM13350		Machine	EQ->EAP	2nd Char	1st Char	Machine ID	String (3) ASCII	350
DM13351				4th Char	3rd Char			351
DM13352				6th Char	5th Char			352
DM13353		DATE	EQ->EAP	y(2st Char)	y(1st Char)	yyyyMMddHHmmss	String (7) ASCII	353
DM13354				y(4st Char)	y(3st Char)			354
DM13355				M(2st Char)	M(1st Char)			355
DM13356				d(2st Char)	d(1st Char)			356
DM13357				H(2st Char)	H(1st Char)			357
DM13358				m(2st Char)	m(1st Char)			358
DM13359				s(2st Char)	s(1st Char)			359
DM13360		AlarmStatus	EQ->EAP	0000 0000	0000 00ba	1 : S / 2 : E	INT(1)	360
DM13361		AlarmType	EQ->EAP	0000 0000	0000 00ba	1 : Alarm / 2 :Warning	INT(1)	361
DM13362		AlarmCode	EQ->EAP	2nd Char	1st Char	Alarm Code	String (2) ASCII	362
DM13363				4th Char	3rd Char			363
DM13364	Spare							364
DM13365	Spare							365
DM13366	Spare							366
DM13367	Spare							367
DM13368	Spare							368
DM13369	Spare							369
DM13370	Spare							370
DM13371		RtnResult	EAP->EQ	0000 0000	0000 00aa	1 : PASS / 2 :FAIL	INT(1)	371
DM13372		RtnCode	EAP->EQ	0000 0000	hhhh hhhh	PASS : 0 / FAIL : 1~99	INT(2)	372
DM13373				4th	3rd			373
DM13374				6th	5th			374
DM13375				8th	7th			375
DM13376	Spare							376
DM13377	Spare							377
DM13378	Spare							378
DM13379	Spare							379
[狀態變更 : StatusChange]								
DM13380		Machine	EQ->EAP	2nd Char	1st Char	Machine ID	String (3) ASCII	380
DM13381				4th Char	3rd Char			381
DM13382				6th Char	5th Char			382
DM13383		DATE	EQ->EAP	y(2st Char)	y(1st Char)	yyyyMMddHHmmss	String (7) ASCII	383
DM13384				y(4st Char)	y(3st Char)			384
DM13385				M(2st Char)	M(1st Char)			385
DM13386				d(2st Char)	d(1st Char)			386
DM13387				H(2st Char)	H(1st Char)			387
DM13388				m(2st Char)	m(1st Char)			388
DM13389				s(2st Char)	s(1st Char)			389
DM13390		OldStatus	EQ->EAP	0000 0000	0000 dcba	Old Status	INT(1) 0~10	390
DM13391		NewStatus	EQ->EAP	0000 0000	0000 dcba	New Status	INT(1) 0~10	391
DM13392	Spare							392
DM13393	Spare							393
DM13394	Spare							394
DM13395		RtnResult	EAP->EQ	0000 0000	0000 00aa	1 : PASS / 2 :FAIL	INT(1)	395
DM13396		RtnCode	EAP->EQ	0000 0000	hhhh hhhh	PASS : 0 / FAIL : 1~99	INT(2)	396
DM13397				4th	3rd			397
DM13398				6th	5th			398
DM13399				8th	7th			399
[載板出料 : Panel Out]								
DM13400		Machine	EQ->EAP	2nd Char	1st Char	Machine ID	String (3) ASCII	400
DM13401				4th Char	3rd Char			401
DM13402				6th Char	5th Char			402
DM13403				y(2st Char)	y(1st Char)			403
DM13404				y(4st Char)	y(3st Char)			404
DM13405				M(2st Char)	M(1st Char)			405

SUBJECT	Equipment Data Mapping
	Doc. No. : CIM Equipment spec.

PLC Start Adress DM13000

PLC Address	Name Designation	Permission	Format(F->0)				Description	Annotation	
DM13406	DATE	EQ->EAP	d(2st Char)		d(1st Char)		yyyyMMddHHmmss	String (7) ASCII	406
DM13407			H(2st Char)		H(1st Char)				407
DM13408			m(2st Char)		m(1st Char)				408
DM13409			s(2st Char)		s(1st Char)				409
DM13410	CassetteID	EQ->EAP	2nd Char		1st Char		Cassette ID	String (10) ASCII	410
DM13411			4th Char		3rd Char				411
DM13412			6th Char		5th Char				412
DM13413			8th Char		7th Char				413
DM13414			10th Char		9th Char				414
DM13415			12th Char		11th Char				415
DM13416			14th Char		13th Char				416
DM13417			16th Char		15th Char				417
DM13418			18th Char		17th Char				418
DM13419			20th Char		19th Char				419
DM13420	PanelID	EQ->EAP	2nd Char		1st Char		Panel ID	String (10) ASCII	420
DM13421			4th Char		3rd Char				421
DM13422			6th Char		5th Char				422
DM13423			8th Char		7th Char				423
DM13424			10th Char		9th Char				424
DM13425			12th Char		11th Char				425
DM13426			14th Char		13th Char				426
DM13427			16th Char		15th Char				427
DM13428			18th Char		17th Char				428
DM13429			20th Char		19th Char				429
DM13430	SlotNo	EQ->EAP	uuuu	uuuu	uuuu	uuuu	Slot Number(Calculations begin at the bottom)	UINT(1) 1~65535	430
DM13431	Result	EQ->EAP	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	431
DM13432	Spare								432
DM13433	Spare								433
DM13434	Spare								434
DM13435	RtnResult	EAP->EQ	0000	0000	0000	00aa	1 : PASS / 2 :FAIL	INT(1)	435
DM13436	RtnCode	EAP->EQ	0000	0000	hhhh	hhhh	PASS : 0 / FAIL : 1~99	INT(2)	436
DM13437	Spare								437
DM13438	Spare								438
DM13439	Spare								439