


Android Things



Android Things







Android Things SoMs













NXP i.MX7D

GPIO

PWM

I2C

UART

SPI



Wi-Fi

Bluetooth


USB

Ethernet


GPIO - General Purpose I/O



PWM - Pulse Width Modulation



I2C - Inter Integrated Circuit



Software

```
dependencies {
    ...
    compileOnly 'com.google.android.things:androidthings:+'
}
```


Software

```
<application>
    <uses-library android:name="com.google.android.things"/>
    <activity android:name=".HomeActivity">
        <!-- Launch activity as default from Android Studio -->
        <intent-filter>
            <action android:name="android.intent.action.MAIN"/>
            <category android:name="android.intent.category.LAUNCHER"/>
        </intent-filter>
       <!-- Launch activity automatically on boot, and re-launch if the app terminates.-->
        <intent-filter>
            <action android:name="android.intent.action.MAIN"/>
            <category android:name="android.intent.category.HOME"/>
            <category android:name="android.intent.category.DEFAULT"/>
        </intent-filter>
    </activity>
</application>
```

Software

```
<uses-permission android:name="com.google.android.things.permission.USE_PERIPHERAL_IO" />
```

Android Things Console





s.eman.cz/at

