



www.preet.co

SPARE PARTS CATALOGUE



PREET 987



PREET 7049

SELF PROPELLED COMBINE HARVESTER

FOREWORD

Preet combine harvesters are indigenously designed and developed machines based on local prevailing conditions in farming. Simple to understand and easy to operate, make Preet combine harvesters Owner's friendly. Timely availability of spare parts plays major role in trouble free operation and routine maintenance. To facilitate the requisition of spare parts, the parts catalogue is prepared mentioning **Part No., Description, Location of parts and Quantity required.** This part catalogue has been prepared to help the customer in ordering parts & also give an idea of assembly sequence through exploded views in the respective layouts.

Though extra care has been taken to prepare this catalogue yet any inconvenience caused on account of any mistake left over is regretted. We hope all the users of this catalogue will find it useful & your suggestion for improving this catalogue shall be most welcome.

Use only genuine spare parts available from the Company or any of the authorized dealers for better performance of your Harvester Combine.

to:

For more information, please write

PREET AGRO INDUSTRIES PVT. LTD.

Patiala Road, NABHA-147201 (INDIA)

EDITION 2025



PREET AGRO IND. PVT. LTD.

PREET 987

Plate No.	Contents	Page No.
1	Cutter Bar Frame	1-2
2	Cutter Bar Main Drive	3-4
3	Feeder Conveyor	5-7
4	Reel Assembly	8-9
5	Reel Support Assembly	10-11
6	Conveyor Worm	12-15
7	Knife Drive	16-17
8	Feeder Lift	18-19
9	Feeder Casing	20-21
10	Trailer ASSY.	22-23
11	Cutter Clutch ASSY.	24-25
12	Chassi ASSY.	26 - 29
13	Safety Frame	30 - 31
14	Stone Trap ASSY.	32 - 33
15	Thresher Drum Wheat	34 - 35
16	Thresher Drum Paddy	36 - 37
17	Thresher Clutch	38 - 39
18	Concave Wheat	40 - 41
19	Concave Paddy	42 - 43
20	Concave Lever ASSY.	44 - 45
21	Guide Drum ASSY.	46 - 47
22	Variator Control	48 - 49

Cutter bar Assy

Thresher Mechanism



Plate No.	Contents	Page No.
23	Blower	50 - 51
24	Blower Drive	52 - 53
25	Strew Baffle	54 - 55
26	Step Bed	56 - 57
27	Cleaner Sieve	58 - 59
28	Sieve Casing ASSY.	60 - 61
29	Sieve Casing Drive	62 - 63
30	Straw Walker ASSY.	64 - 65
31	Auger Body	66 - 67
32	Grain Elevator	68 - 69B
33	Top Grain Auger	70 - 71
34	Tailing Elevator	72 - 73
35	Top Ear Auger	74 - 75
36	Grain Tank	76 - 78
37	Grain Discharge Auger	79 - 80B
38	Grain Discharge Tube	81 - 82
39	Grain Discharge Clutch	83 - 84
40	Discharge Tube Lock	85 - 85A
41	Platform And Ladder ASSY.	86 - 87
42	Fan ASSY. And Mounting	88 - 89
43	Railing & Suntop	90 - 91
44	Engine Railing	92 - 93

Grain Separation

Driver Platform



PREET AGRO IND. PVT. LTD.

PREET 987

Plate NO.	Contents	Page No.	
45	Driver Seat	94 - 95	Driver Plateform
46	Clutch Pedal ASSY	96 - 97	
47	Oil Break Pedal ASSY.	98 - 99	
48	Light	100-101	
49	Instruments & Switches (PREET)	102-103	
49A	Instruments & Switches	103A-103B	
50	Electrical Hardness	104-105	
51	Gear Shifter ASSY.	106-107	
52	Gear Shifter ASSY.(4 Speed)	108-109	
53	Engine & Mounting	110 - 112	
54	Engine & Mounting (PREET)	113 - 115	Engine Mounting
55	Air Intake Mounting	116 - 117	
56	Exhaust Support	118 - 119	
57	Exhaust System (PREET)	120 - 121	
58	Radiator & Mounting	122 - 123	
59	Fuel Tank	124 - 125	
60	Fuel Tank (PREET)	126 - 127	
61	Rotary Sieve MTG.	128 - 129B	
62	Rotary Sieve Drive	130 - 131	
63	Urea Tank	132 - 133	
64	Shields	134 - 135	Shields
65	Engine Side Cover With Rotary	136-137	



PREET AGRO IND. PVT. LTD.

PREET 987

Plate No.	Contents	Page NO.	
66	Tail Cover	138-139	Shields
67	Straw Walker Cover	140-141	
67-A	SMS Transmission ASSY.	142-143	Sms
68	Steering System	144-145	
69	Hydraulic Line - Steering	146-147	Hydraulics
70	Hydraulic Line-Reel & Feeder	148-149	
71	Hydraulic System- Variator Pulley	150-151	
72	Hydraulic Line- Return	152-153	
73	Hyd.. Pump & Related Components	154-155	
74	Variator Pulley Hi-Low	156-157	
75	Variator Pulley Mtg.	158-159	
76	Clutch ASSY.	160-162	
77	Clutch ASSY. (4 Speed)	163-164	
78	Steering Axle	165-166	
79	Gear Box (4-Speed)	167-168	
80	Gear Drive Assy.	169-170	
81	Gear Drive Assembly (4 - Speed)	171-172	
82	Differential Assy Wet Brake	173-174	
83	Differential Assy (4-Speed)	175-176	
84	Wet Brake	177-178	
85	Reduction Unit	179-180	
86	Reduction Unit (4 - Speed)	181-182	




PREET AGRO IND. PVT. LTD.

PREET 987

CUTTER BAR FRAME

PLATE NO. 001






PREET AGRO IND. PVT. LTD.
CUTTER BAR FRAME

Item No.	Part No.	Part Name	Qty.
1	B0101020100	Cutter Bar Frame (With 18" Auger)	1
2	M36032	Flange Head Screw M8x16	6
3	B0101020003	Spacer Ø16xØ11x16	2
4	K01010008	Deflector LH	1
5	M05006	Plain Washer M8	6
6	M28005	Nylock Nut M8	6
7	M28005	Nylock Nut M8	8
8	M05005	Plain Washer M6	8
9	M36018	Flange Head Screw M6x16	8
10	B01011700	Belt Guard Assy.	1
11	M03050	Hex. Screw M10x35	4
12	M05007	Plain Washer M10	8
13	M01004	Hex. Nut M10	4
14	B01010013	Crop Divider RH	1
15	B01010012	Crop Divider LH	1
16	M28005	Nylock Nut M8	4
17	M05006	Plain Washer M8	4
18	K01010006	Side Cover LH	1
19	M36033	Flange Head Screw M8x20	4
20	M03054	Hex. Screw M10x55	2
21	B01010002	Pressure Plate	5
22	M01004	Hex. Nut M10	2
23	A01010204	Nylon Bush	1
24	M03047	Hex. Screw M10x20	5
25	B01020100	Holder Assy	1
26	B01010200	Blade Assy.	1
27	B01011300	Knife Assy with Holder	1
28	M28002	Nylock Nut M10	1
29	M04008	Spring Washer M10	1
30	M02033	Hex. Bolt M10x65	1
31	M03049	Hex. Screw M10x30	16
32	M04008	Spring Washer M10	16
33	M05007	Plain Washer M10	16

SPARE PARTS LIST			
PREET 987D			
PLATE NO. 001			
Item No.	Part No.	Part Name	Qty.
34	B01010001	Mounting Angle	1
35	M03050	Hex. Screw M10x35	48
36	M02029	Hex. Bolt M10x45	8
37	M05007	Plain Washer M10	16
38	B01010004	Knife Guard	29
39	M04008	Spring Washer M10	58
40	M01004	Hex. Nut M10	58
41	K01010005	Side Cover RH	1
42	B01010027	Blade Cover RH Front	1
43	K01010007	Deflector RH	1
44	B01010014	Cover Middle	1
45	M36033	Flange Head Screw M8x20	4
46	M05006	Plain Washer M8	4
47	M01003	Hex. Nut M8	4
48	M01003	Hex. Nut M8	2
49	M05006	Plain Washer M8	4
50	M03034	Hex. Head Screw M8x25	2
51	M05007	Plain Washer M10	2
52	B0101020001	Feeder Pin Locking Plate	2
53	M01004	Hex. Nut M10	8
54	M05007	Plain Washer M10	8
55	M28005	Nylock Nut M8	8
56	M41002	Carriage Screw M10x35	8
57	M03050	Hex. Head Screw M10x35	1
58	M05007	Plain Washer M10	2
59	M04008	Spring Washer M10	1
60	M01004	Hex. Nut M10	1
61	B03140202	Hinge 4"	2
62	B0101020002	Side Cover	1
63	M03049	Hex. Head Screw M10x30	1
64	M05007	Plain Washer M10	1
65	M36033	Flange Head Screw M8x20	8
66	M05006	Plain Washer M8	8

CUTTER BAR MAIN DRIVE

PLATE NO. 002





PREET AGRO IND. PVT. LTD.
CUTTER BAR MAIN DRIVE


SPARE PARTS LIST
PREET 987D
PLATE NO. 002

Item No.	Part No.	Part Name	Qty.
1	M05012	Plain Washer M24	1
2	M22005	Bearing UC-205	1
3	M35007	Bearing Housing UCF-205	1
4	M03049	Hex Head Screw M10x30	8
5	M05007	Plain Washer M10	8
6	M28002	Nylock Nut M10	8
7	M30007	Castle Nut M28x1.5	2
8	M05014	Plain Washer M-30	1
9	M03034	Hex Head Screw M8x25	1
10	M01003	Hex Nut M8	1
11	B01020007	Upper V Belt Pulley	1
12	M44006	Split Pin 5/32"x1.5"	1
13	B01020009	Reel Shaft	1
14	M13004	Parallel Key 8x7x50	1
15	B03080010	Spacer (Ø30xØ40x35)	2
16	B03080022	Spacer (Ø30xØ40x10)	1
17	M35004	Bearing Housing UCF 206	1
18	M22004	Bearing UC 206	1
19	M03034	Hex Head Screw M8x25	1
20	M01003	Hex Nut M8	2
21	B03020009	Counter Sprocket Z-14	1
22	M14001	Gib Head Key 8x7x36	1
23	B01021902	Pulley Coupling 45mm	2
24	M03054	Hex Head Screw M10x55	8
25	B01021900	Pulley Assy 8"x2C with Coupling 45mm	1
26	B01021901	Pulley 8"x2C Coupling Type	1
27	M39166	V-Belt C-124	2
28	M29008	Grease Nipple M6x1	2
29	M22002	Bearing UC 209	3
30	M35002	Bearing Housing UCF 209	3
31	M28003	Nylock Nut M12	4
32	M05008	Plain Washer M12	4
33	M02043	Hex. Head Bolt M12x55	4

Item No.	Part No.	Part Name	Qty.
34	B01020001	Cutter Drive Shaft	1
35	M13027	Parallel Key 10x8x50	3
36	M40002	Grub Screw M8x20	1
37	B01070017	Round Block	1
38	M03048	Hex Head Screw M10x25	3
39	M01004	Hex Nut M10	3
40	B01020003	Back Plate	1
41	B01020004	Coiled Spring	1
42	M39011	V-Belt C-37	1
43	M03049	Hex Head Screw M10x30	1
44	M01004	Hex Nut M10	1
45	B01020005	Lower V belt Pulley	1
46	B01020006	Spacer (Ø45xØ60x40)	1
47	M01006	Hex Nut M14	4
48	M04015	Spring Washer M14	4
49	M03200	Hex Head Screw M14x45	4
50	M40017	Grub Screw M10x10	2
51	M01004	Hex. Nut M10	2
52	B01020025	Sprocket Z-15	1
53	M03033	Hex Head Screw M8x20	1
54	B01022000	Pulley 10" x 1C With Coupling 45mm	1
55	B01022001	Pulley 10" x 1C Coupling Type Cutter Drive	1
56	B03080021	Spacer (Ø30xØ40x6)	1
57	B0107020001	Idle Pulley Tightning Lever	1
58	M05009	Plain Washer M16	1
59	M15012	Ball Bearing 6206 Z	2
60	B01070004	Idle Pulley 8"	1
61	B01070006	Idler Bush Ø40xØ16x83	1
62	B0107020002	Idle Pulley Tightning Bkt.	1

FEEDER CONVEYOR

PLATE NO. 003






PREET AGRO IND. PVT. LTD.
FEEDER CONVEYOR

SPARE PARTS LIST
PREET 987
PLATE NO. 003

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M22001	Bearing UC208	2	23	B0108020001	Spacer (Ø48xØ40x58)	1
2	B01080503	Bearing Housing 208	2	24	B0108020003	Special Washer (Ø50xØ35.5x6)	1
3	M40010	Grub Screw M8x8	8	25	M05006	Plain Washer M8	12
4	B01080505	Sprocket Z11x45	4	26	B01080030	Feeder Pulley 9"	1
5	B01080501	Holding Bracket - RH	1	27	B01080008	V-Belt Pulley	1
6	B01080506	Feeder Shaft (208 BRG)	1	28	M02023	Hex Bolt M8x75	6
7	M14124	Gib Head Key 12x8x63	4	29	B01080508	Coupling Big	1
8	M14374	Gib Head Key 10x8x75	1	30	B01080504	Holder	2
9	M31130	Split Pin 5x50	5	31	M05008	Plain Washer M12	12
10	B01080511	Supporting Plate	2	32	M04009	Spring Washer M12	12
11	B01080005	Strip	2	33	M03065	Hex Head Screw M12x40	12
12	B0108020004	Cover - Feeded Shaft	3	34	M22004	Bearing UC206	2
13	B01080513	Link Pin	2	35	M35004	Bearing Housing UCF 206	2
14	M27002	Linch Pin 8x42	2	36	B01070014	Rubber Bush - Chain Support	4
15	M02184	Hex Head Bolt M16x100	8	37	M26020	Hose Clamp 100	4
16	M05009	Plain Washer M16	8	38	B01070700	Chain Support Pipe Assy.	1
17	B01080502	Holding Bracket - LH	1	39	M28002	Nylock Nut M10	8
18	M04010	Spring Washer M16	8	40	M04008	Spring Washer M10	8
19	M01008	Hex Nut M16	8	41	M03050	Hex Head Screw M10x35	8
20	M04008	Spring Washer M10	6	42	B01080014	Rocker Arm Shaft	1
21	M03049	Hex Head Screw M10x30	6	43	M05012	Plain Washer M25	8
22	B01080013	Shaft Nut M24x1.5	1	44	B01080019	Supporting Bracket	2

FEEDER CONVEYOR

PLATE NO. 003






PREET AGRO IND. PVT. LTD.

FEEDER CONVEYOR

Item No.	Part No.	Part Name	Qty.
45	M28002	Nylock Nut M10	8
46	M04008	Spring Washer M10	8
47	M05007	Plain Washer M10	8
48	B01080018	Rocker Arm	2
49	M35004	Bearing Housing UCF 206	2
50	M02028	Hex Head Bolt M10x40	8
51	M22004	Bearing UC206	2
52	M14006	Gib Head Key 8x7x63	2
53	B0108020005	Sprocket Mtg. Shaft	1
54	B01080020	Sprocket Z-10	4
55	M01004	Hex Nut M10	8
56	M03049	Hex Head Screw M10x30	8
57	M39013	V Belt - C136	1
58	M01003	Hex. Nut M8	2
59	M05006	Plain Washer M8	4
60	M03033	Hex. Head Screw M8x20	2
61	B01100011	Belt Rest	1
62	M99002	Grease Pipe - 15" (M6)	1
63	M28005	Nylock Nut M8	6
64	M02027	Hex. Bolt M10x35	8
65	M01004	Hex. Nut M10	8
66	M29003	Grease Nipple M6 - 90°	1
67	B01080400	Guard Disc	2

REEL ASSY.

PLATE NO. 004






PREET AGRO IND. PVT. LTD.
REEL ASSY.

Item No.	Part No.	Part Name	Qty.
1	B0105040104	Eccentric Guide	1
2	M14001	Gib Head Key 8x7x36	1
3	M39161	V-Belt C160	1
4	M03047	Hex Head Screw M10x20	4
5	M04008	Spring Washer M10	4
6	B01050005	Reel Pulley	1
7	M01003	Hex Nut M8	90
8	M04007	Spring Washer M8	90
9	M03047	Hex Head Screw M10x20	1
10	M01004	Hex. Nut M10	2
11	B01050006	Pulley Holder	1
12	M03048	Hex Head Screw M10x25	1
13	M11028	Internal Circlip B47	2
14	M40002	Grub Screw M8x20	1
15	M02241	Hex. Bolt M10x105	2
16	M05007	Plain Washer M10	4
17	M28002	Nylock Nut M10	2
18	M04008	Spring Washer M10	2
19	B01050600	Supporting Bracket	1
20	B01050002	Reel Bush	2
21	B01050009	Bush (Ø62xØ35x18)	1
22	M02047	Hex Head Bolt M12x75	2
23	M05008	Plain Washer M12	6
24	A01051001	Idler - Reel	2
25	B01030021	Idler Bush - 6204 Brg	2
26	B0105040200	Reel Pipe	1
27	M16008	Ball Bearing 6204 ZZ	2
28	M01005	Hex Nut M12	2
29	M02241	Hex. Head Bolt M10x105	2

Item No.	Part No.	Part Name	Qty.
30	M05007	Plain Washer M10	4
31	M04008	Spring Washer M10	2
32	M28002	Nylock Nut M10	2
33	B01050003	Side Support	1
34	M28002	Nylock Nut M10	12
35	M03048	Hex Head Screw M10x25	12
36	M53001	Flange Head Bolt M8x45	90
37	B0105030603	Spring Tine	90
38	B0105040300	Reel Tube Assy	6
39	M44013	Split Pin 5/32"x2"	48
40	M05013	Plain Washer M28	66
41	B0105030604	Pipe Holding Bush	30
42	B0105040105	Reel Spoke	30
43	B0105040103	Reel Frame	4
44	B0105040101	Spoke Connecting Strip	18
45	B0105040102	T Shape Spoke Connecting Plate	18
46	M03033	Hex. Head Screw M8x20	36
47	M28005	Nylock Nut M8	36
48	M36032	Flange Hex Screw M8x16	90
49	M05006	Plain Washer M8	90
50	M28005	Nylock Nut M8	90
51	M36035	Flange Hex Screw M8x30	60
52	M05006	Plain Washer M8	60
53	M28005	Nylock Nut M8	60

REEL SUPPORT ASSY.

PLATE NO. 005






PREET AGRO IND. PVT. LTD.
REEL SUPPORT ASSY.

SPARE PARTS LIST
PREET 987D
PLATE NO. 005

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B01040100	Reel Support	1	33	M05006	Plain Washer M8	10
2	M44005	Split pin 5/32"x1.0"	2	34	B01040016	Side Cover Holding Bkt. Rear	1
3	M05009	Plain Washer M16	4	35	M05006	Plain Washer M8	1
4	B01040003	Reel Jack Pin	2	36	M28005	Nylock Nut M8	1
5	B01040002	Hydraulic Jack	2	37	B01040017	Side Cover Holding Bkt. Middle	1
6	M27002	Linch Pin 8x42	2	38	B0104010002	Hinge plate	1
7	A01070012	Link Pin	2	39	M02021	Hex. Head Bolt M8x65	1
8	M03050	Hex. Screw M10x35	4	40	B0104010001	Side Cover	1
9	M05007	Plain washer M10	8	41	M03034	Hex. Head Screw M8x25	5
10	M01004	Hex. Nut M10	4	42	M28005	Nylock Nut M8	1
11	K01040200	Mechanical Jack Housing	2	43	M05006	Plain Washer M8	2
12	B01040004	Hex. Nut 1-1/2	2	44	M02021	Hex. Head Bolt M8x65	1
13	B01040200	Mechanical Jack	2	45	M03063	Hex. Head Screw M12x30	1
14	M28009	Nylock Nut M16	2	46	B01040018	Side Cover Holding Bkt. Front	1
15	M02149	Hex. Bolt M10x110	4	47	A01040100	Idle Pulley Assy 5"	2
16	M05007	Plain Washer M10	8	48	M02045	Hex. Head Bolt M12x65	2
17	B01040001	Clamp-Reel Support	4	49	M05008	Plain Washer M12	2
18	M01004	Hex. Nut M10	4	50	M11028	Internal Circlip B47	2
19	B01020012	Chain-Reel Drive	1	51	M16040	Ball Bearing 6204ZZ	2
20	M03048	Hex. Screw M10x25	4	52	A01040012	Idle Pulley 5"	2
21	M04008	Spring Washer M10	4	53	B01030021	Idle Bush-Z15 (\varnothing 28x \varnothing 12x38)	2
22	B01020010	Bearing Support	1	54	B01040005	Idler Holding Bracket 5"	1
23	B01020020	Sprocket Z-52	1	55	M28003	Nylock Nut M12	2
24	M16063	Ball Bearing 6205Z	2	56	M44005	Split pin 5/32"x1.0"	1
25	A01050013	V-Belt Pulley 7"	1	57	M05009	Plain Washer M16	4
26	A03030012	Bush (\varnothing 25x \varnothing 40x30)	1	58	M44006	Split pin 5/32"x1.5"	1
27	M03033	Hex. Head Screw M8x20	2	59	B01040007	Threaded Rod	1
28	M01003	Hex. Nut M8	2	60	M01008	Hex. Nut M16	2
29	M03050	Hex. Screw M10x35	2	61	M05006	Plain Washer M8	1
30	M01004	Hex. Nut M10	2	62	M28005	Nylock Nut M8	1
31	M36033	Flange Screw M8x20	1	63	M05012	Plain Washer M25	1
32	M01003	Hex. Nut M8	5	64	M28003	Nylock Nut M12	1

CONVEYOR WORM

PLATE NO. 006





PREET AGRO IND. PVT. LTD.
CONVEYOR WORM


SPARE PARTS LIST
PREET 987D
PLATE NO. 006

Item No.	Part No.	Part Name	Qty.
1	B0103010500	Conveyor Worm 18"	1
2	M36032	Flange Head Screw M8x16	10
3	B01030023	Cover Long	1
4	M36033	Flange Screw M8x20	36
5	A01030004	Prong Bush	18
6	M28005	Nylock Nut M8	36
7	M03033	Hex. Head Screw M8x20	2
8	B01030005	Cover - Conv Worm Small Window	1
9	M30007	Castle Nut M28x1.5	3
10	M22004	UC Bearing 206	2
11	M28002	Nylock Nut M10	8
12	M04008	Spring Washer M-10	8
13	M22004	Bearing Housing UCF 206	2
14	B0103010503	Worm Disc - 01 (18" Auger)	1
15	M03034	Hex. Screw M8x25	20
16	M05006	Plain Washer M8	20
17	M28005	Nylock Nut M8	20
18	B0103010600	Worm Disc Assy. (18" Assy.)	1
19	M44013	Split Pin 5/32"x2"	2
20	M13003	Parallel Key 8x7x100	1
21	B01030006	Front Auger Drive Shaft	1

Item No.	Part No.	Part Name	Qty.
22	M13006	Parallel Key 8x7x30	1
23	M02027	Hex. Bolt M10	4
24	M41002	Carriage Screw M10x35	2
25	B01030020	Adjusting Plate LH	1
26	B01030019	Sprocket Z-40	1
27	B01030008	Supporting Bracket	1
28	B01030009	Slip Clutch (Set)	1
29	B01030010	Holding Bracket	1
30	B01030011	Coiled Spring - Front Auger	1
31	B01030012	Cup Washer	1
32	M05014	Plain washer M30	1
33	B01030400	Chain - Auger Drive	1
34	M03034	Hex. Head Screw M8x25	6
35	M28005	Nylock Nut M8	6
36	M28003	Nylock Nut M12	1
37	M05008	Plain washer M12	2
38	M11028	Internal Circlip B47	1
39	M16040	Ball Bearing 6204 ZZ	1
40	B03020008	Idler Sprocket Z15	1
41	B01030021	Idler Bush - Brg 6204	1
42	M02043	Hex. Head Bolt M12x55	1

CONVEYOR WORM

PLATE NO. 006





PREET AGRO IND. PVT. LTD.
CONVEYOR WORM


SPARE PARTS LIST
PREET 987D
PLATE NO. 006

Item No.	Part No.	Part Name	Qty.
43	M14001	Gib Head Key 8x7x36	1
44	B01030013	Supporting Shaft - I	1
45	B0103010503	Worm Disc-1 (18" Auger)	2
46	M35004	Bearing Housing UCF 206	2
47	M04008	Spring Washer M-10	8
48	M28002	Nylock Nut M10	8
49	M22004	UC Bearing 206	2
50	M02033	Hex. Bolt M10x65	8
51	B01030014	Prong Shaft Holder (Set)	2
52	B01030015	Prong Shaft	1
53	B01030026	Prong 11.5" with Nut	18
54	M01009	Hex. Nut M16x1.5	18
55	B01030016	Prong Holder	18
56	B01030018	Supporting Shaft - II	1
57	M04008	Spring Washer M10	8
58	M28002	Nylock Nut M10	8
59	M41002	Carriage Screw M10x35	2
60	B01030003	Adjusting Plate RH	1

Item No.	Part No.	Part Name	Qty.
61	M05007	Plain Washer M10	12
62	M01004	Hex. Nut M10	4
63	M03158	Hex. Screw M10x100	2
64	M04008	Spring Washer M10	4
65	M28002	Nylock Nut M10	4
66	M41001	Carriage Screw M10x25	1
67	B01030004	Eccentric Lever	1
68	M05007	Plain Washer M10	1
69	M28002	Nylock Nut M10	1
70	M03047	Hex. Screw M10x20	1
71	M01004	Hex. Nut M10	1
72	M99003	Grease pipe M6x10"	1

KNIFE DRIVE

PLATE NO. 007






PREET AGRO IND. PVT. LTD.
KNIFE DRIVE

SPARE PARTS LIST
PREET 987D
PLATE NO. 007

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B01021100	Knife Drive Assy	1	24	B01080013	Shaft Nut M24 x1.5	1
2	M12037	Seal 130x150x12	1	25	M03067	Hex. Head Screw M12x50	4
3	A01020106	Eccentric Housing	1	26	M05008	Plain Washer M12	4
4	M13005	Parallel Key 8x7x25	1	27	M28003	Nylock Nut M12	4
5	M42001	Needle Bearing 243220	1	28	M39068	V Belt C120	1
6	A01020107	Pinion Gear	1	29	M02047	Hex. Head Bolt M12x75	1
7	M15017	Ball Bearing 5208	1	30	M05008	Plain Washer M12	2
8	M11045	Internal Circlip B80	1	31	B01020023	Idle Bush 1"	1
9	A01020109	Cam-2	1	32	M15011	Ball Bearing 6204	2
10	M102005	Allen Head Bolt M10x90	2	33	A01020004	Idler	1
11	A01020112	Dust Cap	2	34	M11028	Internal Circlip B47	1
12	M42002	Bearing 805233 A	1	35	M29011	Grease Nipple M8	1
13	A01020110	Cam Lock	1	36	M28003	Nylock Nut M12	1
14	M32019	Allen Head Screw M10x20	1				
15	A01020108	Cam 1	1				
16	M32011	Allen Head Screw M8x35	2				
17	M15016	Ball Bearing 6018	1				
18	M32010	Allen Head Screw M8x20	4				
19	A01020104	Internal Gear Z34	1				
20	B01020018	Housing (Knife Drive)	1				
21	M15004	Ball Bearing 6209	1				
22	M10027	External Circlip A45	1				
23	A01020111	Knife Drive Pulley 8"	1				

FEEDER LIFT

PLATE NO. 008






PREET AGRO IND. PVT. LTD.

FEEDER LIFT

FEEDER CASING

PLATE NO. 009






PREET AGRO IND. PVT. LTD.
FEEDER CASING

SPARE PARTS LIST
PREET 987
PLATE NO. 009

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B0107020100	Feeder Casing	1	23	B01070008	Angle Bracket	2
2	M04009	Spring Washer M12	2	24	M05007	Plain Washer M10	4
3	M36032	Flange Head Screw M8x16	6	25	M04008	Spring Washer M10	4
4	B01070001	Concave Strip	1	26	M03048	Hex Head Screw M10x25	4
5	M05007	Plain Washer M10	2	27	B01070013	Feeder Pin	2
6	M03048	Hex Head Screw M10x25	2	28	M02145	Hex Head Bolt M10x85	2
7	M44004	Split Pin 3/32"x3/4"	8	29	A01080019	Chain Lock	4
8	B01070003	Rubber Flap	1	30	M28005	Nylock Nut M8	240
9	M05005	Plain Washer M6	8	31	M05006	Plain Washer M8	240
10	M01002	Hex Nut M6	8	32	B0107010203	Feeder Angle	60
11	M036020	Flange Head Screw M6x25	8	33	M03033	Hex Head Screw M8x20	240
12	B01070018	Feeder Chain Tightener Bolt	2	34	B01071200	Feeder Chain (Set of 04)	1
13	M01008	Hex Nut M16	4	35	B01070015	Feedre Window Cover	1
14	M05009	Plain Washer M16	4	36	M03065	Hex Head Scew M12x40	2
15	B01070020	Rocker Arm Adjusting Bolt	2	37	M05008	Plain Washer M12	2
16	M05008	Plain Washer M12	4	38	M28003	Nylock Nut M12	2
17	M01005	Hex Nut M12	4	39	M03065	Hex Head Scew M12x40	2
18	M05007	Plain Washer M10	8	40	M05008	Plain Washer M12	2
19	M03050	Hex Head Screw M10x35	4	41	M28003	Nylock Nut M12	2
20	B01070007	Adjustable Strip	2				
21	M04008	Spring Washer M10	4				
22	M28002	Nylock Nut M10	4				

TRAILER ASSY.

PLATE NO. 010






PREET AGRO IND. PVT. LTD.
TRAILER ASSY.

				SPARE PARTS LIST			
				PREET 987D			
				PLATE NO. 010			
Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B01060100	Trailer (Wheat & Paddy)	1	28	B01060006	Hub Nut	10
2	M01008	Hex Nut M16	4	29	B01060008	Hub Cap	2
3	M05009	Plain Washer M16	8	30	M30009	Castle Nut M30	2
4	M03094	Hex Head Screw M16x45	4	31	B01060010	Spacer 30x50x8	2
5	M27002	Linch Pin 8x42	2	32	M17008	Taper Roller Bearing 32208	2
6	A01070012	Link Pin	1	33	B01060004	Hub	2
7	B01060007	Pin-Trailer	1	34	B01060600	Hub Assy.	2
8	B01060200	Barrel Assy.	1	35	M17011	Taper Roller Bearing 32210	2
9	M28005	Nylock Nut M8	1	36	M12013	Oil Seal 55x90x10	2
10	B01060002	Hand Lever Weld-Trailer	1	37	M44013	Split Pin 5/32"x2"	2
11	M02017	Hex Head Bolt M8x45	1	38	B01060009	Trailer Axle	2
12	B01060003	Rod-Wheel Holder	1	39	M04010	Spring Washer M16	2
13	B01060300	Wheel Holder Assy.	1	40	M28009	Nylock Nut M16	2
14	B01060013	Combination Light Mtg. Bkt RH	1	41	M05006	Plain Washer M8	1
15	M03033	Hex Head Screw M8x20	6	42	B01060900	Tool Box-Trailer	1
16	M05006	Plain Washer M8	12	43	M36033	Flange Head Screw M8x20	12
17	M01003	Hex Nut M8	6	44	M05006	Plain Washer M8	12
18	M01003	Hex Nut M8	1	45	M01003	Hex Nut M8	1
19	M05006	Plain Washer M8	2	46	J09090001	Hinge	3
20	M03033	Hex Head Screw M8x20	1	47	M36034	Flange Head Screw M8x25	3
21	B01060001	Cover	1	48	M05006	Plain Washer M8	3
22	A01070012	Link Pin	4	49	M36019	Flange Head Screw M6x20	1
23	M27002	Linch Pin 8x42	4	50	M01002	Hex Nut M6	1
24	B01060403	Locking Screw	4	51	M05005	Plain Washer M6	1
25	B01060012	Combination Light Mtg. Bkt LH	1	52	M01003	Hex Nut M8	3
26	M02184	Hex Head Bolt M16x100	2	53	M29001	Grease Nipple M8x1 Type-A	2
27	B01060005	Hub Bolt	10	53	M29001	Grease Nipple M8x1 Type-A	2

CUTTER CLUTCH ASSY.

PLATE NO. 011






PREET AGRO IND. PVT. LTD.

CUTTER CLUTCH ASSY.

Item No.	Part No.	Part Name	Qty.
1	A02040002	Rubber Cover	1
2	B01100100	Cutter Clutch Lever	1
3	M28002	Nylock Nut M10	1
4	M04008	Spring Washer M10	1
5	M02031	Hex Head Bolt M10x55	1
6	M13006	Parallel Key 8x7x30	1
7	M05014	Plain Washer M30 Ø45xØ30.7x2	1
8	B01101200	Lever Shaft Assy	1
9	M44007	Split Pin 7/32" x 2.5"	1
10	M05009	Plain Washer M16 (Ø34xØ16.2x2.8)	1
11	M44005	Split Pin 5/32"x1.5"	3
12	B01100002	Lever Rod	1
13	A01080013	Idler Pulley 8"	1
14	M16009	Ball Bearing 6204 RS	2
15	M11028	Internal Circlip B-47	1
16	B01100009	Taper Collar	1
17	B01100008	Special Washer Ø49xØ20.7x6	1
18	M30005	Castle Nut M20	3
19	M01008	Hex Nut M16	2
20	M05009	Plain Washer M16 Ø34xØ16.2x2.6	2
21	B01100004	Limiting Strip	1
22	B01100005	Belt Rest	1

CHASSIS FRAME

PLATE NO. 013





PREET AGRO IND. PVT. LTD.
CHASSIS FRAME


SPARE PARTS LIST
PREET 987
PLATE NO. 012

Item No.	Part No.	Part Name	Qty.
1	B02010100	Chassis Frame	1
2	B02011400	Cover Plate - Guide Drum	1
3	M01004	Hex Nut M10	13
4	M04008	Spring Washer M10	13
5	M05007	Plain Washer M10	10
6	M03050	Hex Head Screw M10x35	13
7	B02011300	Engine Cover Welded	1
8	M03034	Hex Head Screw M8x25	4
9	M05006	Plain Washer M8	8
10	M01003	Hex Nut M8	4
11	B02012300	Spare Wheel Mtg.	1
12	M03049	Hex Head Screw M10x30	4
12a	M05007	Plain Washer M10	8
12b	M04008	Spring Washer M10	4
12c	M01004	Hex Nut M10	4
13	B02010022	Cover - Battery Frame	1
14	M01027	Hex. Nut M8	2
15	M36032	Flange Head Screw M8 x 16	2
16	B02010021	Cover Plate - Straw Walker Window	2
17	B02010027	Beeding 760 - Cover Plate Straw Walker	2
18	B02010026	Beeding 1490 - Cover Plate Guide Drum	2
19	B02010025	Beeding 1290 -Cover Plate Thresher	2

Item No.	Part No.	Part Name	Qty.
20	M04008	Spring Washer M10	4
21	B02010004	Cover Plate - Thresher Window	2
22	A01060010	Clamp Plate	20
23	B02010400	Rear Support Welded	1
24	M03195	Hex Head Screw M14x35	4
25	M04015	Spring Washer M14	4
26	M01006	Hex Nut M14	4
27	B02012800	Battery Frame Welded	1
28	M28002	Nylock Nut M10	2
29	M05007	Plain Washer M10	4
30	M03051	Hex Head Screw M10x40	2
31	B02010006	Supporting Strip 1	2
32	B02010300	Battery Frame Support	1
33	M03051	Hex Head Screw M10x40	4
34	M05007	Plain Washer M10	8
35	M28002	Nylock Nut M10	4
36	M03050	Hex Head Screw M10x35	2
37	M05007	Plain Washer M10	2
38	M04008	Spring Washer M10	2
39	M01004	Hex Nut M10	2
40	B02010005	Cover Plate - Guide Drum Window	2
41	M49001	Wing Nut M8	20

CHASSIS FRAME

PLATE NO. 012






PREET AGRO IND. PVT. LTD.
CHASSIS FRAME

SPARE PARTS LIST
PREET 987
PLATE NO. 012

Item No.	Part No.	Part Name	Qty.
42	A07030018	Hose Pipe 24" - (M18x1.5 - M18x1.5)	2
43	A02011003	Adaptor - (M22x1.5 - M18x1.5)	2
44	P6M013400100	Adaptor - (M18x1.5 - M16x1.5)	2
45	B07020016	Hose Pipe 36" (M18x1.5 - M18x1.5)	1
46	B02012500	Air Cylinder Welded	1
47	M01004	Hex Nut M10	4
48	M04008	Spring Washer M10	4
49	B02011500	Air Release Valve	1
50	M05007	Plain Washer M10	4
51	M03049	Hex Head Screw M10x30	4
52	B02010023	Air Pipe - Air Tank To Urea Tank	1

SAFETY FRAME

PLATE NO. 013






PREET AGRO IND. PVT. LTD.

SAFETY FRAME

Item No.	Part No.	Part Name	Qty.
1	B02011800	Safety Frame Mtg. Rear RH Welded	1
2	B02011604	Angle Taper RH	1
3	M28002	Nylock Nut M10	35
4	B02011900	Safety Frame Mtg. Middle RH Welded	1
5	B02012000	Safety Frame Mtg. Front RH Welded	1
6	M05007	Plain Washer M10	70
7	M04008	Spring Washer M10	35
8	M02033	Hex Head Bolt M10x65	4
9	B02011606	Angle Cross	3
10	B02011605	Angle Diagonal	4
11	B02011602	Angle Horizontal RH	1
12	M03048	Hex Head Screw M10x25	16
13	B02011601	Angle Horizontal LH	1
14	B02012100	Safety Frame Mtg. Rear LH Welded	1
15	B02011603	Angle Taper LH	1
16	B02011700	Safety Frame Mtg. Front LH Welded	1
17	M02029	Hex Head Bolt M10x45	2
18	M03050	Hex Head Screw M10x35	10
19	B0PN033006	Pin Ø14x90	2
20	B02012400	Safety Frame Mtg. Middle LH Welded	1
21	B02012900	Safety Frame Leg Welded Length - 525	2
22	M27002	Linch Pin 8x42	2

STONE TRAP ASSY

PLATE NO. 014





PREET AGRO IND. PVT. LTD.

STONE TRAP ASSY


SPARE PARTS LIST

PREET 987

PLATE NO. 014

THRESHER DRUM (WHEAT)

PLATE NO. 015





PREET AGRO IND. PVT. LTD.
THRESHER DRUM (WHEAT)

SPARE PARTS LIST

PREET 987


PLATE NO. 015

Item No.	Part No.	Part Name	Qty.
1	B02030400	Thresher RPM Cable Assy.	1
2	M03018	Hex Head Screw M6x16	2
3	M10023	External Circlip A36	3
4	B03020017	Strap	1
5	M05006	Plain Washer M8	4
6	M03034	Hex Head Screw M8x25	2
7	M01003	Hex Nut M8	2
8	B02030009	RPM Bracket	1
9	M10019	External Circlip A30	1
10	M16003	Ball Bearing 6006 ZZ	1
11	B02030501	Bearing Pin	1
12	M10053	External Circlip A120	2
13	B02030604	Thresher Spring Cap Pulley	1
14	B02030004	Coiled Spring	1
15	B02030700	Thresher Drum Wheat Welded	1
16	B02030304	Driver Pin	3
17	B02030302	Thresher Outer Disc	1
18	M29006	Grease Nipple- 45°- M8x1	1
19	B02030306	Guide Bush	1
20	B02030301	Thresher Inner Disc	1
21	M11060	Internal Circlip B-120	2
22	B02030016	Bearing Dust Cap	2
23	B02030015	Felt Seal	2
24	M15009	Ball Bearing 6311	4
25	B02030013	Spacer 5mm	2
26	B02030012	Bearing Housing 6311	2
27	B02030800	Rasp Bar Support With Knob Welded	2
28	B02031100	Rasp Bar Support Without Knob Welded	1
29	M03064	Hex Head Screw M12x35	6
30	M01005	Hex Nut M12	6
31	B02030900	Thresher Drum Pulley Assy.	1

Item No.	Part No.	Part Name	Qty.
32	M04009	Spring Washer M12	8
33	M03063	Hex Head Screw M12x30	8
34	B02030014	Thresher Shaft	1
35	M14008	Gib Head Key 14x9x70	3
36	M14128	Gib Head Key 12x8x100	1
37	M99001	Grease Pipe 10" (M8)	2
38	M01005	Hex Nut M12	40
39	M04009	Spring Washer M12	40
40	M55042	Hex Head Bolt M12x50 -10.9	6
41	B02030101	Rasp Bar LH	4
42	M03064	Hex Head Screw M12x35	40
43	B02030102	Rasp Bar RH	4
44	M39015	V- Belt 50x2170	1
45	M01003	Hex Nut M8	4
46	M05008	Plain Washer M12	8
47	M05006	Plain Washer M8	4
48	B04010015	Bottom Cover Plate	1
49	M03034	Hex Head Screw M8x25	4
50	B02030011	Rubber Flap - Thresher Cover Plate	1
51	B02030307	Nut M20x1.5	3
52	M04009	Spring Washer M12	6
53	M01005	Hex Nut M12	6
54	B02031000	Rasp Bar Support w/o Knob LH Welded	1
55	B02031200	Rasp Bar Support with Knob LH Welde	1
56	B02030018	Rubber Flap Mtg. Strip	1
57	M36018	Flange Head Screw M6x16	8
58	M05005	Plain Washer M6	8
59	M01002	Hex Nut M6	8
60	B02030305	Liner Bush (Thresher Pulley)	3

THRESHER DRUM (PADDY)

PLATE NO. 016





PREET AGRO IND. PVT. LTD.

THRESHER DRUM (PADDY)


SPARE PARTS LIST

PREET 987

PLATE NO. 016

THRESHER CLUTCH

PLATE NO. 017





PREET AGRO IND. PVT. LTD.
THRESHER CLUTCH


SPARE PARTS LIST
PREET 987
PLATE NO. 017

Item No.	Part No.	Part Name	Qty.
1	B02050005	Shaft - Thresher Clutch Pulley	1
2	M01004	Hex. Nut M10	2
3	M11042	Internal Circlip B72	2
4	M16028	Ball Bearing 6207 Z	2
5	B02050004	Spacer - Aluminium Idler	1
6	B02050003	Alluminium Idle Pulley	1
7	B02050200	Support Lever	1
8	M30007	Castle Nut M28x1.5	1
9	B02050002	Special Washer	1
10	M55031	Hex Head Bolt M10x55 - 10.9	2
11	B02050100	Supporting Bracket	2
12	M04008	Spring Washer M-10	6
13	M01004	Hex Nut M10	4
14	M44007	Split Pin 7/32" x 2.5"	2
15	B02050011	Angle Rod - Thresher Clutch	1
16	B02050001	Flat Idle Shaft	1
17	M02028	Hex Head bolt M10x40	4
18	M05007	Plain+C4:C22 Washer M10	8
19	A02040008	Hex Nut 3/4" BSW	4
20	B02050006	Tie Rod - Thresher Clutch	1
21	M05008	Plain Washer M12	1
22	M01004	Hex. Nut M10	2
23	M05007	Plain Washer M10	2
24	M01005	Hex Nut M12	1

Item No.	Part No.	Part Name	Qty.
25	B02050400	Hand Lever - Thresher Clutch	1
26	M03051	Hex Head Screw M10x40	2
27	M03049	Hex. Head screw M10x30 - 8.8	2
28	M02042	Hex Head Bolt M12x50	1
29	A02040014	Bush Nut	1
30	A02040006	Spring - Thresher Clutch	1
31	B02050009	Special Washer	1
32	B02050010	Bracket	1
33	J04060019	Spring	1
34	M02148	Hex Head Bolt M10x100	1
35	M01004	Hex Nut M10	2
36	M28002	Nylock Nut M10	2
37	M99002	Grease Pipe M6(15")	1
38	B02050014	Grease Pipe Mtg	1
39	M28003	Nylock Nut M12	1
40	M04009	Spring Washer M12	2
41	M29008	Grease Nipple M6	1
42	M03049	Hex Screw M10x30	1
43	M05007	Plain Washer M10	1
44	M04008	Spring Washer M10	1
45	M01004	Hex Nut M10	3
46	M05007	Plain Washer M10	2
47	M29001	Grease Nipple M8x1	1

CONCAVE ASSY. (WHEAT)

PLATE NO. 018





PREET AGRO IND. PVT. LTD.
CONCAVE ASSY. (WHEAT)

SPARE PARTS LIST


PREET 987

PLATE NO. 018

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B02060100	Concave Wheat	1				
2	M01004	Hex Nut M10	5				
3	M04008	Spring Washer M10	5				
4	B02060001	Concave Rack Mtg. Angle	1				
5	B02060200	Rack Welded	1				
6	M03050	Hex Head Screw M10x35	5				
7	B02060002	Rubber Flap - Concave	1				
8	M03019	Hex Head Screw M6x20	8				
9	M05005	Plain Washer M6	16				
10	M01002	Hex Nut M6	8				
11	B02060003	Holding Strip - Concave Flap	1				
12	M28009	Nylock Hex Nut M16	4				
13	M05009	Plain Washer M16	4				
14	B02060005	Special Washer Lower	2				
15	B02060004	Concave Bush	4				
16	M02068	Hex Head Bolt M16x60	4				
17	M04008	Spring Washer M10	5				
18	M04006	Spring Washer M6	8				
19	B06020006	Special Washer Upper	2				

CONCAVE ASSY. (PADDY)

PLATE NO. 019





PREET AGRO IND. PVT. LTD.
CONCAVE ASSY. (PADDY)

SPARE PARTS LIST


PREET 987

PLATE NO. 019

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B02070100	Concave Paddy	1				
2	M01004	Hex Nut M10	5				
3	M05007	Plain Washer M10	5				
4	B02060001	Concave Rack Mtg. Angle	1				
5	B02060200	Rack	1				
6	M03050	Hex Head Screw M10x35	5				
7	B02060002	Rubber Flap - Concave	1				
8	M03019	Hex Head Screw M6x20	8				
9	M05005	Plain Washer M6	16				
10	M01002	Hex Nut M6	8				
11	B02060003	Holding Strip - Concave Flap	1				
12	M28009	Nylock Nut M16	4				
13	M05009	Plain Washer M16	4				
14	B02060005	Special Washer Lower	2				
15	B02060004	Concave Bush	4				
16	M02068	Hex Head Bolt M16x60	4				
17	B02040102	Spike	35				
18	M04010	Spring Washer M16	35				
19	B02040001	Spike Nut	35				
20	M04008	Spring Washer M10	5				
21	M04006	Spring Washer M6	8				
22	B02060006	Special Washer Upper	2				

CONCAVE LEVER ASSY.

PLATE NO. 020





PREET AGRO IND. PVT. LTD.
CONCAVE LEVER ASSY.

SPARE PARTS LIST


PREET 987

PLATE NO. 020

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B02080023	Lever Left	1	23	B02080025	Concave Strip Big Right	1
2	B02080010	Spacer (OD 40.2 X ID 30.5 X T 2.2)	1	24	B02081300	Lever Guide Plate Assy Upper	2
3	M13005	Parallel Key 8x7x25	1	25	B02081400	Lever Guide Plate Assy Lower	2
4	B02081200	Concave Lever Shaft Weld	1	26	M02031	Hex Bolt M10x55	1
5	M31085	Split Pin 2.5x22	1	27	M01004	Hex Nut M10	1
6	A04030012	Pin	1				
7	B02080800	Link	1				
8	M10019	External Circlip A 30	1				
9	B03080021	Spacer	1				
10	B02080300	Concave Lever	1				
11	B02080600	Mounting Bracket - Flat Operating Leve	1				
12	B02080200	Lever Shaft Weld	1				
13	B02080012	Bush Nut	1				
14	A02051008	Special Hex Nut M16	1				
15	M01008	Hex Nut M16	4				
16	B02080022	Lever Rod	4				
17	M01008	Hex Nut M16	8				
18	M05007	Plain Washer M10	8				
19	B02080026	Concave Strip Small Left	1				
20	B02080027	Concave Strip Big Left	1				
21	M03092	Hex Head Screw M16x35	4				
22	B02080024	Concave Strip Small Right	1				

GUIDE DRUM ASSY.

PLATE NO. 021





PREET AGRO IND. PVT. LTD.
GUIDE DRUM ASSY.


SPARE PARTS LIST
PREET 987
PLATE NO. 021

Item No.	Part No.	Part Name	Qty.
1	M39115	Flat Belt 114x3650	1
2	M02072	Hex. Bolt M16x80	1
3	B02090600	Flat Pulley	1
4	M01068	Hex. Nut M16	1
5	B02091201	Pulley 13"x1C Coupling Type	1
6	M11060	Internal Circlip B-120	2
7	M15009	Ball Bearing 6311	4
8	B02030013	Spacer Ø55xØ70x5	2
9	B02030012	Bearing Housing 6311	1
10	M01008	Hex Nut M16	2
11	M03033	Hex Head Screw M8x20	12
12	B02090001	Cover Plate - Guide Drum Window	4
13	M03049	Hex Head Screw M10x30	1
14	M03066	Hex Head Screw M12x45 - 10.9	6
15	M04009	Spring Washer M-12	6
16	M05008	Plain Washer M12	6
17	B02090026	L Rod - Flat Belt Retainer	1
18	M14008	Gib Head Key 14x9x70	1
19	M02071	Hex Head Bolt M16x75 - 8.8	2
20	B02090700	Guide Drum	1
21	M13011	Parallel Key 14x9x56	2
22	B02090020	Guide Drum Shaft	1
23	M13012	Parallel Key 12x8x100	1
24	B02090017	Bearing Housing 6311 - guide Drum	1
25	B02090900	Speed Changer Sprocket Sub Assy	1
26	B02090800	Speed Changer Sprocket Assy	1
27	B02091100	Chain - Variator Control	1
28	M20001	Thrust Ball Bearing 51120	1
29	M05007	Plain Washer M10	1

Item No.	Part No.	Part Name	Qty.
30	B02090303	Threaded Pin	3
31	B02090302	Guide Drum Inner Disc	1
32	B02090308	Guide Bush	1
33	B02090304	Guide Drum Outer Disc	1
34	M04009	Spring Washer M-12	6
35	M03065	Hex Head Screw M12x40 - 8.8	6
36	B02090004	Elevator Drive Pulley	1
37	M04007	Spring Washer M-8	6
38	M03156	Hex. Head Screw M8x75 - 8.8	6
39	B02090022	Shaft Nut M40x1.5	1
40	B02091000	Guide Drum Pulley Assy.	1
41	M03070	Hex Head Bolt M12x65 - 10.9	1
42	M05008	Plain Washer M12	2
43	M11028	Internal Circlip B-47	1
44	M16040	Ball Bearing 6204 ZZ	1
45	A01040012	Idle Pulley 5"	1
46	B01030021	Idle Bush	1
47	M01005	Hex Nut M12	1
48	M99006	Grease Pipe 6" (M8)	2
49	B02030307	Nut M20x1.5	3
50	B02030016	Bearing Dust Cap	2
51	B02030015	Felt Seal	2
52	M03054	Hex Screw M10x55	4
53	B02091202	Pulley Coupling 55mmn	1
54	B02091200	Pulley Assy 13"x1C With Coupling 55mm	s
55	M02039	Hex Screw M12x35	2
56	M01005	Hex Nut M12	2
57	M01004	Hex Nut M10	1
58	B02090305	Liner Bush	3

VARIATOR CONTROL (GUIDE DRUM).

PLATE NO. 022





PREET AGRO IND. PVT. LTD.

VARIATOR CONTROL (GUIDE DRUM)


SPARE PARTS LIST

PREET 987

PLATE NO. 022

BLOWER ASSY.

PLATE NO. 023






PREET AGRO IND. PVT. LTD.
BLOWER ASSEMBLY

SPARE PARTS LIST
PREET 987D
PLATE NO. 023

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B03010004	Support	20	23	M05008	Plain Washer M12	3
2	B03010003	Blade	5	24	M28003	Nylock Nut M12	1
3	M36034	Flange Head Screw M8x25	40	25	M39160	V-Belt C-45	1
4	M05006	Plain Washer M8	40	26	B03011202	Pulley coupling 35mm	1
5	M04009	Spring Washer M12	1	27	M28003	Nylock Nut M12	8
6	B03020010	Idler Bush (Use as spacer)	1	28	M04009	Spring Washer M12	8
7	M05007	Plain Washer M10	1	29	M35003	Bearing Housing UCF 207	2
8	M28005	Nylock Nut M8	40	30	M03064	Hex Head Screw M12x35	8
9	M13004	Parallel Key 8x7x50	1	31	B03010900	Bearing Holder Bracket -LH	1
10	B03010600	Spider 1	1	32	M03050	Hex Head Screw M10x35	4
11	B03010020	Blower Shaft	1	33	M05007	Plain Washer M10	4
12	M14086	Gib Head Key 8x7x100	1	34	M04008	Spring Washer M-10	4
13	B03010007	Stiffner	1	35	M28002	Nylock Nut M10	4
14	B03010006	Rubber Flap	1	36	M03033	Hex Head Screw M8x20	8
15	M03033	Hex Head Screw M8x20	6	37	B03011201	Pulley 5"x6" Coupling Type	1
16	M05006	Plain Washer M8	12	38	M22003	Bearing UC 207	2
17	M28005	Nylock Nut M8	6	39	M99003	Grease Pipe M6x10"	1
18	M02163	Hex Head Bolt M12x120	1	40	B03010009	Guard Assy.	2
19	B01020023	Idler Bush	1	41	M01003	Hex Nut M8	8
20	M16008	Ball Bearing 6204Z	2	42	M05006	Plain Washer M8	8
21	A01020004	Idler - Blower Drive	1	43	M04007	Spring Washer M8	8
22	M11028	Internal Circlip B-47	1	44	B03010005	Blower Cover	1

BLOWER DRIVE

PLATE NO. 024





PREET AGRO IND. PVT. LTD.
BLOWER DRIVE

SPARE PARTS LIST


PREET 987D

PLATE NO. 024

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M39162	V-Belt C-115	1	23	M14004	Gib Key 8x7x50	1
2	B03020401	Assy Pulley 13"x1C Coupling Type	1	24	M28003	Nylock Nut M12	1
3	M03051	Hex Head Screw M10x40	4	25	M04009	Spring Washer M12	1
4	B03020302	Coupling 35mm	1	26	B01020023	Idler Bush	1
5	B03020300	Pulley Assy 8"x10" with coupling 35mm	1	27	A01040012	Idler Pulley 5"	1
6	M03066	Hex Head Screw M12x45	2	28	M16040	Ball Bearing 6204ZZ	1
7	M04009	Spring Washer M12	2	29	M11028	Internal Circlip B47	1
8	M05008	Plain Washer M12	2	30	M05008	Plain Washer M12	3
9	M35011	Bearing Housing UCP -207	1	31	M02045	Hex Head Bolt M12x65	1
10	B03020020	Spacing Plate 10mm	1	32	B03150014	Spacer (Ø45xØ35x10)	1
11	M22003	Bearing UC-207	3	33	M03053	Hex Screw M10x50	4
12	B03020016	Counter Sprocket Z-14	1	34	B03020400	Pulley Assy 13"x1C with coupling 35mm	1
13	M03033	Hex Head Screw M8x20	2				
14	M01003	Hex Nut M8	2				
15	M03063	Hex Head Screw M12x30	8				
16	M04009	Spring Washer M12	8				
17	M35003	Bearing Housing UCF -207	2				
18	B03020301	Pulley 8"x10" Coupling Type	1				
19	B03011202	Pulley coupling 35mm	1				
20	B03150016	Spacer (Ø45xØ35x5)	1				
21	M14006	Gib Head Key 8x7x63	2				
22	B03020012	Assembly Shaft	1				

STRAW BAFFLE ASSY.

PLATE NO. 025





PREET AGRO IND. PVT. LTD.

STREW BAFFLE


SPARE PARTS LIST

PREET 987D

PLATE NO. 025

STEPPED BED ASSY.

PLATE NO. 026






PREET AGRO IND. PVT. LTD.
STEPPED BED ASSY.

SPARE PARTS LIST
PREET 987D
PLATE NO. 026

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M55028	Hex Head Bolt M10x40-10.9	5	23	B03040003	Rubber Flap Front - Step Bed	1
2	M05007	Plain washer M10	10	24	M36019	Flange Head Screw M6x20	7
3	B03040200	Rack Assy. - Step Bed	1	25	M01002	Hex Nut M6	7
4	B03040100	Stepped Bed	1	26	B03040006	Holding Strip Long - Step Bed	2
5	M04008	Spring Washer M10	5	27	M01002	Hex Nut M6	24
6	M28002	Nylock Nut M10	5	28	M36019	Flange Head Screw M6x20	24
7	M03053	Hex Head Screw M10x50	4	29	B03040005	Rubber Flap - Step Bed	2
8	M44001	Split Pin 1/8"x1.0"	4				
9	A03030010	Supporting Angle Bracket	2				
10	M05007	Plain washer M10	4				
11	M04008	Spring Washer M10	4				
12	M28002	Nylock Nut M10	4				
13	B03040400	Oscilating Arm Mtg	2				
14	M55066	Hex Head Bolt M16x50-10.9	4				
15	M05009	Plain Washer M16	4				
16	M04010	Spring Washer M16	4				
17	M28009	Nylock Nut M16	4				
18	A03030011	Oscilating Arm	2				
19	M16063	Ball Bearing 6205 ZZ	4				
20	M11031	Internal Circlip B-52	4				
21	M30005	Castle Nut M20x1.5	4				
22	B03040004	Holding Strip Small - Step Bed Flap	1				

CLEANER SIEVES

PLATE NO. 027





PREET AGRO IND. PVT. LTD.

CLEANER SIEVES

SPARE PARTS LIST


PREET 987

PLATE NO. 027

Item No.	Part No.	Part Name	Qty.
1	B03050101	Adjustable Sieve Top	1
2	M53001	Flange Head Bolt M8x45	2
3	M05006	Plain Washer M8	4
4	M01003	Hex Nut M8	2
5	M01003	Hex Nut M8	2
6	B03050103	Short Straw Sieve	1
7	B03050102	Adjustable Sieve Bottom	1
8	M36033	Flange Head Screw M8x20	2
9	M01003	Hex Nut M8	1
10	M36049	Flange Head Screw M10x30	2
11	M05007	Plain Washer M10	2
12	M01004	Hex Nut M10	2
13	M36033	Flange Head Screw M8x20	2
14	M01003	Hex Nut M8	2
15	M36049	Flange Head Screw M10x30	2
16	M05007	Plane Washer M10	2
17	M01004	Hex Nut M10	2
18	M36033	Flange Head Screw M8x20	1

SIEVES CASING ASSY.

PLATE NO. 028





PREET AGRO IND. PVT. LTD.
SIEVES CASING ASSY.


SPARE PARTS LIST
PREET 987
PLATE NO. 028

Item No.	Part No.	Part Name	Qty.
1	M01002	Hex Nut M6	7
2	B03060001	Holding Strip Rear - Lower Chaffer Flap	1
3	B03060002	Rubber Flap Rear - Lower Chaffer	1
4	M05005	Plain Washer M6	7
5	M03019	Hex Head Screw M6x20	7
6	B03060004	Rubber Flap Side - Lower Chaffer	2
7	B03060003	Holding Strip Side - Lower Chaffer	2
8	M01002	Hex. Nut M6	26
9	M05005	Plain Washer M6	26
10	B03060100	Lower Chaffer Board	1
11	M03019	Hex Head Screw M6x20	26
12	M03048	Hex Head Screw M10x25	2
13	M04008	Spring Washer M10	2
14	B03060019	Special Washer	2
15	M15010	Ball Bearing 6205 Z	4
16	B03060012	Spacer Ø25xØ35x36.5	2
17	B03060011	Arm - Sieve Casing	2
18	A0303003	Bush Housing	4
19	A0303004	Rubber Bush	2
20	M02149	Hex Head Bolt M10x110	4
21	B3060009	Pivot Pin	2
22	M04008	Spring Washer M10	4
23	M28002	Nylock Nut M10	4
24	M29001	Grease Nipple M8x1	2
25	M04008	Spring Washer M10	4
26	M28002	Nylock Nut M10	4
27	M05007	Plain Washer M10	4

Item No.	Part No.	Part Name	Qty.
28	B03060017	Pin Assy.	2
29	M02029	Hex. Head Bolt M10x45	4
30	B03060200	Upper Chaffer	1
31	M05008	Plain Washer M12	8
32	M04009	Spring Washer M12	8
33	M03063	Hex. Head Screw M12x30	4
34	M03062	Hex. Head Screw M12x25	4
35	M02241	Hex. Head Bolt M12x105	8
36	A0303003	Bush Housing	8
37	A0303004	Rubber Bush	4
38	B03061200	Arm Lever Welded	2
39	M31154	Split Pin 6x50	4
40	M28002	Nylock Nut M10	8
41	M04008	Spring Washer M10	8
42	M01004	Hex Nut M10	4
43	B03060019	Special Washer 33x59x3.2	8
44	M03048	Hex Head Screw M10x25	2
45	M05007	Plain Washer M10	2
46	M36019	Flange Head Screw M6x20	6
47	B03060005	Rubber Flap Rear - Upper Chaffer	1
48	B03060006	Holding Strip Rear - Upper Chaffer	1
49	M05005	Plain Washer M6	12
50	M01002	Hex Nut M6	6
51	M01002	Hex Nut M6	28
52	M05005	Plain Washer M6	28
53	B03060007	Rubber Flap Side - Upper Chaffer	2
54	B03060008	Holding Strip Side - Upper Chaffer	2

SIEVES CASING DRIVE

PLATE NO. 029






PREET AGRO IND. PVT. LTD.
SIEVES CASING DRIVE

SPARE PARTS LIST
PREET 987
PLATE NO. 029

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M02045	Hex Head Bolt M12x65	2	38	M02045	Hex Head Bolt M12x65	4
2	B03070002	Supporting Bracket	2	39	M15010	Ball Bearing 6205	4
3	M04009	Spring Washer M-12	2	40	B03060012	Spacer 25mm	2
4	M28003	Nylock Nut M12	2	41	M28002	Nylock Nut M10	4
5	M14004	Gib Head Key 8x7x50	2	42	M04008	Spring Washer M10	4
6	B03070001	Cam Shaft	1	43	B03060010	Pin Assy.	2
7	M03052	Hex Head Screw M10x45	4	44	M02028	Hex Head Bolt M10x40	4
8	M35006	Bearing Housing UCP-206	2	45	B03070010	Driven Shaft 20mm	1
9	M22004	Bearing UC 206	2	46	M02148	Hex Head Bolt M10x100	4
10	M05007	Plain Washer M10	2	47	M03048	Hex Head Screw M10x25	6
11	M04008	Spring Washer M-10	2	48	M05007	Plain Washer M10	6
12	M28002	Nylock Nut M10	2	49	B03070009	Bush Housing	2
13	M02045	Hex Head Bolt M12x65	1	50	M04008	Spring Washer M10	4
14	B03070300	Counter Sprocket	1	51	M01004	Hex Nut M10	4
15	M03065	Hex Head Screw M12x40	4	52	B03070014	Nylon Bush	2
16	B03070024	Arm Drive	2	53	B03070011	Stiffner	1
17	M03033	Hex Head Screw M8x20	6	54	B03070007	Angle Strip	2
18	B03070027	Arm drive packing	4	55	B03070005	Threaded Pin	2
19	M21002	Flange Bearing SA 205	2	56	M28002	Nylock Nut M10	5
20	M28005	Nylock Nut M8	6	57	M05007	Plain Washer M10	10
21	M04007	Spring Washer M-8	6	58	M03051	Hex Head Screw M10x40	5
22	M28003	Nylock Nut M12	4	59	M44005	Split Pin 5/32"x1.0"	2
23	M04009	Spring Washer M-12	4	60	M04009	Spring Washer B12	1
24	M30005	Castle Nut M20x1.5	6	61	M28003	Nylock Nut M12	1
25	B03070012	Supporting Bracket	2	62	M10015	External Circlip A-25	1
26	M02152	Hex Head Bolt M10x130	12	63	M04008	Spring Washer M10	5
27	A03030003	Bush Housing	12	64	B03070019	Bush	2
28	A03030004	Rubber Bush	8	65	M01004	Hex Nut M10	4
29	B03060009	Pivot Pin	2	66	M03048	Hex Head Screw M10x25	4
30	M05008	Plain Washer M12	8	67	M04008	Spring Washer M10	6
31	M03063	Hex Head Screw M12x30	8	68	B03070020	Special Washer 33x59x3.2	2
32	B03070200	Arm Lever Right	1	69	M44014	Split Pin 1/4"x 2-1/2"	2
33	B03070100	Arm Lever Left	1	70	M04009	Spring Washer M12	8
34	M04009	Spring Washer M12	12	71	M29008	Grease Nipple M6	2
35	M28002	Nylock Nut M10	12	72	M03050	Hex Head Screw M10x35	4
36	M59002	Dowel Pin 8x20	4	73	M05007	Plain Washer M10	4
37	B03070101	Bearing Holder	2	74	M28002	Nylock Nut M10	4

STRAW WALKER ASSEMBLY

PLATE NO. 030






PREET AGRO IND. PVT. LTD.
STRAW WALKER ASSEMBLY

Item No.	Part No.	Part Name	Qty.
1	B03081200	Straw Walker	5
2	M03032	Hex Head Screw M8x16	10
3	B03080005	Window Cover - Straw Walker	5
4	M03033	Hex Head Screw M8x20	39
5	B03080002	Lifting Flap	13
6	M05006A	Plain Washer M8	78
7	M04007	Spring Washer M8	39
8	M01003	Hex Nut M8	39
9	M22003	Bearing UC-207	4
10	M28003	Nylock Nut M12	16
11	M04009	Spring Washer M12	16
12	M35003	Bearing Housing UCF-207	4
13	B0308010001	Supporting Plate - Crank Bearing 207	2
14	M57066	Hex Head Screw M12x45-10.9	16
15	M02241	Hex Head Bolt M10x105	40
16	M05007	Plain Washer M10	80
17	B03080003	Wooden Block Set	10
18	B03080004	Plate-Wooden Block	10
19	B0308010003	Spacer Ø31xØ12.3x10	5
20	M01004	Hex Nut M10	80
21	B0308010101	Crank Front	1
22	B0308010002	Spacer Plate 3mm - Crank Bearing 207	4
23	M57048	Hex Head Screw M10x25-10.9	4
24	M04008	Spring Washer M10	4

SPARE PARTS LIST			
PREET 987			
PLATE NO. 030			
Item No.	Part No.	Part Name	Qty.
25	B03080023	Coupling Ø35 - Straw Walker Sprocket	1
26	M58036	Spacer Ø43.5xØ36x3	1
27	M28002	Nylock Nut M10	1
28	B03080012	Sprocket Z52	1
29	M55033	Hex Head Bolt M10x65-10.9	1
30	M14004	Gib Head Key 8x7x50	1
31	B03020003	Chain - straw Walker Crank	1
32	B03020100	Angle bracket	1
33	M01004	Hex Nut M10	2
34	M05007	Plain Washer M10	2
35	B03020022	Idler Bush	1
36	B03020008	Idler Sprocket Z-15	1
37	M16040	Ball Bearing 6204 ZZ	1
38	M11028	Internal Circlip B47	1
39	M05008	Plain Washer M12	1
40	M02158	Hex Head Bolt M12x90	1
41	B0308010102	Crank Rear	1
42	B0308010100	Crank Set	2
43	M99003	Grease Pipe - 10" (M6)	2
44	M99002	Grease Pipe - 15" (M6)	2
45	M04008	Spring Washer M10	1
46	M04009	Spring Washer M12	1
47	B03150016	Spacer Ø45xØ35.5x5	2

AUGER CASING

PLATE NO. 031






PREET AGRO IND. PVT. LTD.
AUGER CASING

Item No.	Part No.	Part Name	Qty.
1	M02033	Hex Head Bolt M10x65-10.9	4
2	M05007	Plain Washer M10	26
3	M04008	Spring Washer M10	26
4	M28002	Nylock Nut M10	26
5	B03090100	Auger Casing	1
6	M28004	Nylock Nut M6	6
7	M05005	Plain Washer M6	12
8	B03090009	Rubber Flap - Small	2
9	B03090011	Stiffener - Small	2
10	M03019	Hex Head Screw M6x20	6
11	B03090200	Grain Auger	1
12	M13004	Parallel Key 8x7x50	2
13	M40010	Grub screw M8x8	4
14	A01080003	Sprocket Z-7	2
15	B03090300	Tailing Auger	1
16	M57050	Hex Head Screw M10x35-10.9	8
17	B03090010	Cover Plate - Auger Casing	2
18	M35003	Bearing Housing UCF-207	2
19	M04008	Spring Washer M10	8
20	M28002	Nylock Nut M10	8
21	M22003	Bearing UC-207	2
22	M05007	Plain Washer M10	8
23	M04008	Spring Washer M10	8
24	M28002	Nylock Nut M10	8
25	M03050	Hex. Head Screw M0x35-10.9	4

		SPARE PARTS LIST	
		PREET 987D	
		PLATE NO. 031	
Item No.	Part No.	Part Name	
Qty.		Qty.	
26	M40010	Grub Screw M8x8	4
27	B03091201	Pulley 8" x 35B	1
28	M01003	Hex Nut M8	8
29	M05006	Plain Washer M8	8
30	B03090600	Rubber Pipe Mtg. Bkt.	4
31	B03090001	Rubber Pipe	4
32	M14004	Gib Head Key 8x7x50	1
33	M03019	Hex Head Screw M6x20	9
34	B03090002	Stiffner - Auger Casing Flap	1
35	B03010006	Rubber Flap - Auger Casing	1
36	M05005	Plain Washer M6	18
37	M28004	Nylock Nut M6	9
38	M03049	Hex Head screw M10x30-10.9	22
39	B03020302	Coupling 35 MM Small	1
40	M39002	V Belt C-88	1
41	M02047	Hex Head Bolt M12x75	1
42	M04009	Spring Washer M12	1
43	M110028	Internal circlip B-47	1
44	M16008	Ball Bearing 6204 Z	2
45	A01020004	Idler 60mm	1
46	B01020023	Idler Bush	1
47	M05008	Plain Washer M12	2
48	M01005	Hex Nut M12	1
49	B03090900	Pulley Cover	1

GRAIN ELEVATOR

PLATE NO. 032





PREET AGRO IND. PVT. LTD.
GRAIN ELEVATOR


SPARE PARTS LIST
PREET 987
PLATE NO. 032

Item No	Part No.	Part Name	Qty.
1	M03047	Hex Head Screw M10x20	1
2	M04008	Spring Washer M10	1
3	B03100007	Special Washer Ø39xØ11x2	1
4	M22004	Bearing UC-206	2
5	M35004	Bearing Housing UCF-206	2
6	B0312010101	Tensioner Plate - Elevator Chain	2
7	B03100005	G.E. Shaft	1
8	M13025	Parallel Key 8x7x45	1
9	M14001	Gib Head Key 8x7x36	1
10	M40010	Grub screw M8x8	2
11	A03050006	Sprocket Z-7 x 30B	1
12	B0310020300	Elevator Head - Grain	1
13	M05007	Plain Washer M10	8
14	M01004	Hex Nut M10	8
15	M03158	Hex Head Screw M10x100	2
16	B03100022	Sprocket Z-22 x 30B	1
17	B03100008	Drive Chain - Grain Auger	1
18	M01003	Hex Nut M8	2
19	M03034	Hex Head Screw M8x25	1
20	B0310020201	Rail - Grain Elevator	1
21	B03100002	Carriage Bolt 3/8x 7"	5
22	M22003	Bearing UC-207	1
23	M35003	Bearing Housing UCF-207	1
24	M01004	Hex Nut M10	4
25	M04008	Spring Washer M10	4
26	M57050	Hex Head Screw M10x35-10.9	4
27	M03018	Hex Head Screw M6x16	4
28	M01002	Hex Nut M6	4

Item No	Part No.	Part Name	Qty.
29	B0312010700	Bottom Cover - Elevator	1
30	A03050008	Clamp Screw	1
31	B0312010600	Grain /Tailing Elevator Tail	1
32	M05005	Plain Washer M6	8
33	M05005	Plain Washer M6	16
34	M01002	Hex Nut M6	16
35	M57033	Hex Head Screw M8x20-10.9	6
36	M05006A	Plain Washer M8	12
37	M01003	Hex Nut M8	8
38	B03100025	Elevator Mounting Plate	1
39	M04008	Spring Washer M10	2
40	B0310020400	Grain Elevator Body	1
41	M36018	Flange Head Screw M6x16	16
42	A01080019	Chain Lock	1
43	M53028	Flange Head Bolt M6x25	76
44	B03100009	Conveyer Plate	38
45	B03100010	Cleaning Pad	38
46	B03100011	Backing Plate	38
47	B03100012	Elevator Chain 38 pads - 154 Links	1
48	B0310020001	Elevator Tank Gap Filling Plate upper	2
49	M28004	Nylock Nut M6	76
50	B0310020200	Grain Elevator Body Assy.	1
51	B03101400	Grain Elevator Chain & Pad Assy.	1
52	B0310020100	Grain Elevator Sub. Assy.	1
53	B0310020500	Grain Elevator Body Cover-Lower	1
54	M04008	Spring Washer M10	8
55	M01004	Hex Nut M10	8
56	M57050	Hex Head Screw M10x35-10.9	2

GRAIN ELEVATOR

PLATE NO. 032






PREET AGRO IND. PVT. LTD.

GRAIN ELEVATOR

SPARE PARTS LIST
PREET 987
PLATE NO. 033

TOP GRAIN AUGER

PLATE NO. 033





PREET AGRO IND. PVT. LTD.
TOP GRAIN AUGER


SPARE PARTS LIST
PREET 987
PLATE NO. 033

Item No.	Part No.	Part Name	Qty.
1	M55043	Hex. Head Bolt M12x55-10.9	1
2	M05008	Plain Washer M12	2
3	B01030021	Bush Idler	1
4	B03020008	Idler Sprocket Z15	1
5	M13004	Parallel Key 8x7x50	1
6	B03110001	Top Grain Auger	1
7	M57049	Hex Head Screw M10x30-10.9	2
8	M05007	Plain Washer M10	4
9	B03110002	Bearing Plate - Top Grain Auger	1
10	M01004	Hex Nut M10	2
11	M35004	Bearing Housing UCF-206	2
12	M22004	Bearing UC-206	2
13	B03100007	Special Washer Ø39xØ11x2	1
14	M03047	Hex Head Screw M10x20	1
15	M57050	Hex Head Screw M10x35-10.9	4
16	M04008	Spring Washer M10	4
17	M01004	Hex Nut M10	4
18	M57034	Hex Head Screw M8x25-10.9	1
19	B03100022	Sprocket Z 22 - 30B	1

Item No.	Part No.	Part Name	Qty.
20	M16040	Ball Bearing 6204ZZ	1
21	M11028	Internal Circlip B47	1
22	M01005	Hex. Nut M12	1
23	M01003	Hex Nut M8	2
24	M05007	Plain Washer M10	1
25	M04008	Spring Washer M10	2
26	M04008	Spring Washer M10	1
27	M05014	Plain Washer M30	1
28	M03033	Hex Head Screw M8x20	1
29	M57049	Hex Head Screw M10x30-10.9	4
30	M04008	Spring Washer M10	4
31	M01004	Hex Nut M10	4
32	M36033	Flange Head Screw M8x20-10.9	4
33	M05006	Plain Washer M8	4
34	M01003	Hex Nut M8	4
35	M05006	Plain Washer M8	1
36	M01003	Hex Nut M8	1
37	B03110300	Top Grain Head	1

TAILING ELEVATOR

PLATE NO. 034





PREET AGRO IND. PVT. LTD.
TAILING ELEVATOR

SPARE PARTS LIST


PREET 987

PLATE NO. 034

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M39146	V-Belt C-79	1	31	M28002	Nylock Nut M-10	4
2	M03051	Hex. Head screw M10x40	4	32	M04008	Spring Washer M10	4
3	B03121002	Pulley Coupling 30mm	1	33	M03050	Hex Head Screw M10x35	4
4	B03121001	Pulley 12"x1C Coupling Type	1	34	M03019	Hex. Head Screw M6x20	4
5	M22004	Bearing UC-206	2	35	M01002	Hex Nut M6	4
6	M35004	Bearing Housing UCF-206	2	36	B0312010700	Bottom Cover	1
7	B0312010101	Tensioner Plate	2	37	A03050008	Clamp Screw	1
8	B03121000	Pulley Assy 12"x1C with Coupling 30mm	1	38	B0312010600	Tailing Elevator Tail	1
9	M13025	Parallel Key 8x7x45	1	39	A03050023	Hex Nut 3/8"	5
10	B03120005	T.E. Shaft	1	40	M01004	Hex Nut M10	5
11	A03050006	Sprocket Z-7x B30	1	41	M05007	Plain Washer M10	10
12	M40002	Grub Screw M8x20	2	42	B03120002	Supporting Plate	1
13	M01002	Hex Nut M6	2	43	M03050	Hex. Head screw M10X35	5
14	B03120011	Elevator Mounting Angle	1	44	B0312010200	Supporting Bracket Assy.	1
15	B0312010400	Tailing Elevator Head	1	45	B0312010500	Tailing Elevator Body	1
16	M05006A	Plain Washer M8	2	46	M03018	Hex Head Screw M6x16	20
17	M03019	Hex Head Screw M6x20	2	47	M05005	Plain Washer M6	40
18	M03158	Hex Head Screw M10x100	2	48	M01002	Hex Nut M6	20
19	M01004	Hex Nut M10	8	49	M53028	Flange Head Bolt M6x25	76
20	M05007	Plain Washer M10	8	50	B03100009	Conveyor Plate	38
21	B0312010001	Tensioner rod	1	51	B03100010	Cleaning Pad	38
22	M05008	Plain washer M12	1	52	B03100011	Backing Plate	38
23	M03035	Hex Head Screw M8x30	1	53	B03100013	Elevator Chain Assy	1
24	B03100022	Sprocket Z-22 xB30	1	54	B03110006	Idler pulley holding bkt.2	2
25	M04009	Spring Washer M12	1	55	M28004	Nylock Nut M6	76
26	M01005	Hex. Nut M12	1	56	A01080019	Chain Lock	1
27	B0312010301	Rail	1	57	B0312010300	Tailing Elevator Body Assy.	1
28	B03100002	Carriage Bolt 3/8x 7"	4	58	B03120800	Elevator Chain and Pad Assy.	1
29	M22005	Bearing UC-207	1	59	B0312010100	Tailing Elevator Sub. Assy.	1
30	M35003	Bearing Housing UCF-207	1	60	B03110006	Idler bush	2

TOP EAR AUGER

PLATE NO. 035





PREET AGRO IND. PVT. LTD.
TOP EAR AUGER

SPARE PARTS LIST

PREET 987


PLATE NO. 035

Item No.	Part No.	Part Name	Qty.
1	M01003	Hex Nut M8	4
2	M05006	Plain Washer M8	4
3	B03130100	Discharge Head - Ear Auger	1
4	B03130400	Cover Weld - Top Ear Auger	1
5	M01003	Hex Nut M8	1
6	M05006	Plain Washer M8	1
7	M36033	Flange Head Screw M8x20	1
8	M55043	Hex. Head Bolt M12x55-10.9	1
9	M05008	Plain Washer M12	3
10	B01030021	Bush Idler - 6204 Bearing	1
11	B03020008	Idler Sprocket Z15	1
12	M57033	Hex Head Screw M8x20-10.9	4
13	B03130002	End Cover Plate - Ear Auger Head	1
14	M01004	Hex Nut M10	8
15	M04008	Spring Washer M10	8
16	M35004	Bearing Housing UCF-206	2
17	M57049	Hex Head Screw M10x30-10.9	8
18	M22004	Bearing UC-206	2
19	M03033	Hex Head Screw M8x20	1
20	M01003	Hex Nut M8	2
21	B03100022	Sprocket Z-22	1
22	B03130003	Drive Chain Ear Auger	1

Item No.	Part No.	Part Name	Qty.
23	M14083	Gib Head Key 8x7x40	1
24	B03130001	Top Ear Auger	1
25	B03100007	Special Washer Ø 8 Ø16	1
26	M03047	Hex Head Screw M10x20	1
27	M16040	Ball Bearing 6204 ZZ	1
28	M11028	Internal Circlip B47	1
29	M04009	Spring Washer M12	1
30	M01005	Hex. Nut M12	1
31	B03100030	Shim 2mm	AR
32	B03100031	Shim 3 mm	AR
33	M05007	Plain Washer M10	1
34	M04008	Spring Washer M10	1
35	M03034	Hex Head Screw M8x25	1
36	M04007	Spring Washer M8	1
37	M03018	Hex Head Screw M6x16	2
38	M05005	Plain Washer M6	2
39	M01002	Hex. Nut M6	2
40	M36033	Flange Head Screw M8x20-10.9	4
41	M05006	Plain Washer M8	4
42	M01003	Hex Nut M8	4

GRAIN TANK

PLATE NO. 036






PREET AGRO IND. PVT. LTD.
GRAIN TANK

SPARE PARTS LIST
PREET 987
PLATE NO. 036

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B03140100	Grain Tank	1	27	M04007	Spring Washer M8	1
2	B03140024	Metal Clamp - 2 Hole	2	28	M01003	Hex Nut M8	1
3	M01003	Hex Nut M8	2	29	J0909001	Hinge	4
4	B03140004	Cover-Grain Tank Rear	1	30	M36033	Flange Head Screw M8x20	16
5	M01003	Hex Nut M8	8	31	M05006	Plain Washer M8	16
6	B03140025	Cover Stopper Bkt	1	32	M01003	Hex Nut M8	16
7	B03140002	Grain Tank Side Support	1	33	M36038	Flange Head Bolt M8x45-10.9	6
8	M36034	Flange Head Screw M8x25	8	34	M05006	Plain Washer M8	6
9	M05006	Plain Washer M8	2	35	M04007	Spring Washer M8	6
10	B03140006	Observation Glass	2	36	M28005	Nylock Nut M8	6
11	B03140005	Rubber Beading - Grain Tank	2	37	B03141100	Cable Passage	1
12	M01003	Hex Nut M8	8	38	M36034	Flange Head Screw M8x25	8
13	M04007	Spring washer M8	8	39	M28005	Nylock Nut M8	8
14	B03140001	Cover RHS - Grain Tank	1	40	M03049	Hex Head Screw M10x30	8
15	A06010004	Hinge	2	41	M05007	Plain Washer M10	16
16	M05006	Plain Washer M8	8	42	M01004	Hex Nut M10	8
17	M36033	Flange Head Screw M8x20	8	43	M03050	Hex Head Screw M10x35	10
18	B03140007	Mounting bracket (Stopper rod)	1	44	M05007	Plain Washer M10	20
19	B03140008	Cover Stopper rod	1	45	M04008	Spring Washer M10	10
20	B03140009	Stopper Rod clip	1	46	M01004	Hex Nut M10	10
21	B03141200	Cover RH-Grain Tank	1	47	B03140021	Mtg Angle LH-For Tensioner Assy	1
22	B03140023	Cover LH-Grain Tank	1	48	M36034	Flange Head Screw M8x25	8
23	B03140022	Middle Cover-Grain Tank	1	49	M05006	Plain Washer M8	8
24	B03141300	Mtg Angle RH Assy-Grain Discharge A	1	50	M04007	Spring Washer M8	8
25	M36033	Flange Head Screw M8x20	1	51	M01003	Hex Nut M8	8
26	M05006	Plain Washer M8	1				

GRAIN TANK

PLATE NO. 036






PREET AGRO IND. PVT. LTD.
GRAIN TANK

SPARE PARTS LIST
PREET 987
PLATE NO. 036

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B03140100	Grain Tank	1	27	M04007	Spring Washer M8	1
2	B03140024	Metal Clamp - 2 Hole	2	28	M01003	Hex Nut M8	1
3	M01003	Hex Nut M8	2	29	J0909001	Hinge	4
4	B03140004	Cover-Grain Tank Rear	1	30	M36033	Flange Head Screw M8x20	16
5	M01003	Hex Nut M8	8	31	M05006	Plain Washer M8	16
6	B03140025	Cover Stopper Bkt	1	32	M01003	Hex Nut M8	16
7	B03140002	Grain Tank Side Support	1	33	M36038	Flange Head Bolt M8x45-10.9	6
8	M36034	Flange Head Screw M8x25	8	34	M05006	Plain Washer M8	6
9	M05006	Plain Washer M8	2	35	M04007	Spring Washer M8	6
10	B03140006	Observation Glass	2	36	M28005	Nylock Nut M8	6
11	B03140005	Rubber Beading - Grain Tank	2	37	B03141100	Cable Passage	1
12	M01003	Hex Nut M8	8	38	M36034	Flange Head Screw M8x25	8
13	M04007	Spring washer M8	8	39	M28005	Nylock Nut M8	8
14	B03140001	Cover RHS - Grain Tank	1	40	M03049	Hex Head Screw M10x30	8
15	A06010004	Hinge	2	41	M05007	Plain Washer M10	16
16	M05006	Plain Washer M8	8	42	M01004	Hex Nut M10	8
17	M36033	Flange Head Screw M8x20	8	43	M03050	Hex Head Screw M10x35	10
18	B03140007	Mounting bracket (Stopper rod)	1	44	M05007	Plain Washer M10	20
19	B03140008	Cover Stopper rod	1	45	M04008	Spring Washer M10	10
20	B03140009	Stopper Rod clip	1	46	M01004	Hex Nut M10	10
21	B03141200	Cover RH-Grain Tank	1	47	B03140021	Mtg Angle LH-For Tensioner Assy	1
22	B03140023	Cover LH-Grain Tank	1	48	M36034	Flange Head Screw M8x25	8
23	B03140022	Middle Cover-Grain Tank	1	49	M05006	Plain Washer M8	8
24	B03141300	Mtg Angle RH Assy-Grain Discharge A	1	50	M04007	Spring Washer M8	8
25	M36033	Flange Head Screw M8x20	1	51	M01003	Hex Nut M8	8
26	M05006	Plain Washer M8	1				

GRAIN DISCHARGE AUGER

PLATE NO. 037






PREET AGRO IND. PVT. LTD.
GRAIN DISCHARGE AUGER

Item No.	Part No.	Part Name	Qty.
1	B03020009	Counter Sprocket Z14	1
2	M01003	Hex Nut M8	2
3	M03033	Hex Head Screw M8x20	2
4	B03150009	Drive Chain-Discharge Auger	1
5	B03150021	Spacer 30x40x3	1
6	M22004	Bearing UC-206	3
7	M35004	Bearing Housing UCF-206	3
8	B03150400	Pulley Assy 10"x1C with Coupling 30mm	1
9	B03150006	Grain Discharge Auger Shaft	1
10	M01004	Hex Nut M10	12
11	M05007	Plain Washer M10	12
12	M57049	Hex Head Screw M10x30-10.9	12
13	M39116	V-Belt C-87	1
14	B03150401	Pulley 10"x1C Coupling Type	1
15	B03121002	Pulley Coupling 30mm	1
16	M03050	Hex Head Screw M10x35	4
17	M40008	Grub Screw M10x20	1
18	B03150003	Gun Metal Bush	1
19	M03049	Hex Head Screw M10x30	2
20	M05007	Plain Washer M10	4
21	B03150300	Belt Guard Welded	1
22	M01004	Hex Nut M10	2
23	B03150020	Guard Mtg. Strip	1
24	M03034	Hex. Head Screw M8x25	1
25	B03150002	Drive Pin - Discharge Auger	1

SPARE PARTS LIST			
PREET 987			
PLATE NO. 037			
Item No.	Part No.	Part Name	Qty.
26	M05006	Plain Washer M8	6
27	B03150001	Discharge Grain Auger	1
28	M35003	Bearing Housing UCF-207	1
29	M22003	Bearing UC-207	1
30	M03038	Hex Head Screw M8x45	1
32	B01050006	Pulley Holder	1
33	M01004	Hex Nut M10	2
34	M57048	Hex Head Screw M10x25-10.9	2
35	M57070	Hex. Bolt M12x65-10.9	1
36	M05008	Plain Washer M12	2
37	B01030021	Idler Bush - 6204 Brg	1
38	B03020008	Idler Sprocket Z15	1
39	M16040	Ball Bearing 6204 ZZ	1
40	M11028	Internal Circlip B47	1
41	M03035	Hex Head Screw M8x30	4
42	M01005	Hex. Nut M12	1
43	M04009	Spring Washer M12	4
44	M03048	Hex. Head Screw M10x25	4
45	M01004	Hex. Nut M10	8
46	M05007	Plain Washer M10	8
47	B03150010	Cover	4
48	B03150100	Stay- Grain Tank Auger	1
49	M02039	Hex Head Bolt M12x35	4
50	M04009	Spring Washer M12	4
51	M01005	Hex. Nut M12	4

GRAIN DISCHARGE AUGER

PLATE NO. 037



80-A




PREET AGRO IND. PVT. LTD.
GRAIN DISCHARGE AUGER

SPARE PARTS LIST
PREET 987
PLATE NO. 038

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
52	B03010029	Spring Ø30x50	1				
53	M01003	Hex Nut M8	3				
54	B03150023	Belt Retainer	1				
55	B03150019	Guard Mtg Strip	1				
56	B03150027	Bearing Holding Plate	1				
57	M03030	Hex Head Screw M8x35	1				
58	M03035	Hex Head Screw M8x30	3				
59	M05006	Plain Washer M8	4				
60	M01003	Hex Nut M8	3				
61	M01005	Hex Nut M12	4				
62	M13015	Paraller Key 8x7x36	1				
63	B03150018	Flat Pulley	1				
64	B03150024	Rubber Flap - Flat Pulley	1				
65	B03150025	Holder-Rubber Flap	1				
66	B03150026	L-Shape Bkt	1				
67	B0405020001	Link Rod	1				
68	M05009	Plain Washer M16	2				
69	M01004	Hex Nut M10	4				

GRAIN DISCHARGE TUBE

PLATE NO. 038






PREET AGRO IND. PVT. LTD.
GRAIN DISCHARGE TUBE

Item No.	Part No.	Part Name	Qty.
1	M03049	Hex Head Screw M10x30	2
2	B03160011	Latch Assembly	1
3	M05007	Plain Washer M10	4
4	M01004	Hex Nut M10	2
5	M01004	Hex Nut M10	4
6	B03160010	Supporting Plate	1
7	M03049	Hex Head Screw M10x30	4
8	B03160009	Fork	1
9	A04030012	Pin	1
10	M31085	Split Pin 2.5x22	1
11	M01008	Hex Nut M16	7
12	B03160006	Tension Bar Upper	1
13	B03160007	Tension Bar Lower	1
14	B03160008	Angle	2
15	M03095	Hex Head Screw M16x50	2
16	M01003	Hex Nut M8	12
17	M04008	Spring washer B - 10	4
18	M05006	Plain Washer M8	24
19	M03032	Hex Head Screw M8x16	12
20	B03150003	Gun Metal Bush	1
21	B03160004	Flap	1
22	B03160100	Discharge Tube	1
23	M01003	Hex Nut M8	2
24	M03032	Hex Head Screw M8x16	2
25	B03160005	Discharge Auger	1
26	M55033	Hex Head Bolt M10x65 - 10.9	1
27	M13006	Parallel Key 8x7x30	1
28	M01004	Hex Nut M10	1

Item No.	Part No.	Part Name	Qty.
29	M01004	Hex Nut M10	2
30	M05007	Plain Washer M10	4
31	B03160300	Adjusting Bearing Bracket	1
32	M57050	Hex Head Screw M10x35 - 10.9	2
33	B03160002	Drive Auger	1
34	B03160001	Hinge Pin	1
35	M36034	Flange Head Flange Screw M8x25	16
36	M05006	Plain Washer M8	16
37	B03160200	Bracket Assy.	1
38	M04007	Spring Washer M-8	16
39	M01003	Hex Nut M8	16
40	M04008	Spring Washer M10	2
41	M05006	Plain Washer M8	4
42	M05007	Plain Washer M10	1
43	M03050	Hex Screw M10x35	4
44	M05007	Plain Washer M10	4
45	B03160900	Discharge Auger Mtg. Plate Assy	1
46	M28009	Nylock Nut M16	2
47	M05009	Plain Washer M16	3
48	M04008	Spring Washer M10	4
49	B03150015	Spring	1
50	M35003	Bearing Housong UCF 207	1
51	M22003	UC Bearing 207	1
52	M01004	Hex Nut M10	4

GRAIN DISCHARGE CLUTCH ASSY.

PLATE NO. 039






PREET AGRO IND. PVT. LTD.
GRAIN DISCHARGE CLUTCH ASSY.

SPARE PARTS LIST
PREET 987
PLATE NO. 039

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	A02040002	Rubber Cover	1	23	M55045	Hex Head Bolt M12x65 - 10.9	1
2	B03170100	Grain Discharge clutch lever	1	24	M31130	Split Pin 5x50	1
3	M28002	Nylock Nut M10	2	25	M13005	Parallel Key 8x7x25	1
4	M04008	Spring washer M10	1	26	M05014	PlainWasher M30	1
5	M28002	Nylock Nut M10	1	27	M03049	Hex Screw M10x30	2
6	B03170003	Adjusting Lever	1	28	M03049	Hex Screw M10x30	1
7	B03170008	Link Lever	1	29	M28002	Nylock Nut M10	1
8	M03049	Hex Head Screw M10x30	2	30	M57054	Hex Screw M10x55 - 10.9	1
9	B03170004	Angle Strip	2	31	M28002	Nylock Nut M10	1
10	M01005	Hex Nut M12	4	32	M01004	Hex Nut M10	2
11	B03170005	Connecting Rod	1	33	M02028	Hex bolt M10x40	1
12	M05007	Plain Washer M10	1	34	M01004	Hex Nut M10	1
13	B03170400	Lever	1	35	M03158	Hex Screw M10x100	1
14	B04040013	Spring - Clutch/ Brake Pedal	1	36	M04008	Spring washer M10	1
15	M01005	Hex Nut M12	1				
16	M05008	Plain Washer M12	2				
17	B03170009	Idler Mtg. Strip	1				
18	A01040012	Idle Pulley 5"	1				
19	M16040	Ball Bearing 6204 ZZ	1				
20	M11028	Internal Circlip B-47	1				
21	B01030021	Bush - Idler Pulley	1				
22	B03170007	Belt Guide	1				

DISCHARGE TUBE LOCK

PLATE NO. 040






PREET AGRO IND. PVT. LTD.

DISCHARGE TUBE LOCK

Item No.	Part No.	Part Name	Qty.
1	M03049	Hex Head Screw M10x30	2
2	M05007	Plain Washer M10	4
3	B03180007	Holding Bracket	1
4	M01004	Hex Nut M10	2
5	B03180002	Knob	1
6	B03180001	Lever Rod	1
7	B03180003	Lever	1
8	M05008	Plain Washer M12	1
9	M01005	Hex Nut M12	2
10	M44004	Plit Pin 3/32"x3/4"	2
11	B03180104	Pin	2
12	B03180101	Fork	2
13	B03180102	Hex Nut -1/4"	2
14	B03180103	Link Rod	1
15	M03054	Hex Head Screw M10x55	1
16	M05007	Plain Washer M10	2
17	B03180005	Lock	1
18	M03035	Hex Head Screw M8x30	1
19	M05006	Plain Washer M8	2
20	B03180006	Spring	1
21	M01003	Hex Nut M8	2
22	M03049	Hex Head Screw M10x30	3

PLATFORM & LADDER ASSY.

PLATE NO. 041






PREET AGRO IND. PVT. LTD.
PLATFORM & LADDER ASSY.

SPARE PARTS LIST
PREET 987
PLATE NO. 041

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M03035	Hex Head Screw M8x30	4	37	M01004	Hex Nut M10	4
2	M05006	Plain Washer M8	8	38	M02028	Hex.Bolt M10x40	2
3	M01002	Hex. Nut M6	4	39	M04007	Spring Washer M8	4
4	M01003	Hex Nut M8	4	40	B04010019	Gear Lever Guide Plate	1
5	B0401050100	Control Panel	1	41	M03034	Hex Head Screw M8x25	4
6	B04010400	Tool Box	2	42	M05006	Plain Washer M8	4
7	M03036	Hex Head Screw M8x35	4	43	M04007	Spring Washer M8	4
8	M05006	Plain Washer M8	8	44	M01003	Hex Nut M8	4
9	M01003	Hex Nut M8	4	45	M03158	Hex Head Screw M10x100	4
10	B04010014	Cover - Operation Lever	1	46	M05007	Plain Washer M10	10
11	M55031	Hex Head Bolt M10x55 - 10.9	2	47	M04008	Spring Washer M10	6
12	M28002	Nylock Nut M10	2	48	M01004	Hex. Nut M10	6
13	B0401050200	Ladder Mounting Bracket	1	49	B04011300	LHS Platform Support	1
14	M05007	Plain Washer M10	2	50	B04010018	RHS Platform Support	1
15	M05005	Plain Washer M6	4	51	M03048	Hex Head Screw M10x25	4
16	M36034	Flange Head Screw M8x25	2	52	M05007	Plain Washer M10	12
17	M28005	Nylock Nut M8	2	53	M28002	Nylock Nut M10	6
18	B0401050300	Ladder	1	54	M03049	Hex Head Screw M10x30	2
19	M01003	Hex Nut M8	15	55	M03034	Hex Head Screw M8x25	4
20	M05006	Plain Washer M8	30	56	M05006	Plain Washer M8	8
21	B04010001	Platform Holding Strip	1	57	M01003	Hex Nut M8	4
22	M03034	Hex Head Screw M8x25	15	58	M57050	Hex.Screw M10x35 - 10.9	2
23	B0401050400	Platform	1	59	M05007	Plain Washer M10	4
24	B0401050500	Ladder Release Lever	1	60	M01004	Hex Nut M10	2
25	B0401050600	Ladder Platform	1	61	M04008	Spring Washer M10	2
26	B0401050700	Swing Arm - Ladder	2	62	B0401050003	Light Casing LH	1
27	B0401050001	Swing Strip - Ladder	2	63	B0401050004	Light Casing RH	1
28	B0401050002	Lock Plate - Ladder	1	64	M36020	Flange Head Screw M6x25	14
29	M57176	Hex Screw M16x75 - 10.9	6	65	M05005	Plain Washer M6	14
30	M05009	Plain Washer M16	12	66	M01002	Hex. Nut M6	14
31	M28009	Nylock Nut M16	6	67	B0401050005	Front Hood	1
32	M03034	Hex Screw M8x25	2	68	M36020	Flange Head Screw M6x25	10
33	M05006	Plain Washer M8	4	69	M05005	Plain Washer M6	10
34	M01003	Hex Nut M8	2	70	M01002	Hex. Nut M6	10
35	M03049	Hex Head Screw M10x30	4	71	B0401050006	Hood Support Bracket	2
36	M05007	Plain Washer M10	4	72	M36020	Flange Head Screw M6x25	4

FAN ASSY. & MOUNTING

PLATE NO. 042







PREET AGRO IND. PVT. LTD.
FAN ASSY. & MOUNTING

Item No.	Part No.	Part Name	Qty.
1	M03049	Hex Head Screw M10x30	4
2	B04010901	Fan Mtg. Angle R.H	1
3	B04010902	Fan Mtg. Angle L.H	1
4	M22005	Bearing UC 205	2
5	M35007	Bearing Housing UCF 205	2
6	B04011200	Fan Casing	1
7	M36035	Flange Head Screw M8x30	3
8	M04007	Spring Washer M8	3
9	B04011002	Air Deflector	3
10	M01003	Hex Nut M8	3
11	B04011301	Fan Blade	4
12	B04011400	Spider	1
13	M36033	Flange Head Screw M8x20	8
14	M40002	Grub screw M8x20	2
15	M01003	Hex Nut M8	8
16	B04011300	Fan Assy.	1
17	B04011001	Fan Shaft	1
18	M13006	Parrallel Key 8x7x30	1
19	M14005	Gib Head Key 8x7x45	1
20	M03049	Hex Head Screw M10x30	8
21	M04008	Spring Washer B10	8
22	M01004	Hex Nut M10	8

RAILING & SUNTOP

PLATE NO. 043





PREET AGRO IND. PVT. LTD.

RAILING & SUNTOP

SPARE PARTS LIST

PREET 987


PLATE NO. 043

Item No.	Part No.	Part Name	Qty.
1	B04020300	Railing	1
2	M05007	Plain Washer M10	1
3	M04008	Spring Washer M-10	1
4	M03049	Hex Head Screw M10x30	1
5	B04020800	Front Support RH - Sun Top	1
6	B04020007	Middle Support - Sun Top	1
7	B04020002	Front Support LH - Sun Top	1
8	B04020005	Side View Mirror Mtg.	2
9	B04020100	Sun Top	1
10	B04020004	Side View Mirror	2
11	M02016	Hex Head Bolt M8x40	4
12	M05006	Plain Washer M8	8
13	M28005	Nylock Nut M8	4
14	M55021	Hex. Head Bolt M8x65-10.9	4
15	M05006	Plain Washer M8	8
16	M04007	Spring Washer M8	4
17	M01003	Hex Nut M8	4
18	M57034	Hex Head Screw M8x25-10.9	6
19	M05006	Plain Washer M8	12
20	B04020003	Side Railing LH	1
21	M01003	Hex Nut M8	6
22	B04020200	Rear Support Inner - Sun Top	2
23	K04020001	Rear Support Outer - Sun Top	2
24	A04020009	Water Jug	1
25	B04020006	Rear View Mirror	1
26	M03034	Hex Head Screw M8x25	1
27	M05006	Plain Washer M8	1
28	K04020002	Rear View Mirror Mtg.	1

Item No.	Part No.	Part Name	Qty.
29	M03049	Hex Screw M10x30	2
30	M04008	Spring Washer M10	2
31	M05007	Plain Washer M10	2
32	M03034	Hex Head Screw M8x25	4
33	M05006	Plain Washer M8	8
34	M01003	Hex Nut M8	4
35	M03035	Hex Head Screw M8x30	4
36	M05006	Plain Washer M8	8
37	M01003	Hex Nut M8	4
38	M03049	Hex Head Screw M10x30	4
39	M04008	Spring Washer M-10	4
40	M05007	Plain Washer M 10	4
41	B04021400	Side Railing RH	1
42	M03049	Hex Head Screw M10x30	1
43	M04008	Spring Washer B-10	1
44	M03034	Hex Head Screw M8x25	2
45	M05006	Plain Washer M8	4
46	M01003	Hex Nut M8	2
47	M03049	Hex Head Screw M10x30	1
48	M04008	Spring Washer M-10	1
49	M05007	Plain Washer M10	1
50	M55021	Hex. Head Bolt M8x65-10.9	2
51	M05006	Plain Washer M8	4
52	M01003	Hex Nut M8	2
53	M05007	Plain Washer M10	1

ENGINE RAILING

PLATE NO. 044






PREET AGRO IND. PVT. LTD.

ENGINE RAILING

DRIVER SEAT

PLATE NO. 045






PREET AGRO IND. PVT. LTD.

DRIVER SEAT

Item No.	Part No.	Part Name	Qty
1	M05006	Plain Washer M8	4
2	B04030201	Helper Back Cushion	1
3	B04030202	Helper Seat Cushion	1
4	B04030200	Helper Seat Assy.	1
5	A04010004	Driver Seat Assy.	1
6	M57034	Hex Head Screw M8x25 - 10.9	2
7	M05006	Plain Washer M8	4
8	B04030100	Seat Frame Assy.	1
9	M04007	Spring Washer M8	2
10	M01003	Hex Nut M8	2
11	M03048	Hex Screw M10x25 - 8.8	2
12	M05007	Plain Washer M10	2
13	M01004	Hex Nut M10	2
14	M28005	Nylock Nut M8	2
15	M03049	Hex Screw M10x30 - 8.8	6
16	M05007	Plain Washer M10	12
17	B04030001	Reinforcement - Helper Seat Mtg. Bkt.	1
18	M01004	Hex Nut M10	6
19	M04007	Spring Washer M-8	6
20	M01003	Hex Nut M8	4
21	B04030600	Mtg. Bkt. - Helper Seat Frame	1
22	B04030500	Resting Frame - Helper seat	1

CLUTCH PEDAL ASSY.

PLATE NO. 046





PREET AGRO IND. PVT. LTD.
CLUTCH PEDAL ASSY.

SPARE PARTS LIST

PREET 987

PLATE NO. 046


Item No.	Part No.	Part Name	Qty.
1	M36034	Flange Head Screw M8x25 - 10.9	8
2	M05006	Plain Washer M8	8
3	M01003	Hex Nut M8	8
4	B04090002	NYLON BUSH	1
5	M01003	Hex Nut M8	2
6	M44001	Split Pin 1/8"x1.0"	1
7	B04040005	Spring Mtg. Strip	1
8	B04040013	Spring - Clutch/Brake Pedal135x22x3.2	1
9	M03035	Hex Head Screw M8x30	1
10	B0404020100	Clutch Pedal	1
11	M03034	Hex Head Screw M8x25	1
12	M44013	Split Pin 5/32"x 2.0"	1
13	B0404020001	Clutch Pedal Shaft	1
14	M13005	Parallel Key 8x7x25	4
15	M01004	Hex. Nut M10	4
16	M04008	Spring Washer M10	4
17	B04040002	Nylon Bush Plate	2
18	M29001	Grease Nipple M8x1	2
19	B04050100	Lever	1
20	B04041100	Link Rod Weld	1
21	B04041200	Tie Rod Link (SHAPE CHANGE)	1
22	B03160009	Fork	2
23	M01005	Hex Nut M12	5
24	B04041400	Tie Rod	1
25	A04030012	Pin 10X30	5
26	M44001	Split Pin 1/8"x1.0"	5
27	B04041004	Washer 47x31x2.5	1
28	M05012	Plain Washer M25 (44.5x26x3)	1

Item No.	Part No.	Part Name	Qty.
29	B04060300	Lever	1
30	M55031	Hex Head Bolt M10x55 - 10.9	4
31	M44002	Split Pin 1/8"x1.5"	1
32	B04040600	Lever	1
33	M05010	Plain Washer M20	1
34	M28002	Nylock Nut M10	1
35	B04041005	L Bracket	1
36	B04041002	Tie Rod (SHAPE CHANGE)	1
37	B0404020002	Pin 20x70 - Clutch Link	1
38	M03049	Hex Head Screw M10x30	1
39	B04041300	Clutch Shaft	1
40	B04041001	Tie Rod 12"	1
41	M03033	Hex Head Screw M8x20	3
42	M05006	Plain Washer M8	3
43	B04040010	Braking Leather	1
44	B04040009	Braking Strip	1
45	M05008	Plain Washer M12	1
46	B04040014	Spring	1
47	M28002	Nylock Nut M10	1
48	M04007	Spring Washer M8	5
49	M01003	Hex Nut M8	3
50	M03034	Hex Head Screw M8x25	2
51	M05006	Plain Washer M8	4
52	M01003	Hex Nut M8	2

OIL BRAKE PEDAL ASSY.

PLATE NO. 047

L H





PREET AGRO IND. PVT. LTD.
OIL BRAKE PEDAL ASSY.

SPARE PARTS LIST

PREET 987


PLATE NO. 047

Item No.	Part No.	Part Name	Qty.
1	B0405020400	Brake Pedal Left	1
2	B0405020300	Brake Pedal Right	1
3	M04008	Spring Washer M10	1
4	M05007	Plain Washer M10	8
5	M57048	Hex. Screw M10x25-10.9	1
6	B04040013	Spring - Clutch/Brake Pedal	2
7	M01003	Hex. Nut M8	4
8	B04040005	Spring Mtg Strip	2
9	A04030012	Pin Ø10x30	10
10	M44013	Split Pin 5/32" x2"	10
11	A04030010	Fork 12 mm	6
12	M01005	Hex. Nut M12	8
13	B0405020001	Link Rod 12 mm	2
14	B04040002	Nylon Bush Plate	4
15	M01003	Hex. Nut M8	16
16	M05006	Plain Washer M8	16
17	M03033	Flange Head Screw M8x20	16
18	B04050100	Brake Lever	4
19	M05008	Spring Washer M10	7
20	M01004	Hex. Nut M10	7
21	M55031	Hex. Head Bolt M10x55-10.9	7
22	B0405020008	Counter Brake Shaft RH	1
23	M44001	Split Pin 1/8"x1.0"	4
24	B0405020009	Brake Lever-Upper	2
25	B0405020200	Tie Rod Assy-RH	1
26	B0405020012	Brake Lever-Lower	2
27	B0405020100	Brake Shaft Weld LH	1
28	B0405020011	Special Nut	4
29	B0405020003	Pin Dia 10x40	2

Item No.	Part No.	Part Name	Qty.
30	M05012	Plain Washer M25	4
31	B0405020500	Brake Shaft Weld RH	1
32	M44013	Split Pin 5/32" x2"	1
33	M05007	Plain Washer M10	10
34	B0405020002	Brake Adjusting Rod	2
35	B0405020006	Swivel Bracket	4
36	B0405020004	L-Lever	4
37	M28002	Nylock Nut M10	8
38	M29001	Grease Nipple M8x1	7
39	M05014	Plain Washer M30	4
40	M55031	Hex. Head Bolt M10x55-10.9	1
41	M04008	Spring Washer M10	1
42	M01004	Hex. Nut M10	1
43	B0405020007	Brake Pedal Shaft	1
44	M13014	Parallel Key 8x7x20	8
45	M03035	Hex Head Screw M8x30	2
46	M03049	Hex Head Screw M10x30	8
47	B0405020010	Counter Brake Shaft LH	1
48	B0405021100	Holding Bkt LH-Break Shaft	1
49	B0405021000	Holding Bkt RH-Break Shaft	1
50	B0405020800	L-Type Holding Bkt-Break Shaft	2
51	B0405020900	Tie Rod Assy-LH	1
52	B03080022	Spacer Ø40xØ30x10	1
53	M03033	Hex Head Screw M8x20	2
54	M58019	Special Washer Ø 10 Ø 52	2
55	B03010010	Special Plain Washer Ø50.5xØ11x2	1
56	M58037	Special Washer Ø 0 Ø 13	1
57	M44004	Split Pin 3/32"x3/4"	8
58	M44006	Split Pin 5/32"x1.5"	4

LIGHTS

PLATE NO. 048





PREET AGRO IND. PVT. LTD.
LIGHTS

SPARE PARTS LIST


PREET 987

PLATE NO. 048

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B04070701	High Beam Lamp Bulb	1	23	B04070024	Number Plate	2
2	B04070700	High Beam Lamp Assy.	1	24	B04070025	Reflector Red	2
3	B04070801	Suntop Lamp Bulb	2	25	B04071600	Tail Lamp Assy. LH - LED	1
4	B04070800	Suntop Lamp Assy.	2	26	M36018	Flange Head Screw M6x16	4
5	B04070101	Working Lamp Bulb	9	27	B01010011	Reflector Mtg. Bkt.	2
6	B04070100	Working Lamp Assy.	9	28	M01002	Hex Nut M6	4
7	M36018	Flange head Screw M6x16	4	29	B04070026	Brake Switch Mtg. Bkt	1
8	M05005	Plain Washer M6	4	30	M36032	Flange Head Screw M8x16	1
9	B04070901	Number Plate Lamp Bulb	2	31	M05006	Plain Washer M8	1
10	B04070900	Number Plate Lamp Assy.	2	32	M01003	Hex Nut M8	1
11	B04070401	Bulb	2				
12	B04070402	Bulb	3				
13	B04071700	Tail Lamp Assy RH - LED	2				
14	A04040005	Reverse Gear Switch	1				
15	B04071300	Head Light Assy. - LH	1				
16	B04071201	Bulb	2				
17	B04071202	Bulb	2				
18	B04071203	Bulb	2				
19	M03036	Hex. Screw M8x35	1				
20	A04040011	Horm Assembly (Set)	2				
21	B04071200	Head Light Assy. - RH	1				
22	B04071000	Head Light Assy. - Set	1				

INSTRUMENTS & SWITCHES

PLATE NO. 049






PREET AGRO IND. PVT. LTD.

INSTRUMENTS & SWITCHES

INSTRUMENTS & SWITCHES (LAYLAND) PLATE NO. 049



103A



PREET AGRO IND. PVT. LTD.
INSTRUMENTS & SWITCHES (LAYLAND)


SPARE PARTS LIST

PREET 987

PLATE NO. 049

ELECTRICAL HARNESS

PLATE NO. 050






PREET AGRO IND. PVT. LTD.

ELECTRICAL HARNESS

GEAR SHIFTER ASSY.

PLATE NO. 051





PREET AGRO IND. PVT. LTD.

NEW GEAR SHIFTER ASSY.

SPARE PARTS LIST


PREET 987

PLATE NO. 051

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B04061001	Knob - Gear Lever	1	31	M28002	Nylock Nut M10	2
2	M01073	Hex. Nut M12x1.25	6	32	M04008	Spring Washer M10	2
3	B04090500	Lever - Gear Shifter	1	33	B04040400	Lever	1
4	M30051	Slotted Nut M12x1.25	6	34	M55031	Hex Head Bolt M10x55-10.9	1
5	M28003	Nylock Nut M12	1	35	M05007	Plain Washer M10	4
6	B04091300	Mtg. Bracket - Gear Shifter Lever Big	1	36	M55031	Hex Head Bolt M10x55-10.9	1
7	M01003	Hex Nut M8	4	37	M02028	Hex Head Bolt M10x40	1
8	M02029	Hex Head Bolt M10x45	2	38	B04090011	Pin 20x90	1
9	M05006A	Plain Washer M8	8	39	B04090200	Gear Shifter Lever Big	1
10	B04090015	Spacer Plate	1	40	M29008	Grease Nipple M6 Type-A	1
11	B04061002	Gear Shifter Lever Bolt	1	41	B04091500	Lever Rod Left	1
12	M03034	Hex Head Screw M8x25	4	42	B04091600	Lever Rod Right	1
13	B04090700	Mtg. Bracket-Gear Shifter Lever	1	43	B04091000	Gear Shifter Shaft - Lower	1
14	B04090006	Pin 20x55	1	44	B04090004	Supporting Plate 2	1
15	M44005	Split Pin 5/32"x1.0"	1	45	B04090014	Mtg Angle-Gear Shifter Bkt	1
16	M05010	Plain Washer M20	1	46	M01005	Hex Nut M12	1
17	B04090100	Gear Shifter Lever Small	1	47	M28002	Nylock Nut M10	2
18	B04090002	Nylon Bush	1	48	B04090002	Nylon Bush	2
19	M44002	Split Pin 1/8" x 1.5"	6	49	M44005	Split Pin 5/32"x1.0"	1
20	B04090008	TIE Rod End	6	50	M13005	Parallel Key 8x7x25	1
21	B04091700	Tie Rod Assy - Gear Shifter	1	51	M04008	Spring Washer M10	1
22	B04090010	Locking Bush	2	52	M04008	Spring Washer M10	2
23	M40010	Grub Screw M8x8	4	53	M28002	Nylock Nut M10	1
24	B04090001	Supporting Plate	3	54	M04007	Spring Washer M8	4
25	M13005	Parallel Key 8x7x25	2	55	M03034	Hex Head Screw M8x25	6
26	B04090300	Gear Shifter Shaft - Upper	1	56	M05006	Plain Washer M8	12
27	M03035	Hex Head Screw M8x30	6	57	M04007	Spring Washer M8	6
28	M05006	Plain Washer M8	6	58	M01003	Hex Nut M8	6
29	M05007	Plain Washer M10	4	59	M05008	Plain Washer M12	2
30	M28005	Nylock Nut M8	6	60	M58039	Special Washer Ø26xØ35x1.5	2

GEAR SHIFTER ASSY.

PLATE NO. 052






PREET AGRO IND. PVT. LTD.
GEAR SHIFTER ASSY.

SPARE PARTS LIST
PREET 987
PLATE NO. 052

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B04060100	Gear Lever 1-R	1	23	M31097	Split Pin 5x25	1
2	A02040002	Rubber Cover	2	24	B04060004	Pivot Pin	1
3	B04060200	Gear Lever 2-3	1	25	B04060010	Lever Rod	2
4	M31130	Split Pin	2	26	B04060600	Lever Rod	1
5	M13005	Parallel Key 8x7x25	2				
6	M03035	Hex Head Screw M8x30	8				
7	M05006	Plain Washer M8	16				
8	B04060001	Bush Plate	2				
9	M04007	Spring Washer M-8	8				
10	M01003	Hex Nut M8	8				
11	B04060002	Special Washer	2				
12	M02033	Hex Head Bolt M10x65	2				
13	M04008	Spring Washer M-10	4				
14	B04060300	Lever	2				
15	M01004	Hex Nut M10	2				
16	M31095	Split Pin	8				
17	A04030012	Pin	8				
18	B04060400	Lever Rod	1				
19	K04060001	Stud M12 x 150	2				
20	M01005	Hex Nut M12	8				
21	A04030010	Fork	6				
22	B04060003	Lever	2				

ENGINE & MOUNTINGS

PLATE NO. 053






PREET AGRO IND. PVT. LTD.
ENGINE AND MOUNTINGS

SPARE PARTS LIST
PREET 987
PLATE NO. 053

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B0501030100	Engine 133 HP trem IV comp. Package - Leyland	1	23	M05009	Plain Washer M16	8
2	B05010031	Bush Ø40xØ25x12	1	24	M55184	Hex Head Bolt M16x100-10.9	4
3	M28003	Nylock Nut M12	8	25	M05008	Plain Washer M12	8
4	M05009	Spring Washer M12	8	26	B05010016	Hex Screw 1/2"x20BSFx1-1/4"	16
5	B0501020001	Fly Wheel Plate	1	27	B05010601	Bell Housing Knob	1
6	B05010010	Coupling	1	28	M04009	Spring Washer M12	8
7	M57065	Hex Head Screw M12x40-10.9	8	29	M03065	Hex Head Screw M12x40	8
8	B05010701	Bell Housing Flange	1	30	M57048	Hex Head Screw M10x25-10.9	8
9	M04008	Spring Washer M10	12	31	M04008	Spring Washer M10	8
10	M68007	Hex. Screw 3/8"x16BSFx1.25"	12	32	M04015	Spring Washer M14	16
11	M12017	Oil Seal 80x60x10	1	33	M05007	Plain Washer M10	12
12	M10034	External Circlip A60	2	34	M57063	Hex Head Screw M12x30-10.9	8
13	B05010017	Spacer Ø80xØ60x4	1	35	M04009	Spring Washer M12	8
14	M15019	Ball Bearing 6312	1	36	M28003	Nylock Nut M12	8
15	B05010015	MD Shaft	1	37	A05010017	AVM Pad	4
16	M12018	Oil Seal 130x100x12	1	38	M28009	Nylock Nut M16	4
17	M11062	Internal Circlip B130	1	39	B0501030200	Engine Mtg. Frame	1
18	B05010014	Engine Pulley	1	40	B0501030300	Engine Mtg. Bkt. RH	2
19	M04009	Spring Washer M12	8	41	B0501020002	Locking Plate	1
20	M55042	Hex. Head Bolt M12x50 - 10.9	8	42	M36029	Flange Head Screw M8x10	2
21	M29001	Grease Nipple M8x1 Type-A	1	43	B0501030500	Engine Mtg. Bkt. LH Rear	1
22	B0501030400	Engine Mtg. Bkt. LH Front	1	44	M57050	Hex Head Screw M10x35-10.9	12

ENGINE & MOUNTINGS

PLATE NO. 053






PREET AGRO IND. PVT. LTD.

ENGINE AND MOUNTINGS

SPARE PARTS LIST
PREET 987
PLATE NO. 053

ENGINE & MOUNTINGS (PREET)

PLATE NO. 054





PREET AGRO IND. PVT. LTD.
ENGINE AND MOUNTINGS

SPARE PARTS LIST


PREET 987

PLATE NO. 054

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B0501090100	Engine BS IV - 6 Cylinder (Preet)	1	23	M05009	Plain Washer M16	8
2	B05010031	Bush Ø40xØ25x12	1	24	M55184	Hex Head Bolt M16x100-10.9	4
3	M28003	Nylock Nut M12	8	25	M05008	Plain Washer M12	8
4	M05009	Spring Washer M12	8	26	B05010016	Hex Screw 1/2"x20BSFx1-1/4"	16
5	B0501020001	Fly Wheel Plate	1	27	B05010601	Bell Housing Knob	1
6	B05010010	Coupling	1	28	M04009	Spring Washer M12	8
7	M57065	Hex Head Screw M12x40-10.9	8	29	M03065	Hex Head Screw M12x40	8
8	B05010701	Bell Housing Flange	1	30	M57048	Hex Head Screw M10x25-10.9	8
9	M04008	Spring Washer M10	12	31	M04008	Spring Washer M10	8
10	M68007	Hex. Screw 3/8"x16BSFx1.25"	12	32	M04015	Spring Washer M14	16
11	M12017	Oil Seal 80x60x10	1	33	M05007	Plain Washer M10	12
12	M10034	External Circlip A60	2	34	M57063	Hex Head Screw M12x30-10.9	8
13	B05010017	Spacer Ø80xØ60x4	1	35	M04009	Spring Washer M12	8
14	M15019	Ball Bearing 6312	1	36	M28003	Nylock Nut M12	8
15	B05010015	MD Shaft	1	37	A05010017	AVM Pad	4
16	M12018	Oil Seal 130x100x12	1	38	M28009	Nylock Nut M16	4
17	M11062	Internal Circlip B130	1	39	B0501030200	Engine Mtg. Frame	1
18	B05010014	Engine Pulley	1	40	B0501030300	Engine Mtg. Bkt. RH	2
19	M04009	Spring Washer M12	8	41	B0501020002	Locking Plate	1
20	M55042	Hex. Head Bolt M12x50 - 10.9	8	42	M36029	Flange Head Screw M8x10	2
21	M29001	Grease Nipple M8x1 Type-A	1	43	B0501030500	Engine Mtg. Bkt. LH Rear	1
22	B0501030400	Engine Mtg. Bkt. LH Front	1	44	M57050	Hex Head Screw M10x35-10.9	12

ENGINE & MOUNTINGS (PREET)

PLATE NO. 054





PREET AGRO IND. PVT. LTD.

ENGINE AND MOUNTINGS


SPARE PARTS LIST

PREET 987

PLATE NO. 055

AIR INTAKE MOUNTING

PLATE NO. 055





PREET AGRO IND. PVT. LTD.

AIR INTAKE MOUNTING


SPARE PARTS LIST

PREET 987

PLATE NO. 055

EXHAUST SUPPORT

PLATE NO. 056





PREET AGRO IND. PVT. LTD.
EXHAUST SUPPORT

SPARE PARTS LIST

PREET 987


PLATE NO. 056

Item No.	Part No.	Part Name	Qty.
1	B0503030001	Top Cover-Exhaust Assy	1
2	M36033	Flange Head Screw M8x20	4
3	M05006A	Plain Washer M8	4
4	B0503030100	Mtg Bkt- Top Cover	2
5	B0503030200	Upper Clamp Big	2
6	B0503030300	Upper Clamp Small	2
7	B0503030400	Lower Clamp Big	2
8	B0503030500	Lower Clamp Small	2
9	M36033	Flange Head Screw M8x20	4
10	M05006A	Plain Washer M8	4
11	M01003	Hex Nut M8	4
12	M02028	Hex Head Bolt M10x40	8
13	M05007	Plain Washer M10	16
14	M04008	Spring Washer M10	8
15	M28002	Nylock Nut M10	8
16	M57049	Hex Head Screw M10x30-10.9	8
17	M05007	Plain Washer M10	16
18	M04008	Spring Washer M10	8
19	M28002	Nylock Nut M10	8
20	P6M012800500	Radiator Buffer With Nut	4
21	B0503030002	Mtg Plate-Exhaust Assy	1
22	B0503030003	Supporting Strip - Exhaust Mtg.	2

Item No.	Part No.	Part Name	Qty.
23	M28005	Nylock Nut M8	2
24	M05006	Plain Washer M8	4
25	M03034	Hex Head Screw M8x25	2
26	B0503030004	Front Stay - Exhaust Assy	1
27	M28003	Nylock Nut M12	4
28	M04009	Spring Washer M12	4
29	M57063	Hex Head Screw M12x30-10.9	4
30	M03052	Hex Head Screw M10x45	4
31	M05007	Plain Washer M10	4
32	M04008	Spring Washer M10	4
33	M01004	Hex Nut M10	4
34	B0503030008	Front Stay - Exhaust Assy	8
35	M01003	Hex Nut M8	8
36	M05006A	Plain Washer M8	8
37	M04007	Spring Washer M8	8
38	B0503030005	Rear Stay - Exhaust Assy	1

EXHAUST SYSTEM (PREET)

PLATE NO. 057





PREET AGRO IND. PVT. LTD.

EXHAUST SYSTEM (PREET)


SPARE PARTS LIST

PREET 987

PLATE NO. 057

RADIATOR & MOUNTING

PLATE NO. 058





PREET AGRO IND. PVT. LTD.
RADIATOR AND MOUNTINGS

SPARE PARTS LIST


PREET 987

PLATE NO. 058

Item No.	Part No.	Part Name	Qty.		Item No.	Part No.	Part Name	Qty.
1	B0504010001	Supporting Strip - Radiator	2		23	M01003	Hex. Nut M8	3
2	P6M012801700	Hose Pipe	4					
3	P6M012801300	Coolant , Engine to Radiator	1					
4	P6M012800100	Radiator	1					
5	M26014	Hose Pipe Clamp 60	8					
6	B05040020	Special Washer	4					
7	B03060015	Rubber Bush - 17.5 x 39 x 36						
8	P6M012800300	Pipe Support Front	1					
9	P6M012800400	Pipe Support Rear	1					
10	P6M012800600	Bracket - stay Radiator	1					
11	M02041	Hex. Bolt M8x60	3					
12	M05006	Plain Washer M8	6					
13	M28005	Nylock M8	2					
14	M01003	Hex. Nut M8	1					
15	M02027	Hex. Bolt M10x35	2					
16	M05007	Pain Washer M10	4					
17	M01004	Hex. Nut M10	2					
18	M02045	Hex. Head Bolt M12x65	2					
19	M05008	Pain Washer M12	4					
20	M01005	Hex. Nut M12	2					
21	M36034	Flange Hex. Head Screw M8x25	3					
22	M05006	Plain Washer M8	6					

FUEL TANK (LAYLAND TYPE)

PLATE NO. 059





PREET AGRO IND. PVT. LTD.
FUEL TANK(LAYLAND TYPE)


SPARE PARTS LIST
PREET 987
PLATE NO. 059

Item No.	Part No.	Part Name	Qty.
1	M23006	Copper Washer 14x20x1.5	16
2	M25006	Banjo Bolt M14x1.5	8
3	M03036	Hex Screw M8x35	2
4	M05007	Plain Washer M10	4
5	M01004	Hex Nut M10	4
6	B05050002	Rubber Flap	2
7	B05050003	Supporting Strip	2
8	M05007	Plain Washer M10	4
9	M04007	Spring Washer M8	2
10	M57049	Hex Head Screw M10x30-10.9	2
11	B0505020102	Diesel Pipe (Water Separator To Filter)	1
12	B05050010	Water Separator	1
13	B0505020101	Diesel Pipe - Tank To Water Separator	1
14	A05050004	Drain Plug M14x1.5	2
15	B0505020103	Diesel Pipe - Filter To Engine	1
16	M01004	Hex Nut M10	1
17	B05050011	Supporting Strip - Fuel Tank Mtg.	1
18	M03051	Hex Head Screw M10x40	1
19	M01004	Hex Nut M10	1
20	B05050700	Fuel Tank Mtg. Frame	1
21	M01004	Hex Nut M10	4
22	M05007	Plain Washer M10	8

Item No.	Part No.	Part Name	Qty.
23	M03049	Hex Head Screw M10x30	4
24	M26002	Hose Clamp 16	2
25	B05050001	Fuel Level Pipe	1
26	B05050100	Fuel Tank	1
27	B05050005	Fuel Tank Cap	1
28	B05050800	Fuel Tank with Cap	1
29	B0505020104	Diesel Pipe - Return	1
30	M05006A	Plain Washer M8	4
31	M01003	Hex Nut M8	2
32	M04008	Spring Washer M10	2
33	M04008	Spring Washer M10	2
34	M05007	Plain Washer M10	4
35	M04008	Spring Washer M10	4
36	M03049	Hex Screw M10x30	1
37	B05050007	Diesel filter	1
38	B0505020100	Diesel Pipe Set	1

FUEL TANK (PREET TYPE)

PLATE NO. 060






PREET AGRO IND. PVT. LTD.
FUEL TANK (PREET TYPE)

Item No.	Part No.	Part Name	Qty.
1	M23006	Copper Washer 14x20x1.5	12
2	M25006	Banjo Bolt M14x1.5	6
3	M03036	Hex Screw M8x35	2
4	M05007	Plain Washer M10	4
5	M01004	Hex Nut M10	4
6	B05050002	Rubber Flap	2
7	B05050003	Supporting Strip	2
8	M05007	Plain Washer M10	4
9	M04007	Spring Washer M8	2
10	M57049	Hex Head Screw M10x30-10.9	2
11	B0505020102	Diesel Pipe (Water Separator To Filter)	1
12	B05050010	Water Separator	1
13	B0505020101	Diesel Pipe - Tank To Water Separator	1
14	A05050004	Drain Plug M14x1.5	2
15	M23010	Copper Washer 16x22x2	1
16	M01004	Hex Nut M10	1
17	B05050011	Supporting Strip - Fuel Tank Mtg.	1
18	M03051	Hex Head Screw M10x40	1
19	M01004	Hex Nut M10	1
20	B05050700	Fuel Tank Mtg. Frame	1
21	M01004	Hex Nut M10	4
22	M05007	Plain Washer M10	8

SPARE PARTS LIST			
PREET 987			
PLATE NO. 060			
Item No.	Part No.	Part Name	Qty.
23	M03049	Hex Head Screw M10x30	4
24	M26002	Hose Clamp 16	2
25	B05050001	Fuel Level Pipe	1
26	B05050100	Fuel Tank	1
27	B05050005	Fuel Tank Cap	1
28	B05050800	Fuel Tank with Cap	1
29	B0505020104	Diesel Pipe - Return	1
30	M05006A	Plain Washer M8	4
31	M01003	Hex Nut M8	2
32	M04008	Spring Washer M10	2
33	M04008	Spring Washer M10	2
34	M05007	Plain Washer M10	4
35	M04008	Spring Washer M10	4
36	M03049	Hex Screw M10x30	1
37	B05050014	Adaptor - Fuel cock	
38	B05050013	Fuel Cock	1
39	B0505020100	Diesel Pipe Set	1

ROTARY SIEVE MOUNTING

PLATE NO. 061





PREET AGRO IND. PVT. LTD.
ROTARY SIEVE MOUNTING

SPARE PARTS LIST

PREET 987


PLATE NO. 061

Item No.	Part No.	Part Name	Qty.
1	B0508010100	Fan Cover Assy.	1
2	B0508010600	Base Cover assy.	1
3	M86010	Mushroom Head Screw M6x16	12
4	M04006	Spring Washer M6	12
5	M01002	Hex Nut M6	12
6	M39106	V-Belt A-61	1
7	B0508010500	Base Cover Mtg Assy.	1
8	B0508010002	Bearing Mtg Plate 1	2
9	M41008	Carriage Screw M8x25	10
10	M05006	Plain Washer M8	10
11	M01003	Hex Nut M8	10
12	M35007	Bearing UCF 205	2
13	M03050	Hex Head Screw M10x35	6
14	M04007	Spring Washer M8	6
15	M01008	Hex. Nut M10	6
16	B0508010004	Support	2
17	B0508010400	Shaft with Coupling - Rotary Sieve	1
18	B0508010012	Pulley - Ø225x25B	1
19	B0508010300	Rotary Air sieve	1
20	M03034	Hex. Head Screw M8x25	6
21	M05007	Plain Washer M10	6
22	M40002	Grub Screw M8x20	2
23	M13005	Parallel Key 8x7x25	1

Item No.	Part No.	Part Name	Qty.
24	M02028	Hex Head Bolt M10x40	2
25	M04008	Spring Washer M10	2
26	M01004	Hex Nut M10	2
28	B0508010010	Round Brush - Rotary Sieve	1
29	M05006	Plain Washer M8	2
30	M04007	Spring Washer M8	2
31	B0508010700	Brush Straight with Mtg Strip	1
32	M03019	Hex Head Screw M6x20	2
33	M05005	Plain Washer M6	4
34	M05005	Plain Washer M6	2
35	M28004	Nylock Nut M6	2
36	B0508010017	Brush Mtg Angle	1
37	M03033	Hex Head Screw M8x20	2
38	B0508011000	Top Cover - Rotary Fan Cover	1
39	A03050019	Clamp	1
40	M36018	Flange Head Screw M6x16	2
41	M05005	Plain Washer M6	2
42	M01002	Hex Nut M6	2
43	A03050019	Clamp Bracket	1
44	M36019	Flange Head Screw M6x20	2
45	M05005	Plain Washer M6	2
46	M01002	Hex Nut M6	2

ROTARY SIEVE MOUNTING

PLATE NO. 061





PREET AGRO IND. PVT. LTD.

ROTARY SIEVE MOUNTING


SPARE PARTS LIST

PREET 987

PLATE NO. 061

ROTARY SIEVE DRIVE

PLATE NO. 062





PREET AGRO IND. PVT. LTD.

ROTARY SIEVE DRIVE

SPARE PARTS LIST


PREET 987

PLATE NO. 062

Item No.	Part No.	Part Name	Qty.
1	B0509010100	Mounting Stand	1
2	M28003	Hex Nylock Nut M10	2
3	B0509010200	Shaft Mtg. Bkt.	1
4	M98001	Flange Bearing 205	2
5	M03034	Hex. Screw M10x30	8
6	M40002	Grub Screw M8x20	2
7	M14001	Gib Head Key 8x7x36	1
8	B0508010013	Drive Pulley - Rotary Sieve	1
9	B0509010001	Drive Shaft - Rotary Sieve	1
10	M04007	Spring Washer M10	8
11	M01003	Nylock Nut M10	8
12	M03157	Hex. Screw M12x100	1
13	M40002	Grub Screw M8x20	2
14	B0508010012	Pulley	1
15	M39125	V Belt A33	1
16	B0509010002	Pulley	1
17	M28002	Hex Nut M10	3
18	M04008	Spring Washer B10	3
19	M05007	Punched Washer M10	6
20	M03049	Hex. Screw M10x30	3
21	M03063	Hex. Screw M12x30	2
22	M01005	Hex Nut M12	1

UREA TANK

PLATE NO. 063






PREET AGRO IND. PVT. LTD.

UREA TANK

SPARE PARTS LIST

PREET 987

PLATE NO. 063





PREET AGRO IND. PVT. LTD.
SHIELDS

SPARE PARTS LIST


PREET 987

PLATE NO. 064

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M36033	Flange Head Screw M8x20	24	23	B06010018	Shield Spring Lock	2
2	A06010004	Hinge	6	24	M01003	Hex. Nut M8	2
3	M05006	Plain Washer M8	24	25	M05006	Plain Washer M8	2
4	M04007	Spring Washer M8	24	26	M04007	Spring Washer M8	2
5	M01003	Hex Nut M8	24	27	M36034	Flange Head Screw M8x25	2
6	B06010001	Shield-LH	1	28	B06010009	Shield Clamp Mounting-LH	1
7	B06010004	Shield-RH	1	29	M36034	Flange Head Screw M8x25	2
8	M28005	Nylock Nut M8	6	30	B06010021	Shield Spring Lock Mtg. LH	1
9	M05006	Plain Washer M8	12	31	M04007	Spring Washer M8	2
10	M02021	Hex Head Bolt M8x65	6	32	M01003	Hex Nut M8	2
11	B06010005	Shield Stay Square Tube	2	33	M05006	Plain Washer M8	2
12	B06010007	Shield Stay Mtg. LH	2	34	B06010019	Shield Stopper	2
13	B06010006	Shield Stay Channel	2	35	M01002	Hex Nut M6	4
14	A03050019	Shield Clamp	2	36	M04006	Spring Washer M6	4
15	M01002	Hex Nut M6	2	37	M05005	Plain Washer M8	8
16	M05005	Plain Washer M6	2	38	M36018	Flange Head Screw M6x20	4
17	B06010026	Clamp Mtg Bkt	2	39	B06010027	Shield Spring Lock Mtg. LH	1
18	M36018	Flange Head Screw M6x16	2				
19	M01002	Hex Nut M6	4				
20	M04006	Spring Washer M6	4				
21	M05005	Plain Washer M6	4				
22	M36018	Flange Head Screw M6x16	4				

ENGINE SIDE COVER WITH ROTARY SIEVE

PLATE NO. 065





PREET AGRO IND. PVT. LTD.

ENGINE SIDE COVER WITH ROTARY SIEVE


SPARE PARTS LIST

PREET 987

PLATE NO. 065

TAIL COVER

PLATE NO. 066





PREET AGRO IND. PVT. LTD.

TAIL COVER


SPARE PARTS LIST

PREET 987

PLATE NO. 066

STRAW WALKER COVER

PLATE NO. 067





PREET AGRO IND. PVT. LTD.

STRAW WALKER COVER

SPARE PARTS LIST


PREET 987

PLATE NO. 067

PREET AGRO IND. PVT. LTD.				SPARE PARTS LIST			
STRAW WALKER COVER				PREET 987			
				PLATE NO. 067			
Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B06040300	Ladder - Rear	1	23	M28002	Nylock Nut M10	2
2	M57049	Hex Head Screw M10x30-10.9	3	24	B06040003	Mtg. Bracket - Rear Ladder	1
3	M05007	Plain Washer M10	6	25	M01004	Hex Nut M10	2
4	M28002	Nylock Nut M10	3	26	M04008	Spring Washer M10	2
5	B06040200	Straw Walker Cover Front	1	27	M05007	Plain Washer M10	4
6	M55033	Hex Head Bolt M10x65-10.9	2	28	M57049	Hex Screw M10x30-10.9	2
7	M03034	Hex Head Screw M8x25	28	29	B06040004	Lower Step - Rear Ladder	1
8	M05006A	Plain Washer M8	56	30	B04040013	Spring - Clutch/ Brake Pedal	1
9	M04007	Spring Washer M8	28	31	M28005	Nylock Nut M8	2
10	M01003	Hex Nut M8	28	32	M03035	Hex Screw M8x30	2
11	B06040100	Straw Walker Cover Top	1	33	M05006	Plain Washer M8	2
12	M03034	Hex Head Screw M8x25	5	34	A01060010	Clamp Plate	1
13	M05006A	Plain Washer M8	10	35	M05006	Plain Washer M8	1
14	M04007	Spring Washer M8	5	36	M01003	Hex Nut M8	1
15	M01003	Hex Nut M8	5				
16	M03034	Hex Head Screw M8x25	10				
17	M05006	Plain Washer M8	20				
18	M04007	Spring Washer M8	10				
19	M01003	Hex Nut M8	10				
20	M04008	Spring Washer M10	3				
21	M05007	Plain Washer M10	2				
22	M04008	Spring Washer M10	2				

SMS-TRANSMISSION ASSY.

PLATE NO. 067 - A





PREET AGRO IND. PVT. LTD.
SMS-TRANSMISSION ASSY.


SPARE PARTS LIST
PREET 987
PLATE NO. 067-A

Item No.	Part No.	Part Name	Qty.
1	B0607010001	Adaptor-Sms Main Drive Pulley	1
2	B0607010002	Main Drive Pulley	1
3	M02163	Head Hex Bolt M12x120	6
4	M39157	V Belt C-121	2
5	M03063	Hex Head Screw M 12X30	1
6	M03051	Hex Head Screw M10x40	4
7	B01021902	Pulley Coupling 45mm	1
8	B0607010501	Pulley 10"x 2C Coupling Type	1
9	M22002	Bearing UC-209	2
10	M35002	Bearing Housing UCF-209	2
11	M02051	Hex Head Screw M 14x35	8
12	M05008	Punched Washer M12	8
13	M03195	Hex Nut M14	8
14	B0607010006	SMS-Counter Shaft	1
15	M39158	V Belt C-218	1
16	B0607010300	Belt Gard	1
17	M03051	Hex Head Screw M 10x40	4
18	B01021902	Pulley Coupling 45mm	1
19	B0607010601	Pulley 11"x 2C Coupling Type	1
20	M03051	Hex Head Screw M 10x	1
21	M05007	Washer M10	1
22	M04008	Spring Washer B10	1
23	M01004	Hex Nut M10	1
24	M01003	Hex Nut M8	1
25	M04007	spring Washer B8	1
26	M05006	Punched Washer M8	1

Item No.	Part No.	Part Name	Qty.
27	B0607010007	Strip	1
28	M03035	Hex Head Screw M 8x30	1
29	B0607010100	Counter Shaft Bracket	1
30	M01004	Hex Nut M10	1
31	B0607010200	Belt Gard	1
32	M03033	Hex Head Screw M 8X20	2
33	M05006	Punched Washer M8	2
34	M04007	Spring Washer B8	2
35	M01003	Hex Nut M8	2
36	M03050	Hex Head Screw M 10x35	1
37	M28009	Nylock Nut M16	2
38	M05009	Punched Washer M16	3
39	B01070006	Bush	2
40	M15012	Ball Bearing 6206	4
41	B01070004	Idle Pulley	1
42	B0607010008	Spacer	1
43	M02188	Hex Head Bolt M 16x130	2
44	M04010	Spring Washer B16	1
45	M03051	Hex Head Screw M10x40	4
46	B01021902	Pulley Coupling 45mm	1
47	B0607010501	Pulley 10"x 2C Coupling Type	1
48	M03034	Hex Head Screw M 8x25	4
49	B0607010009	Shaft End Cover	1

STEERING SYSTEM

PLATE NO. 068





PREET AGRO IND. PVT. LTD.
STEERING SYSTEM


SPARE PARTS LIST
PREET 987
PLATE NO. 068

Item No.	Part No.	Part Name	Qty.
1	B0701030500	Steering Column	1
2	M13002	Parallel Key 6x6x20	1
3	M05007	Plain washer M10	2
4	B07010007	Combination Switch	1
5	B0701020100	Steering Wheel	1
6	M05009	Plain washer M16	1
7	M01009	Hex Nut M16x1.5	1
8	A07030018	Hose Pipe 24" -M18x1.5-M18x1.5(90)	3
9	M03034	Hex Head Screw M8x25	4
10	M04007	Spring Washer M8	4
11	M05006	Plain Washer M8	4
12	B07010020	Plate - Dash Board Light	1
13	M01004	Hex nut M10	2
14	M05007	Plain washer M10	2
15	M36038	Flange Head Screw M8x45-8.8	2
16	B07020010	Pipe Clamp 2 Hole (dia 12)	2
17	B0701020200	Cover - Steering Column	1
18	M03034	Hex Head Screw M8x25	4
19	M05006	Plain Washer M8	8
20	B0701020003	Mtg. Plate - Steering Spindle	1
21	M04007	Spring Washer M8	4
22	M01003	Hex Nut M8	4

Item No.	Part No.	Part Name	Qty.
23	B07010100	Arbitrol	1
24	B02010009	Adaptor M18x1.5-M18x1.5	6
25	A01060010	Clamp Plate	2
26	B07010012	Steering Pipe 1 LH - Arbitol Side	1
27	B07010010	Main Supply Pipe-I - Arbitol Side	1
28	M05007	Plain Washer M10	2
29	B07010034	Steering Pipe I - RH - Arbitol Side	1
30	M04007	Spring Washer M8	2
31	M01003	Hex Nut M8	2
32	B07020017	Adaptor with Lock Nut - 18x1.5-18x1.5	6
33	M04008	Spring Washer M10	4
34	M03048	Hex Head Screw M10x25	4
35	B07010031	Cover Plate - Steering Column	1
36	M05005	plain Washer M6	4
37	M36018	Flange Head Screw M6X16	4
38	B07010035	Adaptor Mtg. Bkt.	1
39	M05006	Plain Washer M8	4
40	M03034	Hex Screw M8x25	2
41	B0701020004	Lever - Steering Adhustment	1
42	M04008	Spring washer M10	2
43	M03048	Hex. Head screw M10x25	2

HYDRAULIC LINE - STEERING

PLATE NO. 069






PREET AGRO IND. PVT. LTD.

HYDRAULIC LINE - STEERING

SPARE PARTS LIST
PREET 987
PLATE NO. 069

HYDRAULIC LINE - REEL & FEEDER

PLATE NO. 070






PREET AGRO IND. PVT. LTD.

HYDRAULIC SYSTEM - REEL & FEEDER

HYDRAULIC SYSTEM - VARIATOR PULLEY

PLATE NO. 071






PREET AGRO IND. PVT. LTD.

HYDRAULIC SYSTEM - VARIATOR PULLEY

SPARE PARTS LIST
PREET 987
PLATE NO. 071

HYDRAULIC LINE - RETURN

PLATE NO. 072






PREET AGRO IND. PVT. LTD.

HYDRAULIC LINE - RETURN

SPARE PARTS LIST
PREET 987
PLATE NO. 072

HYD. PUMP & RELATED COMPONENTS

PLATE NO. 073





PREET AGRO IND. PVT. LTD.
HYDRAULIC PUMP & RELATED COMPONENTS

SPARE PARTS LIST


PREET 987

PLATE NO. 073

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B07020018	Adapter	2	23	M02185	Hex Bolt M16x110	2
2	B07030034	Hose Pipe 10"	2	24	M28003	Nylock nut M12	4
3	B07030105	Oil filter (Strainer)	2	25	M04010	Spring Washer B-12	4
4	B07030100	Hydraulic Tank	2	26	A07030014	Adaptor M18x1.5 x 3/8"x19 BSP	2
5	B07030104	Cap	2	27	M05008	Plain Washer M12	8
6	B07030007	Suction Pipe R.H/L.H	2	28	M02017	Hex Head Bolt M8x45	8
7	M63001	Allen Head Screw 5/16"x 3/4	4	29	M39165	V Belt B55	1
8	B07030001	Hydraulic Pump(Mico/Dowty)	2	30	B07030006	Pump Pulley 11"	1
9	B07030003	Coupler	2	31	M03065	Hex. Screw M12x40	4
10	B07030004	Pump Mounting Bracket	2	32	B07030800	Bracket - Pump mtg. bracket	2
11	M10025	External Circlip A-40	2	33	M05008	Plain Washer M12	4
12	M11045	Internal Circlip B-80	2	34	M01005	Hex Nut M12	4
13	M15005	Ball Bearing 6208	4	35	B07030018	Adjusting Rod	2
14	B07030021	Spacer 40x50x8	2	36	A04030010	Fork	2
15	B07030005	Pump Coupling	2	37	M28005	Nyloc Nut M8	2
16	B07030017	Pump Pulley 10"	1	38	M03035	Hex Screw M8x30	2
17	M04008	Spring Washer B-10	8				
18	M03047	Hex Head Screw M10x20	8				
19	M39164	V-Belt B-62	1				
20	M01003	Hex Nut M8	8				
21	M05006	Plain Washer M8	8				
22	M28009	Nylock Nut M16	2				

VARIATOR PULLEY HI - LOW

PLATE NO. 074





PREET AGRO IND. PVT. LTD.

VARIATOR PULLEY HI - LOW


SPARE PARTS LIST

PREET 987

PLATE NO. 074

VARIATOR PULLEY HI - LOW MTG.

PLATE NO. 075





PREET AGRO IND. PVT. LTD.
VARIATOR PULLEY HI - LOW MTG.

SPARE PARTS LIST

PREET 987


PLATE NO. 075

Item No.	Part No.	Part Name	Qty.
1	A07030019	Hose Pipe 18" - M18x1.5-M18x1.5	2
2	B02010009	Adaptor M18x1.5 - M18x1.5	2
3	B08020006	Hydraulic Jack - Hi Low	1
4	M05007	Plain Washer M10	1
5	M28009	Nylock Nut M16.	2
6	M02072	Hex Head Bolt M16x80	2
7	B08020500	U Bracket Assy	1
8	M04009	Spring Washer M12	3
9	M03062	Hex Head Screw M12x25	3
10	M30007	Castle Nut M28x1.5	1
11	M28002	Nylock Nut M10	4
12	M04008	Spring Washer M10	4
13	B08020003	Mtg. Plate - Speed Changer Bracket	1
14	M03049	Hex Head Screw M10x30	4
15	B08020002	Gun Metal Bush	2
16	B08020008	Hex Nut 3/4"	2
17	M05011	Plain Washer M20	2
18	B08020100	Speed Changer Mtg. Bkt.	1
19	M57095	Hex Head Screw M16x50 - 10.9	1
20	B08020009	Supporting Strip 1 - Hi Low	1
21	M04010	Spring Washer M16	1
22	M01008	Hex Nut M16	1
23	M57052	Hex Head Screw M10x45 - 10.9	1
24	B08020012	Supporting Bracket - Hi Low	1
25	M04008	Spring Washer M10	1
26	M28002	Nylock Nut M10	1
27	M57064	Hex Head Screw M12x35 - 10.9	1

Item No.	Part No.	Part Name	Qty.
28	M04009	Spring Washer M12	1
29	M01005	Hex Nut M12	1
30	M44006	Split Pin 5/32"x1.5"	1
31	B08020001	Speed Changer Shaft	1
32	B08020015	Castle Nut 22x14TPI	1
33	B08020011	Supporting Strip 3	1
34	B08020010	Supporting Strip 2	1
35	B08020400	Adjustable Lever - Hi Low	1
36	M05007	Plain Washer M10	6
37	M04008	Spring Washer M10	3
38	M28002	Nylock Nut M10	3
39	B08020007	Hex Nut 7/8"	2
40	B08020300	Supporting Angle	1
41	M03049	Hex Head Screw M10x30	3
42	B08020200	Fork	1
43	M01005	Hex Nut M12	2
44	B08020016	Spacer	1
45	M05010	Plain Washer M16	2
46	M04009	Spring Washer M12	2
47	M57064	Hex Hd. Screw M12x35 - 10.9	1
48	M05008	Plain Washer M12	1
49	M04009	Spring Washer M12	1
50	M28003	Nylock Nut M12	1
51	M57065	Hex Hd. Screw M12x40 - 10.9	2
52	M05008	Plain Washer M12	2
53	M44005	Split Pin5/32"x1.0"	1

CLUTCH ASSY.

PLATE NO. 076






PREET AGRO IND. PVT. LTD.
CLUTCH ASSY.

SPARE PARTS LIST
PREET 987D
PLATE NO. 076

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B08031001	Gasket	1	24	B08030009	Fly Wheel	1
2	M01003	Hex Nut M8	2	25	M04007	Spring Washer M8	12
3	M40013	Grub Screw M8x25	2	26	M02020	Hex Head Bolt M8x60	12
4	B08031200	C. A. Shaft	1	27	B08030010	Clutch Housing Shaft	1
5	M111002	Woodruff Key 6x9	1	28	M13006	Parallel Key 8x7x30	1
6	M04009	Spring Washer M12	5	29	M44006	Split Pin 5/32"x1.5"	1
7	M28003	Nylock Nut M12	5	30	M39022	V Belt 3175	1
8	B08031100	Clutch Housing - 5 Speed	1	31	B08030015	Castle Nut M24x1.5	1
9	B08031004	Cover Plate I	1	32	B08031002	Clutch Pulley 13"	1
10	M05006	Plain Washer M8	2	33	M11049	Internal Circlip B90	2
11	M04007	Spring Washer M8	2	34	B08030013	Cover Plate	1
12	M03032	Hex Head Screw M8x16	2	35	M10025	External Circlip A40	1
13	B08031008	Gasket - Actuator Guide	1	36	M15020	Ball Bearing 6308	2
14	B08030002	Actuator Guide	1	37	M28002	Nylock Nut M10	3
15	M05006	Plain Washer M8	4	38	M05007	Plain washer M10	6
16	M02016	Hex Head Bolt M8x40	4	39	M55033	Hex Head Bolt M10x65-10.9	3
17	B08030003	Actuator Bush	1	40	M28003	Nylock Nut M12	2
18	M15021	Clutch Bearing 1888180	1	41	M05008	Plain Washer M12	4
19	B08031402	Pressure Plate - For Ø 13"	1	42	B08031300	Clutch Assy. Supporting Bracket	1
20	B08031401	Clutch Plate Assy 13"	1	43	B08030012	Clutch Shaft Sleeve	1
21	M57066	Hex Head Screw M12x45-10.9	8	44	M99001	Grease Pipe - 10" (M8)	1
22	M04009	Spring Washer M12	8	45	M28003	Nylock Nut M12	6
23	B08030018	Guide Bush (Input Shaft)	1	46	M04009	Spring Washer M12	6

CLUTCH ASSY.

PLATE NO. 076



161-A




PREET AGRO IND. PVT. LTD.

CLUTCH ASSY.

Item No.	Part No.	Part Name	Qty.
47	B08031007	Clamp	1
48	M55045	Hex Head Bolt M12x65-10.9	2
49	M57049	Hex Head Screw M10x30-10.9	2
50	M04008	Spring Washer M10	12
51	M05007	Plain Washer M10	2
52	M01005	Hex Nut M12	2
53	M05008	Plain Washer M12	4
54	B08031006	Mounting Plate	1
55	M57065	Hex Head Screw M12x40-10.9	2
56	M57048	Hex Head Screw M10x25-10.9	10
57	B08030011	Cover Plate	1
58	M12013	Oil Seal 55x90x10	1
59	M55042	Hex Head Bolt M12x50-10.9	6
60	M57051	Hex Head Screw M10x40-10.9	1
61	M04008	Spring Washer M10	1
62	B08030004	Actuator Fork	1
63	M12019	Oil Seal 35x62x10	1
64			
65			
66			

CLUTCH ASSY.

PLATE NO. 077





PREET AGRO IND. PVT. LTD.
CLUTCH ASSY.

SPARE PARTS LIST


PREET 987

PLATE NO. 077

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M04007	Spring Washer M-8	10	23	M011049	Internal Circlip B-90	2
2	M03035	Hex Head Screw M8x30	10	24	B08030013	Cover Plate	1
3	B08030001	Clutch Housing	1	25	M10025	External Circlip A-40	1
4	B08030002	Actuator Guide	1	26	M15020	Ball Bearing 6308	2
5	M04007	Spring Washer M-8	4	27	M01005	Hex Nut M12	6
6	M02016	Hex Head Bolt M8x40	4	28	M04009	Spring Washer M-12	14
7	B08030003	Actuator Bush	1	29	B08030012	Housing	1
8	M15021	Clutch Bearing 1888180	1	30	M03048	Hex Head Screw M10x25	12
9	B08030007	Pressure Plate	1	31	M04008	Spring Washer M-10	12
10	B08030008	Clutch Plate Assy 13"	1	32	B08030011	Cover Plate	1
11	M03063	Hex Head Screw M12x30	8	33	M02042	Hex Head Bolt M12x50	6
12	M04009	Spring Washer M-12	14	34	M12013	Oil Seal 55x 90x10	1
13	B08030018	Guide Bush (Input Shaft)	1	35	M02028	Hex Head Bolt M10x40	1
14	B08030009	Fly Wheel	1	36	B08030004	Actuator Fork	1
15	M04007	Spring Washer M-8	22	37	B08030005	C.A. Shaft	1
16	M03036	Hex Head Screw M8x35	8	38	B08030006	Woodruff Key	1
17	B08030010	Clutch Housing Shaft	1				
18	M13015	Parallel Key 8x7x36	1				
19	M31130	Split Pin 5x50	1				
20	M39022	V-Belt 3175	1				
21	B08030015	Castle Nut M24	1				
22	B08030014	Clutch Pulley	1				

GEAR BOX & GEAR SHIFT MECHANISM

PLATE NO. 078





PREET AGRO IND. PVT. LTD.
GEAR BOX & GEAR SHIFT MECHANISM


SPARE PARTS LIST
PREET 987
PLATE NO. 078

Item No.	Part No.	Part Name	Qty.
1	M03034	Hex Head Screw M8x25	2
2	M01003	Hex Nut M8	2
3	B08041200	Gear Shifter Shaft	1
4	M03033	Hex Head Screw M8x20	4
5	M04007	Spring Washer M8	4
6	M05006	Plain Washer M8	4
7	B08041138	Cover RH-Gear Shift Bkt.	1
8	B08041142	Gasket - Cover, Gear Shift Bkt.	2
9	M12002	Oil Seal 25x35x7	1
10	B08041132	Bush, Gun Metal - Gear Shift Bkt	2
11	B08081034	Breather M24x1.5	1
12	B08041400	Top Plate Assy.	1
13	B08041141	Gasket- Top Plate	1
14	B08041139	Gear Shift Bracket	1
15	B08041137	Cover LH-Gear Shift Bkt.	1
16	M05005	Plain Washer M6	4
17	M32001	Allen Head Screw M6x20	4
18	M01004	Hex Nut M10	2
19	M03053	Hex Head Screw M10x50	4
20	M32007	Allen Head Screw M10x40	4
21	M40005	Grub Screw M10x10	3
22	B08050008	Spring - Gear Shifter Fork	3
23	M47001	Steel Ball 1/2" Class II	3
24	B08041108	Fork Reverse	1
25	B08041125	Shifter Shaft Reverse	1
26	B08041126	Lock Nut M22x1.5	6
27	B08041106	Fork 3rd & 4th	1
28	B08041123	Shifter Shaft 3rd & 4th	1
29	B08041107	Fork 1st & 2nd	1
30	B08041124	Shifter Shaft 1st & 2nd	1

Item No.	Part No.	Part Name	Qty.
31	M07174	Stud M12x35-TYPE-B	5
32	M05007	Plain Washer M10	12
33	B08080019	Magnatic Plug M24x1.5	1
34	M02072	Hex Head Bolt M16x80	4
35	B08091105	Gear Box Mtg. Bush	8
36	B08041101	Gear Box Housing	1
37	M04010	Spring Washer M16	4
38	M01008	Hex Nut M16	4
39	M40008	Grub Screw M10x20	3
40	B08041111	Gasket - Gear Box Housing	1
41	B08041119	Gear Box Cover	1
42	B08081034	Breather M24x1.5	1
43	B08041121	Gasket - Gear Shift Bkt,	1
44	M03048	Hex Head Screw M10x25	13
45	M04008	Spring Washer M10	13
46	M28002	Nylock Nut M10	6
47	B08041116	Lever - Gear Selector	1
48	M01004	Hex Nut M10	1
49	M32027	Allen Head Screw M10x25	1
50	B08041118	Lock - Gear Selector	1
51	M03093	Hex Screw M16x40	4
52	M03049	Hex Head Screw M10x30	2
53	B08041502	Oil Feeder	1
54	M01082	Lock Nut M18x1.5	1
55	B08041504	Lubrication Pipe	1
56	B02010009	Adaptor	1
57	B08041151	Stiffner Rod Lock Plate	1
58	M03050	Hex Head Screw M10x35	2
59	B08041148	Support Bkt LH Gear Box	1
60	B08041149	Support Bkt RH Gear Box	1
61	B08041150	Support Angle-Gear Box	1

GEAR BOX

PLATE NO. 079





PREET AGRO IND. PVT. LTD.

GEAR BOX


SPARE PARTS LIST

PREET 987

PLATE NO. 079

GEAR DRIVE ASSEMBLY

PLATE NO. 080





PREET AGRO IND. PVT. LTD.
GEAR DRIVE ASSEMBLY


SPARE PARTS LIST
PREET 987D
PLATE NO. 080

Item No.	Part No.	Part Name	Qty.
1	M10020	External Circlip A-32	1
2	B04041006	Flat Pulley	1
3	M12019	Oil Seal 35x62x10	1
4	B08051032	Flange	1
5	B08051033	Gasket	1
6	M15018	Ball Bearing - 6307	1
7	M13008	Parallel Key 10x8x25	1
8	B08051031	Input Shaft	1
9	B08051034	Reverse Sliding Gear Z-21	1
10	M10035	External Circlip A-62	1
11	M10028	External Circlip A-48	2
12	B08051035	Drive Gear Z-23	1
13	M15020	Ball Bearing - 6308	2
14	B08080020	Spacer Ø89.7xØ80x15	1
15	B08051008	Fixed Gear Z-44	1
16	B08051007	Fixed Gear Z-33	1
17	B08051006	Bushing II	1
18	B08051005	Fixed Gear Z-24	1
19	B08051004	Bushing I	1
20	B08051003	Fixed Gear Shaft	1
21	M15018	Ball Bearing - 6307	1
22	B08051002	Gasket Bearing Flange	1
23	B08051001	Bearing Flange	1
24	M05007	Plain Washer M-10	8
25	M04008	Spring Washer M10	8
26	M55029	Hex Head Bolt M10x45-10.9	8
27	B08080019	Magnatic Plug M24x1.5	1
28	M23008	Copper washer 24x34x2	1

Item No.	Part No.	Part Name	Qty.
29	B08051019	C.M. Gear Z-37	1
30	B08051044	Fibre Ring	1
31	M34002	Needle 4x28	54
32	B08051020	Reverse Fixed Gear Z-47	1
33	B08051021	Spacer 48x59X6	1
34	B08051022	Bushing	1
35	M42007	Double Row Needle Cage 55x60x37	1
36	B08051023	C.M. Gear Z-28	1
37	B08051024	Gear - 25 Spline	1
38	B08051025	Coupler Ring II	1
39	B08051026	Spacer - STEPPED	1
40	M42008	Double Row Needle Cage 42x47x27	1
41	B08051027	C.M. Gear Z-17	1
42	B08051028	Washer 58x35x3	1
43	M15028	Ball Bearing - 6407	1
44	B08051018	Gear - 32 Spline	1
45	B08051017	Coupler Ring I	1
46	B08051016	C.M. Gear Z-47	1
47	M42005	Double Row Needle Cage 75x83x34	1
48	B08051014	Bearing Bushing	1
49	B0805010001	Gear Shaft	1
50	M15020	Bearing 6308	2
51	M12060	Oil Seal 40x62x10	1
52	B08051013	Gasket	1
53	B08051050	Flange	1
54	M05007	Plain Washer M10	6
55	M04008	Spring Washer M10	6
56	M55029	Hex Head Bolt M10x45-10.9	6

GEAR DRIVE ASSEMBLY

PLATE NO. 081






PREET AGRO IND. PVT. LTD.
GEAR DRIVE ASSEMBLY

SPARE PARTS LIST
PREET 987
PLATE NO. 081

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M03034	Hex Head Screw M8x25	12	23	B08040106	Gasket	1
2	M04007	Spring Washer M-8	19	24	B08050012	Cover	1
3	B08050001	Shifter Guide	1	25	M03033	Hex Head Screw M8x20	7
4	B08040104	Gasket	2	26	B08050017	Cover	1
5	B08050002	Shifter Rod	2	27	B08040107	Gasket	1
6	B08050005	Locking Screw	2	28	M15004	Ball Bearing 6209	2
7	B08050003	Shifter Fork 1st-Rev.	1	29	B08050023	Spacer	2
8	B08050004	Shifter Fork II-III	1	30	B08050018	Gear Z-35	1
9	M03019	Hex Head Screw M6x20	7	31	M10031	External Circlip A-55	2
10	M04006	Spring Washer M-6	7	32	B08050019	Shaft Fixed Gear	1
11	B08050007	Locking Plate	1	33	B08050020	Gear Z-32	1
12	B08050008	Spring	2	34	M12019	Oil Seal (35x62x10)	1
13	B08050009	Steel Ball 7.5mm	2	35	M15020	Ball Bearing 6308	2
14	B08050006	Shifter Bush	1	36	B08050022	Input Shaft	1
15	B08040105	Gasket	1	37	M13008	Parallel Key 10x8x25	1
16	B08050011	Cover	1	38	M12020	Oil Seal (40x80x10)	1
17	B08050010	Steel Ball 12.5mm	1	39	B08050021	Cover	1
18	M15005	Ball Bearing 6208	2	40	M10019	External Circlip A-30	1
19	B08050013	Spacer 11.5mm	2				
20	B08050016	Gear 2nd,3rd	1				
21	B08050015	Shaft Sliding Gear	1				
22	B08050014	Gear Z-17	1				

DIFFERENTIAL ASSEMBLY (WET BRAKE)

PLATE NO. 082





PREET AGRO IND. PVT. LTD.

DIFFERENTIAL ASSEMBLY (WET BRAKE)

SPARE PARTS LIST


PREET 987

PLATE NO. 082

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M10027	External Circlip A45	8	23	M57066	Hex. Head Screw M12x45-12.9	12
2	B08061008	Coupling Sleeve	4	24	B0806010011	Gasket - Brake Housing Cover	2
3	B0806010003	Extension Shaft LH	1	25	B0806010004	Extension Shaft RH	1
4	B0806010001	Differential Shaft LH (shape change)	1	26	B0806010002	Differential Shaft RH (Shape change)	1
5	M02164	Hex. Head Bolt M12x130	12	27	B0806010009	Wet Brake Housing RH	1
6	B0806010008	Wet Brake Housing LH	1	28	M15029	Ball Bearing 6218	1
7	B08061003	Gasket - Brake Housing	2	29	M03063	Hex Head Screw M12x30	8
8	M15023	Ball Bearing 6211	2	30	B0806010010	Cover-Wet Brake Housing	1
9	M10031	External Circlip A-55	2	31	M12056	Oil Seal 45x62x10	2
10	M11053	Internal Circlip B-100	2	32	M05008	Plain Washer M12	20
11	M15032	Ball Bearing 6018	1	33	B0807010104	Rubber Boot	2
12	M55035	Hex Head Bolt M10x75 - 10.9	8	34	A05050004	Drain Plug M14x1.5	2
13	B08061104	Lock Plate	4	35	M11047	Internal Circlip B85	2
14	B08061101	Differential Housing LH	1	36	M15004	Ball Bearing 6209	2
15	B08061010	Thrust Washer	2				
16	B08060203	Bevel Gear Z18	2				
17	B08061011	Curved Washer	4				
18	B08061103	Spider	1				
19	B08060204	Bevel Pinion Z11	4				
20	M28003	Nylock Nut M12	12				
21	B08061102	Differential Housing RH	1				
22	B08061009	Gear Z52	1				

DIFFERENTIAL ASSEMBLY - 4 SPEED

PLATE NO. 083





PREET AGRO IND. PVT. LTD.
DIFFERENTIAL ASSEMBLY

SPARE PARTS LIST


PREET 987

PLATE NO. 083

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M10026	External Cerclip A-42	8	23	B08060201	Left Cage	1
2	B08060004	Coupling Sleeve	4	24	B08060001	Ring Gear Z-73	1
3	B08060005	Extension Shaft LH	1	25	M02029	Hex Head Bolt M10x40	12
4	B08060003	Half Shaft	2	26	B08060006	Extension Shaft RH	1
5	B0806010010	Cover - Wet Brake Housing	2	27	B0806010011	Gasket - Brake Housing Cover	2
6	M12056	Oil Seal 45 x 62 x 10	2	28	B08061010012	Wet Brake Housing LH	1
7	M15004	Ball Bearing 6209	2	29	B0807010104	Rubber Boot	2
8	M12021	Oil Seal 65x90x10	2	30	A05050004	Drain Plug M14x1.5	2
9	M15023	Ball Bearing 6211	2	31	M03063	Hex. Head Screw M12x30	8
10	M10031	External Circlip A-55	2	32	M05008	Plain Washer M12	20
11	M11053	Internal Circlip B-100	2	33	M02164	Hex. Head Bolt M12x130	12
12	M15022	Ball Bearing 6215	2	34	B08061010013	Wet Brake Housing RH	1
13	M02036	Hex Head Bolt M10x65	8				
14	B08060209	Lock Plate	4				
15	B08060202	Right Cage	1				
16	B08060205	Thrust Washer	2				
17	B08060203	Bevel Wheel	2				
18	M11047	Internal Circlip B - 85	2				
19	B08060208	Spider	1				
20	B08060204	Bevel Pinion	4				
21	M01004	Hex Nut M10	12				
22	B08061003	Gasket - Brake Housing	2				

WET BRAKE

PLATE NO. 084






PREET AGRO IND. PVT. LTD.

WET BRAKE

REDUCTION UNIT (DISC/ WET BRAKE)

PLATE NO. 085






PREET AGRO IND. PVT. LTD.
REDUCTION UNIT

SPARE PARTS LIST
PREET 987
PLATE NO. 085

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M03049	Hex Head Screw M10x30	6	23	B08081020	Lock Plate	2
2	M04008	Spring Washer M10	12	24	B08081019	Flange III	2
3	B08081004	Flange I	2	25	B08081035	Shim 0.25	AR
4	B08081005	Gasket - Flange 1	2		B08081036	Shim 0.50	
5	M17013	Taper Roller Bearing 45x85x32 (33209)	4	26	M17014	Taper Roller Bearing 80x130x37 (33116)	2
6	B08081026	Collar Spacer	2	27	M17015	Taper Roller Bearing 100x160x41(720249)	2
7	B08081013	Drive Shaft	2	28	B08080019	Magnatic Plug M24x1.5	2
8	B08081034	Breather-M24x1.5	2	29	B08081014	Bull Gear Z-68	2
9	B08081001	Reduction Housing	2	30	B08081003	Gasket - Reduction Cover	2
10	B08080011	Dowel Pin \varnothing 16x50	4	31	B08081028	Oil Level Gauge	2
11	B08080021	Stud M16x55	16	32	B08081100	Reduction Cover Assy-LH	1
12	M04010	Spring Washer M16	16	33	M05007	Plain Washer M10	32
13	B08080010	Stud Nut M16	16	34	M04008	Spring Washer M10	32
14	B08081006	Gear Shaft Z11	2	35	M03047	Hex Head Screw M10x20	32
15	M12072	Oil Seal (45x70x10)	2	36	B08081300	Reduction Cover Assy-RH	1
16	B08081200	Hub Bolt & Nut	16	37	B08081038	Shim 1.50	1
17	B08081027	Gasket - Bearing Cover Flange	2				
18	B08081031	Bearing Cover Flange (For Wet)	2				
19	M02028	Hex Head Bolt M10x40	12				
20	B08081015	Spacer Ring	2				
21	B08081023	Gasket - Reduction Housing	2				
22	M03093	Hex Screw M16x40	6				

REDUCTION UNIT

PLATE NO. 086






PREET AGRO IND. PVT. LTD.

REDUCTION UNIT

Item No.	Part No.	Part Name	Qty
1	M03048	Hex Head Screw M10x25	6
2	M04008	Spring Washer M-10	6
3	B08080013	Cover Plate	2
4	B08080104	Gasket	2
5	M15020	Ball Bearing 6308	2
6	B08080020	Spacer	1
7	B08080017	Hub Nut	16
8	B08040003	Breather	2
9	B08080001	Reduction Housing	2
10	B08080011	Dowel Pin	4
11	M07220	Stud M16x55	28
12	M04010	Spring Washer M-16	28
13	B08080010	Stud Nut	28
14	B08080002	Pinion Shaft Z-12	2
15	M15024	Roller Bearing 2210	2
16	M12022	Oil Seal (50x70x10)	2
17	B08080101	Gasket	2
18	B08080003	Caliper Mounting Bracket	2
19	M04008	Spring Washer M-10	12
20	M02035	Hex Head Bolt M10x75	12
21	B08080016	Taper Washer	16
22	B08080014	Axle Hub	2
23	B08080102	Gasket	2
24	B08080018	Lock Plate - Small	2
25	M03064	Hex Head Screw M12x35	4
26	B08080015	Hub Bolt	16
27	B08080004	Hub Lock	2
28	M15024	Roller Bearing NUP 2214	2

FRONT AXLE

PLATE NO. 087






PREET AGRO IND. PVT. LTD.

FRONT AXLE

SPARE PARTS LIST
PREET 987
PLATE NO. 087

FRONT AXLE

PLATE NO. 088





PREET AGRO IND. PVT. LTD.
FRONT AXLE

SPARE PARTS LIST


PREET 987

PLATE NO. 088

Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	M02013	Hex Head Bolt M8x25	6	23	M01008	Hex Nut M16	2
2	B08090003	Angle RH	1	24	M02187	Hex Head Bolt M16x120	6
3	M05006	PlainWasher M8	12	25	M05009	Plain Washer M16	6
4	M01003	Hex Nut M8	6				
5	B08090002	Angle LH	1				
6	M04010	Spring Washer M-16	6				
7	B08090100	Front Axle	1				
8	M02185	Hex Head Bolt M16x110	6				
9	M05009	Plain Washer M16	6				
10	M04010	Spring Washer M-16	6				
11	M01008	Hex Nut M16	6				
12	M01008	Hex Nut M16	6				
13	M01004	Hex Nut M10	1				
14	M04008	Spring Washer M10	1				
15	K08090003	Clutch Shaft Mtg. Block	1				
16	M03053	Hex Head Screw M10x50	1				
17	M02065	Hex Head Bolt M16x45	6				
18	M05009	Spring Washer M16	6				
19	M04010	Spring Washer M-16	6				
20	M02066	Hex Head Bolt M16x50	2				
21	M05009	Plain Washer M16	2				
22	M04010	Spring Washer M-16	2				

REAR AXLE MOUNTING

PLATE NO. 089






PREET AGRO IND. PVT. LTD.

REAR AXLE MOUNTING

STEERING AXLE

PLATE NO. 090













PREET AGRO IND. PVT. LTD.

STEERING AXLE

Item No.	Part No.	Part Name	Qty.
1	B08110100	Steering Axle	1
2	B08110002	Slotted Nut M56	1
3	B08110021	Fiber Bush	2
4	M44015	Split Pin 1/4" x 4"	1
5	B08110001	Pivot Pin	1
6	M11026	Internal Circlip B-42	4
7	B08110016	Ring Plate	8
8	B08110017	King Pin Ring	4
9	B08110015	Bush	4
10	B08110014	King Pin	2
11	B08110013	Shim	2
12	B08110018	Stub Axle	2
13	M21002	Thrust Ball Bearing T 144	2
14	A01060003	Hose	2
15	B02010009	Adaptor	2
16	M30005	Castle Nut M20	4
17	B08110020	Hydraulic Jack	1
18	M44003	Split Pin 1/8" x 2.0"	4
19	B08110005	Link Pin	1
20	M03063	Hex Screw M12x35	2
21	B08110500	Jack Mtg. Plate	1
22	M28003	Nylock Nut M12	2
23	B08110400	Tie Rod Assy	1
24	B08110009	Tie Rod End (RH)	1
25	B08110010	Hex. Nut M24 (RH)	1
26	M44013	Split Pin 5/32" x 2"	2
27	M27002	Oil Seal 55x90x10	2
28	M17011	Taper Roller Bearing 32210	2

RIMS & TYRES

PLATE NO. 091






PREET AGRO IND. PVT. LTD.

RIMS & TYRES

TOOL BOX

PLATE NO. 092





PREET AGRO IND. PVT. LTD.
TOOL BOX

				SPARE PARTS LIST			
				PREET 987			
				PLATE NO. 092			
Item No.	Part No.	Part Name	Qty.	Item No.	Part No.	Part Name	Qty.
1	B09010400	Tool Box Railing	1	23	B09010100	Tool Box	1
2	M05006	Plain Washer M8	4	24	B09010306	Handle	1
3	M04007	Spring Washer M8	2	25	M32017	Allen Screw M6x25	2
4	M03048	Hex Head Screw M8x25	2	26	M28004	Nylock Nut M6	2
5	M03049	Hex Head Screw M10x30	4	27	M05005	Plain Washer M6	4
6	M05007	Plain Washer M10	8	28	M01002	Hex Nut M6	4
7	B09010002	Mounting Strip - Tool Box	2	29	M01002	Hex Nut M6	4
8	M04008	Spring Washer M10	4	30	M05005	Plain Washer M6	4
9	M01004	Hex Nut M10	4	31	M36018	Flange Head Screw M6x16	4
10	M05006	Plain Washer M8	4	32	B09010304	Hinge	2
11	M04007	Spring Washer M8	2	33	M01003	Hex.Nut M8	2
12	M03035	Hex. Screw M8x30	2				
13	M01004	Hex. Nut M10	4				
14	M05008	Spring Washer M10	4				
15	M05007	Plain Washer M10	8				
16	B09010500	Support Angle Rear Assy	1				
17	M57049	Hex. Head Screw M10x30-10.9	4				
18	M01004	Hex. Nut M10	4				
19	M04008	Spring Washer M10	4				
20	M05007	Plain Washer M10	8				
21	M57049	Hex. Head Screw M10x30-10.9	4				
22	B09010600	Support Angle Front Assy	1				



PREET AGRO INDUSTRIES PVT. LTD.

Patiala Road, Nabha-147201 (Pb.) INDIA
Phone: +91-1765-220400, 222609, Web: www.preet.co

Toll Free No.: 1800 419 0349