




Title		
Size A	Number	Revision
Date: 8/05/2024		Sheet of
File: C:\Users\..\Top_Sheet.SchDoc		Drawn By:

INPUT POWER, PB+ COMM & LOW-VOLTAGE RAILS




MEASUREMENT BOARD INTERFACE

(power, comm, programming)




USB UPSTREAM INTERFACE



USB HUB DOWNSTREAM CONNECTIONS



PANEL PC SERIAL COMM INTERFACE





USB 2 PORT 1 TO GNSS MODULE

USB 2 PORT 2 TO GNSS MODULE


USB 2 PORT 3 TO GNSS MODULE

USB 2 PORT 4 TO GNSS MODULE






EXTERNAL TEMP SENSOR INTERFACE



GLOBAL NAVIGATION SATELLITE SYSTEM

(GNSS RECEIVER)




Top_Sheet[4B], Controller_Section[4D]

5V
3V3
1V2
GND


Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.

Title: Power_Section.SchDoc	
File: Interface-Board-7500-0428.PrjPcb	
Date: 8/5/2024	Page Num: 2
Drawn By: Huzaifa Ali	Page Total: 3

USB HUB & PANEL PC SPI-MASTER INTERFACE



INTERFACE BOARD CONTROLLER



Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.

Title: Controller_Section.SchDoc	
File: Interface-Board-7500-0428.PrjPcb	
Date: 8/5/2024	Page Num: 3
Drawn By: Huzaifa Ali	Page Total: 3