
MCU can power the V BACKup of the GNSS module or it can be always on by connecting thru R1. V Bakcup 6 uA it keeps in the GNSS module the previous location



TITLE: Sheet_1	REV: 1.0
Company: Your Company	Sheet: 1/1
Date: 2023-07-24	Drawn By: Guillermo Aramendia