




Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Top-Sheet.SchDoc	
File: STEPPER-Board-v1.0.PrjPcb	
Date: 9/24/2024	Page Num: 1
Drawn By: Huzaifa Ali	Page Total: 8


24V INPUT




5V 3A BUCK




3.3V 1.5A BUCK




TEST POINTS



LEDs







Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Power_Sheet.SchDoc	
File: STEPPER-Board-v1.0.PrjPcb	
Date: 9/24/2024	Page Num: 2
Drawn By: Huzaifa Ali	Page Total: 8


CRYSTAL




DEBUG



BOOT





SWD PORT





FOR RS-485

FOR RS-232




















































USB








RESET




DIO ADC











Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.

Title: Controller_Sheet.SchDoc	
File: STEPPER-Board-v1.0.PrjPcb	
Date: 9/24/2024	Page Num: 3
Drawn By: Huzaifa Ali	Page Total: 8


CAN BUS




CAN TERMINATION




CAN CONNECTOR




CAN BUS





CAN2 TERMINATION



CAN2 CONNECTOR











Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.


Title: CAN_Sheet.SchDoc	
File: STEPPER-Board-v1.0.PrjPcb	
Date: 9/24/2024	Page Num: 4
Drawn By: Huzaifa Ali	Page Total: 8

RS485 TO UART



RS232 TO UART











Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.


Title: RS485_RS232_Sheet.SchDoc	
File: STEPPER-Board-v1.0.PrjPcb	
Date: 9/24/2024	Page Num: 5
Drawn By: Huzaifa Ali	Page Total: 8


ETHERCAT





















Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.


Title: EtherCAT_Sheet.SchDoc	
File: STEPPER-Board-v1.0.PrjPcb	
Date: 9/24/2024	Page Num: 6
Drawn By: Huzaifa Ali	Page Total: 8

Top-Sheet[5B], Controller_Sheet[1C]


STEPPER DRIVER -1




STEPPER DRIVER -2




STEPPER DRIVER -3




STEPPER DRIVER -4



BEMF ADC







Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.

Title: Stepper_Driver_Sheet.SchDoc			
File: STEPPER-Board-v1.0.PrjPcb			
Date: 10/2/2024	Page	Num:	7
Drawn By: Huzaifa Ali	Page	Total:	8


EXTERNAL STEPPER DRIVER -1




EXTERNAL STEPPER DRIVER -3




EXTERNAL STEPPER DRIVER -2



EXTERNAL STEPPER DRIVER -4





Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium
Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Ext_Stepper_Driver_Sheet.SchDoc	
File: STEPPER-Board-v1.0.PrjPcb	
Date: 10/4/2024	Page Num: 8
Drawn By: Huzaifa Ali	Page Total: 8