


Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Top_Sheet.SchDoc	
File: Dimmer_Board.PrjPcb	
Date: 8/8/2024	Page Num: 1
Drawn By: Huzaifa Ali	Page Total: 3

SIGNAL INPUT



HEATSINK


DIMM — DIMM

LIVE — LIVE
LOAD — LOAD
GND — GND

Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.


Title: Opto_Sheet.SchDoc	
File: Dimmer_Board.PrjPcb	
Date: 8/19/2024	Page Num: 2
Drawn By: Huzaifa Ali	Page Total: 3

SIGNAL INPUT




CONNECT ON BOTTOM SIDE OF PCB (AS DAUGHTER CARD)

INPUT 220V





CONNECT ON BOTTOM SIDE OF PCB (AS DAUGHTER CARD)

LOAD CONNECTOR



MOUNTED ON THE SIDE OF DAUGHTER CARD (OUTPUT)





Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Connector_Sheet.SchDoc	
File: Dimmer_Board.PrjPcb	
Date: 8/19/2024	Page Num: 3
Drawn By: Huzaifa Ali	Page Total: 3