




Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Top_Sheet.SchDoc	
File: Relay-Driver-Board-v1.0.PrjPcb	
Date: 8/9/2024	Page Num: 1
Drawn By: Huzaifa Ali	Page Total: 10


24V INPUT




TEST POINTS



LEDs




12V BUCK




20A

3.3V 1A LDO




1.2A

48V BOOST




7A

5V 2A BUCK




2A




Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Power_Sheet.SchDoc	
File: Relay-Driver-Board-v1.0.PrjPcb	
Date: 8/8/2024	Page Num: 2
Drawn By: Huzaifa Ali	Page Total: 10


CRYSTAL




RESET




UART





BOOT




SWD PORT









USB



DIO ADC




DIOs requested by client




Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Controller_Sheet.SchDoc	
File: Relay-Driver-Board-v1.0.PrjPcb	
Date: 8/8/2024	Page Num: 3
Drawn By: Huzaifa Ali	Page Total: 10


CAN BUS




CAN TERMINATION




TESTPOINTS











Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: CAN_Sheet.SchDoc		
File: Relay-Driver-Board-v1.0.PrjPcb		
Date: 8/9/2024	Page	Num: 4
Drawn By: Huzaifa Ali	Page	Total: 10


RS485_2 TO UART




RS485 TO UART



TESTPOINTS



RS232 TO UART



RS485/2_N
RS485/2_P
RS485/2_N
RS485/2_P
RS485_N
RS485_P
RS485_N
RS485_P
RS232_RX
RS232_TX
RS232_RX
RS232_TX

RS-485/232_2
TXD/RS485_2
RXD/RS485_2
RE/DE/RS485/T_2
TXD/RS485_2
RXD/RS485_2
RE/DE/RS485/T_2
RS-485/232_2


RS232
BOARD_RS232_TX
BOARD_RS232_RX
TXD/RS232
RXD/RS232
RS232


RS-485
TXD/RS485
RXD/RS485
RE/DE/RS485/T
TXD/RS485
RXD/RS485
RE/DE/RS485/T
RS-485

+3V3
+3V3
GND
GND


Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.


Title: RS485_RS232_Sheet.SchDoc		
File: Relay-Driver-Board-v1.0.PrjPcb		
Date: 8/9/2024	Page	Num: 5
Drawn By: Huzaifa Ali	Page	Total: 10





ETHERCAT







Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.

Title:	EtherCAT_Sheet.SchDoc
File:	Relay-Driver-Board-v1.0.PrjPcb
Date: 8/8/2024	Page Num: 6
Drawn By: Huzaifa Ali	Page Total: 10

RJ45



EARTH TERMINAL



LED1 (Green) = LINK/ACT
LED2 (Yellow) = SPEED

PORT_A
TXA_N
TXA_P
RXA_N
RXA_P
TXA_N
TXA_P
RXA_N
RXA_P
PORT_A

PORT_B
TXB_N
TXB_P
RXB_N
RXB_P
TXB_N
TXB_P
RXB_N
RXB_P
PORT_B


LEDPOL0
LEDPOL1
LEDPOL0
LEDPOL1

+3V3
+3V3
GND
GND


Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.


Title: RJ45_Sheet.SchDoc	
File: Relay-Driver-Board-v1.0.PrjPcb	
Date: 8/9/2024	Page Num: 7
Drawn By: Huzaifa Ali	Page Total: 10


RELAYS




RELAY DRIVER














Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Relay_Sheet.SchDoc		
File: Relay-Driver-Board-v1.0.PrjPcb		
Date: 8/8/2024	Page	Num: 8
Drawn By: Huzaifa Ali	Page	Total: 10

POWER SELECTOR HEADERS









Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Relay_PWR_Sheet.SchDoc	
File: Relay-Driver-Board-v1.0.PrjPcb	
Date: 8/8/2024	Page Num: 9
Drawn By: Huzaifa Ali	Page Total: 10


+24V OUTPUT




RS-232




RS-485





CAN





RELAY CONNECTION













Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Connector_Sheet.SchDoc	
File: Relay-Driver-Board-v1.0.PrjPcb	
Date: 8/9/2024	Page Num: 10
Drawn By: Huzaifa Ali	Page Total: 10