


ADE9000 POWER PROCESSOR




PHASE A CURRENT INPUT




PHASE B CURRENT INPUT




PHASE C CURRENT INPUT




NEUTRAL CURRENT INPUT (Not Used)




ADE9000 RESET



ADE9000 POWER DECOUPLING




ADE9000 SYSTEM INDICATORS




eSpark Consulting Group

Title: Power-Processor-1-Sheet.SchDoc	
File: OFP_CIM_v1.5.PrjPcb	
Date: 24-Jan-25	Page Num: 1
Drawn By: Huzaifa Ali	Page Total: 4


ADE9000 POWER PROCESSOR




PHASE A CURRENT INPUT




PHASE B CURRENT INPUT




PHASE C CURRENT INPUT




NEUTRAL CURRENT INPUT (Not Used)




ADE9000 RESET



ADE9000 POWER DECOUPLING




ADE9000 SYSTEM INDICATORS




eSpark Consulting Group

Title: Power-Processor-2-Sheet.SchDoc	
File: OFP_CIM_v1.5.PrjPcb	
Date: 24-Jan-25	Page Num: 2
Drawn By: Huzaifa Ali	Page Total: 4


ADE9000 POWER PROCESSOR




ADE9000 RESET




ADE9000 POWER DECOUPLING




ADE9000 SYSTEM INDICATORS




PHASE A CURRENT INPUT




PHASE B CURRENT INPUT



PHASE C CURRENT INPUT




NEUTRAL CURRENT INPUT (Not Used)




eSpark Consulting Group


Title: Power-Processor-3-Sheet.SchDoc	
File: OFP_CIM_v1.5.PrjPcb	
Date: 24-Jan-25	Page Num: 3
Drawn By: Huzaifa Ali	Page Total: 4


CURRENT CHANNELS TERMINAL INPUT





CURRENT CHANNELS CONNECTOR





Title: Connectors-Sheet.SchDoc	
File: OFP_CIM_v1.5.PrjPcb	
Date: 24-Jan-25	Page Num: 4
Drawn By: Huzaifa Ali	Page Total: 4