Temperature
1-wire - DS18B20

Program

Boot-loader

Battery ADC and
Ignition detect

DNF

SPI Radio
interface

PWM Backlight

Boot Mode

Current Detection 20A

Current sense filter

Debug FTDI3v3

TDS

Pressure switch

Heater

Battery Charger
Go Signal

Supply, clamping and protection

Go High or Low to
start charger/Heater?

TITLE: GTV11 Multi-Version Platform	REV: 1.0
Date: 2019-01-04	Sheet: 1/1
EASYEDA V5.8.22	Drawn By: kiwi_ed