

Use


Press enter to display the current TDS purity after the RO and after the DI.




Press enter again to display:
Total water used since last pre-filter change and zeroing of counter.
Overall is the amount of water used since install.



Press enter again to display:
Pressure of mains water in PSI.
Temperature of water to hose (degrees C).



Press enter again to go back to TDS values



Warning Messages

The S3 controller has a number of warning message for when something goes wrong in your system, these are designed to help in any trouble shooting.

The following message during a fill suggests that the mains water has been disconnected (pressure below 10 PSI)



The following message indicates that the pressure sensor has been disconnected or has failed.



The following message is displayed when the amount of water that has flowed goes over the Total Flow Threshold. Check the RO membrane.



The pressure has dropped below the value set in Pressure Threshold, indicating a blocked carbon or sediment filter.

