Kindly follow below steps for IDE Setup:

1. Download **Segger Embedded Studio [64-bit]** from the below reference link. https://www.segger.com/downloads/embedded-studio/EmbeddedStudio_ARM_Win_x64
2. Go to download directory and you will find Setup_EmbeddedStudio_ARM_v550a_win_x64.exe setup file.


Setup_EmbeddedStudio_ARM_v550a_win_x64.exe

3. Double click on **Setup_EmbeddedStudio_ARM_v550a_win_x64.exe**
4. Click on **Yes** when prompted and then click on **Next** button as shown in below screenshot.


SEGGER Embedded Studio for ARM 5.50a Setup

Welcome

Welcome to the installer for SEGGER Embedded Studio for ARM.

The installer will allow you to install SEGGER Embedded Studio for ARM. To continue, click Next.

<Back
Next>
Cancel

5. Select radio button **"I accept the agreement"** and click on **Next** button


SEGGER Embedded Studio for ARM 5.50a Setup

License Agreement

Please read the following License Agreement.

You must accept the License Agreement to continue.

SEGGER's Friendly License (SFL), January 16th 2020

For non-commercial use or for evaluation purposes, you – regardless whether you are an individual person or a legal entity – are welcome to use the software free of charge under this license.
Any other use of the software is considered commercial use, for which a commercial-use license must be obtained from SEGGER.

DEFINITIONS

● I accept the Agreement
○ I do not accept the Agreement

<Back
Next>
Cancel

6. Choose your installation path and click on **Next** button.


SEGGER Embedded Studio for ARM 5.50a Setup

Choose Destination Location

Select folder where Setup will install files.

Setup will install SEGGER Embedded Studio for ARM 5.50a in the following folder.

To install to this folder, click Next. To install to a different folder, click Browse and select another folder.

Destination Folder: C:\Program Files\SEGGER\SEGGER Embedded Studio for ARM 5.50a

...
<Back
Next>
Cancel

7. Click on **Next** button


SEGGER Embedded Studio for ARM 5.50a Setup

Select Program Folder

Please select a program folder.

Setup will add program icons to the Program Folder below.

You may type a new folder name. Click Next to continue.

Program Folder: SEGGER\SEGGER Embedded Studio for ARM 5.50a

<Back
Next>
Cancel

8. Make sure all checkboxes are checked as below screenshot and then click on **Next** button


SEGGER Embedded Studio for ARM 5.50a Setup

Associate Files

Select the file types you want to associate with SEGGER Embedded Studio for ARM.

The installer can associate the following file types with SEGGER Embedded Studio for ARM 5.50a.

Select the files you want associate, then click Next to continue.

☑ .emArchive Files
☑ .emPackage Files
☑ .emProject Files

Description:

<Back
Next>
Cancel

9. Again make sure All checkboxes are **checked** as below screenshot and then click on **Next** button


SEGGER Embedded Studio for ARM 5.50a Setup

Additional Components

Select the additional components to install.

The installer can install the following additional components.

Select required components, then click Next to continue.

☑ Install emStudio Desktop Shortcut
☑ Install J-Link Device Drivers

Description:

<Back
Next>
Cancel

10. Click on **Install** button


SEGGER Embedded Studio for ARM 5.50a Setup

Start Installation

To start installation of SEGGER Embedded Studio for ARM, click Install.

<Back
Install
Cancel

11. It will start installation as per below screenshot


SEGGER Embedded Studio for ARM 5.50a Setup

Installing

Installing Binary Files

Current Progress
Total Progress
<Back
Next>
Cancel

12. Once installation completed, it will show checkboxes. Kindly check the checkbox **"Start SEGGER Embedded Studio for ARM 5.50a"** and click on **Finish** button as below screenshot.


SEGGER Embedded Studio for ARM 5.50a Setup

Install Complete

SEGGER Embedded Studio for ARM 5.50a has now been installed.

Click Finish to complete the installation.

☐ Show Release Notes

☑ Start SEGGER Embedded Studio for ARM 5.50a

<Back
Finish
Cancel

13. It will open IDE and prompt a window for license agreement. Kindly Click on **Accept** button.


SEGGER Embedded Studio V5.50a

Thank you for using Embedded Studio!

A license for commercial use could not be found.

Do you want to use Embedded Studio for non-commercial or educational purposes?
Please click "Accept" to use the software under the terms of SEGGER's Friendly License for educational purposes (teaching yourself or as part of a university course) or for non-commercial projects.

Do you have a commercial-use license?
If you do have a commercial-use license, but that license is temporarily unavailable, please click "Accept" and continue to use Embedded Studio as if it were present.

Would you like to use Embedded Studio for commercial purposes?
Evaluate Embedded Studio for as long as you feel it is necessary using SEGGER's Friendly License terms by clicking "Accept".
Please respect the trust that we extend to you through this offer.

Once you complete your evaluation and decide to use Embedded Studio for your commercial purposes, you must obtain a commercial-use license.

None of the above apply or you are not sure?
Please press "Decline" to close Embedded Studio. Feel free to contact SEGGER for clarification.

SEGGER Embedded Studio for ARM is up

All packages are up to date

File
Edit
View
Search
Navigate
Project
Build
Debug
Target
Tools
Window
Help
Dashboard
SEGGER Embedded Studio
Read our License Agreements
Obtain a License
Accept
Decline
Open existing
Create new

14. You are **done** with **IDE Installation**.

Serial Utility [Putty] Setup

1. Download Putty Software from below link and install it. https://the.earth.li/~sgtatham/putty/latest/w64/putty.exe


PuTTY Configuration

Basic options for your PuTTY session

Specify the destination you want to connect to

Serial line: COM15

Speed: 9600

Connection type: ○ Raw ○ Telnet ○ Rlogin ○ SSH ● Serial

Load, save or delete a stored session

Saved Sessions:
Default Settings
Beaglebone
RPI
aws-parth

Close window on exit: ○ Always ○ Never ● Only on clean exit

Category:
Session
Logging
Terminal
Keyboard
Bell
Features
Window
Appearance
Behaviour
Translation
Selection
Colours
Connection
Data
Proxy
Telnet
Rlogin
SSH
Serial
Load
Save
Delete
About
Help
Open
Cancel

2. Once installation is completed, open it and Select Serial option from Radio Button as below Screenshot.
3. Go to Serial configuration menu and configure baudrate and other settings as per below screenshot. Baudrate - 9600 Data bits - 8 Stop bits - 1 Parity - None Flow Control - None


PuTTY Configuration

Options controlling local serial lines

Select a serial line

Serial line to connect to: COM15

Configure the serial line

Speed (baud): 9600

Data bits: 8

Stop bits: 1

Parity: None

Flow control: XON/XOFF

Category:
Session
Logging
Terminal
Keyboard
Bell
Features
Window
Appearance
Behaviour
Translation
Selection
Colours
Connection
Data
Proxy
Telnet
Rlogin
SSH
Serial
About
Help
Open
Cancel

4. Now press Open button to open Com port/Serial port to view data log