



Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.


| | |
|---|---|
| Title: Top-Sheet.SchDoc | |
| File: IoT-Speaker.PrjPcb | |
| Date: 4/18/2023 | Page Num: 1 |
| Drawn By: Huzaifa Ali | Page Total: 5 |

## VUSB 5V CHARGE INPUT




Decoupling capacitors should be placed close to each VBUS pin
ESD Diode is to be placed in manner that it has minimum impedance path with VBUS


## BATTERY INPUT




Battery Capacity = 4.2V 2600mA


## BATTERY SUPERVISOR CIRCUIT

Battery will automatically cutoff below 3.1V
This is open-drain output IC that has Active LOW output




Connect R13 to allow MOSFET control
Connect R14 to allow supervisor circuit control


## BATTERY CHARGING CIRCUIT





0.1uF capacitor should be placed closest to VCC pin

Battery Charging current = 1000mA


## TEST POINTS




## POWER SUPPLY ORING CIRCUITRY

The BATT-VBAT circuit is only for testing and maybe removed in production. This is to evaluate if the battery supervisory doesn't quickly activate when charger is connected





C7 and C8 should be placed as close to their pins as possible
The highest voltage supply is automatically selected. ST pin is used to detect which voltage is currently selected

Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.


| | |
|---|---|
| Title: Power-Sheet-1.SchDoc | |
| File: IoT-Speaker.PrjPcb | |
| Date: 4/18/2023 | Page Num: 2 |
| Drawn By: Huzaifa Ali | Page Total: 5 |

## LATCH ON/OFF CONTROLLER





The OUT pin changes state whenever
LOW logic is received at IN pin


## BOOST CONVERTER






## READ BATTERY VOLTAGE





## 3V3 LDO









## TEST POINTS






Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

| | |
|---|---|
| Title: Power-Sheet-2.SchDoc | |
| File: IoT-Speaker.PrjPcb | |
| Date: 4/26/2023 | Page Num: 3 |
| Drawn By: Huzaifa Ali | Page Total: 5 |








Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium
Template\espark-consulting-group-800x300.jpg.
File does not exist.

| | |
|---|---|
| Title: Controller-Sheet.SchDoc | |
| File: IoT-Speaker.PrjPcb | |
| Date: 4/26/2023 | Page Num: 4 |
| Drawn By: Huzaifa Ali | Page Total: 5 |




Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.

| | |
|---|---|
| Title: Audio-Amplifier.SchDoc | |
| File: IoT-Speaker.PrjPcb | |
| Date: 4/26/2023 | Page Num: 5 |
| Drawn By: Huzaifa Ali | Page Total: 5 |