












Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.


Title: Power_Supply_Sheet.SchDoc		
File: Power_Board-V1.0.PrjPcb		
Date: 12/02/2026	Page	Num: 1
Drawn By: Huzaifa Ali	Page	Total: 4















Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.


Title: Metering_Sheet.SchDoc	
File: Power_Board-V1.0.PrjPcb	
Date: 12/02/2026	Page Num: 2
Drawn By: Huzaifa Ali	Page Total: 4

PHASE A VOLTAGE INPUT




Voltage Divider = 1 / (800 + 1)

PHASE B VOLTAGE INPUT




Voltage Divider = 1 / (800 + 1)

PHASE C VOLTAGE INPUT




Voltage Divider = 1 / (800 + 1)


NEUTRAL INPUT




PHASE A CURRENT INPUT




PHASE B CURRENT INPUT



PHASE C CURRENT INPUT





NEUTRAL CURRENT INPUT (OPTIONAL)





Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.


Title: Interface_Sheet.SchDoc	
File: Power_Board-V1.0.PrjPcb	
Date: 12/02/2026	Page Num: 3
Drawn By: Huzaifa Ali	Page Total: 4


























Cannot open file
D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg.
File does not exist.

Title: Connector_Sheet.SchDoc	
File: Power_Board-V1.0.PrjPcb	
Date: 13/02/2026	Page Num: 4
Drawn By: Huzaifa Ali	Page Total: 4