





Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.

| | |
|---|---|
| Title: TopSheet.SchDoc | |
| File: DC-Motor-Driver-v1.0.PrjPcb | |
| Date: 6/11/2024 | Page Num: 1 |
| Drawn By: Huzaifa Ali | Page Total: 4 |


## BATTERY





## POWER SWITCH FOR BATTERY CUTOFF





## 3V3 BUCK REGULATOR





## BATTERY SUPERVISORY CIRCUIT





## 6V BUCK REGULATOR






## 3V3 LDO FOR SNVS




## USB









Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.


| | |
|---|---|
| Title: Power_Section.SchDoc | |
| File: DC-Motor-Driver-v1.0.PrjPcb | |
| Date: 6/11/2024 | Page Num: 2 |
| Drawn By: Huzaifa Ali | Page Total: 4 |




## SWITCHES





## DEBUGGING HEADER





1.SWD debug is enabled by default
2.Board rework and fuse programming are needed to support JTAG debug

## COIN CELL





## BOOT SETTING





Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.

| | |
|---|---|
| Title: Controller_Section.SchDoc | |
| File: DC-Motor-Driver-v1.0.PrjPcb | |
| Date: 6/11/2024 | Page Num: 3 |
| Drawn By: Huzaifa Ali | Page Total: 4 |


## MOTOR 1





## MOTOR 4





## MCU





## UART HEADER





## POTENTIOMETERS





## POWER HEADER





## MOTOR 2





## MOTOR 5





## FSRs





## TEST LED





## MOTOR 3




## MOTOR 6




Cannot open file D:\eSpark-Consultants\eSpark-Hardware\Altium Template\espark-consulting-group-800x300.jpg. File does not exist.

| | |
|---|---|
| Title: Motor_Section.SchDoc | |
| File: DC-Motor-Driver-v1.0.PrjPcb | |
| Date: 6/11/2024 | Page Num: 4 |
| Drawn By: Huzaifa Ali | Page Total: 4 |