


Battery Charger Section




USB Type-C PD Sink Controller




TYPE_C Power Input




XT-30_BAT




BAT_VSENSE



TEMP_SENSE



LED_HMI



currently Led current at 3mA

Enable ki logic dekhni hai kia aesa kry k input agr 9v or 12v sy ziada ho to enable on ho ?

Title: Power_Sheet.SchDoc	
File: Internal Battery Charger - v1.0.PrjPcb	
Date: 28/11/2024	Page Num: 1
Drawn By: Huzaifa Ali	Page Total: 1