






Item	Part No.	Qty.	Description
1	A3-SIM1-008	1	Operating panel, Right
2	A3-SIM1-001	1	Operating panel, Left
3	A3-S120-003	1	Cabinet, Feed belt cover, Right
4	A3-S120-004	1	Cabinet, Feed belt cover, Left
5	A3-S120-005	1	Cabinet, Front lower cover
6	A3-S120-006	1	Cabinet, Front lower air vent cover
7	A3-SIM1-002	1	Cover plate air supply
8	A0-E012-013	1	Filter, Air Cooling
9	A3-S120-025	4	Side door panel
10	A3-SIM1-003	1	Safety cover end, Feed belt right
11	A3-SIM1-004	1	Safety cover end, Feed belt left
12	A3-S120-201	1	Front cover plate, Top
13	A3-S120-220	1	Safety finger guard


Item	Part No.	Qty.	Description
14	A3-S120-203	2	Front cover plate, lower Left/Right
15	A0-A002-002-14	21	Feed belt
16	A3-S120-010	1	Electrical door cover
17	A3-S120-026	1	Temperature digital display door cover
18	A3-S120-027	1	Pump motor door cover
19	A0-E027-048	2	Temp digital display
20	A0-A125-181	1 Set	Feed Roller Complete Set
21	A0-E012-005	1	Fan, Cooling Size 10"
22	A0-E055-038	2	Multipole, Female Insert 1-16-16P+E-TOP 16A,500V.
23	A0-E055-055	2	Multipole Housing Side Entry
24	A0-A028-003	3	Cable Gland + Lock Nut
25	A0-E055-036	1	Multipole, Male Insert, 1-16-16P+E-TOP 16A,500V.
26	A0-E055-056	1	Multipole Closed Housing




Item	Part No.	Qty.	Description
1	A0-A090-110	1	Sticker DCI Left Hot oil
2	A0-E032-022	1	Emergency Stop Button Turn To Release Metal Ring
	A0-E032-023	1	Connector Base, E-Stop
	A0-E032-024	1	Contact Block, E-Stop
3	A0-A035-010	1	Pressure Gauge 0-60mbar
4	A0-A035-011	1	Pressure Gauge 0-2.5 BAR/PSI
5	A0-E027-063	2	Temperature Indicator K
6	A0-E027-052	1	Temp Controller
7	A0-E032-223	1	Push Button Switch With
8	A0-E035-051	1	Pilot Lamp (Red)
9	A0-E035-052	1	Pilot Lamp (Yellow)
10	A0-E032-075	1	Selector Switch Actuator (Black/Green)
	A0-E032-077	1	Contact LED Element GN (Green)
11	A0-E032-073	1	Selector Switch Actuator (Black/white)




Item	Part No.	Qty.	Description
1	A0-A090-073	1	Sticker Decal
2	A0-E032-022	1	Emergency Stop Button Turn To Release Metal Ring
	A0-E032-023	1	Connector Base, E-Stop
	A0-E032-024	1	Contact Block, E-Stop
3	A0-E035-052	1	Pilot Lamp (Yellow)
4	A0-E032-223	1	Push Button Switch
5	A0-E035-050	2	Pilot Lamp (Green)
6	A0-E028-088	1	Frequency Rate Meter
7	A0-E032-068	2	Push Button Switch (Green)
8	A0-E038-005	1	Speed Volume Adjust 2.5 Watt
9	A0-E032-069	1	Push Button Switch (Red)
10	A0-E035-051	1	Pilot Lamp (Red)
11	A0-E032-062	1	Push-Button Switch (Black)
12	A0-E032-073	2	Selector Switch Actuator (Black/white)




Item	Part No.	Qty.	Description
1	A0-E008-971	1	Helical Worm Gear Motor 0.75KW/ 99RPM/ 60HZ
2	A0-M001-026	1	Feed motor sprocket
3	A0-A051-004	1	Single chain
4	A0-M001-115	1	Sprocket
5	A0-A004-154	2	Y-Bearing




Item	Part No.	Qty.	Description
1	A0-P004-064	1	Regulator
2	A0-A035-025	1	Pressure Gauge
3	A0-A046-004	1	Tee Brass Fitting
	A0-A011-093	1	Nipple Brass 1/4"
	A0-A096-044	1	Brass Reducer
	A0-A046-030	1	Nipple
4	A0-P005-180	5	Coil, Air Solenoid Valve
	A0-P005-181	5	Coil Connector
5	A0-P005-032	2	Solenoid Valve 3/2, 1/4"
6	A0-P005-033	3	Solenoid Valve 3/2, 1/8"
7	A0-P005-126	1	Kit base for air solenoid valve 2P
8	A0-P006-109	2	Plug With Exagon Embedded 3/8"
9	A0-P006-016	2	Silencers SFE 3/8"
10	A0-P004-021	1	Regulator 1/4"
11	A0-A035-024	1	Pressure Gauge
12	A0-P005-024	1	Manifolds 1/8" 2P
	A0-P005-128	1	Bracket Set H 60
13	A0-P006-017	3	Silencers SFE 1/8"
14	A0-E018-020	1	Pressure switch
15	A0-E042-002	1	Buzzer bell EBL-2 24 VDC



Item	Part No.	Qty.	Description
1	A0-X002-011	1	Filler breather filter
2	A0-A002-289	-	Tape, Aramid 1/2 Inch
3	A0-A125-030	51	Black Roller For Guide Tape
4	A3-S120-213	1	Translucent canopy
5	A3-S120-212	1	Canopy




Item	Part No.	Qty.	Description
1	A0-X053-004	1	Butterfly valve
2	A0-A018-032	1	Fiberglass exhaust pipes
3	A0-E008-924	1	Suction Blower
4	A0-A004-287	1	Y-Bearing
5	A3-S120-036	1	Control arm with key
6	A0-P003-263	1	Air cylinder
7	A0-E015-011	1	Door Switch
8	A0-A007-036	1	Bearing housing complete set
	A0-A007-037	1	Bearing housing main
	A0-A007-038	1	Bearing retainer plate
	A3-S120-307	1	Collar, Seal For Main Bearing Housing. Blower Side
	A0-A004-163	1	Bearing
9	A0-P003-166	1	Cylinder short stroke
10	A0-E014-016	1	Reed sensor




Item	Part No.	Qty.	Description
1	A0-X053-004	1	Butterfly valve
2	A0-A018-032	2	Fiberglass exhaust pipes
3	A0-E008-924	1	Suction Blower
4	A0-A020-016	1	Ball valve size 1"
5	A3-S120-036	1	Control arm with key
6	A0-E063-003	1	Hot Oil Pump With Base Plate Coupling For Voltage 60Hz
7	A0-A021-050	2	Globe valve, 1/2"
8	A0-A099-016	1	Y-Strainer DN80 Flanged ends
9	A0-A021-052	2	Globe Valve Flanged Din. Std. DN80
10	A0-P003-263	1	Air cylinder
11	A0-A017-029	3	Flexible pipes, 1/2" X 1000MM.
12	A0-A035-016	1	Pressure gauge (0-10 bar)
13	A0-A020-008	1	Needle Valve Stainless 1/4"
14	A0-A234-002	1	Siphon Stainless 1/4"
15	A0-E008-921	1	Motor 20 HP/2P 230/380/400/460V 50/60 Hz
16	A0-E015-011	1	Door over travel switch


Item	Part No.	Qty.	Description
17	A0-A007-036	1	Bearing housing complete set
	A0-A007-037	1	Bearing housing main
	A0-A007-038	1	Bearing retainer plate
	A3-S120-307	1	Collar, Seal For Main Bearing Housing. Blower Side
	A0-A004-163	1	Bearing
18	A0-A004-287	1	Y-Bearing
19	A0-P003-166	1	Cylinder short stroke
20	A0-E014-016	1	Reed sensor
21	A0-A036-001	1	Magnet actuator for magnetic reed Switch (White)
22	A0-E014-007	1	Switch, Magnet reed




Item	Part No.	Qty.	Description
1	A0-E032-073	2	Selector Switch
2	A0-E010-035	2	Breaker Fuse 2A
	A0-E010-029	1	Breaker Fuse 6A
3	A0-E004-065	3	Magnetic Contactor 24 VAC.
4	A0-E025-054	2	Over Load 4-6 Amp.
5	A0-E010-074	1	Circuit Breaker 3A 2 Pole 240VAC.
6	A0-E009-080	1	Relay
	A0-E009-081	1	Socket Relay
7	A0-E009-075	1	Relay
	A0-E024-012	1	Auxiliary Contact
8	A0-E009-075	7	Relay
9	A0-E050-002	1	Bridge Rectifler
10	A0-E009-002	3	Relay
	A0-E009-020	3	Socket Relay
11	A0-E009-082	2	Relay
	A0-E009-083	2	Socket relay
12	A0-E009-073	1	Relay
	A0-E009-024	1	Socket relay
13	A0-E031-025	2	Timer
	A0-E031-026	2	Socket Timer




Item	Part No.	Qty.	Description
1	A0-E001-920	1	Inverter 25HP. 230V. 3 PH.
2	A0-E015-051	1	Handle Operation
	A0-E010-081	1	Circuit Breaker Manual Start-Stop 150A.
	A0-E010-300	1	Steel Rod
	A0-E010-301	1	Steel Rod
3	A0-E010-080	1	Circuit Breaker Manual Start-Stop 100A.
4	A0-E004-076	1	Magnetic Contactor 24 VAC.
5	A0-E025-062	1	Over Load 34-50 Amp.
6	A0-E024-015	1	Auxiliary Contact
7	A0-E010-060	2	Circuit Breaker Manual Start-Stop 2.5-4.0 A.
8	A0-E006-032	1	Transformer (250VA)




Item	Part No.	Qty.	Description
1	A3-SIM1-005	1	Disc speed sensor
2	A0-E023-003	1	Proximity sensor
3	A0-M002-007	1	Gear shelf mount reducers (New)
4	A0-A002-026	1	V-Belt (C62)
5	A0-M008-193	1	Pulley
6	A0-M008-194	1	Pulley, Tension
	A0-A004-067	1	Ball Bearing (Two seals)
7	A0-M008-091	1	Pulley, Idler
	A0-A004-196	2	Ball bearing
8	A0-E011-033	1	Limit switch variable
9	A3-S120-232	1	Chest 1, Assembly thermal hot oil
10	A0-A004-287	1	Y-Bearing
11	A3-S120-036	1	Control arm with key
12	A0-P003-068	1	Air cylinder
13	A0-E015-011	1	Door Switch
14	A0-P003-166	1	Cylinder short stroke
15	A0-E014-016	1	Reed sensor





Item	Part No.	Qty.	Description
1	A0-M002-007	1	Gear shelf mount reducers (New)
2	A0-A002-142	1	V-Belt (C166)
3	A0-A002-026	1	V-Belt (C62)
4	A0-M008-193	1	Pulley
5	A0-M008-194	1	Pulley, Tension
	A0-A004-067	1	Ball Bearing (Two seals)
6	A0-M008-053	1	Pulley, Idler
	A0-A004-196	2	Ball bearing
7	A0-E011-033	1	Limit switch variable
8	A3-S120-235	1	Chest 2 Assembly Thermal hot oil
9	A0-M008-196	1	Pulley
	A0-A004-067	1	Ball Bearing (Two seals)
10	A0-A004-287	1	Y-Bearing
11	A3-S120-036	1	Control arm with key
12	A0-P003-068	1	Air cylinder
13	A0-A002-041	2	V-Belt (C91)
14	A0-M008-057	1	Pulley, Motor
15	A0-E015-011	1	Door Switch
16	A0-P003-166	1	Cylinder short stroke
17	A0-E014-016	1	Reed sensor




Item	Part No.	Qty.	Description
1	A0-E032-022	1	Emergency Stop Button Turn To Release Metal Ring
	A0-E032-023	1	Connector Base, E-Stop
	A0-E032-024	1	Contact Block, E-Stop
2	A0-E008-217	1	Motor 25 HP. /4P. /190,380V. 60HZ. /3PH.
	A0-E012-005	1	Fan, Cooling Size 10"
3	A3-S120-241	1	Gap piece, Bridging
4	A0-A017-093	2	Flexible Steam Pipe 1-1/2"x200 mm.
5	A0-A017-029	2	Flexible Pipe, 1/2"X1000MM.



Item	Part No.	Qty.	Description
1	A3-S120-223	1	Rear cover burner, Left
2	A3-S120-224	2	Rear cover burner, Middle
3	A3-S120-225	1	Rear cover burner, Right
4	A3-S120-126	1	Burner door cover
5	A0-A086-005	10	Door handle
6	A0-A020-008	1	Needle Valve Stainless 1/4"
7	A0-A013-011	14	Key, Lock C-174-04
	A0-A013-010	14	Key
8	A0-A029-005	6	Hinge, Off set panel door
9	A0-A003-033	1	Oil Level 1/4"



Item	Part No.	Qty.	Description
1	A0-A035-016	1	Pressure gauge (0-10 bar)
2	A0-E030-009	1	Pressure control breaks on press rise range 10-150 Psi.
3	A0-A003-024	1	Glass
4	A0-E030-008	1	Pressure control breaks on press rise range 5-50 Psi.
5	A0-A035-017	1	Pressure Gauge 0-6 Bar
6	A3-SIM1-013	1	Heat exchanger H730-(80-120)(300-330)2R38
7	A0-E062-035	1	Gas Burner Assembly RS38/M
8	A0-A020-019	1	Ball Valve 1"
9	A0-P004-032	1	Low regulator fisher
10	A0-A035-021	1	Pressure Gauge Range:0-1000 mm.
11	A0-E018-016	1	Gas Solenoid Valve
12	A0-E018-017	1	Gas Solenoid Valve And Pressure Regulator
13	A0-E018-018	1	Pressure Switch (Primary)
14	A0-E018-027	1	Valve, Shut-Off, Pilot 3/8" 110V/50Hz 120V/60Hz
15	A0-E018-024	1	Pressure Regulator 3/8"
16	A0-A023-021	1	Plug Valve 1"
17	A0-A020-009	1	Ball Valve, Cut Off Valve 3/8"



Item	Part No.	Qty.	Description
TC1	A0-E027-033	1	Thermocouple Model. 5M
TC2	A0-E027-034	1	Thermocouple Model. 6M
TC3	A0-E027-037	1	Thermocouple Model. 12M
TC4	A0-E027-045	1	Thermocouple Model. 4M
TC5	A0-E027-033	1	Thermocouple Model. 5M
TC6	A0-E027-036	1	Thermocouple Model. 8M
TC7	A0-E027-037	1	Thermocouple Model. 12M
TC8	A0-E027-034	1	Thermocouple Model. 6M
TC9	A0-E027-035	1	Thermocouple Model. 7M
TC10	A0-E027-036	1	Thermocouple Model. 8M
TC11	A0-E027-036	1	Thermocouple Model. 8M
TC12	A0-E027-046	1	Thermocouple Model. 15M