

PROMPT:KL · 31 OCTOBER 2026

Hello, citizen keeper!

The round badge in this box holds a small pixel creature from Kuala Lumpur. It hatched from one line we wrote about your talk.

It gets hungry, it likes to play, it sleeps when you leave it alone, and it can chat with anyone who scans it. This little book shows you how to look after it.

MEET YOUR CITIZEN

One of three.



TENUK

the tapir



KENYALANG

the hornbill



HARIMAU

the tiger cub

Yours was born from a one-line system prompt about your talk. The first time it boots, it types that line out, then hatches. The same line is its personality when people chat with it.

HEARTS	Up to 4. It loses one every 90 minutes without food.
SULK	One heart or less, or 6 hours unfed, and it sulks. Feed it and it cheers up.
ALWAYS MOVING	It breathes, blinks and bobs. It is never a still picture while awake.
DAY AND NIGHT	The sky follows the real clock: dawn, blue day, dusk, then lit windows and a moon.



DAWN



DAY



DUSK



NIGHT

GESTURES


Four touches. That is all.



Tap

FEED

A quick touch. Feeds it nasi lemak, wakes it up, closes the QR.



Swipe

PLAY


Slide sideways. It plays with the ball, once every half hour for a heart.



Hold

SHOW QR

Keep your finger down for a second. A QR code appears for chatting.



Double tap

SETTINGS

Two quick taps. Opens Settings for brightness, clock and more. Tap the row above or below to move, the arrows to change, and double tap again to leave.

THE SCREENS

What you will see.



HOME
hearts, skyline, its name



FEED
after a tap



PLAY
after a swipe



TALK
a reply from the web



CHECK-IN
you arrived somewhere



SULK
hungry, please feed



QR
scan to chat



SLEEP
resting, tap to wake



HATCH
first boot only

A gold band at the bottom means something just happened.

POWER AND SLEEP

Plug it in anywhere.



1. It runs from any USB-C source: a laptop, a phone charger or a power bank. There is no battery inside, so it needs a cable to stay on.
2. After 30 seconds without a touch it falls asleep and the screen goes dark. A tap wakes it.
3. Unplugging is fine. It remembers its hearts and how long it has been, so it may be a little hungry when you come back.

WIFI AND THE QR CHAT

Let people talk to it.

BADGE asks for news → **WIFI** your hotspot → **PRMPT.CITY** keeps the chat

Someone scans the QR and types on the chat page. The reply comes back to the badge within a minute.

Set up WiFi

1. Double tap, go to WiFi, swipe right. Or hold the BOOT button on the back for 2 seconds.
2. On your phone, join the network called CITIZEN followed by four letters.
3. A page opens. Pick your WiFi, type the password, save.

Chat



Hold the screen for a second and the QR appears. Anyone can scan it with a phone camera to chat with your citizen. Tap to close.

No WiFi? The pet still works. Replies wait and arrive next time it connects.

SETTINGS AND UPDATES

Double tap for settings.



BRIGHTNESS	100, 40 or 10
CLOCK	Set the time in 15 minute steps. It sets itself on WiFi.
TIMEZONE	UTC−12 to UTC+14, starts at UTC+8
CITIZEN	Tenuk, Kenyalang or Harimau
WIFI	Shows your network, starts setup
UPDATE	"UP TO DATE", or "NEW 1.2.0" when there is a newer version
ABOUT	Version and badge name
EXIT	Back to your citizen

Tap moves to the next item. **Swipe right** changes it, **swipe left** changes it back. **Hold**, or wait 20 seconds, to leave.

The badge checks for a new version when it syncs on WiFi. When there is one, Update shows "NEW" and the version number. The badge installs it by itself when you have not touched it for 10 seconds on the home screen (or swipe right on Update to do it yourself); it downloads it, restarts, and keeps hearts and settings. This version does not check a signature on the download, so only use the official server.

WHEN SOMETHING LOOKS WRONG

Quick fixes.



The screen is off

It is asleep. Tap it. If nothing happens, check the USB-C cable is plugged into something with power.



The colours look odd

Tell us. It is a setting we can fix with an update.



No reply on the badge

It needs WiFi to fetch messages. Set it up from Settings → WiFi, then wait a minute.



Something else is off

Try an update: Settings → Update. If that does not help, message the PROMPT:KL team.