


Flex sensor



A flex/bend sensor measures the amount of deflection or bending.

Usually, the sensor is attached to the surface, and resistance of sensor element is varied by bending the surface, which return a resistance value depending the amount of bending.

This video about **Flex sensor** makes everything simple!



