

#### Motherboard

# ProArt B650-CREATOR

Quick start guide Hurtigstartsveiledning Кратко упътване за бърз старт Guia de consulta rápida Stručná příručka Instrukcja szybkiej instalacji Quick Start-vejledning Краткое руководство Ghid de pornire rapidă **Snelstartgids** Guía de inicio rápida Lühijuhend Guide de démarrage rapide Vodič za brzo korišćenje Pikakäynnistysopas Stručný návod na spustenie Schnellstartanleitung Snabbstartsguide คู่มือเริ่มต้นอย่างเร็ว Οδηγός γρήγορης έναρξης Hızlı Başlatma Kılavuzu Beüzemelési útmutató

クイックスタートガイド Короткий посібник Жылдам іске қосу нұсқаулығы Vodnik za hitri začetek

Greitos darbo pradžios vadovas

Īsa pamācība

Guida Rapida

Panduan Ringkas

빠른 시작 설명서

Installare la CPU **Pasang CPU** CPUを取り付ける CPU орнатыңыз

Höôùng daãn khôûi ñoäng nhanh

دليل التشغيل السريع

راهنمای شروع سریع

Vodič za brzi početak rada

Sumontuokite centrinį procesorių Uzstādiet centrālo procesoru


Installer sentralprosessoren (CPU) Instale a CPU Instalacja procesora Установка процессора Instalați CPU-ul Instalar la CPU Instalirajte CPU Inštalácia centrálneho procesora Installera CPU ติดตั้ง CPU CPU'yu takın

Namestitev CPE-ja قم بتثبيت وحدة المعالجة المركزية (CPU) CPU را نصب کنید

Lắp CPU

Instalacija procesora

Інсталюйте процесор



#### Step 2

CPU 설치

Step 1

Install the CPU

Installer CPU'en

Paigaldage CPU

Instalace procesoru

De CPU installeren

Installez le processeur Asenna suoritin

Installieren der CPU

Helyezze be a CPU-t


Εγκατάσταση της CPU


Инсталирайте процесора

Install the CPU fan Инсталирайте вентилатора на процесора Instalace ventilátoru procesoru Installer CPU-blæseren De CPU-ventilator installeren Paigaldage CPU ventilaator Installez le ventilateur du processeur Asenna suorittimen tuuletin Installieren des CPU-Lüfters Εγκατάσταση του ανεμιστήρα της CPU Szerelje be a CPU ventillátort Installare la ventola della CPU Pasang kipas CPU CPUクーラーを取り付ける CPU желдеткішін орнатыңыз CPU 팬 설치 Sumontuokite centrinio procesoriaus ventiliatorių Uzstādiet centrālā procesora ventilatoru

Installera CPU-fläkten ติดตั้งพัดลม CPU **CPU fanını takın** Lắp quạt CPU Instalacija ventilatora procesora Інсталюйте вентилятор процесора Namestitev ventilatorja CPE-ja

تثبيت مروحة وحدة المعالجة المركزية پنکه CPU را نصب کنید










# **Motherboard Layout**



# **Australia Statement Notice**

From 1 January 2012 updated warranties apply to all ASUS products, consistent with the Australian Consumer Law. For the latest product warranty details please visit https://www.asus.com/support/. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. If you require assistance please call ASUS Customer Service 1300 2787 88 or visit us at https://www.asus.com/support/.

#### India RoHS

This product complies with the "India E-Waste (Management) Rules, 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls (PBBs) and polybrominated diphenyl ethers (PBDEs) in concentrations exceeding 0.1% by weight in homogenous materials and 0.01 % by weight in homogenous materials for cadmium, except for the exemptions listed in Schedule II of the Rule.

#### Türkive RoHS

AEEE Yönetmeliğine Uygundur

#### **HDMI Trademark Notice**

The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc

Q25013 Revised Edition V2 September 2024 Copyright © ASUSTeK Computer Inc. All Rights Reserved



#### Step 3


Installer CPU-viften Instale a ventoinha de CPU Instalacja wentylatora procesora Установка вентилятора Instalati ventilatorul CPU-ului Instalar el ventilador de la CPU Instalirajte CPU ventilator

**Install memory modules** Инсталирайте модулите памет Instalace paměťových modulů Installer hukommelsesmodulerne Geheugenmodules installeren Paigaldage mälumoodulid Installez les modules de mémoire Asenna muistimoduulit Installieren der Speichermodule Εγκατάσταση των στοιχείων μνήμης Helyezze be a memória modulokat Installare i moduli di memoria Pasang modul memori メモリーモジュールを取り付ける Жад моульдерін орнатыңыз 메모리 모듈 설치 Sumontuokite atminties modulius Uzstādiet atmiņas moduļus

Inštalácia ventilátora centrálneho procesora

Installer minnemoduler Instale módulos de memória Instalacja modułów pamięci Установка модулей памяти Instalați modulele de memorie Instalar los módulos de memoria Instaliraite module memorije Inštalácia pamäťových modulov Installera minnesmoduler ติดตั้งโมดูลหน่วยความจำ Bellek modüllerini takın Lắp các thanh nhớ Instalacija memorijskih modula Інсталюйте модулі пам'яті Namestitev pomnilniških modulov تثبيت وحدات الذاكرة

مادول های حافظه را نصب کنید



#### Step 4

Install storage devices. To install M.2, refer to user guide.

Инсталиране на устройства за съхранение. За инсталиране на М.2, вижте

Instalování paměťových zařízení. Pokyny pro instalaci M.2 najdete v uživatelské

Installering af lagerenheder. Se brugsvejledningen for oplysninger om Opslagapparaten installeren. Raadpleeg de gebruiksaanwijzing voor het

installeren van M.2.

Installige salvestid. M.2 installimisel juhinduge kasutusjuhendist. Installez les périphériques de stockage. Pour installer un module M.2, consultez le

Tallennuslaitteiden asentaminen. Katso M.2:n asennusohjeet käyttöoppaasta. Installieren der Speichergeräte. Zur Installation von M.2-Geräten schauen Sie bitte im Benutzerhandbuch.

Εγκατάσταση συσκευών αποθήκευσης. Για την εγκατάσταση του Μ.2, ανατρέξτε στο εγχειρίδιο χρήστη.

Tárolóeszközök telepítése. Az M.2 telepítését illetően lásd a felhasználói útmutatót.

Installare dispositivi di archiviazione. Per installare M.2, fare riferimento alla guida per l'utente.

Memasang perangkat penyimpanan. Untuk memasang M2, lihat panduan pengguna.

ストレージデバイスを取り付ける。M.2 SSDの取り付け方法は、ユーザーガイドをご覧ください。 Сақтау құрылғыларын орнату. М.2 орнату үшін пайдалану нұсқаулығын

저장 장치 설치. M.2를 설치하려면 사용 설명서를 참조하십시오.

Įdiegti saugojimo įrenginius. Kaip montuoti M.2, žr. naudojimo instrukciją. Instalējiet atmiņas ierīces. Lai instalētu M.2, skatiet lietotāja rokasgrāmatu. Montere lagringsenheter. Se bruksanvisningen for installasjon av M.2. Instalar dispositivos de armazenamento. Consulte o guia do utilizador para

Instalacja urządzeń pamięci. W celu instalacji M.2 należy zapoznać się z podręcznikiem użytkownika.

Установка накопителей. Для установки М.2 обратитесь к руководству

Instalarea dispozitivelor de stocare. Consultați manualul de utilizare pentru detalii despre instalarea M.2

Instalar dispositivos de almacenamiento. Para instalar M.2, consulte la guía del usuario.

Instalirajte uređaje za skladištenje. Pogledajte uputstvo za korišćenje da biste instalirali M.2.

Ištalácia pamäťových zariadení. Postup inštalácie M.2 si pozrite v príručke pre

Installera lagringsenheter. För att installera M.2, se bruksanvisningen. การติดตั้งอุปกรณ์เก็บข้อมูล ในการติดตั้ง M.2 โปรดดูคู่มือผู้ใช้

Depolama aygıtlarınızı takma. M.2'yi kurmak için kullanım kılavuzuna bakın. lắp đặt các thiết bị lưu trữ. Để lắp đặt M.2, hãy tham khảo sổ hướng dẫn sử dụng. Instalirajte uređaje za pohranjivanje. Pogledajte korisnički priručnik za ugradnju M.2.

Інсталяція пристроїв пам'яті. Щоб встановити М.2, див. Посібник користувачів. Namestitev naprav za shranjevanje. Za namestitev M.2 glejte navodila za uporabo.

> تثبيت أجهزة التخزين لتثبيت M.2، ارجع إلى دليل المستخدم. نصب دستگاه های ذخیره سازی برای نصب M.2، به دفترچه راهنمای کاربر مراجعه کنید.

### Step 5

Install expansion card(s) Инсталирайте допълнителна карта (допълнителни карти) Instalace přídavné karty (karet)

Installer udvidelseskortene

Uitbreidingskaart(en) installeren

Paigaldage laienduskaart(-kaardid)

Installez les cartes d'extension Asenna laajennuskortti/kortit

Installieren der Erweiterungskarte(n)

Εγκατάσταση καρτών επέκτασης

Helyezze be a bővítőkártyá(ka)t

Installare le schede di espansione

Pasang kartu ekspansi

拡張カードを取り付ける

Кеңейту картас(лар)ын орнатыңыз

확장 카드 설치

Sumontuokite išplėtimo plokštę (-es)

Uzstādiet izvērses karti(-es)

Installer utvidelseskort

Instale placas de expansão

Instalacia kart(v) rozszerzenia

Установка карт расширения

Instalați cardul/cardurile de extensie Instalar tarjetas de expansión

Instaliraite ekspanzionu/e karticu/e

Inštalácia rozširujúcich kariet

Installera expansionskort

ติดตั้งเอ็กซแพนชั้นการด

Genisletme kartlarını takın

Lắp (các) thẻ mở rộng Instalacija kartica za proširenje

Інсталюйте плати розширення

Namestitev razširitvenih kartic تثبيت بطاقة (بطاقات) التوسعة

کارت های گسترش را نصب کنید

#### Step 6

Install the system panel connector Инсталирайте конектора за системния панел Nainstalujte konektor pro panel systému Tilslut stikket til systempanelet Installeer de connectors van het systeempaneel Ühendage süsteemi paneeli liitmik Installer le connecteur de panneau système

Telepítse a rendszerpanell csatlakozót

Ενκατάσταση του συνδέσμου του πίνακα του συστήματος

Installieren des Systembereich-Anschlusses

Installa il connettore del pannello di sistema

Pasang konektor panel sistem

システムパネルコネクターを取り付ける

Asenna järjestelmäpaneelin liitäntä

Жүйе панелінің коннекторын орнатыңыз

시스템 패널 커넥터를 설치하십시오 Sumontuokite sistemos valdymo plokštės jungtį

Sistemas panela savienotaia instalešana

Installer systempanelkontakten

Instalar o conector do painel do sistema Zainstaluj złącze panelu systemowego

Установка разъема системной панели

Instalați Conector pentru placa de bază Instalar el conector del panel del sistema

Instalirajte priključak za sistemsku ploču

Inštalácia konektora systémového panela

Sätt i systempanelens kontakt

ติดตั้งขั้วต่อแผงระบบ

Sistem paneli konnektörünü takın Lắp đầu nối bảng điều khiển hệ thống Instalacija konektora ploče sustava Встановіть з'єднувач системної панелі

Namestitev Konektor matične plošče

### Step 7

**Install ATX power connectors** 

Инсталирайте ATX конекторите за захранване

Instalace konektorů napájení ATX Installer ATX-strømtilslutningerne ATX-voedingsaansluitingen installeren Paigaldage ATX-i toitekonnektorid Installez les connecteurs d'alimentation ATX

Asenna ATX-virtaliittimet Installieren der ATX-Stromanschlüsse

Εγκατάσταση συνδέσμων τροφοδοσίας ΑΤΧ Csatlakoztassa az ATX tápcsatlakozókat

Installare i connettori di alimentazione ATX

Pasang konektor daya ATX 電源ケーブルを接続する

АТХ электр қуат қосқыштарын орнатыңыз

ATX 전원 커넥터 설치

Sumontuokite ATX maitinimo jungtis Uzstādiet ATX strāvas savienotājus

Installer kontakter for ATX-strøm

Instale os conectores de alimentação ATX

Instalacja złączy zasilacza ATX

Установка АТХ разъема

Instalati pinii conectori ATX

Instalar conectores de alimentación ATX Instalirajte ATX električne priključke

Inštalácia napájacích konektorov ATX

Installera ATX strömkontakter

ติดตั้งขั้วต่อ ATX เพาเวอร์


ATX güç konnektörlerini takın


Lắp các đầu nối nguồn ATX Instalacija konektora ATX napajanja


Інсталюйте розніми живлення АТХ


Namestitev priključkov za napajanje ATX


تثبيت توصيلات الطاقة ATX رابط های برق ATX را نصب کنید















تركيب موصل لوحة النظام

رابط صفحه سیستم را نصب کنید









# Step 8

입력/출력 장치 연결


**Connect input/output devices** Свързване на І/О устройства Připojení vstupních/výstupních zařízení Tilslut input-/outputudstyr I/O-apparaten aansluiten Ühendage sisend -/väljundseadmed Connectez les périphériques d'entrée/sortie Liitä tulo/lähtölaitteita Eingabe-/Ausgabe-Geräte verbinden Σύνδεση συσκευών εισόδου/εξόδου Bemeneti/kimeneti eszközök csatlakoztatása Collegate i dispositivi di input/output Sambungkan perangkat input/output 入出力デバイスに接続する Кіріс/шығыс кұрылғыларын қосу

Prijunkite įvesties / išvesties įrenginius

Pievienot ievades/izvades ierīces

Koble til inngang/utgangsenheter Ligar dispositivos de entrada/saída Podłączenie urządzeń wejścia/wyjścia Подключение устройств ввода/вывода Conectare dispozitive de intrare/ieşire Conectar dispositivos de entrada y salida Povežite ulazne/izlazne uređaje Pripojenie vstupných/výstupných zariadení Anslut ingående/utgående enheter ชื่อมตออุปกรณ์อินพุต/เอาตพุต Giriş/çıkış aygıtlarına bağlan Kết nối các thiết bị đầu vào/đầu ra Spajanje ulaznih/izlaznih uređaja Під'єднайте пристрої вводу/виводу Priključitev vhodnih/izhodnih naprav

توصيل أجهزة الدخل/الخرج دستگاه های ورودی/خروجی را متصل نمایید



# Step 9

Power on the system and install operating system and drivers

Включете системата и инсталирайте операционната система и драйверите

Zapnutí napájení systému a instalace operačního systému a ovladačů

Tænd for systemet, og installer operativsystemet og de tilhørende drivere

Het systeem inschakelen en het besturingssysteem en de stuurprogramma's installeren

Lülitage süsteemi toide sisse ning installige operatsioonisüsteem ja draiverid

Démarrez le système et installez le système d'exploitation et les pilotes

Käynnistä järjestelmä ja asenna käyttöjärjestelmä ja ohjaimet

Einschalten des Systems und Installieren des Betriebssystems und der Treiber

Ενεργοποιήστε το σύστημα και εγκαταστήστε το λειτουργικό σύστημα και τα προγράμματα οδήγησης

Kapcsolja be a rendszert és telepítse az operációs rendszert és illesztőprogramokat

Accendere il sistema e installare il sistema operativo e i driver

Hidupkan sistem, lalu instal sistem operasi dan driver システムを起動しOSとドライバーをインストールする

Жүйені қосып, операциялық жүйені жәнә драйверлерді орнатыңыз

시스템 전원 켜기 및 운영체제와 드라이버 설치

liunkite sistema ir idiekite operacine sistema ir tvarkykles

leslēdziet sistēmu un instalējiet operētājsistēmu un draiverus

Slå på systemet og installer operativsystem og drivere

Ligue o sistema e instale o sistema operativo e os controladores

Włącz zasilanie i zainstaluj system operacyjny oraz sterowniki

Включение системы и установка операционной системы и драйверов Porniți sistemul și instalați sistemul de operare și driverele

Proporcionar alimentación al sistema e instalar el sistema operativo y los controladores Uključite sistem i instalirajte operativni sistem i drajvere

Zapnutie systému a inštalácia operačného systému a ovládačov

Slå på systemet och installera operativsystem och drivrutiner

เปิดระบบ และติดตั้งระบบปฏิบัติการและใดรเวอร์ Sistemi açıp işletim sistemini ve sürücüleri yükleyin

Bật nguồn hệ thống và cài đặt hệ điều hành cũng như các driver

Uključivanje sustava i instaliranje operativnih sustava i upravljačkih programa

Увімкніть живлення системи та інсталюйте операційну систему та драйвери

Vklop sistema ter namestitev operacijskega sistema in gonilnikov تشغيل الجهاز وتثبيت نظام وبرمجيات التشغيل سیستم را روشن کرده و درایورها و سیستم عامل را نصب کنید